# Oracle® Communications EAGLE Application Processor

Upgrade/Installation Guide

Release 16.4

F29906-16

August, 2024



Oracle Communications EAGLE Application Processor Upgrade/Installation Guide, Release 16.4

Copyright © 2000, 2024, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notices are applicable:

U.S. GOVERNMENT END USERS: Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information about content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third party content, products, and services unless otherwise set forth in an applicable agreement between you and Oracle. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services, except as set forth in an applicable agreement between you and Oracle.

CAUTION: Use only the guide downloaded from the Oracle Technology Network (OTN) (<u>http://www.oracle.com/technetwork/indexes/documentation/oracle-comms-tekelec-2136003.html</u>). Before running upgrade on your system, access the My Oracle Support web portal (<u>https://support.oracle.com</u>) and review any Knowledge Alerts that may be related to the System Health Check or the I Upgrade.

Before beginning this procedure, contact My Oracle Support and inform them of your upgrade plans. Refer to Appendix F for instructions on accessing My Oracle Support.

# What's New in this Guide

This section introduces the documentation updates for Release 16.4 in Oracle Communications EAGLE Application Processor Upgrade/Installation Guide.

#### Release 16.4 – F29906-16, August 2024

Added a note in the <u>Purpose and Scope</u> section to provide information about a new parameter, LSBLSET, introduced in EPAP 16.4.

# TABLE OF CONTENTS

1	INTRODUCTION Purpose and Scope References 1.1.1 External 1.1.2 Internal (Oracle)	9 9 9
	Software Release Numbering Acronyms Terminology Recommendations Requirements	.10 .10 .11
~		
2	GENERAL DESCRIPTION	
	Upgrading Provisionable mixed EPAP Mated Pairs	
	Backout Provisionable mixed EPAP Mated Pairs	
	Upgrading EPAP Non-Provisionable MPS Servers	
	2.1.1 Upgrading Non-Provisional MPS pairs in Mixed EPAP configuration	.16
	2.1.2 Upgrading Non-Provisional MPS pairs in dual PDBonly configuration	
	Backout EPAP Non-provisionable MPS servers	
	2.1.3 Backout Non-Provisionable MPS pairs in dual PDBonly configuration	
		. 17
3	UPGRADE OVERVIEW	19
Ū	Upgrade Provisioning Rules	
	Required Materials	
	Installation Phases	
	3.1.1 Installation Phases for Mixed and Non-Provisionable EPAP	
	3.1.2 Installation Phases for Standalone PDB	
	Split Mirror Upgrade Phases	
	3.1.3 Split Mirror Upgrade Phases for Mixed and Non-Provisionable EPAP	
	3.1.4 Split Mirror Upgrade Phases for Standalone PDB	
	Incremental Upgrade Phases	
	3.1.5 Incremental Upgrade Phases for Mixed and Non-Provisionable EPAP	
	3.1.6 Incremental Upgrade Phases for Standalone PDB	
	Backout Phases	
	3.1.7 Backout Phases for Mixed and Non-Provisionable EPAP	
	Log Files	
		01
4	DB ARCHITECTURE OVERVIEW	32
•	Overview of DB architecture change in Customer Network	
	Overview of DB architecture change from Compact to Extreme	
	Change DB Architecture from COMPACT to eXtreme to support EAGLE release	
	46.7.0.0.0(eXtreme feature)	34
	4.1.1 Phases to change DB Architecture to eXtreme (Standalone PDB)	34
	4.1.2 Phases to change DB architecture to eXtreme (First Non-Prov site)	
	4.1.3 Phases to change DB architecture to eXtreme (Remaining Non-Prov sites)	35
5	UPGRADE PREPARATION	
	Procedure 1 Setting up the upgrade environment	37
	Procedure 2 Determine if upgrade or installation is required	
	Procedure 3 Pre-upgrade requirements	
	Procedure 4 System Health check	41
5.	SOFTWARE INSTALLATION PROCEDURES	42

	Procedure 5 Pre-	-Install configuration on server A	42
	Procedure 6 Pre-	-Install configuration on server B	47
		all Application on server A	
	Procedure 8 Insta	all Application on server B	56
	Procedure 9 Sw	vitch Configuration	62
	Procedure 10 P	Procedure to Configure Sync Network Redundancy	71
		Configuring the application	
	Procedure 12 P	Provision data from GUI	96
		Change DB Architecture	
		5	
6	SOFTWARE UP	GRADE PROCEDURES	105
	Procedure 14 A	Assess MPS server's readiness for upgrade	105
		Pre and Post Upgrade Backups	
	Procedure 16 P	Pre-upgrade system time check	108
	Procedure 17 C	Check 9dig counts before moving to eXtreme architecture	109
	Procedure 18 U	Jpgrade Server B	110
		Jpgrade server A	
		Run RTDB Converter	
		Reboot EAGLE Cards	
		ccept Upgrade	
		Keys exchange between active and standby PDB	
6.	SOFTWARE REG	COVERY PROCEDURES	140
		Server B Backout	
		Backout both Server A and B	
		Stop the Pdba software	
	FIDCEDUIE ZD G	000 UIE E 00a 301Wale	
		Restart PDBA Software (Post-Backout and Post-Upgrade)	
AF	Procedure 27 R		157
AF	Procedure 27 R	Restart PDBA Software (Post-Backout and Post-Upgrade)	157 <b>160</b>
AF	Procedure 27 R PENDIX A GEN Procedure A.1 I	Restart PDBA Software (Post-Backout and Post-Upgrade) <b>IERIC PROCEDURES</b> Perform System Health Check	157 <b>160</b> 160
AF	Procedure 27 R PENDIX A GEN Procedure A.1 I Procedure A.2	Restart PDBA Software (Post-Backout and Post-Upgrade) <b>IERIC PROCEDURES</b> Perform System Health Check Validate Upgrade Media	157 160 162
AF	Procedure 27 R PENDIX A GEN Procedure A.1 I Procedure A.2 V Procedure A.3 S	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup	157 160 162 165
AF	Procedure 27 R PENDIX A GEN Procedure A.1 I Procedure A.2 V Procedure A.3 S Procedure A.4 I	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script	157 160 160 162 165 167
AF	Procedure 27 R PENDIX A GEN Procedure A.1 F Procedure A.2 Procedure A.3 S Procedure A.4 F Procedure A.5 F	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov	157 160 162 165 167 168
AF	Procedure 27 R PENDIX A GEN Procedure A.1 H Procedure A.2 N Procedure A.3 S Procedure A.4 H Procedure A.5 H Procedure A.6 H	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup	157 160 160 162 165 167 168 171
AF	Procedure 27 R PENDIX A GEN Procedure A.1 F Procedure A.2 Procedure A.3 S Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.7 F	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup	157 160 162 165 167 168 171 173
AF	Procedure 27 R PENDIX A GEN Procedure A.1 F Procedure A.2 Procedure A.3 S Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.7 F Procedure A.8 F	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup EuiDB Backup	157 160 162 165 167 167 171 173 176
AF	Procedure 27 R PENDIX A GEN Procedure A.1 F Procedure A.2 Procedure A.3 S Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.6 F Procedure A.8 F Procedure A.8 F	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup EuiDB Backup RTDB Reload from PDBA	157 160 162 165 165 167 168 171 173 176 178
AF	Procedure 27 R Procedure A.1 F Procedure A.2 Procedure A.2 Procedure A.3 S Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.6 F Procedure A.7 F Procedure A.8 F Procedure A.9 F Procedure A.10	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup RTDB Backup RTDB Reload from PDBA RTDB Restore	157 160 162 165 165 167 168 171 173 176 178 180
AF	Procedure 27 R PENDIX A GEN Procedure A.1 F Procedure A.2 P Procedure A.3 Procedure A.3 Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.7 F Procedure A.8 F Procedure A.9 F Procedure A.9 F Procedure A.10	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup EuiDB Backup RTDB Reload from PDBA RTDB Reload from Remote	157 160 160 162 165 167 168 171 173 176 178 180 183
AF	Procedure 27 R PENDIX A GEN Procedure A.1 F Procedure A.2 P Procedure A.3 S Procedure A.3 F Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.7 F Procedure A.7 F Procedure A.8 F Procedure A.9 F Procedure A.10 Procedure A.11 Procedure A.12	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup EuiDB Backup RTDB Reload from PDBA RTDB Reload from Remote ISO Image download from Oracle Software Delivery Cloud	157 160 162 165 165 167 168 171 173 173 176 178 180 183 185
AF	Procedure 27 R Procedure A.1 F Procedure A.2 Procedure A.3 S Procedure A.3 S Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.7 F Procedure A.8 F Procedure A.8 F Procedure A.9 F Procedure A.10 Procedure A.11 Procedure A.12 Procedure A.13	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup PDB Backup RTDB Backup RTDB Reload from PDBA RTDB Reload from Remote ISO Image download from Oracle Software Delivery Cloud IPM MPS Server with TPD 7.6.2	157 160 162 165 165 167 168 171 173 173 176 178 180 183 185 187
AF	Procedure 27 R Procedure A.1 F Procedure A.2 Procedure A.2 Procedure A.3 Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.6 F Procedure A.7 F Procedure A.8 F Procedure A.8 F Procedure A.9 F Procedure A.10 Procedure A.11 Procedure A.12 Procedure A.13 Procedure A.14	Restart PDBA Software (Post-Backout and Post-Upgrade) NERIC PROCEDURES Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup RTDB Backup RTDB Reload from PDBA RTDB Reload from Remote ISO Image download from Oracle Software Delivery Cloud IPM MPS Server with TPD 7.6.2 Standalone PDB Segmented Configuration	157 160 162 165 165 167 168 171 173 173 178 180 183 185 187 195
AF	Procedure 27 R Procedure A.1 F Procedure A.2 Procedure A.2 Procedure A.3 Procedure A.4 F Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.6 F Procedure A.7 F Procedure A.7 F Procedure A.8 F Procedure A.10 Procedure A.11 Procedure A.12 Procedure A.13 Procedure A.14 Procedure A.15	Restart PDBA Software (Post-Backout and Post-Upgrade)         NERIC PROCEDURES         Perform System Health Check         Validate Upgrade Media         System Configuration Backup         Execute parse9Dig script         Increase rtVolume size for Non-prov         PDB Backup         RTDB Backup         RTDB Reload from PDBA         RTDB Reload from Remote         ISO Image download from Oracle Software Delivery Cloud         IPM MPS Server with TPD 7.6.2         Standalone PDB Segmented Configuration         Password change for EPAP System Users	157 160 160 162 165 167 168 171 173 178 178 178 180 183 185 187 195 200
AF	Procedure 27 R Procedure A.1 F Procedure A.2 P Procedure A.3 P Procedure A.3 P Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.6 F Procedure A.7 F Procedure A.7 F Procedure A.8 F Procedure A.10 Procedure A.10 Procedure A.11 Procedure A.13 Procedure A.14 Procedure A.15 Procedure A.16	Restart PDBA Software (Post-Backout and Post-Upgrade) <b>VERIC PROCEDURES</b> Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup RTDB Backup RTDB Reload from PDBA RTDB Reload from PDBA RTDB Reload from Remote ISO Image download from Oracle Software Delivery Cloud IPM MPS Server with TPD 7.6.2 Standalone PDB Segmented Configuration Password change for EPAP System Users E5-APP-B Halt/Shutdown	157 160 160 162 165 167 168 171 173 173 178 178 180 183 185 187 195 200 202
AF	Procedure 27 R Procedure A.1 F Procedure A.2 P Procedure A.3 P Procedure A.3 P Procedure A.4 F Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.7 F Procedure A.7 F Procedure A.8 F Procedure A.10 Procedure A.11 Procedure A.12 Procedure A.13 Procedure A.14 Procedure A.15 Procedure A.17	Restart PDBA Software (Post-Backout and Post-Upgrade) <b>Verific PROCEDURES</b> Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup EuiDB Backup RTDB Reload from PDBA RTDB Reload from PDBA RTDB Reload from Remote ISO Image download from Oracle Software Delivery Cloud. IPM MPS Server with TPD 7.6.2 Standalone PDB Segmented Configuration Password change for EPAP System Users E5-APP-B Halt/Shutdown Procedure to Configure EPAP switch ports and EAGLE SM cards to	157 160 162 165 165 167 168 171 173 173 173 178 180 183 185 187 195 200 202
AF	Procedure 27 R Procedure A.1 F Procedure A.2 Procedure A.2 Procedure A.3 Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.6 F Procedure A.7 F Procedure A.8 F Procedure A.8 F Procedure A.10 Procedure A.10 Procedure A.11 Procedure A.12 Procedure A.13 Procedure A.14 Procedure A.15 Procedure A.16 Procedure A.17 support 1G EPAF	Restart PDBA Software (Post-Backout and Post-Upgrade) <b>Verific PROCEDURES</b> Perform System Health Check Validate Upgrade Media. System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup RTDB Reload from PDBA RTDB Reload from PDBA RTDB Reload from Remote. ISO Image download from Oracle Software Delivery Cloud. IPM MPS Server with TPD 7.6.2 Standalone PDB Segmented Configuration. Password change for EPAP System Users E5-APP-B Halt/Shutdown. Procedure to Configure EPAP switch ports and EAGLE SM cards to P-to-Eagle RTDB download speed	157 160 160 162 165 165 167 168 171 173 173 173 176 178 180 183 185 185 195 200 203
AF	Procedure 27 R Procedure A.1 F Procedure A.2 P Procedure A.2 P Procedure A.3 P Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.6 F Procedure A.7 F Procedure A.7 F Procedure A.8 F Procedure A.10 Procedure A.10 Procedure A.11 Procedure A.12 Procedure A.13 Procedure A.14 Procedure A.15 Procedure A.16 Procedure A.17 support 1G EPAF Procedure A.18	Restart PDBA Software (Post-Backout and Post-Upgrade) <b>NERIC PROCEDURES</b> Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup RTDB Backup RTDB Reload from PDBA RTDB Reload from Remote ISO Image download from Oracle Software Delivery Cloud IPM MPS Server with TPD 7.6.2 Standalone PDB Segmented Configuration Password change for EPAP System Users E5-APP-B Halt/Shutdown Procedure to Configure EPAP switch ports and EAGLE SM cards to P-to-Eagle RTDB download speed Upgrade SSL certificate from SHA-1 to SHA-512	157 160 160 162 165 167 168 171 173 173 176 178 180 183 185 185 185 195 200 203 203 222
AF	Procedure 27 R Procedure A.1 F Procedure A.2 P Procedure A.2 P Procedure A.3 P Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.6 F Procedure A.7 F Procedure A.7 F Procedure A.7 F Procedure A.8 F Procedure A.10 Procedure A.11 Procedure A.12 Procedure A.13 Procedure A.14 Procedure A.15 Procedure A.16 Procedure A.17 support 1G EPAF Procedure A.18 Procedure A.19	Restart PDBA Software (Post-Backout and Post-Upgrade) <b>NERIC PROCEDURES</b> Perform System Health Check	157 160 160 162 165 167 168 171 173 176 178 178 180 183 185 187 195 200 202 203 222 223
AF	Procedure 27 R PENDIX A GEN Procedure A.1 F Procedure A.2 P Procedure A.3 P Procedure A.3 P Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.7 F Procedure A.7 F Procedure A.7 F Procedure A.8 F Procedure A.10 Procedure A.10 Procedure A.11 Procedure A.12 Procedure A.13 Procedure A.14 Procedure A.15 Procedure A.15 Procedure A.16 Procedure A.17 support 1G EPAF Procedure A.18 Procedure A.19 Procedure A.20	Restart PDBA Software (Post-Backout and Post-Upgrade) <b>NERIC PROCEDURES</b> Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup RTDB Reload from PDBA RTDB Reload from Remote ISO Image download from Oracle Software Delivery Cloud IPM MPS Server with TPD 7.6.2 Standalone PDB Segmented Configuration Password change for EPAP System Users E5-APP-B Halt/Shutdown Procedure to Configure EPAP switch ports and EAGLE SM cards to P-to-Eagle RTDB download speed Upgrade SSL certificate from SHA-1 to SHA-512 Disable Epap VIP And Deactivate PDBA Proxy Feature Enable EPAP PDBA Proxy and EPAP VIP Optional Features	157 160 162 165 165 167 168 171 173 173 173 176 178 180 183 185 187 200 202 203 223 229
AF	Procedure 27 R PENDIX A GEN Procedure A.1 F Procedure A.2 P Procedure A.3 Procedure A.3 Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.6 F Procedure A.7 F Procedure A.7 F Procedure A.8 F Procedure A.9 F Procedure A.10 Procedure A.10 Procedure A.11 Procedure A.12 Procedure A.13 Procedure A.14 Procedure A.15 Procedure A.16 Procedure A.17 support 1G EPAF Procedure A.18 Procedure A.20 Procedure A.21	Restart PDBA Software (Post-Backout and Post-Upgrade)         Image: Constraint of the system of th	157 160 160 162 165 167 168 171 173 173 173 173 176 178 180 183 185 187 200 202 203 223 229 239 239
AF	Procedure 27 R PENDIX A GEN Procedure A.1 F Procedure A.2 P Procedure A.3 P Procedure A.3 P Procedure A.4 F Procedure A.5 F Procedure A.6 F Procedure A.7 F Procedure A.7 F Procedure A.7 F Procedure A.8 F Procedure A.10 Procedure A.10 Procedure A.11 Procedure A.12 Procedure A.13 Procedure A.14 Procedure A.15 Procedure A.15 Procedure A.16 Procedure A.17 support 1G EPAF Procedure A.18 Procedure A.19 Procedure A.20	Restart PDBA Software (Post-Backout and Post-Upgrade) <b>NERIC PROCEDURES</b> Perform System Health Check Validate Upgrade Media System Configuration Backup Execute parse9Dig script Increase rtVolume size for Non-prov PDB Backup RTDB Backup RTDB Reload from PDBA RTDB Reload from Remote ISO Image download from Oracle Software Delivery Cloud IPM MPS Server with TPD 7.6.2 Standalone PDB Segmented Configuration Password change for EPAP System Users E5-APP-B Halt/Shutdown Procedure to Configure EPAP switch ports and EAGLE SM cards to P-to-Eagle RTDB download speed Upgrade SSL certificate from SHA-1 to SHA-512 Disable Epap VIP And Deactivate PDBA Proxy Feature Enable EPAP PDBA Proxy and EPAP VIP Optional Features	157 160 160 162 165 167 168 171 173 173 176 178 180 183 185 185 200 202 203 222 223 229 239 240

**Upgrade/Installation Guide** 

Procedure A	.24 PDB Restore	242
Procedure A	.25 Conversion from Prov(mixed EPAP) to Non-Prov	248
Procedure A	26 Conversion from mixed EPAP to StandalonePDB+Non-Prov EPAP	252
	27 Procedure to add/edit the /etc/minirc.mate file	
	28 Configure the Auto Backup	
	.29 STOP ACTIVE PDBA AND VERIFY REPL LOGS	
PROCEDUF	RE A.30 Resolve the false accept upgrade alarm situation	258
APPENDIX B	INTERCONNECTION DIAGRAM	259
		261
SWITCH RE	PLACEMENT	261
SWITCH RE		261
SWITCH RE SWITCH CC	PLACEMENT	261 267
SWITCH RE SWITCH CC	PLACEMENT DNFIGURATION	261 267
SWITCH RE SWITCH CC APPENDIX D	PLACEMENT DNFIGURATION	261 267 <b>277</b>
SWITCH RE SWITCH CC APPENDIX D APPENDIX E	PLACEMENT DNFIGURATION SWOPS SIGN OFF.	261 267 <b>277</b> <b>278</b>

# List of Figures

Figure 1: Example of a step that indicates the Server on which it needs to be executed	10
Figure 2: Initial Application Installation Path	14
Figure 3: Split Mirror Upgrade Path – EPAP 16.4.a.0.0-b.b.b	14
Figure 4: Incremental Upgrade Path – EPAP 16.4.a.0.0-b.b.b.	14
Figure 5: EPAP Mated Pairs	15
Figure 6: EPAP Mated Pairs with Non-Provisioning MPS Servers	16
Figure 7: Slide the Ejector Switch	203
Figure 8: Release Lever	203
Figure 9: Interconnectivity Diagram for Sync Network Redundancy (Eth04 used for Sync Netw	vork)259
Figure 10: Default Interconnectivity Diagram (Eth04 used for Backup Provisioning Network)	260

# List of Tables

Table 1. Acronyms	10
Table 2. Terminology	11
Table 3 Install-Upgrade paths	13
Table 4: System Configuration Information	
Table 5. User Password Table	
Table 6. Installation Phases for Mixed EPAP and Non-Provisional EPAP	
Table 7 Installation Phases for Standalone PDB	
Table 8 Split Mirror Upgrade Phases for Mixed and Non-Provisionable EPAP	
Table 9 Split Mirror Upgrade Phases on Standalone PDB	
Table 10 Incremental Upgrade Phases for Mixed and Non-Provisionable EPAP	
Table 11 Incremental Upgrade Phases on Standalone PDB	
Table 12. Backout Phases for Mixed and Non-Provisionable EPAP	
Table 13. Backout Phases for Standalone PDB	
Table 14. DB Conversion	
Table 15 Phases to change DB Architecture to eXtreme (Standalone PDB)	
Table 16 Phases to change DB Architecture to eXtreme (First Non-prov site)	
Table 17 Phases to change DB Architecture to eXtreme (Remaining Non-Prov sites)	

# **List of Procedures**

Procedure 1: Setting up the upgrade environment	37
Procedure 2: Determine if upgrade or installation is required	38
Procedure 3: Verifying Pre-Upgrade Requirements and Capturing Upgrade Data	40
Procedure 4: System Health Check	41
Procedure 5: Pre-Install Configuration on Server A	
Procedure 6: Pre-Install Configuration on Server B	47
Procedure 7: Install the Application on Server A	51
Procedure 8: Install the Application on Server B	56
Procedure 9: Switch Configuration	62
Procedure 10: Procedure to Configure Sync Network Redundancy	71
Procedure 11: Configuring the Application	76

<b>Upgrade/Installation Guide</b>
-----------------------------------

Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as	
designated by customer)	. 96
Procedure 13: Change the DB Architecture	. 99
Procedure 14: Assess the MPS Server's Readiness for Upgrade	105
Procedure 15: Pre and Post Upgrade Backups	107
Procedure 16: Pre-Upgrade System Time Check	108
Procedure 17: Check 9dig counts before moving to eXtreme architecture	109
Procedure 18: Upgrade Server B	110
Procedure 19: Upgrade Server A	
Procedure 20: Run RTDB Converter	135
Procedure 21: Reboot EAGLE Cards	136
Procedure 22: Accept upgrade	136
Procedure 23: Keys exchange between active PDB and standby PDB	
Procedure 24: Server B Backout	140
Procedure 25: Backout both MPS A and B	146
Procedure 26: Stop the PDBA Software	156
Procedure 27: Restart the PDBA Software Post-Backout and Post-Upgrade	157

# **1 INTRODUCTION**

## **Purpose and Scope**

This document describes methods utilized and procedures executed to perform the following tasks:

- a. An initial installation of the EPAP 16.4.1 application software if it is not currently installed on an inservice E5-APP-B system running a release of TPD 7.8.1.0.0\_89.9.0
- b. A split-mirror upgrade on an in-service E5-APP-B system running an EPAP Release 16.2.x/16.3.x/16.4.x
- c. An incremental software upgrade on an in-service E5-APP-B system running an EPAP Release 16.4.x

The audience for this document consists of Oracle customers and the following groups: Software System, Product Verification, Documentation, and Customer Service including Software Operations and NPI. This document provides step-by-step instructions to execute any MPS upgrade or installation using an ISO image.

This document does not address requirements relating to the interaction, if any, between EAGLE and MPS upgrade. This document does not address feature activation.

#### Note:

- In this release, the upgrade sequence is different from the previous releases. In this release, the upgrade for standby and active PDBAs is performed first and it is followed by the non Prov upgrade. For the previous releases, the non Prov upgrade is performed first and it is followed by the active and standby PDBAs.
- EPAP 16.4 introduced a new parameter LSBLSET in the DN table. EPAP releases prior to 16.4 do not have LSBSSET in their DN table. Customers who use LSBLSET in their provisioning, and upgrading their EPAP network from EPAP 16.3 to a higher release (16.4) need to make sure they provision LSBLSET ONLY after they have upgraded the whole network with EPAP 17.0. When customers have DUAL PDBA (DUAL Mixed-EPAP or DUAL PDBonly), after upgrading one site from 16.3 to EPAP 16.4, that upgraded site should not be made Active if the customer uses LSBLSET in their provisioning. If EPAP 16.4 Active PDB site upgrades a DN with LSBLSET parameter, the EPAP 16.3 EPAPs will reject that update as they do not have LSBLSET parameter in their DB. Further provisioning at the Standby PDBA and Non-PROVS will be barred once one upgrade fails to replicate to Standby PDBA or Non-PROVs.

#### References

#### 1.1.1 External

- [1] EAGLE Application Processor (EPAP) Administration Guide, E54368-01, latest revision, Oracle
- [2] EPAP 16.4 Administration Manual, Oracle

#### 1.1.2 Internal (Oracle)

The following are references internal to Oracle. They are provided here to capture the source material used to create this document. Internal references are only available to Oracle's personnel.

- [1] TEKELEC Acronym Guide, MS005077, revision 2.35, September 2005.
- [2] Software Upgrade Procedure Template, TM005074, Current Version
- [3] Integrating MPS into the Customer Network, TR005014, version 3.1, October 2009
- [4] TPD Initial Product Manufacture TPD 7.6+, E53017-04, Latest revision
- [5] *PFS EPAP 16.4*, Latest revision

- [6] EPAP Administration Manual for EPAP 16.4, Latest version
- [7] EPAP Linkset Based Blocklisting, CGBU\_042015

## Software Release Numbering

Refer to Engineering Release Notes or other appropriate document with the most recent build numbers in order to identify the proper components (software loads, GPLs, etc.) that comprise the product's software release.

#### Acronyms

An alphabetized list of acronyms used in the document that are not included in [1]:

Table 1. Acronyn	ns
------------------	----

AS	Application Server
E5-APP-B	E5 Based Application Card
OCEPAP	Oracle Communication EAGLE Provisioning Application Processor
GA	General Availability
IPM	Initial Product Manufacture
LA	Limited Availability
MPS	Multi-Purpose Server
MOS	My Oracle Support
OSDC	Oracle Software Delivery Cloud
SM	Service Module
TPD	Tekelec Platform Distribution

## Terminology

Multiple servers may be involved with the procedures in this manual. Therefore, most steps in the written procedures begin with the name or type of server to which the step applies. For example:

Each step has a checkbox for every command within the step that the technician should check to keep track of the progress of the procedure.




Figure 1: Example of a step that indicates the Server on which it needs to be executed

Other terminology follows.

#### Table 2. Terminology

Backout (abort)	The process to take a system back to a Source Release prior to completion of
	upgrade to Target release. Includes preservation of databases and system
	configuration.
Mixed EPAP	An EPAP where both PDB and RTDB databases reside.
Non-provisionable (Non-	An EPAP server hosting a Real Time DB without any provisioning interfaces to
prov) EPAP	external provisioning applications. Non-Prov servers are connected to a pair of
	Provisionable EPAP(mixed-EPAP or PDBonly) from where they get their
	updates.
Provisionable EPAP	An EPAP server hosting PDB with provisioning interfaces to AS. Both Mixed
	EPAP and Standalone PDB are Provisionable EPAP.
Source release	Software release to upgrade from.
Split Mirror	Systems that use software RAID instead of hardware RAID can use the software RAID mirrors as a backout mechanism. Conceptually in a software RAID1 with two disks there are two sides to the mirror; let them be side A and side B. For a system with multiple software RAID devices, each device will have an A side and a B side. For an upgrade with a BACKOUT_TYPE=SPLIT_MIRROR the upgrade will break the mirrors at the beginning of the upgrade and perform the upgrade on the <i>Asides</i> of the mirrors. The other sides of the mirrors ( <i>B sides</i> ) are left intact in their pre-upgrade state throughout the duration of the upgrade.
	environment'. Inside this 'backout environment' the RAID mirrors are rebuilt from the <i>B sides</i> of the arrays, thus restoring the system to the pre-upgrade state
Standalone PDB	Also known as 'PDB Only', this type of EPAP shall have PDB database only. No
	RTDB database shall exist on the standalone PDB site.
Target release	Software release to upgrade to.
Upgrade media	USB media or ISO image for E5-APP-B.

## Recommendations

This procedure should be followed thoroughly utilizing the steps as written. When planning to run upgrade on the server, contact My Oracle Support at least 48 hours before the upgrade process has been planned to be initiated. In the event any unexpected results are returned while executing steps in this procedure, halt the activity and contact My Oracle Support for assistance.

#### Please read the following notes on procedures:

- 1. While doing upgrade, do not open the epapconfig menu if it is not mentioned in the procedure. Do not run anything in the setup that is not documented in the install/upgrade manual.
- 2. Any procedure completion times are estimates. Times may vary due to differences in database size, user experience, and user preparation.
- 3. The shaded area within response steps must be verified in order to successfully complete that step.
- 4. Output displayed in the procedures' response steps is presented. Actual output varies depending on system. Output is presented for reference only.
- 5. Where possible, command response outputs are shown as accurately as possible. However, exceptions may include the following:
  - Information such as *time* and *date*.
  - ANY information marked with "*XXXX*." Where appropriate, instructions are provided to determine what output should be expected in place of "*XXXX*."

- 6. After completing each step and **at each point where data is recorded from the screen**, *the technician performing the procedure must check each step*. A checkbox has been provided beneath each step number for this purpose.
- 7. Captured data is required for future support reference if My Oracle Support is not present during the execution of procedures.
- 8. In procedures that require a command to be executed on a specific MPS, the command is prefaced with MPS A: or MPS B:
- 9. User Interface menu items displayed in this document were correct at the time the document was published but may appear differently at time that this procedure is executed.

#### Requirements

- Screen logging is required throughout the procedure. These logs should be made available to My Oracle Support in the event their assistance is needed.
- Target-release USB media or ISO image

# 2 GENERAL DESCRIPTION

This document defines the step-by-step actions performed to execute a software upgrade of an in-service MPS running the EPAP application from the source release to the target release on **E5-APP-B-01/02**.

For the EPAP application, some steps in this procedure refer to the PDB application feature on the MPS A of the MPS pair. The EPAP application makes it optional for a newly installed MPS A node to be configured as a Provisioning (PDB) node (upgrades of MPS A nodes already configured as a provisioning node does not change this configuration).

Also, the conversion from provisionable mixed EPAP to Non-provisionable EPAP is supported in EPAP 16.4.1 without any loss of data. Refer to Procedure A.25 to perform this operation.

The EPAP application can be installed and upgraded based on the table below.


#### Table 3 Install-Upgrade paths

TPD Release for IPM	EPAP Initial Installation Release
7.8.1.0.0_89.9.0	16.4.1

		TARGET
		RELEASE
		16.4.1
		(7.8.1)
	16.2.0	Split Mirror
ш	(TPD 7.4)	Upgrade
AS		
RELEASE	16.3.0	Split Mirror
RE	(TPD 7.6)	Upgrade
Ш		
UR	16.3.1	Split Mirror
SOURCE	(TPD 7.6)	Upgrade
	16.4	
	(TPD	Split Mirror
	7.6.2)	Upgrade

**NOTE**: If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 16.4. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

The EPAP upgrade paths are shown in the figures below. The general timeline for all processes to perform a software incremental upgrade, from pre-upgrade backups to a final system health check, is also included below.



#### **Figure 2: Initial Application Installation Path**




Figure 3: Split Mirror Upgrade Path – EPAP 16.4.a.0.0-b.b.b





Figure 4: Incremental Upgrade Path – EPAP 16.4.a.0.0-b.b.b

# **Upgrading Provisionable mixed EPAP Mated Pairs**

Current deployments of the EPAP support two geographically separated EPAP systems that are "mated", meaning they communicate and replicate PDB information between the two sites. An EPAP system is a pair of MPS servers (an **A** and a **B** node). So a mated pair of EPAP systems consists of four MPS servers, an **A** and a **B** node for each EPAP system (see Figure 5: EPAP Mated Pairs). EPAP allows more than two EPAP systems in a related configuration (up to 22 Non-Provision able MPS servers).

This document describes upgrade (and, if necessary, backout) of the EPAP software on one system, that system consisting of two MPS servers (A and B). However, for mated pairs of EPAP systems, upgrades (and backouts) must be coordinated between both the local EPAP system and the remote EPAP system and performed during the same maintenance period.



**Figure 5: EPAP Mated Pairs** 

Upgrade of provisionable EPAP(mixed-EPAP) mated pairs must be carried out in the following order:

- 1. Ensure PDB databases are at the same level. Stop all provisioning to ensure that all PDB databases are in sync before proceeding. Also, ensure that no PDB/RTDB maintenance activity is in progress and clear all scheduled activities.
- 2. Local MPS-B
- 3. Local MPS-A (Standby PDBA)
- 4. Remote MPS-B
- 5. Remote MPS-A (Active PDBA)

When upgrade is initiated on the local MPS-B, the scripts controlling the upgrade will cause the local MPS-B to communicate using Secure-Shell to both the local MPS-A and the remote MPS-A to stop the PDBA software. The PDBAs should be restarted only after both the local and remote EPAP systems have successfully completed the upgrade.

NOTE: Since the PDBA software is not running immediately after an upgrade, the syscheck utility will alarm the fact that the PDBA is not running on the local and remote EPAP A-servers.

## **Backout Provisionable mixed EPAP Mated Pairs**

Backout of Provisionable EPAP (mixed-EPAP) Mated Pairs should be done in the reverse order that the upgrade was performed:

- 1. Identify a PDB backup that was made prior to upgrade, on the EPAP release that backout will target. Note that backout always carries the risk of losing data, should a restore from database backup become necessary.
- 2. Remote MPS-A (Active PDBA)
- 3. Remote MPS-B
- 4. Local MPS-A (Standby PDBA)
- 5. Local MPS-B

On a backout of an upgrade, the server will remain in runlevel 3 (no applications running). The user will be required to manually reboot the server to bring it back into service and a syscheck can be performed.

# **Upgrading EPAP Non-Provisionable MPS Servers**

EPAP Non-Provisional MPS pairs can connect to: Mixed EPAP or Standalone PDB.

#### 2.1.1 Upgrading Non-Provisional MPS pairs in Mixed EPAP configuration

EPAP provides the ability to expand the concept of a mated pair of EPAP systems to have up to 24 EPAP systems (48 MPS servers total) configured such that two of the MPS-A servers will run the PDBA software and RTDB software both and handle provisioning (Provisionable nodes) and the other 22 MPS-B and 22 MPS-A servers will only run the RTDB software, taking their updates from the two Provisionable (mixed-EPAP or PDBonly) MPS-A servers.




Figure 6: EPAP Mated Pairs with Non-Provisioning MPS Servers

In such configurations, the upgrade for the EPAP system containing the provisionable MPS servers must complete before upgrading any EPAP system containing the non-provisionable MPS servers. The order of upgrade for such configuration must be as follows:

#### Mixed EPAP (with standby PDBA)

- 1. Mixed EPAP (MPS B)
- 2. Mixed EPAP (MPS A

#### Mixed EPAP (with active PDBA)

- 3. Mixed EPAP (MPS B)
- 4. Mixed EPAP (MPS A)

Non-provisionable EPAPs (All Non-Provs)

- 5. Non-Provisionable (MPS B)
- 6. Non-Provisionable (MPS A)

**Note:** In this release, the upgrade sequence is different from the previous releases. In this release, the upgrade for standby and active PDBAs is performed first and it is followed by the non Prov upgrade. For the previous releases, the non Prov upgrade is performed first and it is followed by the active and standby PDBAs.

# 2.1.2 Upgrading Non-Provisional MPS pairs in dual PDBonly configuration

EPAP provides the ability to separate the RTDB from PDB to create the following two architectures:

- Standalone PDB running PDB process only
- Non-Provisionable PDB running RTDB only

Up to 22 Non-Provisional EPAP mated pairs are connected to two Standalone PDBs that are configured as Active/Standby.

In such configurations, the upgrade for the EPAP system containing the provisionable MPS servers must complete before upgrading any EPAP system containing the non-provisionable MPS servers.

The order of upgrade for such configuration must be as follows:

- 1. Standby PDBonly
- 2. Active PDBonly
- 3. Non-Prov (MPS B)
- 4. Non-Prov (MPS A)

**Note:** In this release, the upgrade sequence is different from the previous releases. In this release, the upgrade for standby and active PDBAs is performed first and it is followed by the non Prov upgrade. For the previous releases, the non Prov upgrade is performed first and it is followed by the active and standby PDBAs.

#### **Backout EPAP Non-provisionable MPS servers**

EPAP Non-Provisional MPS pairs can connect to: Mixed EPAP or Standalone PDB.

#### 2.1.3 Backout Non-Provisionable MPS pairs in dual PDBonly configuration

Backout of Non-Provisionable MPS pairs in Standalone configuration should be done in the reverse order that the upgrade was performed. Please follow the below mentioned steps for backout:

- 1. Non-Provisionable (MPS A)
- 2. Non-Provisionable (MPS B)
- 3. Active PDBonly
- 4. Standby PDBonly

On a backout of an upgrade, the server will remain in runlevel 3 (no applications running). The user will be required to manually reboot the server to bring it back into service and a syscheck can be performed.

# 2.1.4 Backout Non-Provisionable MPS pairs in mixed EPAP configuration

Backout of EPAP Non-provisionable MPS pairs in mixed EPAP configuration should be done in the reverse order that the upgrade was performed:

Non-provisionable EPAP

- 1. Non-Provisionable (MPS A)
- 2. Non-Provisionable (MPS B)

Mixed EPAP (with active PDBA)

- 3. Mixed EPAP (MPS A)
- 4. Mixed EPAP (MPS B)

Mixed EPAP (with standby PDBA)

5. Mixed EPAP (MPS A)

Upgrade/Installation Guide

6. Mixed EPAP (MPS B)

# **3 UPGRADE OVERVIEW**

## **Upgrade Provisioning Rules**

When a Provisionable EPAP mated pair is upgraded or backed out, the EPAP upgrade scripts disable provisioning when the upgrade is initiated on the first MPS server. The PDBA software remains disabled until the last server in the MPS in the mated pair has been upgraded or backed out. The user has-to enable the PDBA software, allowing provisioning, after the upgrade/backout is complete on last MPS server in an EPAP mated pair. Provisioning is not disabled during the upgrade of a Non-Provisionable MPS.

Because EPAP MPS pairs are generally located at geographically distinct sites, significant time may elapse between the upgrade of the Provisionable EPAP pair and the upgrade of the Non-Provisionable EPAP pairs. Non-Provisionable EPAP pairs must always be upgraded before any Provisionable EPAP MPS pairs.

The "DB Architecture" will be changed post upgrade to accommodate new "lsblset" parameter introduced in EPAP 16.4 release. Refer Section 4 for more details. Due to this new parameter post upgrade user will have to run converter script to convert the existing RTDB to make it compatible with new architecture.

#### **Required Materials**

- For Mixed EPAP or Non-Provisional EPAP: Two (2) target-release USB media or a target-release ISO file. For Standalone PDB: One (1) target-release USB media or a target-release ISO file
- A terminal and null modem cable to establish a serial connection.
- Write down the system configuration information.

Description	Information
PROVISIONABLE (Yes/No)	
PDBA state (Active/Standby)	
Provisioning IP (IPv4)	
Provisioning Mask (IPv4)	
Provisioning Default Router IP (IPv4)	
Provisioning IP (IPv6)	
Provisioning Netmask (IPv6)	
Provisioning Default Router IP (IPv6)	
NTP1 IP (IPv4/IPv6)	
NTP2 IP (IPv4/IPv6)	
NTP3 IP (IPv4/IPv6)	
Local VIP	
Remote VIP	
Local PDBA IP (IPv4)	
Local PDBA IP (IPv6)	
Remote PDBA IP (IPv4/IPv6)	
Remote PDBA B IP (IPv4/IPv6)	
RTDB Homing	
Time Zone	
PDBA Proxy Feature	
Others	

**Upgrade/Installation Guide** 

# Table 4: System Configuration Information

• Passwords for users on the local system:

EPAP USERS								
login	MPS A password	MPS B password						
epapconfig								
epapdev								
(needed for backout								
only)								
root								
epapall								
(needed for GUI access)								
admusr								

Table 5. User Password Table

## **Installation Phases**

The following table illustrates the progression of the installation process by procedure with estimated times. The estimated times and the phases that must be completed may vary due to differences in typing ability and system configuration. The phases outlined in Table 6 and Table 7 are to be executed in the order they are listed.

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS Servers.	Procedure 1
Verify install	5	20	Verify this should be an install.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for install are met.	Procedure 3
Pre-install health check	5	40	Run the syscheck utility to verify that all servers are operationally sound.	Procedure 4
Configure Server 1A	5	45	Set hostname, designation, function and time.	Procedure 5
Configure Server 1B	5	50	Set hostname, designation, function and time.	Procedure 6
Install Servers	30	80	Install software on sides 1A and 1B	Procedure 7 Procedure 8
Configure Switches	30*	110*	Configure the Switches	Procedure 9
Post-install application processing	30	140	Perform first time configuration.	Procedure 11 Procedure 12
Post-upgrade health check	5	150	Run the syscheck utility to verify all servers are operationally sound.	Procedure 4
**Configure Auto Backup Note: Skip this step if the EPAP is configured as Non-Provisionable.	5	155	Configure Auto Backup from PDB GUI on Provisionable EPAP's, this backup will also get scheduled on attached Non- Prov sites present on the setup.	Procedure A.28
Check EPAP-EAGLE connectivity speed	20	190	Configure and verify that EAGLE SM cards are getting auto-negotiated to 1000Mbps/Full Duplex	Procedure A.17

## 3.1.1 Installation Phases for Mixed and Non-Provisionable EPAP

#### Table 6. Installation Phases for Mixed EPAP and Non-Provisional EPAP

**\*NOTE:** If configuring 4 switches, add 30 minutes to the current setup

**\*\*NOTE:** Configuring Auto backup is a compulsory step to enable PDB-RTDB translogs pruning.

## 3.1.2 Installation Phases for Standalone PDB

Note: In the procedures below, skip the steps which need to be executed on MPS B, since MPS B is not present in the Standalone PDB configuration''.

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS Servers.	Procedure 1
Verify install	5	20	Verify this should be an install.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for install are met.	Procedure 3
Pre-install health check	5	40	Run the syscheck utility to verify that all servers are operationally sound.	Procedure 4
Configure Server 1A	5	45	Set hostname, designation, function and time.	Procedure 5
Install Server	30	75	Install software on sides 1A	Procedure 7
Post-install application processing	30	105	Perform first time configuration. Refer to Procedure A.14 to configure the Standalone PDB in segmented network configuration.	Procedure 11 Procedure 12
Post-upgrade health check	5	115	Run the syscheck utility to verify all servers are operationally sound.	Procedure 4
**Configure Auto Backup. Note: Perform this step once Non- Provisionable EPAPs are attached to this Standalone PDB	5	120	Configure Auto Backup from PDB GUI on Provisionable EPAP's, this backup will also get scheduled on attached Non- Prov sites present on the setup.	Procedure A.28
Restore PDB backup (optional)	*See notes below	*See notes below	Restore EPAP 16.1/16.2 PDB backup if there is any. Note: This step is required when a mixed EPAP with release 16.1/16.2, is getting converted to PDBonly+Non- PROV in 16.3. Skip this step for initial installation of a PDBonly EPAP 16.3 where there is no dependency on previous release.	Procedure A.24

#### Table 7 Installation Phases for Standalone PDB

**\*NOTE:** The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

#### **\*\*NOTE:** Configuring Auto backup is a compulsory step to enable PDB-RTDB translog pruning.

# Split Mirror Upgrade Phases

The following table illustrates the progression of the Split Mirror upgrade process by procedure with estimated times and may vary due to differences in typing ability and system configuration. The procedures outlined in below

**Table 8** are to be executed in the order they are listed.

Note: Before proceeding with the Split Mirror upgrade process, refer to section 0 and section 0 to get the overview of the EPAP setup and upgrade order.

# 3.1.3 Split Mirror Upgrade Phases for Mixed and Non-Provisionable EPAP

Phase	Ti (Min This	psed me nutes) Cum.	Activity	Procedure
Connectivity setup	<b>Step</b> 15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify Major upgrade	5	20	Verify this should be a Major upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for Major Upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
Pre-upgrade Backup	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Pre-upgrade system time check	5	60	Pre-upgrade system time check.	Procedure 16
Exchange the keys between active and standby PDB	05	65	Pre-upgrade keys exchange between active and standby PDB. <b>Note:</b> Execute this procedure only for	Procedure 23
Stop the PDB software.	05	70	dual mixed EPAP.Stop the Pdba software before initiating upgrade.Note: This Step only necessary for provisionable EPAP(mixed-EPAP or PDBonly).Skip for Non-prov EPAP.	Procedure 26
Upgrade MPS B	30	100	Execute the upgrade procedure on MPS B.	Procedure 18
Upgrade MPS A	30	130	Execute the upgrade procedure on MPS A. Note: Time taken by this upgrade may vary depending on the DB present on setup. 75 min is valid for mixed EPAP with maximum DB, 528M.	Procedure 19
Run RTDB Converter on MPS A	20	150	Run RTDB converter to convert database schema for new field	Procedure 20
Reload RTDB from mate	10	160	Reload RTDB from mate on Non-prov MPS B	RTDB Reload from Remote
Reboot EAGLE Cards	***See Notes Below	***See Notes Below	Reboot Eagle Cards to reload updated DB	Procedure 21
Post-upgrade health check	5	165	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Increase rtVolume size.	10	175	Increase rtVolume size by executing "rtdir" script. <b>Note:</b> skip this step for provisionable EPAP(mixed-EPAP and PDBonly).	Procedure A.5

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Cum. Step			
Start the PDB software.	10	185	Re-activate the PDB on the Provisionable MPS A servers(mixed- EPAP in this case). Note: Step only necessary during upgrade of a Provisionable mated EPAP pair (mixed EPAP + PDBonly).	Procedure 27
Configure Switches	30**	215**	Re-configure the switch and verify that EAGLE SM cards are getting auto- negotiated to 1000Mbps/Full Duplex. Note: Skip this step if speed is already set to 1000Mbps/Full Duplex.	Procedure 9
***Configure Auto Backup Note: Skip this step if the EPAP is configured as Non-Provisionable.	5	220	Configure Auto Backup from PDB GUI on Provisionable EPAP's, this backup will get scheduled on attached Non-Prov sites present on the setup.	Procedure A.28
Post-upgrade Backups	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Accept the upgrade after successful soak period NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given. NOTE: After EPAP upgrade, if EMS is not able to receive alarms from EPAP, delete the EPAP from EMS discovery screen and then rediscover the EPAP on EMS.	5	This is done in a separate MTC	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 22

#### Table 8 Split Mirror Upgrade Phases for Mixed and Non-Provisionable EPAP

**\*NOTE:** The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

**\*\*NOTE:** If configuring 4 switches, add 30 minutes to the current setup.

**\*\*\*NOTE:** The time needed to reload EAGLE cards is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

**\*\*\*\*NOTE:** Configuring Auto backup is a compulsory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.

\*\*\*\*\***NOTE**: If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 16.4. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

# 3.1.4 Split Mirror Upgrade Phases for Standalone PDB

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify Major upgrade	5	20	Verify this should be a Major upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	40	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	55	Assess the server's readiness for upgrade.	Procedure 14
Pre-upgrade Backup	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Pre-upgrade system time check	5	60	Pre-upgrade system time check.	Procedure 16
Stop the PDB software.	05	65	Stop the Pdba software before initiating upgrade. This Step only necessary for provisionable EPAP(mixed-EPAP or PDBonly).Skip for Non-prov EPAP.	Procedure 26
Upgrade MPS A	30	95	Execute the upgrade procedure on MPS A. Note: Time taken by this upgrade may vary depending on the DB present on setup. 75 min is valid for maximum DB, 528M.	Procedure 19
Post-upgrade health check	5	100	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Start the PDB software.	10	110	Re-activate the PDB on theProvisionable MPS A servers (PDBonly in this case). <b>Note:</b> Step only necessary during upgrade of a Provisionable mated EPAP pair (mixed EPAP + PDBonly).	Procedure 27
**Configure Auto Backup.	5	115	Configure auto backup to schedule RTDB Auto-Backup on Non- Provisionable EPAP	Procedure A.28
Post-upgrade Backups	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Accept the upgrade after successful soak period NOTE: If the node is to be converted from Compact to eXtreme DB architecture, delay this step until the conversion is done and sufficient soak time is given. NOTE: After EPAP upgrade, if EMS is not able to receive alarms from EPAP, delete the EPAP from EMS discovery screen and then rediscover the EPAP on EMS.	5	This is done in a separate MTC	Accept the upgrade on both MPS-A after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 22

#### Table 9 Split Mirror Upgrade Phases on Standalone PDB

**\*NOTE:** The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

**\*\*NOTE:** Configuring Auto backup is a compulsory step to enable PDB-RTDB translog pruning. Ignore this step if auto-backup is already configured.

**\*\*\*NOTE**: If you are using Eagle Query Server with EPAP, you need to do a fresh installation of Eagle Query Server after upgrading EPAP to Release 16.4. See Eagle Query Server Installation Guide for installing a fresh EAGLE Query Server.

## **Incremental Upgrade Phases**

The following table illustrates the progression of the incremental upgrade process by procedure with estimated times and may vary due to differences in typing ability and system configuration. The procedures outlined in below Table 10 are to be executed in the order they are listed.

Note: Before proceeding with the incremental upgrade process, refer to section 0 to get the overview of the EPAP setup and upgrade order.

## 3.1.5 Incremental Upgrade Phases for Mixed and Non-Provisionable EPAP

Phase	ElapsedTime(Minutes)ThisCum.Step		Activity	Procedure
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1
Verify incremental upgrade	5	20	Verify this should be an incremental upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	55	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	50	Assess the server's readiness for upgrade.	Procedure 14
Pre-upgrade Backup	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Pre-upgrade system time check	5	60	Pre-upgrade system time check.	Procedure 16
Upgrade MPS B	30	90	Execute the upgrade procedure on MPS B.	Procedure 18
Upgrade MPS A	30	120	Execute the upgrade procedure on MPS A.	Procedure 19
Post-upgrade health check	5	125	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Start the PDB software.	10	135	Re-activate the PDB on the Provisionable MPS A server(mixed- EPAP in this case). Note: Step only necessary during upgrade of a Provisionable mated EPAP pair (mixed EPAP + PDBonly).	Procedure 27
Configure Switches	30**	205**	Re-configure the switch and verify that EAGLE SM cards are getting auto- negotiated to 1000Mbps/Full Duplex. Note: Skip this step if speed is already set to 1000Mbps/Full Duplex.	Procedure 9
Post-upgrade Backups	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15

#### Table 10 Incremental Upgrade Phases for Mixed and Non-Provisionable EPAP

**\*NOTE:** The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

# 3.1.6 Incremental Upgrade Phases for Standalone PDB

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Connectivity setup	15	15	Set up connectivity to the MPS servers.	Procedure 1

Phase	Ti	psed ime nutes)	Activity	Procedure
	This Step	Cum.		
Verify incremental upgrade	5	20	Verify this should be an incremental upgrade.	Procedure 2
Pre-upgrade check	15	35	Verify requirements for upgrade are met.	Procedure 3
Pre-upgrade health check	5	55	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Assess readiness for upgrade	15	50	Assess the server's readiness for upgrade.	Procedure 14
Pre-upgrade Backup	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15
Pre-upgrade system time check	5	60	Pre-upgrade system time check.	Procedure 16
Upgrade MPS A	30	90	Execute the Upgrade procedure on MPS A.	Procedure 19
Post-upgrade health check	5	95	Run the syscheck utility to verify the MPS server is operationally sound.	Procedure 4
Start the PDB software.	10	105	Re-activate the PDB on the Provisionable MPS A servers (mixed- EPAP in this case). Note: Step only necessary during upgrade of a Provisionable mated EPAP pair (mixed EPAP + PDBonly).	Procedure 27
Post-upgrade Backups	*See notes below	*See notes below	Backup application databases and other pertinent information.	Procedure 15

#### Table 11 Incremental Upgrade Phases on Standalone PDB

**\*NOTE:** The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

#### **Backout Phases**

Note: Before proceeding with the backout process, refer to sections 0 and 0 to get the overview of the EPAP setup and the backout order.

# 3.1.7 Backout Phases for Mixed and Non-Provisionable EPAP

Phase	Elapsed Time (Hours or Minutes)		Activity	Impact	Procedure	
	ThisCuStepm.					
Determine state of system	15- 30	15- 30	Investigate and determine the state of the MPS system. This may take anywhere from 15 to 30 minutes.	Cannot proceed with backout until failure analysis is complete. Some hand-fixes may be required before proceeding with backout.	Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F	
Backout MPS B only	30	45- 60	If required, backout MPS B. If backout of MPS A and B is required, execute <b>Procedure 25</b> . Otherwise, if backout required only on MPS B, then execute <b>Procedure</b> <b>24</b> .		Procedure 24	
Backout MPS A and B	100	145- 160	Backout MPS A and B.		Procedure 25	
Post-backout health check	10	155- 170	Run the syscheck utility to verify the MPS server is operationally sound.	Verify that the backout was successful.	Procedure 4	
Start the PDBA software	5	160- 175	Re-activate the PDB on the Provisionable MPS A servers (mixed-EPAP in this case).Note: Read the instructions given in Procedure A.1 before executing the procedure.		Procedure 27	
Configure Switches	30*	190- 205*	Re-configure the switch and verify that EAGLE SM cards are getting auto- negotiated to previous speed. Note: Skip this step if speed before upgrade was 1000Mbps/Full Duplex.	Verify that speed of switch is negotiated to previous speed.	Procedure 9	

**\*NOTE:** If configuring 4 switches, add 30 minutes to the current setup.

# 3.1.8 Backout Phases for Standalone PDB

Phase	Elapsed Time Phase (Hours or Minutes)		Activity	Impact	Procedure	
	This Step	Cu m.				
Determine state of system	15- 30	15- 30	Investigate and determine the state of the MPS system. This may take anywhere from 15 to 30 minutes.	Cannot proceed with backout until failure analysis is complete. Some hand-fixes may be required before proceeding with backout.	Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F.	
Backout MPS A	30	45- 60	Backout MPS A.		Procedure 25 step 1 through 14.	
Post-backout health check	10	155- 170	Run the syscheck utility to verify the MPS server is operationally sound.	Verify that the backout was successful.	Procedure 4 step 1.	
Start the PDBA software	5	160- 175	Re-activate the PDB on the Provisionable(PDBonly) MPS A servers.		Procedure 27	

**Table 13. Backout Phases for Standalone PDB** 

# Log Files

All commands executed during an upgrade or installation, are logged in the "/var/TKLC/log/upgrade/upgrade.log" file. This log file is automatically initiated when upgrade software is invoked. This log file is rolled every time an upgrade is initiated. A total of up to five upgrade log files are stored on the server.

The upgrade wrapper script, ugwrap, logs its actions also to the "/var/TKLC/log/upgrade/ugwrap.log" file. This log file is rolled every time ugwrap is initiated. A total of up to five ugwrap log files are stored on the server.

# 4 DB ARCHITECTURE OVERVIEW

A new parameter LSBLSET would be added to DN and DN Block tables. This parameter will be used along with CGPNBLSET parameter on EAGLE that would be configured in the linkset table on EAGLE. If the value of LSBLSET parameter for a DN/DN Block on EPAP is found to match with the CGPNBLSET parameter of linkset table on EAGLE, it will be considered as blocklisted DN/DN Block. IAM message will be released (i.e. send back to originator) from EAGLE for the corresponding DN/DN Block. In all other cases, the existing functionality will continue to hold true.

The existing DN/ DN Block table parameters that are configured in the GUI are stored in multiple SQL tables, the DN table for example has only two parameters dnID and PT(port type) parameters in it.

There are other tables (example  $dn_bl$ ,  $dn_asd$  etc. ) which help in storing the other parameters entered in GUI forms for DN and DNBlock.

While entering values write operation, is performed with the help of multiple joins with these supporting tables.

Finally, while displaying these values during retrieve operation the join of all the supporting tables is taken and the values fetched are displayed together.

The new parameter LSBLSET is part of dn\_bl table and dnB\_bl SQL tables for DN and DN Block respectively. This new parameter will be compatible only with eagle 46.9 release.

From EPAP 16.3 onwands different DB architectures are supported i.e. "Compact" and "Extreme". This was done to support enhanced DB capacity.

EPAP 16.4 also supports both compact and extreme architecture. Post upgrade user will remain on existing architecture and will have to change the architecture from compact to extreme as an optional step if required. In changing the DB Architecture from "Compact" to "eXtreme", the EPAP software shall restart to support the capacity expansion. Before the change in DB Architecture on EPAP, the connecting EAGLE must upgrade to the new release with SLIC cards. Also, the user has-to enable the EPAPX feature on eagle card to support the eXtreme feature. Refer to section 0 to change DB Architecture from Compact to eXtreme.

NOTE: Section 4.2 and 4.3 are only required if customer setup is on compact architecture and wants to change architecture to extreme. Others i.e. thos who are already on extreme architecture or doesn't want to change to extreme architecture can skip these sections.

## **Overview of DB architecture change in Customer Network**

Upgrade from EPAP 16.2/16.3 to EPAP 16.4 followed by DB Architecture conversion to support new LSBLSET parameter must be carried out as per the below table after upgrade is completed in same MTC window. Based on the existing DB Architecture either compact to compact converter script will be executed or extreme to extreme converter script will be executed. Follow procedure to identify DB architecture and run conversion script.

Base Release	Target Release	Data Base Architecture	Target Architecture	Converter Required
16.2	16.4	NA	Compact	Compact to Compact converter to accommodate lsblset parameter
16.3	16.4	Compact	Compact	Compact to Compact converter to accommodate lsblset parameter
16.3	16.4	Extreme	Extreme	Extreme to Extreme converter to accommodate lsblset parameter

Table 14. DB Conversion

\*Note: Allow soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade. After getting convinced that system is working fine, accept the upgrade.

**Upgrade/Installation Guide** 

# **Overview of DB architecture change from Compact to Extreme**

Upgrade from EPAP 16.2/16.3 to EPAP 16.4 followed by DB Architecture conversion from Compact to Extreme must be carried out in following order with different MTC window:

**Note:** This step is required only when EPAP 16.4 and Eagle are to run in eXtreme mode. If EPAP and Eagle are to run in COMPACT mode, skip this section.

#### Phase-1 (Upgrade the EPAPs to EPAP 16.4 release in COMPACT mode):

**NOTE:** If the network consists of Non-PROVs and Mixed-EPAP, please refer Procedure A.26, after executing A.26, return to Phase-2 (Change the Mode from COMPACT mode to eXtreme mode for one Non-PROV site) otherwise continue with the following steps if the setup consists of StandAlonePDB + Non-PROVS.

- 1. First all non-PROVs should be upgraded to EPAP 16.4 in COMPACT mode. Refer to section 0 for the upgrade process.
- 2. Next the Standalone PDBs will be upgraded to EPAP 16.4 in COMPACT mode. Refer to section 0 for the upgrade process.

After this phase all EPAPs in the customer network are in EPAP 16.4 and are working in COMPACT mode.

#### Phase 2: Change the Mode from COMPACT mode to eXtreme mode for one Non-PROV site:

Execute the procedure in the following sequence.

- 1. Choose one EPAP-Eagle site from the customer network, which will be converted to eXtreme mode.
- 2. On the EAGLE, replace all non-SLIC SCCP cards to SLIC 64-bit SCCP cards. Change stpopts: EPAPX ON.
- 3. On the connecting Non-Prov, change the mode from COMPACT to eXtreme. Refer section 0 to change DB Architecture to eXtreme. The StandalonePDB should remain in COMPACT mode at this stage.
- 4. Restore RTDB on Non-Prov EPAP-A (refer to Procedure A.10) and after successfully restored RTDB on EPAP-A(refer to Procedure A.11), perform reload from mate on Non-Prov EPAP-B. Reload the Eagle from EPAP. Check that the DB downloads and EPAP-Eagle network work normally. Live provisioning flows all the way to Eagle. Let the node soak for some \*time-period.

#### Phase 3: Change the Mode from COMPACT mode to eXtreme mode for whole network:

At this stage, we have seen that EPAP and Eagle are working fine in eXtreme mode. All the remaining Non-PROVs and StandAlone PDBs will be converted to eXtreme mode now. All the remaining Non-PROVs will be converted to eXtreme mode first. After all Non-PROVs are converted to eXtreme, the StandalonePDBs will be converted to eXtreme. For every site, before converting the EPAPs, connected eagles will have EPAPx feature ON.

- 1. First on the EAGLE, replace all non-SLIC SCCP cards to SLIC 64-bit SCCP cards. Change stpopts:EPAPX ON.
- On the connected Non-Prov, change the mode from Compact to eXtreme. Refer section 0Change DB Architecture from COMPACT to eXtreme to support EAGLE release 46.7.0.0.0(eXtreme feature) to change DB Architecture to eXtreme.
- 3. Reload the RTDB from already converted eXtreme mode RTDB in **phase 1**. Refer Procedure A.11.
- 4. Reload the Eagle SM cards from the EPAP.
- 5. Repeat steps 1 to 4 for all remaining Non-PROVs in the Customers network
- 6. Convert the StandalonePDBs to eXtreme mode.

# Change DB Architecture from COMPACT to eXtreme to support EAGLE release 46.7.0.0.0(eXtreme feature)

The following table illustrates the progression of the movement of DB Architecture from COMPACT to eXtreme by procedure with estimated times and may vary due to differences in typing ability and system configuration. The procedures outlined in below **Table 15 Phases to change DB Architecture to eXtreme (Standalone PDB)** are to be executed in the order they are listed.

Before proceeding with the change DB Architecture process, refer to section 4 and section 5 to get the overview of the DB Architecture and upgrade order.

Notes: 1. Skip this section for mixed EPAP as eXtreme feature not supported on mixed EPAP. 2. DB Architecture cannot be reverted to COMPACT once moved to eXtreme architecture.

# 4.1.1 Phases to change DB Architecture to eXtreme (Standalone PDB)

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Cum. Step			
Check database before changing DB architecture to eXtreme.	40	40	Check 9dig counts for all DN/IMSI and IMEI before changing DB architecture to eXtreme.	Procedure 17
Change DB Architecture to eXtreme	40	80	Note: Skip this procedure on Mixed EPAP. Change DB Architecture from COMPACT to eXtreme. Note: If parsing gets failed at this stage then user needs to run it manually. Check Procedure A.4 to execute it manually.	Procedure 13
Accept the upgrade after successful soak period	5	This is done in a separate MTC	Accept the upgrade after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 21

 Table 15 Phases to change DB Architecture to eXtreme (Standalone PDB)

## 4.1.2 Phases to change DB architecture to eXtreme (First Non-Prov site)

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Check database before changing DB architecture to eXtreme.	*see notes below	*see notes below	NOTE: Execute this step on attached PDBonly EPAP if not already exececuted.	Procedure 17
			Check 9dig counts for all DN/IMSI and IMEI before changing DB architecture to eXtreme.	
Take backup before moving to eXtreme architecture	**See notes below	**See notes below	Take RTDB backup if not already taken, before moving to eXtreme architecture. <b>Note: Skip this step for PDBonly.</b>	Procedure A.7
Change DB Architecture to eXtreme	5	5	Change DB Architecture from COMPACT to eXtreme <b>Note:</b> EPAPX feature must be "ON" on the connected eagle before procedure 13	Procedure 13
Restore RTDB backup on Non-prov.	240	245	Restore RTDB backup on Non-prov MPS A.	Procedure A.10
Reload RTDB from mate	10	255	Reload RTDB from mate on Non-prov MPS B.	Procedure A.11
Accept the upgrade after successful soak period	5	This is done in a separate MTC	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 22

#### Table 16 Phases to change DB Architecture to eXtreme (First Non-prov site)

**\*NOTE:** The time for checking database will be added for attached PDBonly EPAP(Added in section 4.2.1).

**\*\*NOTE:** The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

## 4.1.3 Phases to change DB architecture to eXtreme (Remaining Non-Prov sites)

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Take backup before moving to eXtreme architecture	*See notes below	*See notes below	Take RTDB backup if not already taken, before moving to eXtreme architecture. <b>Note: Skip this step for PDBonly.</b>	Procedure A.7

Phase	Elapsed Time (Minutes)		Activity	Procedure
	This Step	Cum.		
Change DB Architecture to eXtreme	5	5	Change DB Architecture from COMPACT to eXtreme <b>Note:</b> EPAPX feature must be "ON" on the connected eagle before procedure 13	Procedure 13
Reload RTDB from remote	10	15	Reload the RTDB from remote(already in eXtreme mode) <b>Note: Remote Non-Prov EPAP must</b> <b>be in eXtreme mode.</b> (Which may be the first Non-Prov site converted in table 15 or any other remote EPAP which is already in eXtreme mode)	Procedure A.11
Reload RTDB from mate	10	25	Reload RTDB from mate on Non-prov MPS B.	Procedure A.11
Accept the upgrade after successful soak period	5	This is done in a separate MTC	Accept the upgrade on both MPS-A and MPS-B after sufficient soak period of around 1-7 days (depending upon customer provisioning volume) to see that everything works fine after the upgrade.	Procedure 21

#### Table 17 Phases to change DB Architecture to eXtreme (Remaining Non-Prov sites)

**\*NOTE:** The time needed to backup application data is dependent on the amount of application data. This procedure cannot specify an exact length of time since different customers have different amounts of application data.

## 5 UPGRADE PREPARATION

#### Procedure 1 Setting up the upgrade environment

#### **Procedure 1: Setting up the upgrade environment**

S	This procedure sets up the upgrade environment. Windows are opened for both MPS servers.							
T E P	NOTE: Call My Oracle Support for assistance if modem access is the method use for upgrade.							
#	Check off ( $$ ) each step as	s it is completed. Boxes have been provided for this purpose under each step number.						
	IF THIS PROCEDURE FA	HIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.						
1.	Ensure MPS X: All the console/PuTTY	On all the console/PuTTY sessions, make sure that the logging in enabled and logs are written to a file. For example, on a PuTTY session, do the following.						
	Sessions.	<b>1.</b> Right click on the top bar in the PuTTY and choose "change setting".						
		2. Click on "Logging".						
		3. Select "Printable output".						
		4. Click on "Browse" and choose where you want the logs to be written so that you can collect those later, if needed. Put a name which will serve better on a later date to understand, for example, name of the log file can be <server name="">_active_pdba_A_server_puttylog_ddmmyyyy.</server>						
		5. Click on "Save".						
		6. Type a text "Putty Logging starts" in the PuTTY session and check that above text is logged in the PuTTY log file.						
		Repeat the above six steps on every console/PuTTY session that will be used to enter commands or execute procedure of this document.						
2.	Establish a connection to MPS A.	If access to the MPS servers is not available through an IP network, connect to the E5- APP-B card via the serial port.						
		For connecting the E5-APP-B A card, disconnect the console cable from the serial port on the E5-APP-B B card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B B card's adapter and use it for serial access. <b>Cable part numbers - 830-1220-xx</b>						
3.	On the workstation, open one terminal window in preparation for establishing remote connections to the MPS servers.	Create a terminal window						
4.	Create a terminal window for MPS A.	Create a terminal window and give it a title of "MPS A"						
5.	<b>MPS A</b> : Enable capture file and verify the correspondent file is created.	Enable the data capture and verify that the data capture file is created at the path specified.						
6.	Log into MPS A.	<hostname> console login: admusr password: <password></password></hostname>						
7.	MPS A: Start screen Session.	Execute the following command to start screen and establish a console session with MPS A. <b>\$ screen -L</b>						

#### Procedure 1: Setting up the upgrade environment

		If for Standalone PDB, the procedure is complete. Otherwise, continue with the next step.			
8.	Establish a connection to MPS B.	If access to the MPS servers is not available through an IP network, connect to the E5 APP-B card via the serial port.			
		For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A card's adapter and use it for serial access. <b>Cable part numbers - 830-1220-xx</b>			
9.	Create a terminal window for MPS B.	Create a terminal window and give it a title of "MPS B"			
10.	<b>MPS B</b> : Enable capture file and verify a correspondent file is created.	Enable the data capture and verify that the data capture file is created at the path specified.			
11.	Log into MPS B.	<hostname> console login: admusr password: <password></password></hostname>			
12.	<b>MPS B</b> : Start screen Session.	Execute the following command to start screen and establish a console session with MPS B. \$ screen -L			
13.	MPS A and B: Procedure Complete.	This procedure is complete.			
14.	Note down the timestamp in log.	Run the following command: \$ date			

# Procedure 2 Determine if upgrade or installation is required

#### Procedure 2: Determine if upgrade or installation is required

S T E P #	This procedure executes the steps required to determine if an upgrade of the system is required or an initial application installation is required. Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND <b>ASK FOR UPGRADE</b> <u>ASSISTANCE</u> .		
1.	<b>MPS A</b> : Log in to MPS A.	If not already logged-in, login at MPS A as 'admusr'. <hostname> console login: admusr password: <password></password></hostname>	
2.	<b>MPS B</b> : Log in to MPS B.	If not already logged-in, login at MPS B as 'admusr'. <hostname> console login: admusr password: <password></password></hostname>	
3.	<b>MPS B:</b> Determine if the application is currently installed on the servers.	Execute an rpm query command and examine the output: <b>\$ rpm -qi TKLCepap</b>	

Procedure 2: Determine if upgrade or installation is requ	ired
---	------

	(MPS B will be used to determine the current state of the servers. We will assume that the state of the A server is the same).	Name: TKLCepapRelocations: (not relocatable)Version: 163.0.8Vendor: TekelecRelease: 16.3.0.0_163.8.0Build Date: Wed 27 Jun 2018 11:19:33 AM EDTInstall Date: Tue 03 Jul 2018 03:41:55 AM EDTBuild Host: coach-11.tekelec.comGroup: Development/BuildSource RPM: TKLCepap-163.0.8-16.3.0.0_163.8.0.src.rpmSize: 162888034Size: 162888034License: © TEKELEC 2005-2018Signature: (none)Packager: <@ tekelec.com>URL: http://www.tekelec.com/Summary: Oracle Communications EPAP PackageDescription:This is the Oracle Communications EAGLE Application Processor(EPAP) Package.The Package installs EPAP software. EPAP provides Provisioning Database Application(PDBA on A side) and Real Time Database (RTDB).
4.	<b>MPS B:</b> Observe the output from the rpm query.	The following is an example of what the output may look like: \$ appRev
		Install Time: Tue Jul 3 03:52:57 2018 Product Name: EPAP Product Release: 16.3.0.0.0_163.8.0 Base Distro Product: TPD Base Distro Release: 7.6.0.0.0_88.48.0 Base Distro ISO: TPD.install-7.6.0.0.0_88.48.0-OracleLinux6.9-x86_64.iso ISO name: EPAP-16.3.0.0.0_163.8.0-x86_64.iso OS: OracleLinux 6.9 If the output similar-to the above example is displayed, then skip to step 6. Otherwise,
5.	<b>MPS B:</b> Installation is required if the application is not present on the server, else upgrade is required.	proceed to the next step. If the application is not currently installed, output similar-to the example below will be returned from the <b>rpm -qi</b> command in step-3. If this is the case, then an application <b>installation</b> is required. Refer to section 0 to perform EPAP installation.
		<pre>\$ rpm -qi TKLCepap package TKLCepap is not installed Skip to step 10.</pre>
6.	<b>MPS B:</b> Determine which version of the application is present.	Write Down the Release Number: Release Number: If the release number on the MPS is less than the release number on the upgrade media, then an upgrade is required.
7.	Determine if a Split Mirror Upgrade is required.	If the current release is 16.2.x/16.3.x and target release is 16.4.y, it is a <b>SPLIT MIRROR</b> UPGRADE.
8.	Determine if an incremental Upgrade is required.	If the current release is 16.4.x.x and target release is 16.4.y.y (x.x is less than the number y.y on the upgrade media), it is an <b>INCREMENTAL</b> Upgrade.
9.	<b>MPS A:</b> Determine if it is Provisionable (either mixed-EPAP or	Execute the following command to determine if the EPAP is Provisionable(either mixed- EPAP or PDBonly) or Non-Provisionable.

#### Procedure 2: Determine if upgrade or installation is required

	PDBonly) or Non- Provisionable EPAP setup.	<pre>\$ uiEdit   grep "PROVISIONABLE" "PROVISIONABLE_MPS" is set to "YES" If the above output contains "YES", then the EPAP is Provisionable(either mixed-EPAP or PDBonly). Otherwise, the EPAP is Non-Provisionable. Write down this information. EPAP setup type:</pre>
10.	MPS B: Determine if the current DB Architecture is compact or extreme. (MPS B will be used to determine the current state of the servers. We will assume that the state of the A server is the same).	Execute the following command to determine if the EPAP DB Architecture is Extreme or Compact. \$ uiEdit   grep "DB_ARCHITECTURE" "DB_ARCHITECTURE" is set to "COMPACT" If the above output contains "COMPACT" or no output is displayed, then the EPAP DB Architecture is Compact. If the above output contains "EXTREME", then the EPAP DB Architecture is Compact. Write down this information. EPAP DB Architecture type: Based on this information DB converter will be run.
11.	MPS A and B: Procedure Complete.	This procedure is complete.
12.	Note down the timestamp in log.	Run the following command: \$ date

## **Procedure 3 Pre-upgrade requirements**

#### Procedure 3: Verifying Pre-Upgrade Requirements and Capturing Upgrade Data

S	This procedure verifies that all pre-upgrade requirements have been met.			
Т				
Ε	Check off ( $$ ) each step as it	is completed. Boxes have been provided for this purpose under each step number.		
Р				
#	IF THIS PROCEDURE FAIL	.S, CONTACT MY ORACLE SUPPORTAND ASK FOR <u>UPGRADE ASSISTANCE</u> .		
1.	Verify all required materials	Verify that the materials listed in Upgrade Material List (Section 0) are present.		
	are present.			
2.	Verify the availability of	Refer to Table 5 for the list of users.		
	passwords for MPS systems.			
3.	Review provisioning rules.	Please review the Provisioning information as defined in Section 0. If you do not		
		understand the information provided in this section, contact My Oracle Support following		
		the instructions on the front page or the instructions on the Appendix F.		
4.	Verify and close active GUI Skip this step for fresh install.			
	Sessions.			
	Login to EPAP GUI as uiadmin user. Terminate all the active GUI sessions from EPAP			
	On the menu, click User GUI			
	Administration->HTTP(s)			
	Support->Terminate UI			
	Sessions			

		A						Terminate Active UI Sessions
		Delete?	Session Id	User Id	User Name	Admin	IP Addr	Last Access
		0	44	99	uiadmin	YES	10.250.32.216	2017-06-20 07:04:11
		0	45	99	uiadmin	YES	10.250.32.216	2017-06-20 07:04:20
		0	46	99	uiadmin	YES	10.250.32.216	2017-06-20 07:04:33
		sessions.	sessions ar		"Delete Se	lected Acti	ive Session" to	delete all active
5. □	Procedure Complete.	This proce	edure is co	mplete.				
6.	Note down the timestamp in	Run the following command:						
	log.	\$ date						

# Procedure 4 System Health check

#### **Procedure 4: System Health Check**

S	This procedure determines the health of the MPS System before beginning an upgrade.			
Т				
Ε	Check off ( $$ ) each step	as it is completed. Boxes have been provided for this purpose under each step number.		
Р	() 11	r r r r r r r r r r r r r r r r r r r		
	IE THIS DROCEDURE	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.		
#	IF THIS FROCEDURE	FAILS, CONTACT MIT ORACLE SUFFORT AND ASK FOR UPGRADE ASSISTANCE.		
1.	MPS A: Verify health	Execute Procedure A.1 on MPS A to verify the health of MPS A.		
	of MPS A.	Execute Freedule A.T on WEST to verify the neutral of WEST.		
	OI MPS A.			
2.	<b>MPS B</b> : Verify health	Execute Procedure A.1 on MPS B to verify the health of MPS B.		
	of MPS B.			
	or wir 5 D.			
3.	Procedure Complete.	This procedure is complete.		
		This procedure is complete.		
4.	Note down the Run the following command:			
	timestamp in log.			
	\$ date			

## 5. SOFTWARE INSTALLATION PROCEDURES

Pre install configuration and initial installation of EPAP can be done on any of the server in the mated pair in any order. These operations can be done simultaneously on both the servers.

## Procedure 5 Pre-Install configuration on server A

S	This procedure provides instructions to perform pre-configuration for an initial install of the
Т	application.
E	
P	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.
#	
	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.

**IMPORTANT:** Installation of the Operating System on an Oracle Application Server should be completed before starting installation procedure. Refer to Procedure A.13 or [4] for TPD installation guide.

1.	Connect to the Server.	If not already connected, connect to the E5-APP-B card via the serial port.
2.	Log in as "admusr"	For connecting the E5-APP-B A card, disconnect the console cable from the serial port on the E5-APP-B B card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B B card's adapter and use it for serial access. <b>Cable part numbers - 830-1220-xx</b> If not already logged in, then login as "admusr":
	user.	[hostname] consolelogin: admusr password: <i>password</i>
3.	Start platcfg utility.	\$ sudo su - platcfg
4.	Navigate to the <b>Server</b> <b>Configuration</b> screen.	Select Server Configuration and press [ENTER] ++ Main Menu ++   Maintenance ^     Diagnostics :     Berver Configuration #     Security :     Remote Consoles :     Network Configuration :     Exit v     ++
5.	Navigate to the <b>Hostname</b> screen.	Select Hostname and press [ENTER] ++ Server Configuration Menu ++       Bostname ^     Designation/Function #     Configure Storage :     Set Clock :     Time Zone :     Exit v   

#### Select Edit to edit the 6. Select Edit and press [ENTER] hostname. Options Exit dit. 7. Enter the hostname Delete the default entry and enter the Hostname as mps-xxxx-a where xxxx is the last 4 and press ok. digits of server serial number. Press OK when done. + Edit Hostname Hostname: OSORNA-A OK Cancel While connected to the serial console, some console output might come when the user is using the serial console to configure the EPAP. Those serial output are harmless and can be ignored. 8. Exit Back to the Server Select EXIT to exit back to the Server Configuration Menu. Verify that the hostname has Configuration Menu. been properly set. 2016, Oracle and/or its affiliates. opyright (C) 2003, Al Hostname: OSORNA-A Hostname Configuration Edit E<mark>xit |</mark> Current Hostname: OSORNA-A 9. Navigate to the Select **Designation/Function** and press [ENTER] **Designation/Function** Server Configuration Menu menu option. Hostname Designation/Function Configure Storage ŧ Set Clock Time Zone Exit

10.	View the current designation and function.	The screen will show the current designation and function setting. On initial install, these fields are blank. Copyright (C) 2003, 2016, Oracle and/or its affiliates. Al++ Options ++ Hostname: OSORNA-A
		<ul> <li>If not blank, the values should be as follows for Mixed EPAP and Non-Provisional EPAP: <ol> <li>The Designation is "1A" for the A server</li> <li>The Function field should be set to EPAP.</li> </ol> </li> <li>If not blank, the values should be as follows for Standalone PDB. <ol> <li>The Designation is "1A" for the A server</li> <li>The Designation is "1A" for the A server</li> </ol> </li> <li>If both the fields are blank or either value is not correct, then select Edit and press [ENTER].</li> <li>If both values are correct, select Exit, press [ENTER] and skip the next step.</li> </ul>
	View the current designation and function.	Skip to Step 13 if Exit was selected in the previous step, otherwise if Edit was selected, delete the current designation and function if already set, and type in the desired values. Enter the appriopriate designation in the Designation field (Note: the designation must be capitalized).         Select OK and press [ENTER].         For Mixed EPAP or Non-Provisional EPAP, the following is a correct example: <ul> <li></li></ul>

		++ Edit Designation ++       Designation: _A     Function: PDBonly     ++ ++       OK     Cancel       ++ ++                     ++ ++
12.	Verify that the Designation and Function information is correct then select and press "Exit".	For Mixed EPAP or Non-Provisional EPAP, the following is a correct example:         Copyright (C) 2003, 2016, Oracle and/or its affiliates. Al++ Options ++         Hostname: OSORNA-A                 Designation Information         ++         Designation: 1A                 Function: EPAP                 Copyright (C) 2003, 2016, Oracle and/or its affiliates. Al++                 Image: Osorna-A                 Image: Osorna-B                 Image: Osorna-A                 Image: Osorna-A
13.	Select "Set Clock" Menu.	++ Server Configuration Menu ++       Hostname ^     Designation/Function :     Configure Storage :     Set Clock #     Time Zone :     Exit v     ++
14.	<ol> <li>Select "Edit" from the options dialogue box.</li> <li>Using an NTP source, set the Date/Time to be correct for the Eastern Time zone (GMT -5) and press "OK".</li> <li>NOTE: All systems default to Eastern time</li> </ol>	++ Options ++         ++ ++       Edit     Exit       ++         ++

15.	post IPM. It is important to set the time for the Eastern Time zone at this time. Verify that the Date and Time is correct then select and press "Exit".	<pre>++ Change Date and Time ++  </pre>
16.	Exit from platcfg menu.	Select <b>EXIT</b> until the platcfg menu is closed and the command line is displayed.
17.	Reboot the Server.	\$ sudo reboot
18.	Procedure complete.	Procedure is complete.
10	Note down the	Due the fellowing common h
19.	Note down the timestamp in log.	Run the following command:
		\$ date

# Procedure 6 Pre-Install configuration on server B

S T E	This procedure prov application.	vides instructions to perform pre configuration for an initial install of the
Р #	Check off ( $\checkmark$ ) each step	o as it is completed. Boxes have been provided for this purpose under each step number.
	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.
		n of the Operating System on an Oracle Application Server should be completed n procedure. Refer to Procedure A.13 or [4] for TPD installation.
1.	Connect to the Server.	If not already connected, connect to the E5-APP-B card via the serial port.
		For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A cards' adapter and use it for serial access. <b>Cable part numbers - 830-1220-xx</b>
2.	Log in as "admusr" user.	If not already logged in, then login as 'admusr': [hostname] consolelogin: admusr password: password
3.	Start platcfg utility.	\$ sudo su – platcfg
4.	Navigate to the <b>Server</b> <b>Configuration</b> screen.	Select Server Configuration and press [ENTER] ++ Main Menu ++   Maintenance ^     Diagnostics :     Server Configuration #     Security :     Remote Consoles :     Network Configuration :     Exit v     ++
5. <b>6</b> .	Navigate to the <b>Hostname</b> screen. Select <b>Edit</b> to edit the	Select Hostname and press [ENTER]  ++ Server Configuration Menu ++          dostname
	hostname.	

		++ Options ++           ++ ++       Edit     Exit       ++ ++           ++
7.	Enter the hostname and press ok.	Delete the default entry and enter the Hostname as mps-xxxx-b where xxxx is the last 4 digits of server serial number. Press OK when done.         Image: Osorna-B       Image: Osorna-B         Image: Osorna-B       Image: Osorna-B
8.	Exit Back to the Server Configuration Menu.	Select EXIT to exit back to the Server Configuration Menu. Verify that the hostname has been properly set. Copyright (C) 2003, 2016, Oracle and/or its affiliates. Al++ Options ++ Hostname Configuration   ++       Edit     =xit       ++ ++         Edit     =xit       Current Hostname: OSORNA-B ++
9.	Navigate to the <b>Designation/Function</b> menu option.	Select Designation/Function and press [ENTER]         ++ Server Configuration Menu ++                                   Hostname       ^                 Hostname       ^                 Besignation/Function :                         Configure Storage       #                 Set Clock       :                 Time Zone       :                 Exit       v
10.	View the current designation and function.	The screen will show the current designation and function setting. On initial install, these fields are blank.

		Copyright (C) 2003, 2016, Oracle and/or its affiliates. Alt+ Options t++         Hostname: OSORNA-B         Designation Information         I   edit   Exit           I   edit   Exit           I ++ +         Designation: 1B         Function: EPAP         If not blank the values should be as follows for Mixed EPAP and Non-Provisional         EPAP:         1.       The Designation is "1B" for the B server         2.       The Function field should be set to EPAP.
		If either value is not correct, then select <b>Edit</b> and press [ENTER]. If both values are correct, select <b>Exit</b> , press [ENTER] and skip the next step.
	View the current designation and function.	Skip to Step 13 if Exit was selected in the previous step, otherwise if Edit was selected, delete the current designation and function if already set, and type in the desired values. Enter the appriopriate designation in the Designation field (Note: The designation must be capitalized). Select <b>OK</b> and press [ENTER].
12.	Verify that the Designation and Function information is correct then select and press "Exit".	Copyright (C) 2003, 2016, Oracle and/or its affiliates. Al++ Options ++ Hostname: OSORNA-B       Designation Information   ++     Edit     Exit     Designation: 1B     Function: EPAP
13.	Select "Set Clock" Menu.	<pre>++ Server Configuration Menu ++       Hostname ^     Designation/Function :     Configure Storage :     Set Clock #     Time Zone :     Exit v     ++</pre>

	<ol> <li>Select "Edit" from the options dialogue box.</li> <li>Using an NTP source, set the Date/Time to be correct for the Eastern Time zone (GMT -5) and press "OK".</li> <li>NOTE: All systems default to Eastern time post IPM. It is important to set the time for the Eastern Time zone at this time.</li> </ol>	<pre>++ Options ++     ++ +++       Edit   Exit     ++ +++           ++ +++                                      </pre>
15.	Verify that the Date and Time is correct then select and press "Exit".	Time Configuration Current Date: 01/02/2017 Current Time: 20:01:12 ++ Options ++   ++       Edit     xit       ++       Edit     xit       ++   
16.	Exit from platcfg menu.	Select <b>EXIT</b> until the platcfg menu is closed and the command line is displayed.
17.	Reboot the Server.	\$ sudo reboot
18.	Procedure complete.	Procedure is complete.
19.	Note down the timestamp in log.	Run the following command:
	unicountp in log.	\$ date

S T	This procedure installs	s the application on the server.
Ε	Check off ( $\checkmark$ ) each step	o as it is completed. Boxes have been provided for this purpose under each step number.
P #	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.
1.	MPS A: Install EPAP	Perform Procedure in Procedure A.12 or copy EPAP 16.4 ISO to /var/TKLC/upgrade
	on 1A.	directory.
2.	Create a terminal window and log into	If not already connected, connect to the E5-APP-B card via the serial Port.
ш	MPS A.	For connecting the E5-APP-B A card, disconnect the console cable from the serial port on
		the E5-APP-B B card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B B card's adapter and use it for
		serial access. Cable part numbers - 830-1220-xx
3.	MPS A: Login prompt	<hostname> console login:</hostname>
	is displayed.	Note: Hit enter if no login prompt is displayed.
4.	MPS A: log in as	[hostname] consolelogin: admusr
	"admusr" user.	password: password
5.	MPS A: Start platcfg	
	utility.	\$ sudo su - platcfg
6.	<b>MPS A:</b> Navigate to the Upgrade menu.	The platcfg Main Menu appears. On the Main Menu, select Maintenance and press [ENTER].
ш	the opplate montal	
		Main Menu
		Maintenance
		Diagnostics
		Server Configuration Security
		Network Configuration
		Remote Consoles
		Exit
		Select the Upgrade menu and press [ENTER].
		Maintenance Menu
		Upgrade
		Patching
		Backup and Restore Halt Server
		Restart Server
		Eject CDROM Save Platform Debug Logs
		Platform Data Collector
		Exit

7.	<b>MPS X:</b> Validate ISO file.	Validate ISO file using <b>Procedure A.2</b> .
8.	MPS A: Select Early Upgrade Checks	Select the "Early Upgrade Checks" menu to verify that the system is ready for upgrade.          Upgrade Menu         Validate Media         Early Upgrade Checks         Initiate Upgrade         Copy USB Upgrade Image         Non Tekelec RPM Management         Exit
		If the Early Upgrade Checks fail due to the ongoing syncing of raid mirrors, then wait until the resync is completed and run the "Early Upgrade Checks" again. Early Checks failed for the next upgrade Look at earlyChecks.log for more info tarting Early Upgrade Checks at 1011413059 Running earlyUpgradeChecks() for Upgrade::EarlyPolicy::TPDEarlyChecks upgrade policy Verified server is not pending accept of previous upgrade ERROR: Raid mirrors are syncing! ERROR: railed running earlyUpgradeChecks() code failed for Upgrade::EarlyPolicy::TPDEarlyChecks ERROR: Failed running earlyUpgradeChecks() code Hardware architectures match Install products match. No Application installed yet Skip alarm check! ERROR: Early Upgrade Checks Failed! User has requested just to run early checks. No upgrade will be performed Early Upgrade Checks failed i 1011413059 [admusr&epappri ~]% cat /proc/mdstat Personalities : [raid] md1 : active raid1 sdb2[1] sda2[0] 262008 blocks super 1.0 [2/2] [UU] [======
9.	<b>MPS A:</b> Navigate to the Initiate Upgrade menu	Select the Initiate Upgrade menu and press [ENTER].

		Upgrade Menu Validate Media Early Upgrade Checks Initiate Upgrade Copy USB Upgrade Image Non Tekelec RPM Management Exit
	<b>MPS A:</b> Select the Upgrade Media.	The screen displays a message that it is searching for upgrade media. When the upgrade media is found, an Upgrade Media selection menu appears similar-to the example below. Select the desired upgrade media and press [ENTER]. lqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqq
	<b>MPS A:</b> Upgrade proceeds.	The screen displays the output like following, indicating that the upgrade software is first running the upgrade checks, and then proceeding with the upgrade. No Application installed yet Skip alarm check! Verified all raid mirrors are synced. Early Upgrade Checks Have Passed! Early Upgrade Checks finished at 1447429031 Initializing upgrade information
12.	<b>MPS A:</b> Upgrade proceeds.	Many informational messages appear on the terminal screen as the upgrade proceeds. The messages are not shown here for clarity sake. When installation is complete, the server reboots.
13.	MPS A: Upgrade completed.	After the final reboot, the screen displays the login prompt as in the example below. Starting atd: [ OK ] ~~ /etc/rc4.d/S98ExQueue start ~~ ExQueue started. Starting TKLCe5appb: [ OK ] Checking network config files: [ OK ] Daemon is not running AlarmMgr daemon is not running, delaying by 1 minute ~~ /etc/rc4.d/S99Epap start ~~ EPAP configuration data not found. Exiting ~~ /etc/rc4.d/S99Pdba start ~~ EPAP configuration data not found. Exiting Starting smartd: [ OK ] Daemon is not running, delaying by 1 minute TPDhpDiskStatus stop/pre-start, process 5527 TKLChwmgmtcli stop/pre-start, process 5508 Oracle Linux Server release 6.9 Kernel 2.6.32-642.6.2.el6prerel7.4.0.0.0_88.32.0.x86_64 on an x86_64
		Kerner 2.0.52-0+2.0.2.eloprerer/.+.0.0.0_00.52.0.X00_04 0II all X00_04

14.	<b>MPS A:</b> log in as "epapdev" user.	[hostname] consolelogin: epapdev password: <i>password</i>
15.	MPS A: Check the Upgrade log.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors and warnings were reported.
		<pre>\$ grep -i error /var/TKLC/log/upgrade/upgrade.log</pre>
		Check the output of the upgrade log, Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any errors beside the following:
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MyI'
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
		1487820277::2017-02-23T03:24:40.278652Z 0 [Warning] 'NO_ZERO_DATE', 'NO_ZERO_IN_DATE' and 'ERROR_FOR_DIVISION_BY_ZERO' sql modes should be used with strict mode. They will be merged with strict mode in a future release.
		Following statement for missing binary file shall be observed in upgrade.log: 1530885808::/bin/df: `/mnt/ugchroot/sys': No such file or directory
		All those messages are expected, and therefore aren't considered errors.
		Also note that sometime a carriage return is inserted in the log file causing some of the error messages to appear truncated, for example in "1252687151::myisamchk: error: File " case, "1252687169::myisa" might show up on one line while the rest "mchk: error: File '/" might
		show up on the next line. This is acceptable and should be ignored.
		<pre>\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log</pre>
		Examine the output of the above command to determine if any warnings were reported. Contact My Oracle Support following the instructions on the front page or the instructions
		on the Appendix F, if the output contains any warnings beside the following: [1487820277::2017-02-23T03:24:40.2786522 0 [Warning] 'NO_ZERO_DATE', 'NO_ZERO_IN_DATE' and 'ERROR_FOR_DIVISION_BY_ZERO' sql modes should be used with strict mode. They will be merged with strict mode in a future release. [root@hvar-A ~]# grep -i warning /var/TKLC/log/upgrade/upgrade.log 1487820160::WARNING: /usr/TKLC/plat/etc/alarms/alarms.xml has been
		updatedreparsing xml 1487820270::* write: WARNING:: Could not find configured path "/var/TKLC/epap/rt".
		1487820270::* write: WARNING:: Could not find configured path "/var/TKLC/epap/db". 1487820270::* write: WARNING:: Could not find configured path
		"/var/TKLC/epap/logs". 1487820270::* write: WARNING:: Could not find configured path
		"/var/TKLC/epap/free". 1487820270::* write: WARNING:: Could not find configured path "/var/TKLC/epap/rt".
		"/var/IKLC/epap/rt". 1487820270::* write: WARNING:: Could not find configured path "/var/TKLC/epap/db".
		/var/IKLC/epap/ab . 1487820270::* write: WARNING:: Could not find configured path "/var/TKLC/epap/logs".
		1487820270::* write: WARNING:: Could not find configured path "/var/TKLC/epap/free".
		1487820272::useradd: warning: the home directory already exists.

1		
		<pre>1487820277::2017-02-23T03:24:40.2786522 0 [Warning] 'NO_ZERO_DATE', 'No_ZERO_IN_DATE' and 'EROR_FOR_DIVISION_BY_ZERO' sql modes should be used with strict mode. They will be merged with strict mode in a future release. 1487820280::2017-02-23T03:24:40.2786942 0 [Warning] 'NO_AUTO_CREATE_USER' sql mode was not set. 1487820709::2017-02-23T03:31:55.0222272 0 [Warning] InnoDB: New log files created, LSN=45792 1487820715::2017-02-23T03:31:55.18777Z 0 [Warning] InnoDB: Creating foreign key constraint system tables. 1487820715::2017-02-23T03:31:55.18777Z 0 [Warning] No existing UUID has been found, so we assume that this is the first time that this server has been started. Generating a new UUID: 9fafedc2-f978-11e6-a8a8-0010e0850417. 1487820715::2017-02-23T03:31:55.180473Z 0 [Warning] Gtid table is not ready to be used. Table 'mysql.gtid_executed' cannot be opened. 1487820715::2017-02-23T03:31:56.2331572 0 [Warning] cot@localhost is created with an empty password ! Please consider switching off theinitialize-insecure option. 1487820716::2017-02-23T03:31:56.7027692 1 [Warning] TIMESTAMP with implicit DEFAULT value is deprecated. Please useexplicit_defaults_for_timestamp server option (see documentation for more details). 1487820723::2017-02-23T03:32:04.035042 0 [Warning] InnoDB: New log files created, LSN=45790 1487820724::2017-02-23T03:32:04.116918Z 0 [Warning] InnoDB: Creating foreign key constraint system tables. 1487820724::2017-02-23T03:32:04.1780962 0 [Warning] No existing UUID has been found, so we assume that this is the first time that this server has been started. Generating a new UUID: a50be8F-f978-11e6-bcbc-0100e085047. 1487820724::2017-02-23T03:32:04.1780952 0 [Warning] CA certificate ca.pem is self signed. 1487820724::2017-02-23T03:32:04.1780952 0 [Warning] CA certificate ca.pem is self signed. 1487820724::2017-02-23T03:32:05.9575832 0 [Warning] CA certificate ca.pem is self signed. 1487820724::2017-02-23T03:32:06.1650592 1 [Warning] CA certificate ca.pem is self</pre>
16.	<b>MPS A:</b> Check that the upgrade completed successfully.	Refer to section 0 to know more about logging. \$ grep "Upgrade returned success" /var/TKLC/log/upgrade/upgrade.log
17.	MPS A: Check that the upgrade completed successfully.	Verify that the message "Upgrade returned success!" is displayed. If it is not, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F.
		1399367207:: Upgrade returned success!
18.	MPS B:	
18.	MPS B: Update ssh_config to disable MD5 and MAC algorithm for security	1399367207:: Upgrade returned success!
	Update ssh_config to disable MD5 and MAC algorithm for	<pre>1399367207:: Upgrade returned success! Perform following steps to disable unsecure algorithm for ssh: 1. \$ grep "MACs hmac-md5,hmac-md5-96," /etc/ssh/ssh_config If output contains "MACs hmac-md5,hmac-md5-96", execute the below steps 2 and 3. Else go to step 4.</pre>
	Update ssh_config to disable MD5 and MAC algorithm for	<pre>1399367207:: Upgrade returned success! Perform following steps to disable unsecure algorithm for ssh: 1. \$ grep "MACs hmac-md5,hmac-md5-96," /etc/ssh/ssh_config If output contains "MACs hmac-md5,hmac-md5-96", execute the below steps 2 and 3. Else go to step 4. 2. \$ sudo rcstool co /etc/ssh/ssh_config 3. \$ sudo sed -i -e '/MACs hmac-md5,hmac-md5-96,hmac-sha1-96/d'</pre>
	Update ssh_config to disable MD5 and MAC algorithm for	<pre>1399367207:: Upgrade returned success! Perform following steps to disable unsecure algorithm for ssh: 1. \$ grep "MACs hmac-md5,hmac-md5-96," /etc/ssh/ssh_config If output contains "MACs hmac-md5,hmac-md5-96", execute the below steps 2 and 3. Else go to step 4. 2. \$ sudo rcstool co /etc/ssh/ssh_config 3. \$ sudo sed -i -e '/MACs hmac-md5,hmac-md5-96,hmac-sha1-96/d' /etc/ssh/ssh_config</pre>

		6. \$ sudo sed -i '\$ a \\tMACs hmac-sha2-256,hmac-sha2-512' /etc/ssh/sshd_config
		<pre>7. \$ sudo rcstool ci /etc/ssh/sshd_config</pre>
		8. \$ sudo service sshd restart
19.	Update the httpd.conf file to disable the	Perform the following steps to disable Cache control no-store policy:
	Cache control no-store policy	1. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf
		If the output contains "Header set Cache-Control no-store", Execute the below steps. If no output is displayed for the above command, skip the steps mentioned below.
		2. \$ sudo sed -i '/Cache-Control no-store/c\#Header set Cache- Control no-store' /etc/httpd/conf/httpd.conf
		3. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf
		The output should be "#Header set Cache-Control no-store" showing that the line has been commented.
		4. \$ sudo service httpd restart
20.	MPS A: Install Complete.	Install Procedure is complete.
21.	Note down the timestamp in log.	Run the following command:
	uniestamp in iog.	\$ date

Procedure	8:	Install	the	Application	on Server B
-----------	----	---------	-----	-------------	-------------

S	This procedure installs	This procedure installs the application on the server.		
T E P	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.			
#		FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.		
1.	MPS B: Install 1B.	Perform Procedure in Procedure A.12 or copy EPAP 16.3 ISO to /var/TKLC/upgrade directory.		
2.	Create a terminal window log into MPS B.	If not already connected, connect to the E5-APP-B card via the serial port. For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A card's adapter and use it for serial access. <b>Cable part numbers - 830-1220-xx</b>		
3.	<b>MPS B</b> : Login prompt is displayed.	<pre><hostname> console login: Note: Hit enter if no login prompt is displayed.</hostname></pre>		

4.	MPS B: log in as "admusr" user.	[hostname] consolelogin: admusr password: password
5.	<b>MPS B:</b> Start platcfg utility.	\$ sudo su - platcfg
6.	MPS B: Navigate to the Upgrade menu.	The platcfg Main Menu appears. On the Main Menu, select Maintenance and press [ENTER]. Main Menu Maintenance Diagnostics Server Configuration Security Network Configuration Remote Consoles Exit Select the Upgrade menu and press [ENTER].
		UpgradePatchingBackup and RestoreHalt ServerRestart ServerEject CDROMSave Platform Debug LogsPlatform Data CollectorExit
7.	<b>MPS X:</b> Validate ISO file.	Validate ISO file using <b>Procedure A.2</b> .
8.	MPS A: Select Early Upgrade Checks	Select the "Early Upgrade Checks" menu to verify that the system is ready for upgrade.          Upgrade Menu         Validate Media         Early Upgrade Checks         Initiate Upgrade         Copy USB Upgrade Image         Non Tekelec RPM Management         Exit

		If the Early Upgrade Checks fail due to the ongoing syncing of raid mirrors, then wait
		until the resync is completed and run the "Early Upgrade Checks" again.
		Early Checks failed for the next upgrade Look at earlyChecks.log for more info tarting Early Upgrade Checks at 1011413059 Running earlyUpgradeChecks() for Upgrade::EarlyPolicy::TPDEarlyChecks upgrade policy
		Verified server is not pending accept of previous upgrade ERROR: Raid mirrors are syncing! ERROR: md2 is syncing! ERROR: earlyUpgradeChecks() code failed for Upgrade::EarlyPolicy::TPDEarlyChecks ERROR: Failed running earlyUpgradeChecks() code
		Hardware architectures match Install products match. No Application installed yet Skip alarm check!
		ERROR: Early Upgrade Checks Failed! User has requested just to run early checks. No upgrade will be performed Early Upgrade Checks finished at 1011413059
		[admusr@epappri ~]\$ cat /proc/mdstat Personalities : [raid1] md1 : active raid1 sdb2[1] sda2[0] 262080 blocks super 1.0 [2/2] [UU]
		md2 : active raid1 sda1[0] sdb1[1] 468447232 blocks super 1.1 [2/2] [UU] [====>] resync = 29.7% (139377920/468447232) finish=73.0min speed=75060K/sec bitmap: 4/4 pages [16KB], 65536KB chunk
		unused devices: <none></none>
		Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the early upgrade checks fail due to any other reason.
9.	<b>MPS A:</b> Navigate to the Initiate Upgrade menu	Select the Initiate Upgrade menu and press [ENTER]. Upgrade Menu Validate Media Early Upgrade Checks
		Initiate Upgrade Copy USB Upgrade Image Non Tekelec RPM Management Exit
10		
	<b>MPS B:</b> Select the Upgrade Media.	The screen displays a message that it is searching for upgrade media. When the upgrade media is found, an Upgrade Media selection menu appears similar-to the example below. Select the desired upgrade media and press [ENTER].
		lqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqq
		waaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa
11.	MPS B: Upgrade	The screen displays the following, indicating that the upgrade software is first validating
10.	menu MPS B: Select the	Validate Media         Early Upgrade Checks         Initiate Upgrade         Copy USB Upgrade Image         Non Tekelec RPM Management         Exit         The screen displays a message that it is searching for upgrade media. When the upgrade media is found, an Upgrade Media selection menu appears similar-to the example below Select the desired upgrade media and press [ENTER].         Iqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqq

	cedure of mistan the h	
		No Application installed yet Skip alarm check! Verified all raid mirrors are synced. Early Upgrade Checks Have Passed! Early Upgrade Checks finished at 1447429031 Initializing upgrade information
12.	<b>MPS B:</b> Upgrade proceeds.	Many informational messages appear on the terminal screen as the upgrade proceeds. The messages are not shown here for clarity sake.
		When installation is complete, the server reboots.
13.	MPS B: Upgrade completed.	After the final reboot, the screen displays the login prompt as in the example below.
		Starting atd: [OK] ~~ /etc/rc4.d/S98ExQueue start ~~ ExQueue started. Starting TKLCe5appb: [OK] Checking network config files: [OK] Daemon is not running AlarmMgr daemon is not running, delaying by 1 minute ~~ /etc/rc4.d/S99Epap start ~~ EPAP configuration data not found. Exiting ~~ /etc/rc4.d/S99Pdba start ~~ EPAP configuration data not found. Exiting Starting smartd: [OK] Daemon is not running AlarmMgr daemon is not running, delaying by 1 minute TPDhpDiskStatus stop/pre-start, process 5527 TKLChwmgmtcli stop/pre-start, process 5508 Oracle Linux Server release 6.9 Kernel 2.6.32-642.6.2.el6prerel7.4.0.0.0_88.32.0.x86_64 on an x86_64
14.	<b>MPS B:</b> log in as "epapdev" user.	[hostname] consolelogin: epapdev password: password
15.	MPS B: Check the Upgrade log.	<ul> <li>Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors and warnings were reported.</li> <li>\$ grep -i error /var/TKLC/log/upgrade/upgrade.log</li> <li>Check the output of the upgrade log, Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any error except the following:</li> <li>1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'</li> <li>1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'</li> <li>1487896226:: 2017-02-24T00:30:28.652213Z 0 [Warning] 'No_ZERO_DATE', 'No_ZERO_DATE' and 'ERROR_FOR_DIVISION_BY_ZERO' sql modes should be used with strict mode. They will be merged with strict mode in a future release.</li> </ul>

r	
	Following statement for missing binary file shall be observed in upgrade.log: 1530885808::/bin/df: `/mnt/ugchroot/sys': No such file or directory
	All those messages are expected, and therefore aren't considered errors. Also note that sometime a carriage return is inserted in the log file causing some of the error messages to appear truncated. This is acceptable and should be ignored.
	<pre>\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log</pre>
	Examine the output of the above command to determine if any warnings were reported. Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any warnings beside the following:
	1487896226::2017-02-24T00:30:28.652213Z 0 [Warning] 'NO_ZERO_DATE', 'NO_ZERO_IN_DATE' and 'ERROR_FOR_DIVISION_BY_ZERO' sql modes should be used with strict mode. They will be merged with strict mode in a future release. [epapdev@hvar-b ~]\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log 1487896106::WARNING: /usr/TKLC/plat/etc/alarms/alarms.xml has been updatedreparsing xml
	1487896218::*
	1487896219::* write: WARNING:: Could not find configured path "/var/TKLC/epap/db". 1487896219::* write: WARNING:: Could not find configured path
	1487896219::* write: WARNING:: Could not find configured path "/var/TKLC/epap/logs". 1487896219::* write: WARNING:: Could not find configured path
	<pre>''/var/TKLC/epap/free". 1487896219::* write: WARNING:: Could not find configured path ''/var/TKLC/epap/rt". 1487896219::* write: WARNING:: Could not find configured path ''/var/TKLC/epap/rt".</pre>
	"/var/TKLC/epap/db". 1487896219::* write: WARNING:: Could not find configured path
	"/var/TKLC/epap/logs". 1487896219::* write: WARNING:: Could not find configured path "/var/TKLC/epap/free".
	1487896220::useradd: warning: the home directory already exists. 1487896226::2017-02-24T00:30:28.652213Z 0 [warning] 'NO_ZERO_DATE', 'NO_ZERO_IN_DATE' and 'ERROR_FOR_DIVISION_BY_ZERO' sql modes should be used with strict mode. They will be merged with strict mode in a future release. 1487896229::2017-02-24T00:30:28.652254Z 0 [warning] 'NO_AUTO_CREATE_USER' sql
	mode was not set. 1487896242::2017-02-24T00:30:46.762649z 0 [Warning] InnoDB: New log files created. LSN=45791
	1487896247::2017-02-24T00:30:46.856447Z 0 [Warning] InnoDB: Creating foreign key constraint system tables.
	1487896247::2017-02-24T00:30:46.918223Z 0 [Warning] No existing UUID has been found, so we assume that this is the first time that this server has been started. Generating a new UUID: 7c1b5ac5-fa28-11e6-ac40-0010e08503fb. 1487896247::2017-02-24T00:30:46.919104Z 0 [Warning] Gtid table is not ready to be used. Table 'mysql.gtid_executed' cannot be opened. 1487896247::2017-02-24T00:30:48.561021Z 0 [Warning] CA certificate ca.pem is
	self signed. 1487896249::2017-02-24T00:30:49.018012Z 1 [Warning] root@localhost is created with an empty password ! Please consider switching off theinitialize- insecure option.
	1487896252::2017-02-24T00:30:55.321537Z 0 [Warning] TIMESTAMP with implicit DEFAULT value is deprecated. Please useexplicit_defaults_for_timestamp server option (see documentation for more details). 1487896255::2017-02-24T00:30:55.888792Z 0 [Warning] InnoDB: New log files
	created, LSN=45790 1487896256::2017-02-24T00:30:55.977153z 0 [Warning] InnoDB: Creating foreign
	key constraint system tables. 1487896256::2017-02-24T00:30:56.040240z 0 [Warning] No existing UUID has been found, so we assume that this is the first time that this server has been
	started. Generating a new UUID: 818b4391-fa28-11e6-946c-0010e08503fb. 1487896256::2017-02-24T00:30:56.0410137 0 [Warning] Gtid table is not ready to
	be used. Table 'mysql.gtid_executed' cannot be opened. 1487896256::2017-02-24T00:30:56.7653112 0 [warning] CA certificate ca.pem is self signed. 1487896257::2017-02-24T00:30:57.213158z 1 [warning] root@localhost is created
	with an empty password ! Please consider switching off theinitialize- insecure option.
	1487896284::WARNING: A new file was added to xml alarm filesreparsing xml 1487896285::WARNING: FILE: /usr/TKLC/plat/etc/alarms/alarms_mps.xml 1487896292::TKLCepap-HA
	######################################
	1

16.	<b>MPS B:</b> Check that the upgrade completed successfully.	\$ grep "Upgrade returned success" /var/TKLC/log/upgrade/upgrade.log
17.	<b>MPS B:</b> Check that the upgrade completed successfully.	Verify that the message "Upgrade returned success!" is displayed. If it is not, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F.
		1399367207:: Upgrade returned success!
18.	MPS B:	Perform following steps to disable unsecure algorithm for ssh:
	Update ssh_config to disable MD5 and	1. \$ grep "MACs hmac-md5,hmac-md5-96," /etc/ssh/ssh_config
	MAC algorithm for security	If output contains "MACs hmac-md5,hmac-md5-96", execute the below steps 2 and 3. Else go to step 4.
	Ĵ	<pre>2. \$ sudo rcstool co /etc/ssh/ssh_config</pre>
		3. \$ sudo sed -i -e '/MACs hmac-md5,hmac-md5-96,hmac-sha1-96/d' /etc/ssh/ssh_config
		4.\$ sudo rcstool ci /etc/ssh/ssh_config
		4. \$ grep "MACs hmac-sha2-256,hmac-sha2-512" /etc/ssh/sshd_config
		If no output is displayed for above command continue to next
		command in step 5 and 6 else skip these steps
		5. \$ sudo rcstool co /etc/ssh/sshd_config
		6. \$ sudo sed -i '\$ a \\tMACs hmac-sha2-256,hmac-sha2-512' /etc/ssh/sshd_config
		7. \$ sudo rcstool ci /etc/ssh/sshd_config
		8. \$ sudo service sshd restart
19.	Update the httpd.conf file to disable the	Perform the following steps to disable Cache control no-store policy:
	Cache control no-store policy.	1. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf
		If the output contains "Header set Cache-Control no-store", Execute the below steps. If no output is displayed for the above command, skip the steps mentioned below.
		2. \$ sudo sed -i '/Cache-Control no-store/c\#Header set Cache- Control no-store' /etc/httpd/conf/httpd.conf
		3. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf
		The output should be "#Header set Cache-Control no-store" showing that the line has been commented.
		4. \$ sudo service httpd restart
20.	<b>MPS B:</b> Install Complete.	Install Procedure is complete.
	complete.	

21.	Note down the	Run the following command:
	timestamp in log.	\$ date

# Procedure 9 Switch Configuration

S	This procedure Configures the Switches of a new Installed E5-APP-B EPAP Server Pair.		
Т	Charle off (a) as the star	a sitis second to d. Deves have been succided for this successory devices have successory	
E P	Check off ( $\psi$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.		
#	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.	
1.	Make the cross-over cable connections.	NOTE: THIS IS IMPORTANT	
		CONNECT the cross-over cable from <b>Port 1</b> of <b>Switch1A</b> to <b>Port 1</b> of <b>Switch1B</b> .	
		DISCONNECT the cross-over cable from <b>Port</b> 2 of <b>Switch1A</b> to <b>Port 2</b> of <b>Switch1B</b> . Please make a note that the switch configuration should only be attempted by a skilled technician and not all.	
		All uplinks should be removed while switch configuration.	
		There should not be any loop in the switches during their configuration.	
2.	MPS B: log in as "admusr" user.	[hostname] consolelogin: admusr password: <i>password</i>	
3.	MPS B: Set Telco Switch with non- default speed.	Note: The default speed to be set on the switch is 1000Mbps. However, the recommended setting can be changed to 'auto', '1000/full' or '100/full'. At the EAGLE end, the operator can set the IP LINK to 'auto'.	
4.	<b>MPS B:</b> Start platcfg utility.	\$ sudo su – platcfg	
5.	<b>MPS B:</b> Navigate to the Network Configuration Menu.	On the platefg Main Menu, select Network Configuration and press [ENTER].	
6.	<b>MPS B:</b> Navigate to the Configure Switch Menu.	On the Network Configuration menu, select <b>Configure Switch</b> and press [ENTER].	

		Network Configuration Menu SNMP Configuration Network Interfaces Configure Network Network Bridges Routing Iptables Resolv IPSEC Configuration Stunnel Modify Hosts File Configure Switch Exit
7.	MPS B: Select Switch1B.	On the Select Switch Menu, select Switch1B - Second Switch in Frame 1 and press [ENTER]. Select Switch Menu switch1A - Upper Switch in Frame 1 switch1B - Second Switch in Frame 1 switch1C - Third Switch in Frame 1 switch1D - Lower Switch in Frame 1 All Switches Exit
8.	MPS B: Confirm Switch 1B Configuration.	Select Yes and press [ENTER] to configure Switch 1B.
9.	MPS B: Switch Configuration Screen.	Configuring the switch takes about 10 minutes, once complete press [ENTER] to continue.

	cedure 9: Switch Com	
		Successfully enabled on switch switch1B. Reloading switch switch1B with defaults, please standby Switch switch1B successfully set to default configuration. Successfully started management VLAN on switch1B. Startup configuration created OK. Successfully uploaded startup config for switch1B. Removing config file switch1B.startup-config for switch1B. Removing switch switch1B complete. Switch switch1B successfully configured. Press any key to continue Netication completed successfully Switch Configuration Completed successfully Press any key to continue
10.	<b>MPS B:</b> Exit out of platcfg.	Select Exit and press [ENTER] to return to the Network Configuration Menu. Select Exit and press [ENTER] to return to the Main Menu. Select Exit and press [ENTER] to exit out of platcfg.
11.	MPS A: Connect to Server 1A.	Now that Switch 1B is configured, we need to configure switch 1A. Connect to server 1A to configure switch 1A [hostname] consolelogin: admusr password: password
12.	<b>MPS A:</b> Set Telco Switch with non- default speed.	Note: The default speed to be set on the switch is 1000Mbps. However, the recommended setting can be changed to 'auto', '1000/full' or '100/full'. At the EAGLE end, the operator can set the IP LINK to 'auto'. Otherwise proceed to step 13.
13.	<b>MPS A:</b> Start platcfg. utility	\$ sudo su - platcfg
14.	<b>MPS A:</b> Navigate to the Network Configuration Menu.	On the platcfg Main Menu, select Network Configuration and press [ENTER].

	1	
		Main Menu       Maintenance       Diagnostics       Server Configuration       Security       Network Configuration       Remote Consoles       Exit
15.	MPS A: Navigate to the Configure Switch Menu.	On the Network Configuration menu, select Configure Switch and press (ENTER).
	MPS A: Select Switch1A.	On the Select Switch Menu, select Switch1A – Upper Switch in Frame 1 and press [ENTER]. Select Switch Menu Switch1A – Upper Switch in Frame 1 switch1B – Second Switch in Frame 1 switch1C – Third Switch in Frame 1 switch1D – Lower Switch in Frame 1 All Switches Exit
17.	MPS A: Confirm Switch 1A Configuration.	Select Yes and press [ENTER] to configure Switch 1A.           Verify Action           Really configure switch switch1A? Disrupt network connectivity?

	MPS A: Navigate to the Configure Switch Menu.	Configuring the switch takes about 10 minutes, once complete press [ENTER] to continue. Successfully enabled on switch switch10. Reloading switch switch10 with defaults, please standby Successfully started management ULAN on switch10. Startup configuration created 0K. Successfully unded startup config for switch10. Reload of switch switch10, please standby Reload of switch switch10, please standby Reload of switch switch10, please standby Reload of switch switch10, successfully configured. Press any key to continue Switch Configuration Completed successfully Press any key to continue
19.	<b>MPS A:</b> Exit out of platcfg.	Select Exit and press [ENTER] to return to the Network Configuration Menu. Select Exit and press [ENTER] to return to the Main Menu. Select Exit and press [ENTER] to exit out of platcfg.
20.	<b>MPS A:</b> Optional Configuration of Switch 1C.	If the system is installed with 4 switches, proceed with the next step, otherwise skip to step 37.
21.	Move Serial Cables.	On the front of switches 1A and 1B, unplug the serial cables connected to Console port and plug them in switches 1C and 1D Console port respectively.
22.	<b>MPS A:</b> Start platcfg utility.	\$ sudo su - platcfg
23.	<b>MPS A:</b> Navigate to the Network Configuration Menu.	On the platcfg Main Menu, select Network Configuration and press [ENTER].

		Main Menu       Maintenance       Diagnostics       Server Configuration       Security       Network Configuration       Remote Consoles       Exit
24.	MPS A: Navigate to the Configure Switch Menu.	On the Network Configuration menu, select Configure Switch and press [ENTER].
25.	MPS A: Select Switch1C.	On the Select Switch Menu, select Switch1C - Third Switch in Frame 1 and press [ENTER].  Select Switch Menu switch1A - Upper Switch in Frame 1 switch1B - Second Switch in Frame 1 switch1C - Third Switch in Frame 1 switch1D - Lower Switch in Frame 1 All Switches Exit
26.	MPS A: Confirm Switch 1C Configuration.	Select Yes and press [ENTER] to configure Switch 1C           Verify Action           Really configure switch switch1C? Disrupt network connectivity?

27.	MPS A: Navigate to the Configure Switch Menu.	Configuring the switch takes about 10 minutes, once complete press [ENTER] to continue.
28.	<b>MPS A:</b> Exit out of platcfg.	Select Exit and press [ENTER] to return to the Network Configuration Menu. Select Exit and press [ENTER] to return to the Main Menu. Select Exit and press [ENTER] to exit out of platcfg.
29.	MPS B: Connect to Server 1B.	[hostname] consolelogin: admusr password: <i>password</i>
30.	<b>MPS B:</b> Start platcfg utility.	\$ sudo su - platcfg
31.	<b>MPS B:</b> Navigate to the Network Configuration Menu.	On the platcfg Main Menu, select Network Configuration and press [ENTER].

		Main Menu Maintenance Diagnostics Server Configuration Security Network Configuration Remote Consoles Exit
32.	<b>MPS B:</b> Navigate to the Configure Switch Menu.	On the Network Configuration menu, select Configure Switch and press [ENTER].
33.	<b>MPS B:</b> Select Switch1D.	On the Select Switch Menu, select Switch1D - Lower Switch in Frame 1 and press [ENTER].
34.	MPS B: Confirm Switch 1D Configuration.	Select Yes and press [ENTER] to configure Switch 1D.           Verify Action           Really configure switch switch1D? Disrupt network connectivity?

35.	MPS B: Switch Configuration Screen.	Configuring the switch takes about 10 minutes, once complete press [ENTER] to continue. Successfully enabled on switch switch10. Reloading switch switch10 witchesfully set to default configuration. Successfully started management V(AN on switch10. Startup config file switch10. Startup-config from /tftpboot. Reloading switch switch10, please standby Reload of switch switch10 complete.
		Switch Configuration Completed successfully Press any key to continue
36.	<b>MPS B:</b> Exit out of platcfg.	Select Exit and press [ENTER] to return to the Network Configuration Menu. Select Exit and press [ENTER] to return to the Main Menu. Select Exit and press [ENTER] to exit out of platcfg.
37.	Connect the cross-over cable from <b>Port 2</b> of <b>Switch1A</b> to <b>Port 2</b> of <b>Switch1B</b> .	$A \begin{bmatrix} 5 & 7 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 3 & 4 & 5 & 6 & 7 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 3 & 4 & 5 & 6 & 7 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 3 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 3 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 3 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 9 & 10 & 11 & 12 & 13 & 14 & 15 & 16 & 17 & 18 & 19 & 20 \\ \hline 1 & 2 & 4 & 5 & 6 & 7 & 8 & 10 & 10 & 10 & 10 & 10 & 10 & 10 $
38.	Procedure complete.	Procedure is complete.
39.	Note down the timestamp in log.	Run the following command: \$ date

## Procedure 10 Procedure to Configure Sync Network Redundancy

Note: This procedure will configure the E5-APP-B EPAP cards with the Sync Network Redundancy feature. This will use the Backup Provisioning Network ports, therefor the Backup Provisioning Network feature cannot be used.

S		work redundancy in place of backup provisioning network.
	This procedure will sync her	work redundancy in place of backup provisioning network.
Т	Note: Estimated time of cor	npletion is 90 minutes
Е	Tote. Estimated time of col	ipiedon is yo minutes.
Р		
#		
1.	<b>MPS A:</b> Log in as "admusr" user to the serial console of E5-APP-B card.	[hostname] consolelogin: admusr password: <i>password</i>
2.	<b>MPS A:</b> Start platcfg utility.	\$ sudo su - platcfg
3.	<b>MPS A:</b> Navigate to the Network Configuration Menu.	On the platcfg Main Menu, select Network Configuration and press [ENTER].
		Main Menu Maintenance Diagnostics Server Configuration Remote Consoles Network Configuration Security Exit
4.	MPS A: Navigate to the Network Interfaces Menu.	On the Network Configuration menu, select Network Interfaces and press [ENTER].

#### **Procedure 10: Procedure to Configure Sync Network Redundancy**

	<b>MPS A:</b> Navigate to the Delete an Interface Menu.	On the Network Interfaces Menu, select Delete an Interface and press [ENTER].
5.		Network Interfaces Menu         Add an Interface         Edit an Interface         Delete an Interface         Restart an Interface         Exit
6.	<b>MPS A:</b> Select to delete eth03.1 and press Enter.	On the Connection to delete Menu, select eth03.1 and press [ENTER].
		Connection to delete Menu eth01 eth02 eth03 eth03.1 eth03.3 eth04 Exit
7.	<b>MPS A:</b> Confirm eth03.1 interface deletion.	Select <b>Yes</b> and press <b>[ENTER]</b> to delete the eth03.1 interface.
		Delete Interface Do you wish to remove the eth03.1 interface?

		Magaza
		Interface eth03.1 deleted
		Press any key to continue
8.	<b>MPS A:</b> Press any key to continue.	On the Network Interfaces Menu, select <b>Delete an Interface</b> and press [ENTER].
	Navigate to the Delete an Interface Menu.	Network Interfaces Menu         Add an Interface         Edit an Interface         Delete an Interface         Restart an Interface         Exit
9.	<b>MPS A:</b> Select to delete eth03.3 and press Enter.	On the Connection to delete Menu, select <b>eth03.3</b> and press [ENTER].
10		Connection to delete Menu eth01 eth02 eth03 eth03.3 eth04 Exit
10.	<b>MPS A:</b> Confirm eth03.3 interface deletion.	Select <b>Yes</b> and press <b>[ENTER]</b> to delete the eth03.3 interface.

		Delete Interface
		Do you wish to remove the eth03.3 interface?
		Message Interface eth03.3 deleted
		Press any key to continue
11.	<b>MPS A:</b> Press any key to continue and exit out of platcfg.	Select Exit and press [ENTER] to return to the Network Configuration Menu. Select Exit and press [ENTER] to return to the Main Menu. Select Exit and press [ENTER] to exit out of platcfg.
12.	<b>MPS A:</b> Verify that eth03.1 and eth03.3 are deleted.	<pre>\$ sudo netAdm show eth01 eth02 eth03 eth04 The interfaces eth03.1 and eth03.3 should not be listed.</pre>
13.	<b>MPS A:</b> Take the backup of original net.conf.	<pre>\$ sudo cp /usr/TKLC/plat/etc/net.conf /usr/TKLC/plat/etc/net.conf_orig</pre>
14.	<b>MPS A:</b> Replace the network configuration file for sync network redundancy.	<pre>\$ sudo cp /usr/TKLC/plat/etc/net.sync.conf /usr/TKLC/plat/etc/net.conf cp: overwrite `/usr/TKLC/plat/etc/net.conf'? y</pre>
15.	<b>MPS A A:</b> Take the backup of original vlan.conf.	<pre>\$ sudo cp /usr/TKLC/plat/etc/vlan.conf /usr/TKLC/plat/etc/vlan.conf_orig</pre>
16.	<b>MPS A:</b> Replace the vlan configuration file for sync network redundancy.	E5-APP-B Card: Single Pair of Switch(18 SM Cards): vlan.sync.single_pair_switch.e5appb.conf

		(Ports 7 to 24 on switch 1A and ports 5 to 24 on switch 1B can be used for SM card connectivity)		
		Two Pair of switches (40 SM Cards): vlan.sync.e5appb.conf		
		(Ports 7 to 22 on switch 1A and ports 5 to 22 on switch 1B can be used for SM card connectivity, no change for switch 1C and 1D)		
		For e.g., on T1200 server for Single pair of switches: <b>\$ sudo cp</b> /usr/TKLC/plat/etc/vlan.sync.single_pair_switch.t1200.conf /usr/TKLC/plat/etc/vlan.conf		
		cp: overwrite `/usr/TKLC/plat/etc/vlan.conf'? <mark>y</mark>		
17.	<b>MPS A:</b> Reconfigure the network interfaces.	\$ sudo netAdm init		
	network interfaces.	Interface bond0 added		
		Interface eth01 added		
		Interface eth02 added		
		Interface bond0.3 added		
		Interface eth03 added		
		Interface eth04 added		
		Interface bond0.1 added		
		Successfully configured network		
		<pre>\$ sudo service network restart</pre>		
18.	<b>MPS A:</b> Restart network service.	<pre>\$ sudo service network restart</pre>		
_		\$ sudo service network restart Repeat all the above steps on the MPS B.		
<b>1</b> 9.	service.			
□ 19. □ 20.	service. MPS B	Repeat all the above steps on the MPS B. Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to		
□ 19. 20. □ 21. □ 22.	service. MPS B Network Connectivity Configure Switch 1B first and then Switch 1A using Procedure 9. MPS A: Verify that ping mate	Repeat all the above steps on the MPS B. Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to port 6 on Switch 1A. Perform <b>Procedure 9</b> – Switch1B and Switch1A Configuration to configure		
□ 19. □ 20. □ 21. □	service. MPS B Network Connectivity Configure Switch 1B first and then Switch 1A using Procedure 9.	Repeat all the above steps on the MPS B.         Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to port 6 on Switch 1A.         Perform Procedure 9 – Switch1B and Switch1A Configuration to configure Switch1B and then Switch1A.		
□ 19. 20. □ 21. □ 22.	service. MPS B Network Connectivity Configure Switch 1B first and then Switch 1A using Procedure 9. MPS A: Verify that ping mate	Repeat all the above steps on the MPS B.         Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to port 6 on Switch 1A.         Perform Procedure 9 – Switch1B and Switch1A Configuration to configure Switch1B and then Switch1A.         \$ ping -c 4 mate		
□ 19. 20. □ 21. □ 22.	service. MPS B Network Connectivity Configure Switch 1B first and then Switch 1A using Procedure 9. MPS A: Verify that ping mate is working. Also ensure that the sync redundancy is working fine by	Repeat all the above steps on the MPS B.         Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to port 6 on Switch 1A.         Perform Procedure 9 – Switch1B and Switch1A Configuration to configure Switch1B and then Switch1A.         \$ ping -c 4 mate         PING mate (192.168.2.100) 56(84) bytes of data.		
□ 19. 20. □ 21. □ 22.	service. MPS B Network Connectivity Configure Switch 1B first and then Switch 1A using Procedure 9. MPS A: Verify that ping mate is working. Also ensure that the sync	Repeat all the above steps on the MPS B.         Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to port 6 on Switch 1A.         Perform Procedure 9 – Switch1B and Switch1A Configuration to configure Switch1B and then Switch1A.         \$ ping -c 4 mate         PING mate (192.168.2.100) 56(84) bytes of data.         64 bytes from mate (192.168.2.100): icmp_seq=1 ttl=64 time=0.189 ms		
□ 19. 20. □ 21. □ 22.	service. MPS B Network Connectivity Configure Switch 1B first and then Switch 1A using Procedure 9. MPS A: Verify that ping mate is working. Also ensure that the sync redundancy is working fine by turning off one switch and	Repeat all the above steps on the MPS B.         Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to port 6 on Switch 1A.         Perform Procedure 9 – Switch1B and Switch1A Configuration to configure Switch1B and then Switch1A.         \$ ping -c 4 mate         PING mate (192.168.2.100) 56(84) bytes of data.         64 bytes from mate (192.168.2.100): icmp_seq=1 ttl=64 time=0.189 ms         64 bytes from mate (192.168.2.100): icmp_seq=2 ttl=64 time=0.188 ms		
□ 19. 20. □ 21. □ 22.	service. MPS B Network Connectivity Configure Switch 1B first and then Switch 1A using Procedure 9. MPS A: Verify that ping mate is working. Also ensure that the sync redundancy is working fine by turning off one switch and	Repeat all the above steps on the MPS B.         Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to port 6 on Switch 1A.         Perform Procedure 9 – Switch1B and Switch1A Configuration to configure Switch1B and then Switch1A.         \$ ping -c 4 mate         PING mate (192.168.2.100) 56(84) bytes of data.         64 bytes from mate (192.168.2.100): icmp_seq=1 ttl=64 time=0.189 ms         64 bytes from mate (192.168.2.100): icmp_seq=3 ttl=64 time=0.166 ms		
□ 19. 20. □ 21. □ 22.	service. MPS B Network Connectivity Configure Switch 1B first and then Switch 1A using Procedure 9. MPS A: Verify that ping mate is working. Also ensure that the sync redundancy is working fine by turning off one switch and	Repeat all the above steps on the MPS B.         Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to port 6 on Switch 1A.         Perform Procedure 9 – Switch1B and Switch1A Configuration to configure Switch1B and then Switch1A.         \$ ping -c 4 mate         PING mate (192.168.2.100) 56(84) bytes of data.         64 bytes from mate (192.168.2.100): icmp_seq=1 ttl=64 time=0.189 ms         64 bytes from mate (192.168.2.100): icmp_seq=3 ttl=64 time=0.188 ms         64 bytes from mate (192.168.2.100): icmp_seq=3 ttl=64 time=0.166 ms         64 bytes from mate (192.168.2.100): icmp_seq=4 ttl=64 time=0.143 ms		
□ 19. 20. □ 21. □ 22.	service. MPS B Network Connectivity Configure Switch 1B first and then Switch 1A using Procedure 9. MPS A: Verify that ping mate is working. Also ensure that the sync redundancy is working fine by turning off one switch and	Repeat all the above steps on the MPS B.         Connect eth04 on MPS A to port 5 on Switch 1A and connect eth04 on MPS B to port 6 on Switch 1A.         Perform Procedure 9 – Switch1B and Switch1A Configuration to configure Switch1B and then Switch1A.         \$ ping -c 4 mate         PING mate (192.168.2.100) 56(84) bytes of data.         64 bytes from mate (192.168.2.100): icmp_seq=1 ttl=64 time=0.189 ms         64 bytes from mate (192.168.2.100): icmp_seq=2 ttl=64 time=0.188 ms         64 bytes from mate (192.168.2.100): icmp_seq=3 ttl=64 time=0.166 ms         64 bytes from mate (192.168.2.100): icmp_seq=4 ttl=64 time=0.143 ms         mate ping statistics		

23.	<b>MPS A:</b> Reconfigure EPAP using epapconfig menu if the configuration was done before configuring sync network redundancy.	\$ su - epapconfig Please follow the instructions written in Procedure 11.
24.	Procedure complete.	Procedure is complete.
25.	Note down the timestamp in log.	Run the following command: \$ date

#### **Procedure 11: Configuring the Application**

S	This procedure configures the application on the server.
T E	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.
Р #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.

# NOTE: This procedure configures the application in the IPv4 configuration. To configure the application in the IPv6 configuration, refer to [6].

1.	<b>MPS A:</b> Log on Server A.	[hostname] consolelogin: admusr password: <i>password</i>			
2.	<b>MPS A:</b> Switch user to epapconfig.	\$ sudo su - epapconfig			
3.	<b>MPS A:</b> A note of caution appears. Evaluate the conditions listed. When all the conditions are satisfied, press Return to continue.	Caution: This is the first login of the text user interface. Please review the following checklist before continuing. Failure to enter complete and accurate information at this time will have unpredictable results. 1. The mate MPS servers (MPS A and MPS B) must be powered on. 2. "Initial Platform Manufacture" for the mate MPS servers must be complete. 3. The sync network between the mate MPS servers must be operational. 4. You must have the correct password for the epapdev user on the mate MPS server. 5. You must be prepared to designate this MPS as provisionable or non-provisionable. Press return to continue			
4.	<b>MPS A:</b> Upon pressing Return you can now abort or proceed with the initial configuration. To continue with the configuration, enter Y.	Are you sure you wish to continue? [N]:Y			

5.	MPS A:	Password of epapdev:			
	For Mixed EPAP or	ssh is working correctly. Password of root:			
	Non-Provisionable	ssh is working correctly.			
	EPAP: You are	Password of admusr:			
		ssh is working correctly.			
	prompted for the	Password of root:			
	epapdev, root and	ssh is working correctly.			
	admusr user password	Building the initial database on side A.			
	on the mate MPS server	Stopping local slave			
	in order to confirm the	Stopping remote slave			
	secure shell keys are	EuiDB already exists.			
	successfully exchanged.	FIPS integrity verification test failed.			
	The example shows the	Starting local slave			
	output generated when	Starting remote slave			
	the correct password is				
	entered, the secure shell	The provisioning architecture of the EPAP software allows for			
	keys are successfully	exactly 2 customer provisionable sites. Additional sites that			
	exchanged, and the UI	are to receive the data provisioned to the provisionable sites			
	database is set up on	should answer 'N' here.			
	MPS A and MPS B at this				
	site.	If there are only 2 mated sites, it is safe to answer `Y' here.			
	Type Y if this site is Provisionable(either	Is this site provisionable? [Y]: Y			
	mixed-EPAP or				
	PDBonly), otherwise				
	Type N.				
	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Caution: This is the first login of the text user interface.			
		Press return to continue			
	For Standalone PDB:	Are you sure you wish to continue? [N]: Y			
		Building the initial database on side A.			
	You are prompted for	Stopping local slave			
	the System Number and	No preexisting EuiDB database was detected.			
	Network Configuration	Set EPAP System Number: ES12345678 Enter the Network Configuration Type (1 for Single, 2 for Segmented): 2			
	Туре.	shoel one neovork configuration type (I for single, a for segmented); a			
6.	MPS A: The EPAP	EPAP Configuration Menu for standalone PDB:			
	Configuration Menu is	-			
	displayed. Select choice				
	2, Configure Network Interfaces Menu.				
	interfaces Menu.				

	EPAP Configuration Menu\
Í.	1   Display Configuration
i	2   Configure Network Interfaces Menu
i	3   Set Time Zone
i i	4   Exchange Secure Shell Keys
	5   Change Password   
i i	6   Platform Menu
	7   Configure NTP Server
	8   PDB Configuration Menu
	9   Security
1	
1	1   Configure Alarm Feed
1	.2   Configure Query Server
1	.3   Configure Query Server Alarm Feed
_	.4   Configure SNMP Agent Community
	.5   DB Architecture Menu
	e   Exit
\	/
EPA	P Configuration Menu for NON-Prov EPAP:

	cedure 11: Configuring		
		/EPAP Configuration Menu	
		/ 1   Display Configuration	
		2   Configure Network Interfaces Menu	
		3   Set Time Zone	
		4   Exchange Secure Shell Keys	
		   5   Change Password	
		   6   Platform Menu	
		   7   Configure NTP Server	
		   8   PDB Configuration Menu	
		   9   Security	
		   10   SNMP Configuration	
		   11   Configure Alarm Feed	
		   12   Configure SNMP Agent Community	
		   13   Mate Disaster Recovery	
		   14   DB Architecture Menu	
		   e   Exit	
		\/	
		Enter Choice: 2	
7.	MPS A: The Configure		
	Network Interfaces Menu is displayed.	Configuration Menu for Mixed EPAP and Non-Provisionable EPAP:	
	Select choice 1,	/Configure Network Interfaces Menu\ /\	
	Configure Provisioning Network.	1   Configure Provisioning Network   	
		2   Configure Sync Network	
		3   Configure DSM Network	
		4   Configure Backup Provisioning Network	
		5   Configure Static NAT Addresses	
		6   Configure Provisioning VIP Addresses	
		e   Exit   \/	
		Enter Choice:1	
		Configuration Menu for Standalone PDB:	
L	ada/Installation Cuida	70 of 270	August 2024

		/Configure Network Interfaces Menu\				
		1   Configure Provisioning Network				
		2   Configure Backup Provisioning Network				
		3   Configure Static NAT Addresses				
		   Exit  /				
		Enter Choice:1				
8.	MPS A: The submenu	/Configure Provisiong Network Menu-\ /)				
	for configuring communications	1   IPv4 Configuration				
	networks and other information is	   2   IPv6 Configuration				
	displayed.	   e   Exit				
		()				
		Enter Choice:				
	Note: Enter choice "1" for IPv4 configuration.	Example output for Mixed EPAP and Non-Provisionable EPAP in IPv4 configuration:				
	Otherwise, enter choice "2" for IPv6	Enter Choice: 1				
	configuration.					
		Verifying connectivity with mate EPAP A provisioning network IP Address: 10.75.141.47				
		EPAP B provisioning network IP Address: 10.75.141.48				
		EPAP provisioning network netmask: 255.255.255.128 EPAP provisioning network default router: 10.75.141.1				
		Example output Standalone PDB in IPv4 configuration:				
		EPAP A provisioning network IP Address:10.75.141.47 EPAP provisioning network netmask:255.255.255.128 EPAP provisioning network default router:10.75.141.1				
9.	MPS A: The Configure	Configuration Menu for Mixed EPAP and Non-Provisionable EPAP:				
	Network Interfaces menu is displayed. Select choice e, Exit.	/Configure Network Interfaces Menu\				
		1   Configure Provisioning Network				
		2   Configure Sync Network				
		3   Configure DSM Network				
		4   Configure Backup Provisioning Network				
		5 Configure Static NAT Addresses				
		6 Configure Provisioning VIP Addresses				
		e   Exit				
		Enter Choice: e				
		Configuration Menu for Standalone PDB:				
		/Configure Network Interfaces Menu\				

<b></b>		/\
		1   Configure Provisioning Network
		2   Configure Backup Provisioning Network
		3 Configure Static NAT Addresses
		   e   Exit  /
		Enter Choice: e
10.	<b>MPS A:</b> The EPAP Configuration Menu is displayed. Select choice 3, Set Time Zone.	EPAP Configuration Menu for Non-prov EPAP: /EPAP Configuration Menu\
		1   Display Configuration
		2   Configure Network Interfaces Menu
		3   Set Time Zone
		4   Exchange Secure Shell Keys
		5   Change Password
		6   Platform Menu
		7   Configure NTP Server
		8   PDB Configuration Menu
		   9   Security
		   11   Configure Alarm Feed
		Configure SNMP Agent Community
		   13   Mate Disaster Recovery
		   14   DB Architecture Menu
		   e   Exit
		\/
		Enter Choice:3
11.	<b>MPS A:</b> An important Caution statement is displayed. After noting the caution press	Caution: This action requires a reboot of the affected MPS servers to activate the change. Operation of the EPAP software before the MPS servers are rebooted may have unpredictable consequences.
	the caution, press Return to continue.	Press return to continue <return></return>
		Are you sure you wish to change the timezone for MPS A and B? [N]: Y

	0			
	You are prompted for			
	confirmation on setting			
	the time zone for the			
	MPS A and MPS B at			
	this site for Mixed			
	EPAP or Non-			
	provisionable EPAP.			
	For Standalone PDB,			
	time zone for MPS A is			
	prompted only. Enter y			
	to confirm the change.			
	(Pressing Return accepts			
	the default of 'N' (no),			
	cancels the action and			
	you are returned to the			
	EPAP Configuration			
	Menu). Type Y to set the			
	time zone.			
12.	MPS A: The following	Enter a time zone:		
	prompt is displayed. If			
	the time zone is known,			
1	it can be entered at the			
	prompt. If the exact			
	time zone value is not			
	known, press Return,			
	and a list of the valid			
	names is displayed.			
	numes is displayed.			
13.	If an incorrect time zone			
		Valid time zone files an	re:	
	is entered or if only the	Australia/Broken_Hill	Australia/LHI	
	Return key is pressed, a	Australia/NSW		
	list of all available time	Australia/North	Australia/Queensland	
	zone values is	Australia/South	Aus er ar ray gacens rana	
		Australia/Tasmania	Australia/Victoria	
	displayed.	Australia/West	Australia, victoria	
		Australia (Vancowinna	Australia /ACT	Brazil/Acre
		Australia/Yancowinna	Australia/ACT	
	Note: The time zone	Brazil/DeNoronha	Brazil/East	Brazil/West
	change does not take	Canada/Atlantic	Canada/Central	Canada/East-
		Saskatchewan		
	effect until the next time	Canada/Eastern	Canada/Mountain	
	the MPS is rebooted.	Canada/Newfoundland		
		Canada/Pacific	Canada/Yukon	
		Chile/Continental		
		Chile/EasterIsland	Etc/GMT	Etc/GMT+1
		Sample Output co	ontinues	
		End of ou	tput below	
		MST	MST7MDT	NZ
		NZ-CHAT	PRC	PST8PDT
1		Poland	Portugal	ROC
		ROK	Singapore	Turkey
1		W-SU	WET	africa
		asia	australasia	backward
1		etcetera	europe	factory
		northamerica	pacificnew	solar87
		solar88	solar89	southamerica
1		GB-Eire	GMT	GMT+0
		GMT+1	GMT+10	GMT+11
		GMT+12	GMT+13	GMT+2
1		GMT+3	GMT+4	GMT+5
		GMT+6	GMT+7	GMT+8
1		GMT+9	GMT-0	GMT-1
		GMT-10	GMT-11	GMT-12
		GMT-2	GMT-3	GMT-4
1		GMT-2 GMT-5	GMT-6	GMT-7
		GMT-S GMT-8	GMT-0 GMT-9	Greenwich
1				
		Jamaica	Navajo	UCT
1		UTC	Universal	Zulu

		Enter a time zone file (relative to /usr/share/lib/zoneinfo): <b>US/Eastern</b>
14.	SERVER A: Enter choice 7, Configure NTP Server Menu. NOTE: If an NTP server does not need to be added at this time, you can skip all steps related to option 7 Configure NTP Server Menu, and proceed to the PDB Configuration Menu at step 20.	Enter a time zone file (relative to /usr/share/lib/zoneinfo): US/Eastern  EPAP Configuration Menu for Non-prov EPAP: /EPAP Configuration Menu
15.	<b>MPS A:</b> The EPAP Configure NTP Server Menu is displayed. Enter choice 2, Add External NTP Server.	/EPAP Configure NTP Server Menu- 1   Display External NTP Server 2   Add External NTP Server 3   Remove External NTP Server 

I	Γ	/ Idd Dutewerl MTD Course Manu \
16.	Note: Enter choice "1" to configure IPv4 NTP server. Otherwise, enter choice "2" to configure IPv6 NTP server. <b>MPS A:</b> You are prompted to confirm the action of adding a new NTP Server. (Pressing Return would accept the default of 'N' or 'no', and would cancel the action to add an external NTP server.) Type Y and press return. <b>NOTE:</b> All NTP	/Add External NTP Server Menu-/ / 1   IPv4 Configuration   
	NOTE: All NTP Server IP addresses shown are only examples.	
17.	MPS A: The EPAP Configure NTP Server Menu is displayed. Enter choice 1, Display External NTP Server.	/EPAP Configure NTP Server Menu- 1   Display External NTP Server 2   Add External NTP Server 3   Remove External NTP Server 
18.	MPS A: Verify the External NTP Server IP address is correct and press Return. NOTE: All NTP Server IP addresses shown are only examples.	ntpserver1 <ipaddress> Press return to continue<return></return></ipaddress>
19.	<b>MPS A:</b> The EPAP Configure NTP Server Menu is displayed. Select choice e, Exit.	/EPAP Configure NTP Server Menu-\ 1   Display External NTP Server 2   Add External NTP Server 3   Remove External NTP Server

		e   Exit
		\/
		Enter Choice: <b>e</b>
20		
20.	MPS A: The EPAP	PDB Configuration Menu for Non-prov EPAP:
	Configuration Menu is displayed. Select choice	
	8, PDB Configuration Menu.	/EPAP Configuration Menu\ /\
	Monu.	1   Display Configuration
	Note: Execute the step to do PDB	2   Configure Network Interfaces Menu
	Configuration Menu (except step 27) even if	   3   Set Time Zone
	the EPAP is to be configured as Non-	   4   Exchange Secure Shell Keys
	Provisionable.	
		5   Change Password
		6   Platform Menu
		7   Configure NTP Server
		8   PDB Configuration Menu
		9   Security
		10   SNMP Configuration
		11   Configure Alarm Feed
		12   Configure SNMP Agent Community
		13   Mate Disaster Recovery
		14   DB Architecture Menu
		e   Exit
		Enter choice: 8

	cedure 11. Configuring	
21.	<b>MPS A:</b> The Configure PDB Menu is displayed. Select choice 1.	PDB Configuration Menu for Mixed EPAP: /Configure PDB Menu>
		1   Configure PDB Network
		2   RTDB Homing Menu
		   3   Change MPS Provisionable State   
		4   Create PDB
		   5   Change Auto DB Recovery State
		   6   Change PDBA Proxy State
		   e   Exit
		\/
		PDB Configuration menu for Non-Provisionable EPAP:
		/Configure PDB Menu\
		/(   1   Configure PDB Network   
		2   RTDB Homing Menu
		   3   Change Auto DB Recovery State
	Note: Configure the PDB network in the	   e   Exit
	same format as that of the provisioning network format.	<pre>\/ Enter Choice: 1</pre>
		PDB Configuration Menu for Standalone PDB (for default DB Architecture: COMPACT):
		/Configure PDB Menu\
		/\   1   Configure PDB Network
		2   Create PDB
		3 Change Auto DB Recovery State
		e   Exit \/
		Enter Choice: 1
22.	<b>.</b>	PDB Network Configuration menu:
	<b>MPS A:</b> The PDB Network Configuration Menu is displayed.	
	niona is displayed.	
	Select choice 1.	
L		

<b></b>		
		/PDB Network Configuration Menu-\ /
		1   IPv4 Configuration
		2   IPv6 Configuration
		e Exit
		\/
		Enter Choice: 1
23.	<b>MPS A:</b> Provide the IP address of the MPS A	Following is the output on Mixed EPAP.
	on EAGLE A and the IP address for the MPS A on EAGLE B where the remote PDBA database is to reside. Enter the password for MPS A on	Verifying connectivity with mate This MPS is configured to be provisionable. The EPAP local PDBA IPv4 address is currently set to <ip>. The EPAP local PDBA IPv6 address is currently not configured. The EPAP local PDBA IPv4 Address is <ip>. EPAP remote PDBA IP Address [0.0.0.0]: <a address="" ip=""></a></ip></ip>
	EAGLE B. If configuration of the PDB network is successful, the output confirms the secure	EPAP remote PDBA B machine IP Address [0.0.0.0]: <b address="" ip=""> The server does not know of <a address="" ip=""> Will just exchange host keys for the name given! Password of epapdev: <epapdev password=""></epapdev></a></b>
	shell keys are successfully exchanged, as shown in the output for Provisionable(mixed- EPAP and PDBonly)	
	MPSs Note: If the default	Following is the output on Non-Provisionable EPAP.
	values shown are correct press return to accept them. Otherwise, enter the values and	Verifying connectivity with mate This MPS is configured to be non-provisionable. You will be prompted for both of the remote PDBA addresses. Order does not matter.
	press Return. In case of Non-	Enter one of the two PDBA IP addresses [0.0.0.0]: <ip address=""> Enter the other of the two PDBA IP addresses [0.0.0.0]: <ip Address&gt;</ip </ip>
	Provisionable EPAP	
	provide the IP address	Following is the output on Standalone PDB.
	of Active and Standby PDBA.	This MPS is configured to be provisionable. The EPAP local PDBA
		IPv4 address is currently set to <ip></ip>
		The EPAP local PDBA IPv6 address is currently not set.
	In case of Standalone	The EPAP local PDBA IPv4 Address is <ip>.</ip>
	PDB, provide remote PDBA IP address.	EPAP remote PDBA IP Address [0.0.0.0]:
24.	<b>MPS A:</b> Press Return to return to the Configure PDB Menu.	Skip this step if EPAP configured as Standalone PDB.
	Enter choice 2, RTDB Homing Menu.	

		( Configure DDR Mary
		/\ /\ /\
		1   Configure PDB Network
		2   RTDB Homing Menu
		3   Change MPS Provisionable State   
		4   Create PDB   
		5   Change Auto DB Recovery State   
		6   Change PDBA Proxy State
		e   Exit
		Enter Choice: 2
25.	MPS A: The RTDB	Skip this step for Standalone PDB.
	Homing Menu is displayed. Enter choice	/RTDB Homing Menu\
	3, Configure Standby	/\   1   Configure Specific RTDB Homing
	RTDB Homing.	2   Configure Active RTDB Homing
		 3   Configure Standby RTDB Homing
		\/
		Enter Choice: 3
		In the event that the Standby PDB is unavailable, should updates be allowed to the RTDBs from the Active MPS? [Y]: $\mathbf{Y}$
		The RTDBs will home to the Standby and will allow updates from the Active PDB.
		Press return to continue <return></return>
26.	MPS A: The RTDB	Skip this step for Standalone PDB.
	Homing Menu is displayed. Enter <b>e</b> to	/RTDB Homing Menu\
	exit.	1   Configure Specific RTDB Homing
		2   Configure Active RTDB Homing
		3 Configure Standby RTDB Homing
		   e   Exit
		Enter Choice: e
27.	<b>MPS A:</b> Enter choice 4, Create PDB.	Note: Perform this step only for the Provisionable EPAP (Mixed EPAP or Standalone
	Create I DD.	PDB). Skip this step if the EPAP is configured as Non-Provisionable.
		The Menu for Mixed EPAP.
	Note:	


<b></b>	a 1 5545 a	
	Stop the EPAP software by answering 'Y', If you	/\ /\
	get the message to stop it. Note:	1   Configure PDB Network
	While creating PDB database using the Create	
	PDB option of the EPAP Configuration Menu, ensure that the value for	3   Change MPS Provisionable State   
	remote PBD IP is set to 0.0.0.0.	4   Create PDB
		5   Change Auto DB Recovery State
		6   Change PDBA Proxy State
		e   Exit   \/
		Enter Choice: 4
		The Menu for Standalone PDB(for default DB Architecture: COMPACT):
		/Configure PDB Menu\ /
		1   Configure PDB Network
		2 Create PDB
		3   Change Auto DB Recovery State
		   e   Exit
		e   Exit   \/
		Enter Choice: 2
		localIp = 10.75.141.47 localName=Natal-47A remoteIp = 0.0.0.0 There is no remote PDB
		INELE IS NO LEMOCE FDD
		remoteBIp = 0.0.0.0 There is no remote B PDB mysqld is alive
		Local PDB database does not exist. Creating the local database ~~ /etc/init.d/Pdba stop ~~
		PDBA process is already stopped. Removing local pdba status file.
		Creating the remote database
28.	NOTE:	TRUNCATED OUTPUT
	The example output to the right has been truncated for brevity.	MyISAM file: /var/TKLC/epap/db/pdb/stats/pdbaStats.MYI is already checked Waiting for mysqlpdb to start done Removing local pdba status file.
		Removing remote pdba status file.

29.	<b>MPS A:</b> The Configure PDB Menu is displayed.	The Configure PDB Menu for Mixed EPAP: /Configure PDB Menu\
	Enter choice <b>e</b> , Exit. The Configure PDB Menu is displayed.	/\    1   Configure PDB Network
	Enter choice <b>e</b> , Exit.	2   RTDB Homing Menu
		3   Change MPS Provisionable State
		4 Create PDB
		5 Change Auto DB Recovery State
		6 Change PDBA Proxy State
		e   Exit   \/
		Enter Choice: e
		The Configure PDB Menu for Standalone PDB:
		/Configure PDB Menu\
		/\    1   Configure PDB Network   
		2   Create PDB
		3 Change Auto DB Recovery State
		e   Exit    /
		Enter Choice: e
30.	MPS A: The EPAP	
	MPS A: The EPAP Configuration Menu is displayed. Enter choice 1, Display Configuration.	

<b></b>		
		/\ /\
		1   Display Configuration
		2   Configure Network Interfaces Menu
		3   Set Time Zone
		4   Exchange Secure Shell Keys   
		5   Change Password
		   6   Platform Menu
		   7   Configure NTP Server
		   8   PDB Configuration Menu
		   9   Security
		   10   SNMP Configuration
		   11   Configure Alarm Feed
		   12   Configure Query Server
		   13   Configure Query Server Alarm Feed
		   14   Configure SNMP Agent Community   
		   15   Mate Disaster Recovery   
		   e   Exit    /
		Enter Choice: 1
31.	MPS A: The configuration	For Mixed EPAP and Non-Provisionable EPAP configured in IPv4 configuration,
	information is displayed. Verify that	the configuration data shall look like:
	the configuration data displayed is correct.	EPAP A Provisioning Network IP Address= 10.75.141.55EPAP A Provisioning Network IP Address v6= Not configuredEPAP B Provisioning Network IP Address= 10.75.141.56EPAP B Provisioning Network IP Address v6= Not configuredProvisioning Network Netmask= 255.255.255.128Provisioning Network Default Router= Not configuredProvisioning Network Default Router= 10.75.141.1Provisioning Network Default Router v6= Not configuredEPAP A Backup Prov Network IP Address= Not configuredEPAP A Backup Prov Network IP Address= Not configuredEPAP B Backup Prov Network IP Address= Not configuredEPAP B Backup Prov Network IP Address v6= Not configuredBackup Prov Network Netmask= Not configuredBackup Prov Network Netmask= Not configuredBackup Prov Network Default Router= Not configuredBackup Prov Network Address= 192.168.2.100EPAP B Sync Network Address= 192.168.2.200
		EPAP A Main DSM Network Address= 192.168.120.100EPAP B Main DSM Network Address= 192.168.120.200EPAP A Backup DSM Network Address= 192.168.121.100EPAP B Backup DSM Network Address= 192.168.121.200

	Trocedure 11: Configuring the Application		
		EPAP IP Version EPAP A HTTP Port EPAP A HTTP Port EPAP B HTTP SUEXEC Port EPAP A HTTP SUEXEC Port EPAP A Banner Connection Port EPAP A Banner Connection Port EPAP A Static NAT Address EPAP B Static NAT Address PDBI Port Remote MPS A Static NAT Address Remote MPS A Static NAT Address Remote MPS A HTTP Port Local Provisioning VIP Remote Provisioning VIP Local PDBA Address Local PDBA Address v6 0000:0000:0000:0000:0000:0000:0000 Remote PDBA B Address Remote PDBA B Address Time Zone PDB Database Preferred PDB Allow updates from alternate PDB Auto DB Recovery Enabled PDBA Proxy Enabled Press return to continue<	<pre>= IPv4 = 80 = 80 = 8001 = 8001 = 8473 = 8473 = Not configured = Not configured = 80 = Not configured = 10.75.141.55 = = 0.0.0.0 = America/New_York = Exists = 10.75.141.55 = Yes = No = No</pre>
		For Standalone PDB, the configuration data shall lo	ok like:
		EPAP A Provisioning Network IP Address EPAP B Provisioning Network IP Address Provisioning Network Netmask Provisioning Network Prefix Provisioning Network Default Router Provisioning Network Default Router v6 EPAP A Backup Prov Network IP Address EPAP A Backup Prov Network IP Address v6 Backup Prov Network Netmask Backup Prov Network Netmask Backup Prov Network Default Router Backup Prov Address PDB Address V6 Remote PDBA Address Fime Zone PDB Database	= 10.250.51.130 = Not configured = 255.255.255.128 = Not configured = 10.250.51.1 = Not configured = Not configured
32.	<b>MPS A:</b> The EPAP Configuration Menu is displayed. Enter choice <b>e</b> , Exit.	EPAP Configuration Menu for Non-Provision	al EPAP:

	Note: Skip this step for	/EPAP Configuration Menu\
	provisionable EPAP (mixed EPAP or	/\
	standalone PDB) and	1   Display Configuration   
	directly move to step 33.	2   Configure Network Interfaces Menu
		3   Set Time Zone
		4   Exchange Secure Shell Keys
		5   Change Password
		6   Platform Menu   
		7   Configure NTP Server
		8   PDB Configuration Menu
		9   Security
		10   SNMP Configuration
		   11   Configure Alarm Feed   
		12   Configure SNMP Agent Community
		13   Mate Disaster Recovery
		   14   DB Architecture Menu
		   e   Exit
		Enter Choice: e
		For Non-Provisionable EPAP, the following is displayed.
		INFO: Increasing rt volume size for Non-provisionable EPAP. Please wait INFO: db space increased on 'A'. INFO: Stopping Epap, mysqlapp and mysqlpdb services Done. INFO: Starting Epap, mysqlapp and mysqlpdb services Done. INFO: Successfully configured Non-provisionable EPAP.
33.	MPS A: The EPAP Configuration Menu is displayed. Select choice <b>6</b> , Platform Menu.	EPAP Configuration Menu for mixed EPAP:



		1	
		/EPAP Platform Menu-\ /\	
		1   Initiate Upgrade	
		2 Reboot MPS	
		3   MySQL Backup	
		4 PDB Backup	
		e   Exit	
		Enter Choice: 2	
		CAUTION: Rebooting this MPS will stop all EPAP processes will prevent updating of the RTDB until the EPAP software is automatically re-started when the system comes back up.	
35.	MPS A: For Mixed	For Mixed EPAP and Non-Provisionable EPAP, a prompt is displayed:	
	EPAP and Non- Provisionable EPAP	Reboot MPS A, MPS B or [BOTH]: <b><return></return></b>	
	you are prompted whether MPS A, MPS B		
	or BOTH sides are to be		
	rebooted. Select the default value of <b>BOTH</b>		
	by pressing Return.		
	In case of the	For Standalone PDB, the following is displayed.	
	Standalone PDB, no	Reboot local MPS	
	prompt is given and the server goes down for a reboot.	Broadcast message from root (pts/1) (Thu May 29 16:13:51 2014):	
		The system is going down for reboot NOW!	
36.			
	<b>MPS A:</b> Determine the mysqld multi log file	Refer to Procedure 14, step 4 and 5.	
	permissions are correct.		
37.	MPS A: The console		
	logon appears at the	<hostname> login: admusr Password:</hostname>	
	system prompt signifying the	Note: The console logon will be preceded by many lines of reboot output.	
	EPAP initial configuration is		
1	completed.		
38.	MDS A: Accort	Refer to Procedure 21 to accept the upgrade.	
	MPS A: Accept		
39.	Upgrade		
	MPS B: Determine the	Refer to Procedure 14, step 4 and 5.	
39.		Refer to Procedure 14, step 4 and 5.	
	<b>MPS B:</b> Determine the mysqld multi log file permissions are correct.	Refer to Procedure 14, step 4 and 5.	
	MPS B: Determine the mysqld multi log file	Refer to Procedure 14, step 4 and 5.         Repeat Procedure 21 on MPS B to accept upgrade.	
40. 41.	MPS B: Determine the mysqld multi log file permissions are correct. MPS B: Accept Upgrade Connected PDBonly:	Repeat Procedure 21 on MPS B to accept upgrade.         Execute Procedure A.21 only if the Non-Prov EPAP is installed and is connected to	
40.	MPS B: Determine the mysqld multi log file permissions are correct. MPS B: Accept Upgrade Connected PDBonly: Configure DSM Min	Repeat Procedure 21 on MPS B to accept upgrade.         Execute Procedure A.21 only if the Non-Prov EPAP is installed and is connected to Standalone PDB server. Otherwise, skip this step if –	
40. 41.	MPS B: Determine the mysqld multi log file permissions are correct. MPS B: Accept Upgrade Connected PDBonly:	Repeat Procedure 21 on MPS B to accept upgrade.         Execute Procedure A.21 only if the Non-Prov EPAP is installed and is connected to Standalone PDB server. Otherwise, skip this step if –	

42.	Reconnect console cables.	On E5-APP-B card, reconnect the console cable between the serial port labeled 'S0' on E5-APP-B B card's adapter and the serial port labeled 'S1' on the E5-APP-B A card's adapter and the console cable between the serial port labeled 'S0' on E5-APP-B A card's adapter and the serial port labeled 'S1' on the E5-APP-B B card's adapter. <b>Cable part numbers - 830-1220-xx</b>
43.	Procedure complete.	Procedure is complete.
44.	Note down the timestamp in log.	Run the following command: \$ date

# Procedure 12 Provision data from GUI

# Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as designated by customer)

S	This procedure provisio	This procedure provision 1 NE and 1 DN from GUI on Active Site.		
T E P	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.			
#	IF THIS PROCEDURE F	FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.		
# 1. 	Access the EPAP GUI by opening a web browser (Preferably IE) via HTTPS and providing the IP address of Server A. The EPAP LOGIN screen should appear.	The GUI screen on Mixed EPAP should look like: Image: Contract My ORACLE SUPPORTAND ASK FOR ASSISTANCE.         The GUI screen on Mixed EPAP should look like:         Image: Contract Contra		

2.	Login as uiadmin.	The GUI s	creen on M	lixed EPAP should look lik	ke:	
	Login as unadmin.	ORACLE	PDBA@ 10.75.141.47 A 10.75.141.47 STANDBY	STANDBY Alarms 00:00:00 UNK 🔴 👍	<ul> <li>PDBA@ 10.75.141.64</li> <li>PDBA@ 10.75.141.48</li> <li>PDBA@ 10.75.141.48</li> </ul>	ACTIVE Alarms 🗉 00:00:00 UNK 🔴 (3) (4) (1)
		COMMUNICATIONS	min .	CR MR		
		Select Mate	<u>A</u>			Logged in to EPAP A
		Maintenance     ATDB     Debug	NO	TICE: This is a private computer sys	stem. Unauthorized access or	use may lead to prosecution.
		Platform     PDBA     User Administral	tion Last 1	have been no failed login attempts since last login. ogin for uiadmin was on Wed March 08 2017 04:52:21	EST	
		Change Passwo	rd Thu M	arch 09 2017 00:31:18 EST		
				Copyright © 2	2000, 2017, Oracle and/or its affiliates. All rights res	served.
		The GUI s	creen on St	andalone PDB should look	k like:	
			PDBA@ 10.75.141.102	STANDBY	PDBA@ NONE	m
			A 10.75.141.102	314001	16:17:05 E	ST Alarms II
		EPAP A: uiadr				Logged in to EPAP A
		Process Control     Maintenance     Debug				
		Platform     PDBA     User Administral		TICE: This is a private computer sys have been no failed login attempts since last login.	stem. Unauthorized access or	use may lead to prosecution.
		Change Passwo	rd	ogin for uiadmin was on Wed March 08 2017 16:04:23	3 EST.	
			Thu H	arch 09 2017 16:17:02 EST	2000, 2017, Oracle and/or its affiliates. All rights re	earved
		The GUI s	creen on N	on-Prov EPAP should lool	k like:	
			PDBA@ 10.75.138.			
			PDBA@ 10.75.158.	77 STANDBY Alarn	ns 📳 PDBA@ NONE	Alarms 🗐
			_	23:53:01 EDT 🛛 🔴 🚺	2 0 R10.75.141.62	Alarms 📰 23:36:03 EDT 🔴 1 2
			<b>A</b> 10.75.141.61 ACTIVE	23:53:01 EDT 🥚 🚺 CR MA	2 0 R10.75.141.62	23:36:03 EDT 🕘 1 2 💭 CR MA MI IM
		COMMUNICATIONS	A10.75.141.61 admin	23:53:01 EDT 🛛 🔴 🚺	2 0 R10.75.141.62	23:36:03 EDT 🛛 😑 🕘
		COMMUNICATIONS EPAP A: ui Select Mate Process Cor Maintenance	A10.75.141.61 admin	23:53:01 EDT 🥚 🚺 CR MA	2 <b>B</b> STANDBY	23:36:03 EDT 0 2 CR MA MI M
		COMMUNICATIONS EPAP A: ui Select Mate Process Cor Maintenance ATDB C Debug Platform	A 10.75.141.61 admin	23:53:01 EDT er ma	2 <b>B</b> STANDBY	23:36:03 EDT 0 2 CR MA MI M
		COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance TRTDB Debug Platform User Admini Change Pas	A 10.75.141.61 admin atrol	23:53:01 EDT et a cr ma	computer system. Unaut	23:36:03 EDT 0 2 CR MA MI M
		COMMUNICATIONS EPAP A: ui Select Mate Process Cor Maintenance RTDB Debug Platform User Admini	A 10.75.141.61 admin atrol	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sinc Last login for uiadmin was on Sun June 10 2	computer system. Unaut	23:36:03 EDT 0 2 CR MA MI M
		COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance TRTDB Debug Platform User Admini Change Pas	A 10.75.141.61 admin atrol	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:41:33 EDT	computer system. Unaut	23:36:03 EDT CR MA M M Logged in to EPAP A thorized access or use may
		COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance TRTDB Debug Platform User Admini Change Pas	A 10.75.141.61 admin atrol	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:41:33 EDT	computer system. Unaut	23:36:03 EDT CR MA M M Logged in to EPAP A thorized access or use may
		COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance TRTDB Debug Platform User Admini Change Pas	A 10.75.141.61 admin atrol	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:41:33 EDT	computer system. Unaut	23:36:03 EDT CR MA M M Logged in to EPAP A thorized access or use may
		COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance TRTDB Debug Platform User Admini Change Pas	A 10.75.141.61 admin atrol	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:41:33 EDT	computer system. Unaut	23:36:03 EDT CR MA M M Logged in to EPAP A thorized access or use may
3.	On the Site designated	COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance TRTDB Debug Platform User Admini Change Pas	A 10.75.141.61 admin atrol	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:41:33 EDT	computer system. Unaut	23:36:03 EDT CR MA M M Logged in to EPAP A thorized access or use may
3.	On the Site designated by the customer Active	COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance TRTDB Debug Platform User Admini Change Pas	A 10.75.141.61 ACTIVE admin atrol stration sword	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts since Last login for uiadmin was on Sun June 10 2 Sun June 10 2016 23:41:33 EPT Copyright ©	computer system. Unaut	23:36:03 EDT CR MA M M Logged in to EPAP A thorized access or use may
	by the customer Active PDB GUI select	COMMUNICATIONS EPAP A: ui Select Mate Process Cor Maintenance Process Cor Debug Debug Platform Change Pas Logout	A 10.75.141.61 ACTIVE admin atrol stration sword	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2016 23:41:33 EDT Copyright © Ook like:	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may
	by the customer Active PDB GUI select "Switchover PDBA	COMMUNICATIONS EPAP A: ui Select Mate Process Cor Maintenance Process Cor Debug Debug Platform Change Pas Logout	A 10.75.141.61 ACTIVE admin atrol stration sword	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2016 23:41:33 EDT Copyright © Ook like:	computer system. Unaut	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may
	by the customer Active PDB GUI select	COMMUNICATIONS EPAP A: ui Select Mate Process Cor Maintenance Process Cor Debug Debug Platform Change Pas Logout	A 10.75.141.61 ACTIVE admin atrol stration sword	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2016 23:41:33 EDT Copyright © Ook like:	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may
	by the customer Active PDB GUI select "Switchover PDBA State" to make the PDBA Active.	COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance Process Cor Debug Debug Change Pas Logout	A 10.75-141.61 ACTIVE admin strol stration sword	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:41:33 EDT Copyright © Ook like:	Computer system. Unaut te last login. 1018 23:39:13 EDT 2000, 2018, Oracle and/or its affiliates. All	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may trights reserved.
	by the customer Active PDB GUI select "Switchover PDBA State" to make the PDBA Active.	COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance Platform User Admini Change Pas Logout	A 10.75-141.61 ACTIVE admin strol stration sword	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2016 23:41:33 EDT Copyright © Ook like:	Computer system. Unaut te last login. 1018 23:39:13 EDT 2000, 2018, Oracle and/or its affiliates. All	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may trights reserved.
	by the customer Active PDB GUI select "Switchover PDBA State" to make the PDBA Active. Debug Platform Select Other PDBA	COMMUNICATIONS EPAP A: UI Select Mate Process Cor Ministenance Construction Cons	A 10.75-141.61 admin atrol stration sword n should I re you sure ACTIVE?	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:41:33 EDT Copyright © Ook like:	Computer system. Unaut te last login. 1018 23:39:13 EDT 2000, 2018, Oracle and/or its affiliates. All	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may trights reserved.
	by the customer Active PDB GUI select "Switchover PDBA State" to make the PDBA Active. Debug Debug PIAtform PDBA Select Other PDBA Switchover PDBA State	COMMUNICATIONS EPAP A: UI Select Mate Process Cor Ministenance Construction Cons	A 10.75-141.61 admin strol stration sword	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:41:33 EDT Copyright © Ook like:	Computer system. Unaut te last login. 1018 23:39:13 EDT 2000, 2018, Oracle and/or its affiliates. All	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may trights reserved.
	by the customer Active PDB GUI select "Switchover PDBA State" to make the PDBA Active.	COMMUNICATIONS EPAP A: UI Select Mate Process Cor Ministenance Construction Cons	A 10.75-141.61 admin atrol stration sword n should I re you sure ACTIVE?	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:41:33 EDT Copyright © Ook like:	Computer system. Unaut te last login. 1018 23:39:13 EDT 2000, 2018, Oracle and/or its affiliates. All	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may trights reserved.
	by the customer Active PDB GUI select "Switchover PDBA State" to make the PDBA Active.	COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance Platform User Admini Change Pas Logout	A 10.75-141.61 admin atrol stration sword n should l re you sure ACTIVE? Switchover	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:41:33 EDT Copyright © Ook like:	Computer system. Unaut the last login. 1018 23:39:13 EDT 2000, 2018, Oracle and/or its affiliates. All	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may trights reserved.
	by the customer Active PDB GUI select "Switchover PDBA State" to make the PDBA Active. Pebug Platform PDBA Select Other PDBA Switchover PDBA State Process Control View PDBA Status Manage Data Authorized IP List DSM Info	COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance Platform User Admini Change Pas Logout	A 10.75-141.61 admin atrol stration sword n should l re you sure ACTIVE? Switchover	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts since Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:43:133 EDT Copyright © Ook like:	Computer system. Unaut the last login. 1018 23:39:13 EDT 2000, 2018, Oracle and/or its affiliates. All	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may trights reserved.
	by the customer Active PDB GUI select "Switchover PDBA State" to make the PDBA Active.	COMMUNICATIONS EPAP A: UI Select Mate Process Cor Maintenance Platform User Admini Change Pas Logout	A 10.75-141.61 admin atrol stration sword n should l re you sure ACTIVE? Switchover	23:53:01 EDT CR MA A NOTICE: This is a private of lead to prosecution. There have been no failed login attempts sind Last login for uiadmin was on Sun June 10 2 Sun June 10 2018 23:43:133 EDT Copyright © Ook like:	Computer system. Unaut the last login. 1018 23:39:13 EDT 2000, 2018, Oracle and/or its affiliates. All	23:36:03 EDT CR MA M M M Logged in to EPAP A thorized access or use may trights reserved.

Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as designated by customer)

4	T	<b>TT</b> 1 1 1 1 1	1 1'1			
4.	Click on the	The screen should l	look like:			
	"Switchover" button.	A		Switch	over PDBA	State
			CESS: Switchove TVE.	r successfully compl	leted from STANI	DBY to
		ACI	IVE.			
		Thu May 22	2 2014 15:49:35	EDT		
5.	PDBA should become	The screen should l	look like:			
	ACTIVE.	ORACLE'		ACTIVE PDBA@ NONE		Alarms
		COMMUNICATIONS A 10.75.141.102			16:30:01 EST	
6.		The screen should l	ook like:			
	On the ACTIVE PDBA site, select	А			Add an N	F
	PDBA→Manage Data→Network	<u>^</u>			Audanna	
	Entity → Add	ID to add:	(	Tunnal	SP ·	
	+ 🛄 Platform = 🔄 PDBA	ID to add.	Internetional a	Туре:	51 -	
	<ul> <li>Select Other PDBA</li> <li>Switchover PDBA State</li> <li>Process Control</li> </ul>	Point Code:	International •	Group Code:		
	<ul> <li>View PDBA Status</li> <li>S Manage Data</li> <li>IMSI</li> </ul>	Routing Indicator:	GT •	Subsystem Number	r:	
	IMSI Range     IMSI DN     DN     DN	Cancel Called Global Title:	NO •	New Nature of Address Indicator:		
	Add     Dotate     Delete	New Numbering Plan:		New Translation Type:		
	Belete     Retrieve     IMEI	Digit Action:	None •	SRF IMSI:		
	IMEI Block     Send PDBI Command     PROV BL	Add NE				
7.		The screen should l	ook like			
	Enter ID as "12345", select Type "RN" and	1.80	look like.			Add an NE
	select Point Code as	Α				Add an NE
	"None".	ID to add:	12345	Ту	pe:	RN 💌
		Point Code:	None 💌		roup Code:	
		Routing Indicator:	GT 💌	Su	ibsystem Number:	
		Cancel Called Global Title:	NO 💌		ew Nature of Address dicator:	
		New Numbering Plan:			ew Translation Type:	
		Digit Action:	None		RF IMSI:	
8.		The screen should l	ook like:			
	Click on the "Add NE" button. Network Entity	A			4	Add an NE
	should be successfully added.					
	สนับชิน.	SUCCESS:	Network Entity successful	y created.		
1						

Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as designated by customer)

9.	Select PDBA→Manage	The screen should look like:
	$Data \rightarrow Network$ Entity $\rightarrow Delete$	A Delete an NE
		ID to delete: Type: SP  Delete NE
10.	Enter ID as "12345" and	The screen should look like:
	select Type "RN".	A Delete an NE
		ID to delete: 12345 Type: RN V
		Delete NE
11.	Click on the "Delete NE" button. Network Entity should be	A Delete an NE
	successfully deleted.	SUCCESS: Network Entity successfully deleted.
12.	View PDBA Status	The screen should look like:
		A View PDBA Status
	PDBA     Select Other PDBA     Switchover PDBA State	PDBA@10.253.103.18 Status
	Process Control     View PDBA Status     Manage Data	Status:         ACTIVE         Version:         1.0           Level:         2         Birthday:         07/23/2009 15:56:51 GMT           DN Prefix:         IMSI Prefix:         IMSI Prefix:
	Authorized IP List     DSM Info	Counts: IMSIs=0, DNs=0, DN Blocks=0, NEs=0, IMEI Blocks=0, ASDs=0, DN_DNs=0, DNB_DNs=0
	Connections	RTDB Address Level
	PDBI Statistics Report	10.253.103.18 2 192.168.2.200 (mate) 2
		PDB@10.253.103.18 Status
		Status:       Database daemon is running         Counts:       IMSIs=0, DNs=0, DNBlocks=0, NEs=0, IMEIBlocks=0, ASDs=0, DN_DNs=0, DNB_DNs=0
13.	Procedure complete	Procedure is complete.
14.	Note down the	Run the following command:
	timestamp in log.	\$ date

Procedure 12: Provision data from GUI (Active Provisionable(mixed-EPAP or PDBonly) Site as designated by customer)

#### Procedure 13 Change DB Architecture

**Procedure 13: Change the DB Architecture** 

NOTE: Skip this procedure in following three cases:

- 1. EPAP 16.4 is a Mixed EPAP.
- 2. Extreme architecture is not required
- 3. The Eagle connected to EPAP has release 47.0.0.0.0 or earlier release.

S T E P	This procedure change the DB Architecture from COMPACT to eXtreme. Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number.				
#	IF THIS PROCEDURE FAILS, C	FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.			
1.	MPS A: Log in as epapdev user.	[hostname] consolelogin: epapdev password: <i>password</i>			
2.	MPS A: Log into epapconfig.	\$ sudo su - epapconfig			
3.	MPS A: The EPAP	Note: Start Pdba software before executing this operation.			
	Configuration Menu is displayed. Select choice 14 or 15, DB Architecture Menu	EPAP Configuration Menu for Non-Provisionable:			
		/\			
	Note: Select choice 14 on	1   Display Configuration   			
	Non-provisionable EPAP and 15 on PDBonly.	2   Configure Network Interfaces Menu			
		3   Set Time Zone			
		   4   Exchange Secure Shell Keys   			
		   5   Change Password   			
		6   Platform Menu			
		   7   Configure NTP Server			
		   8   PDB Configuration Menu   			
		9   Security			
		10   SNMP Configuration			
		   11   Configure Alarm Feed			
		12   Configure SNMP Agent Community			
		13   Mate Disaster Recovery			
		14   DB Architecture Menu			
		   e   Exit   \/			
		Enter choice: 14			
		EPAP Configuration Menu for standalone PDB:			

<ul> <li>5. MPS A: The DB Architecture Menu is</li> </ul>	DB Architecture: COMPACT         Skip this step if DB Architecture already set to eXtreme.
<ul> <li>MPS A: The DB Architecture Menu is displayed. Select choice 1, Display current DB Architecture</li> <li>Note: Default DB Architecture is displayed.</li> </ul>	/DB Architecture Menu
	<pre>/EPAP Configuration Menu /</pre>

	Change DB Architecture to eXtreme <b>NOTE:</b> It may be asked to stop the EPAP software if it is running. Stop it by answering 'Y'.	/DB Architecture Menu
		<pre>Enter Choice: 2 Example output Non-Provisionable EPAP: Caution: If this option is selected, the DB Architecture shall be changed     from Compact to eXtreme and this architecture cannot be reverted. WARNING: In order to complete this change in DB Architecture, you must perform RTDB conversion. Are you sure you want to change the DB Architecture from Compact to eXtreme? [N]: y EPAP software is running. Stop it? [N]: y EPAP software is running on mate MPS. Stop it? [N]: y INFO: DB ARCHITECTURE changed to eXtreme.</pre>
		Example output Standalone PDB:
		Caution: If this option is selected, the DB Architecture shall be changed from Compact to eXtreme and this architecture cannot be reverted. Please verify that all connected Non-Provisional Sites are running on eXtreme Architecture. It will take 30 minutes or more to populate the PDB 9Dig tables. Are you sure you want to change the DB Architecture from Compact to eXtreme? [N]: Y EPAP software is running. Stop it? [N]: Y PDBA software is running. Stop it? [N]: Y
		INFO: Populating the DN 9 Digit tables
		INFO: Populating the IMSI 9 Digit tables
		INFO: Populating the IMEI 9 Digit tables INFO: DB ARCHITECTURE changed to eXtreme.
		Press return to continue
6.	MPS A: The DB Architecture Menu is displayed. Select choice e, Exit	/DB Architecture Menu

		Enter Choice: e		
7.	MPS A: EPAP Configuration Menu is	/EPAP Configuration Menu\		
	displayed. Select choice e, Exit	1   Display Configuration		
		2   Configure Network Interfaces Menu		
		3   Set Time Zone		
		   4   Exchange Secure Shell Keys		
		   5   Change Password		
		   6   Platform Menu		
		   7   Configure NTP Server		
		   8   PDB Configuration Menu		
		   9   Security		
		   10   SNMP Configuration		
		   11   Configure Alarm Feed		
		   12   Configure Query Server		
		   13   Configure Query Server Alarm Feed		
		10   Configure SNMP Agent Community		
		15   DB Architecture Menu   		
		e   Exit   \/		
		Enter Choice: e		
8.	<b>MPS A:</b> Start Epap and Pdba software.	Start Epap and Pdba software to reflect the changes. Use the following command to start Epap:		
		<pre>\$ service Epap start</pre>		
	Note: Move to step 11 if it is configured as PDBonly.	~~ /etc/init.d/Epap start ~~ "EPAP_RELEASE" is set to "0.617" EPAP application start Successful.		
	Otherwise continue to next step.	t \$ service Pdba start		
		~~ /etc/init.d/Pdba start ~~ PDBA application start Successful.		
9.	MPS B: Log on Server B.	[hostname] consolelogin: epapdev password: <i>password</i>		
10.	MPS B: Start Epap software.	Start Epap software to reflect the changes. Use the following command to start Epap:		
		- coo che controlling commune co ocare coup		

		<pre>\$ service Epap start ~~ /etc/init.d/Epap start ~~ "EPAP_RELEASE" is set to "0.617" EPAP application start Successful.</pre>
11.	Procedure complete.	Procedure is complete.
12.	Note down the timestamp in log.	Run the following command: \$ date

# 6 SOFTWARE UPGRADE PROCEDURES

#### Procedure 14 Assess MPS server's readiness for upgrade

#### Procedure 14: Assess the MPS Server's Readiness for Upgrade

S	This procedure executes the steps required to assess the readiness of a system to be upgraded.					
T E	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.					
P #	F THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.					
1.	MPS B: Log in as the	If not already logged-in, then log in.				
	user "admusr".	<hostname> console login: admusr</hostname>				
		password: <password></password>				
2.	<b>MPS B:</b> Display the /etc/hosts configuration for the pdb entities.	If upgrading the first MPS B of a Provisionable mated pair, execute the following command to display the configuration of pdb entries:				
		\$ grep pdb /etc/hosts				
		Otherwise, skip to step 4.				
3.	<b>MPS B:</b> Verify the correct configuration for	Below is an example of the output of the grep command:				
	pdb entities in the /etc/hosts file.	192.168.55.176 host1-a pdba				
		192.168.61.76 host2-a prova-ip pdbb				
		If the command output contains 2 entries (pdba and pdbb are both configured), continue to the next step.				
		If the command output does not contain unique entries for pdba and pdbb, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F.				
4.	<b>MPS B:</b> Determine the mysqld multi log file permissions are correct.	Execute the following command to display the file properties of the mysqld_multi log file:				
	permissions are correct.	<pre>\$ ls -1 /var/TKLC/epap/db/mysqld_multi.log</pre>				
		-rw-rw-r 1 mysql mysql 5460 Jun 21 05:37 /var/TKLC/epap/db/mysqld_multi.log				
		If permissions are as displayed above skip next step.				
5.	<b>MPS B:</b> Verify the file permissions.	Ownerships and permissions of mysqld_multi.log should be set as mysql:mysql and 644 respectively. If it is not same as illustrated in above step 4 then change it using following command:				
		Execute the following command to change the ownership: \$ sudo chown mysql:mysql /var/TKLC/epap/db/mysqld_multi.log				
		Execute the following command to change the file permission: \$ sudo chmod 644 /var/TKLC/epap/db/mysqld_multi.log				
		Repeat above step 4 to verify ownerships and permissions of mysqld_multi.log .				
6.	MPS B: Display the	Execute the following command to display the presence of EPAP software ISO images:				
	contents of the /var/TKLC/upgrade directory.	\$ ls -la /var/TKLC/upgrade				
Unan	ade/Installation Guide	105 of 279 August 2024				

#### Procedure 14: Assess the MPS Server's Readiness for Upgrade

		<b>Note:</b> The file permissions and ownership may vary due to the different methods used to transfer the file.
		Below is an example of the output of the 'ls -la' command for EPAP16.2: [root@Natal-A upgrade]# ls -la total 1785996
		drwxrwxr-x.         3 root admgrp         4096 Jun 23 01:19 .           dr-xr-xr-x.         21 root root         4096 Jun 23 00:00           -rr-n         1 root root         904644608 Jun 23 01:19 EPAP-16.2.0.0.1_162.26.0-x86_64.iso
7.	<b>MPS B:</b> Delete old ISO images.	Remove any ISO images that are not the target software ISO image using the following command:
		# sudo rm -f /var/TKLC/upgrade/ <filename></filename>
		Refer to step 6 to display the content of /var/TKLC/upgrade directory. Removed ISO should not be displayed.
8.	MPS B: Determine when last reboot	\$ uptime
	occurred. For any server up longer than 180 days would be a candidate for reboot during a maintenance window.	15:19:34 up 23 days, 3:05, 2 users, load average: 0.10, 0.13, 0.09
9.	<b>MPS B:</b> Disk Integrity step: Executing self-test on the disk.	Execute the following command: \$ sudo smartctl -t short /dev/sda
	on the disk.	The output on E5-APP-B card would be like:
		<pre>smartctl 5.43 2012-06-30 r3573 [x86_64-linux-2.6.32- 642.6.2.el6prerel7.4.0.0.0_88.32.0.x86_64] (local build) Copyright (C)2002-12 by Bruce Allen, http://smartmontools.sourceforge.net</pre>
		=== START OF OFFLINE IMMEDIATE AND SELF-TEST SECTION === Sending command: "Execute SMART Short self-test routine immediately in off-line mode".
		Drive command "Execute SMART Short self-test routine immediately in off-line mode" successful. Testing has begun.
		Please wait 1 minutes for test to complete. Test will complete after Sat Feb 25 22:08:20 2017
		Use smartctl -X to abort test. Note: Please wait for 5 minutes for the test to complete.
10.	MPS B: Disk Integrity	•
		Ensents the following common to
	step.	Execute the following command:
	Contact My Oracle	\$ sudo smartctl -l selftest /dev/sda
	Contact My Oracle Support if the output shows any error/failure.	The output on E5-APP-B card would be like:
		<pre>smartctl 5.43 2012-06-30 r3573 [x86_64-linux-2.6.32- 642.6.2.el6prerel7.4.0.0.0_88.32.0.x86_64] (local build) Copyright (C) 2002-12 by Bruce Allen, bttp://dmpretmenteels.coursesforce.pet</pre>
		http://smartmontools.sourceforge.net
		СПАРП ОГ РЕАР СМАРП РАПА СРОПТОМ
		=== START OF READ SMART DATA SECTION ===
		SMART Self-test log structure revision number 1 Num Test Description Status Remaining
		LifeTime(hours) LBA of first error
		# 1 Short offline Completed without error 00% 12435

Procedure 14: Assess the MPS Server's Readiness for Upgrade

	•••						
11.	MPS B: Disk Integrity	Execute the following command:					
	step	\$ sudo smartctl -a /dev/sda   grep -i LBA					
	Contact My Oracle Support if any output shows "Completed: read failure" or "Error: UNC xxx sectors".	The output would be like: 241 Total_LBAs_Written 0x0032 100 100 000 Old_age Always - 340851 242 Total_LBAs_Read 0x0032 100 100 000 Old_age Always - 1689714 Num Test_Description Status Remaining LifeTime(hours) LBA_of_first_error SPAN MIN_LBA MAX_LBA CURRENT_TEST_STATUS					
12.	<b>MPS B:</b> Disk Integrity Test.	Repeat steps 9 to 11 for the /dev/sdb disk drive on E5-APP-B card:					
13.	MPS B: Logout from "admusr".	Logout from the "admusr" user by executing the following command: <b>\$ exit</b>					
14.	<b>MPS A:</b> Repeat checks on Server A.	Repeat steps-1 to 13 on MPS A.					
15.	Procedure Complete.	This procedure is complete.					
16.	Note down the timestamp in log.	Run the following command: \$ date					

# Procedure 15 Pre and Post Upgrade Backups

#### **Procedure 15: Pre and Post Upgrade Backups**

S T	This procedure performs the pre and post upgrade backups.		
E P	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.		
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.		
1.	<b>MPS A:</b> Backup system configuration on MPS A.	Execute Procedure A.3 to backup the system configuration on MPS A.	
2.	MPS B: Backup system configuration on MPS B.	Execute Procedure A.3 to backup the system configuration on MPS B.	
3.	MPS B: Backup RTDB database.	Execute Procedure A.7 to backup the RTDB database on MPS B.	
4.	<b>MPS A:</b> Backup PDB database.	Execute Procedure A.6 to backup the PDB on MPS A of the Active PDBA. NOTE: Only execute this step if the MPS-A is configured as a Provisionable node. Check the output of Procedure 2, step 9 to verify if MPS A is Provisionable or not.	
5.	<b>MPS A:</b> Backup EuiDB database.	Execute Procedure A.8 to backup the EuiDB database on MPS A.	
6.	Procedure Complete.	This procedure is complete.	
7.	Note down the timestamp in log.	Run the following command: <b>\$ date</b>	

#### Procedure 16 Pre-upgrade system time check

**Procedure 16: Pre-Upgrade System Time Check** 

#

 S
 This procedure performs the pre-upgrade system time check.

 T
 F

 E
 Check off (𝔅) each step as it is completed. Boxes have been provided for this purpose under each step number.

 P
 T

IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.

The MPS servers make use of NTP to keep time synchronized between servers. Under some circumstances, either at initial installation in the customer's network or due to power interruption and battery failure, it is possible for an MPS server to have a system date/time value too large for NTP to correct. If the system time is 20 minutes or more off from the real time, NTP cannot correct it.

Check the date/time on *both* MPS-A and MPS-B servers, and correct the system time on any server off by more than 15 minutes from the real time.

1.	<b>MPS A:</b> Login as the user "epapdev".	If not already logged-in, then login at MPS A: <hostname> console login: epapdev password: <password></password></hostname>
2.	<b>MPS A:</b> Execute the "date" command.	Execute the "date" command and examine the result. <b>\$ date</b> Sat Feb 25 22:09:58 EDT 2018
3.	<b>MPS B:</b> Login as the user "epapdev".	If not already logged-in, then login at MPS B: <hostname> console login: epapdev password: <password></password></hostname>
4.	<b>MPS B:</b> Execute the "date" command.	Execute the "date" command and examine the result. <b>\$ date</b> Sat Feb 25 22:09:58 EDT 2018
5.	Compare result to the real time.	Compare the result from the "date" command in the previous step to the real time. If the difference is 15 minutes or less, then this procedure is complete, otherwise if the difference exceeds 15 minutes, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F.
6.	Procedure Complete.	This procedure is complete.
7.	Note down the timestamp in log.	Run the following command: \$ date

#### Procedure 17 Check 9dig counts before moving to eXtreme architecture

#### Procedure 17: Check 9dig counts before moving to eXtreme architecture

Note: This step is only required before converting DB architecture from Compact to Extreme S This procedurechecks the 9dig counts for all DN/IMSI and IMEI. Т Ε

Check off ( $\sqrt{}$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.

IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.

#### Verify the PDB data are within 9dig limitation

Maximum 9dig limit for DN: 65K Maximum 9dig limit for IMSI: 65K Maximum 9dig limit for IMEI: 250K

Р

#

1.	MPS A: Login as the	If not already logged-in, then login at MPS A:	
	user "epapdev" on	<hostname> console login: epapdev</hostname>	
	standalone PDB.	password: <password></password>	
2.	MPS A: Execute the	Execute the "parse9Dig" script and examine the result.	
Ш	"parse9Dig" script on standalone PDB.	Note: Stop the Pdba software before executing this script.	
	standarone i BB.	The stop file I and software before executing this seript.	
		\$ /usr/TKLC/epap/config/parse9Dig all c	
		Get reference from the following snapshot:	
		<pre>[epapdev@Osorna-1B-PDBonly config]\$ /usr/TKLC/epap/config/parse9Dig all c</pre>	
		This utility will retrieve all digits for DB and parse them into 9Dig entries.	
		Utility Start Time: 06/13/18-20:51:48	
		Parsing DN digits into 9digits	
		INFO: DN 9dig count 2.	
		Parsing IMSI digits into 9digits	
		INFO: IMSI 9dig count: 9.	
		Parsing IMEI digits into 9digits	
		INFO: IMEI 9dig count: 1.	
		Utility End Time: 06/13/18-20:51:48 [epapdev@Osorna-1B-PDBonly config]\$	
		If any of the data type from DN/IMSI and IMEI exeeds the 9Dig limit, then DB Architecture cannot be changed to eXtreme.	
3.	MPS A: Start Pdba	\$ service Pdba start	
	software.	~~ /etc/init.d/Pdba start ~~ PDBA application start Successful.	
4.	<b>MPS A:</b> Procedure is complete.	This procedure is complete.	
5.	Note down the	Run the following command:	
Ц	timestamp in log.	\$ date	

S	This procedure upgrades MPS B server.			
T E	Check off ( $$ ) each step	as it is completed. Boxes have been provided for this purpose under each step number.		
P #	IF THIS PROCEDURE F	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.		
1.				
	Notify the potential use	rs not to start the PDBA software during the duration of the upgrade.		
		d EPAP or PDBonly) upgrade must complete before the Non-Provisionable EPAP. For ding EPAP Non-Provisionable MPS Servers.		
2.	Establish a connection to MPS B.	If access to the MPS servers is not available through an IP network, connect to the E5- APP-B card via the serial port.		
		For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A card's adapter and use it for serial access. <b>Cable part numbers - 830-1220-xx</b>		
		Skip to step 7, if connected through serial console.		
3.	Create a terminal window and establish a connection by logging into MPS A.	In a newly created terminal window labeled "MPS B – from MPS A", connect directly into MPS A.		
	Log in to MPS A.	# ssh admusr@ <mps a=""> Password: <password></password></mps>		
4.	MPS A: Start screen session.	Execute the following commands to start screen and establish a console session to MPS B.		
		\$ screen -L		
	<b>MPS A</b> : Connect to the console of MPS B.	Execute the following command on E5-APP-B:		
		\$ sudo minicom mate		
		If above command fails then refer to Procedure A.27.		
5.	<b>MPS B</b> : Login prompt is displayed.	<pre><hostname> console login: Note: Hit enter if no login prompt is displayed.</hostname></pre>		
6.	<b>MPS B:</b> Log in to the server as the user "epapdev".	<hostname> console login: epapdev password: <password></password></hostname>		
7.	<b>MPS B</b> : Determine media available for upgrade.	Perform Procedure A.12 or use an EPAP ISO image to perform upgrade.		
8.	<b>MPS B:</b> Verify that it is an Incremental Upgrade or a Major upgrade	Check Procedure 2, Step 7 and 8. If the upgrade type is a split mirror upgrade, proceed with the following step. If it's Incremental, proceed to step 11		

9.		Execute the following command to disable the syscheck fs module.
	<b>MPS B</b> : Disable syscheck fs module.	\$ su - root Password:
		# syscheckAdmdisable disk fs
10.	<b>MPS B:</b> Create upgrade.conf for splitting mirrors.	Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:
		<pre>1.#vi/usr/TKLC/plat/etc/upgrade/upgrade.conf 2.If file already contains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line: BACKOUT_TYPE=SPLIT_MIRROR</pre>
		NOTE: Not performing this step will prevent any successful backout.
		Execute the following command to verify that the above command has been executed successfully:
		<pre># cat /usr/TKLC/plat/etc/upgrade/upgrade.conf</pre>
		The output should be:
		<pre>[root@MPS-B ~]# cat /usr/TKLC/plat/etc/upgrade/upgrade.conf BACKOUT_TYPE=SPLIT_MIRROR</pre>
		# su – admusr
11.	MPS A: Log in to the server as the user "admusr".	login to MPS A:
		<hostname> console login: admusr password: <password></password></hostname>
12.	<b>MPS A:</b> Check if eagle_alarm_feed	Run below command to check if uiEdit variable is present or not.
	variable is present in	\$ uiEdit   grep "EAGLE_ALARM_FEED"
	EuiDB	"EAGLE_ALARM_FEED" is set to "ON"
		Note: If no output is displayed after above command is run, then run next step else skip next step.
13.	<b>MPS A:</b> Insert EAGLE_ALARM_F EED variable in	NOTE: Skipping this step if EAGLE_ALARM_FEED variable is not present in EuiDB will cause upgrade to fail Run below command to insert missing variable in EuiDB.
	EuiDB	<pre>\$ /usr/bin/mysql -uroot -p<password> -B EuiDB -e "insert into econfig values ('EAGLE_ALARM_FEED','ON')"</password></pre>
		Charle if a barry common damage and a failed a contract should be an disclosed below.
		Check if above command was successful. Output should be as displayed below: \$ echo \$?
		0
		Repet Step 12 to check if value is inserted successfully in DB.
		Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if this step fails.

14.	<b>MPS A:</b> Verify that the state of PDBA	# sudo su - epapconfig
	Proxy Feature is No. <b>Note: S</b> kip this step	/EPAP Configuration Menu\
	for Non-Prov and PDBonly EPAP.	1   Display Configuration
	r Dbolliy Er Ar.	
		2   Configure Network Interfaces Menu
		3   Set Time Zone   
		4   Exchange Secure Shell Keys   
		5   Change Password   
		6   Platform Menu
		7   Configure NTP Server
		8   PDB Configuration Menu
		9   Security
		10   SNMP Configuration
		   11   Configure Alarm Feed   
		12   Configure Query Server
		13   Configure Query Server Alarm Feed
		14   Configure SNMP Agent Community
		15   Mate Disaster Recovery
		   e   Exit
		Enter Choice: 1 EPAP A Provisioning Network IP Address = 192.168.61.115 EPAP B Provisioning Network IP Address = 192.168.61.116 Provisioning Network Netmask = 255.255.0 Provisioning Network Default Router = 192.168.61.1 EPAP A Backup Prov Network IP Address = Not configured Backup Prov Network Netmask = Not configured Backup Prov Network Netmask = Not configured Backup Prov Network Default Router = Not configured Backup Prov Network Address = 192.168.2.100 EPAP A Sync Network Address = 192.168.2.200 EPAP A Main DSM Network Address = 192.168.120.100 EPAP B Main DSM Network Address = 192.168.120.100 EPAP B Backup DSM Network Address = 192.168.120.200 EPAP A Backup DSM Network Address = 192.168.121.200 EPAP B Backup DSM Network Address = 192.168.121.200 EPAP B HTTP Port = 80 EPAP A HTTP SuExec Port = 8001 EPAP B HTTP SuExec Port = 8001 EPAP B Banner Connection Port = 8473 EPAP A Static NAT Address = Not configured EPAP B Static NAT Address = Not configured

**Upgrade/Installation Guide** 

		PDBI Port Remote MPS A Static NAT Address Remote MPS A HTTP Port Local Provisioning VIP Remote Provisioning VIP Local PDBA Address Remote PDBA Address Remote PDBA B Address Time Zone PDB Database Preferred PDB Allow updates from alternate PDB Auto DB Recovery Enabled PDBA Proxy Enabled If PDBA Proxy Enabled = Yes then Execu Active and Standby for dual PDBA setup to disa features. Otherwise, if PDBA Proxy Enabled = No, then ski	able EPAP VIP and PDBA proxy
15.	MPS A: Clear PDB replication logs	If PDBA Proxy Enabled = Yes then Execu logs Otherwise, if PDBA Proxy Enabled = No, then ski	
16.	<b>MPS A</b> : Choose "e" to exit.	MPS Side A:	

		/EPAP Configuration Menu\	
		/\   1   Display Configuration	
		   2   Configure Network Interfaces Menu	
		   3   Set Time Zone	
		   4   Exchange Secure Shell Keys	
		   5   Change Password	
		   6   Platform Menu	
		   7   Configure NTP Server	
		   8   PDB Configuration Menu	
		   9   Security	
		   10   SNMP Configuration	
		   11   Configure Alarm Feed	
		   12   Configure Query Server	
		   13   Configure Query Server Alarm Feed   	
		14   Configure SNMP Agent Community	
		15   Mate Disaster Recovery	
		   e   Exit	
		\/	
		Enter Choice: e	
17.	<b>MPS B:</b> Log in to the server as the user	login to MPS B if not already logged in:	
	"admusr".	<hostname> console login: admusr password: <password></password></hostname>	
18.	<b>MPS B:</b> Execute the platcfg menu.	\$ sudo su – platcfg	
19.	<b>MPS B</b> : Select the Maintenance submenu.	The platcfg <b>Main Menu</b> appears. On the <b>Main Menu</b> , select <b>Maintenance</b> and press [ENTER].	

		Main Menu Maintenance Diagnostics Server Configuration Network Configuration Remote Consoles Exit	
20.	<b>MPS B</b> : Select the Upgrade submenu.	Select the Upgrade menu and press [ENTER].	
21.	MPS B: Select Early Upgrade Checks	Select the "Early Upgrade Checks" menu to verify that the system is ready for upgrade.          Upgrade Menu         Validate Media         Early Upgrade Checks         Initiate Upgrade         Copy USB Upgrade Image         Non Tekelec RPM Management         Exit         If the Early Upgrade Checks fail due to the NTP related alarms, then execute step 22.         Otherwise, skip to step 23.         Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the early upgrade checks fail due to any other reason.	
22.	MPS B: Allow List NTP Alarms	<ol> <li>If the Early Upgrade Checks fail due to the NTP related alarms, then ignore the NTP alarms using the following commands:         <ul> <li>Exit the platcfg menu</li> <li>Change to root user using the "su –" command.</li> <li>vim /usr/TKLC/plat/etc/upgrade/upgrade.conf</li> <li>Edit the following line to include the NTP related alarms. EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2</li> </ul> </li> <li>For example – To allowlist the NTP alarm "tpdNTPDaemonNotSynchronizedWarning" which has the alarm code TKLCPLATMI10, the above mentioned line should be edited as EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2,TKSPLATMI10</li> <li>Note: There should not be any space between two alarms i.e. between TKSPLATMI2 and TKSPLATMI10</li> </ol>	

		2) If the Early Upgrade Checks fail due to "Server Default Route Network Error", then this alarm shall be allowlisted in upgrade.conf file. To allowlist this alarm which has the alarm code TKSPLATMA14, the above mentioned line should be edited as EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2,TKSPLATMI10, TKSPLATMA14	
23.	<b>MPS B</b> : Select Initiate Upgrade.	Select the Initiate Upgrade menu and press [ENTER]. Upgrade Menu Validate Media Early Upgrade Checks Initiate Upgrade Copy USB Upgrade Image Non Tekelec RPM Management Exit	
24.	MPS B: Select the Upgrade Media.	The screen will display a message that it is searching for upgrade media. Once the upgrade media is found, an Upgrade Media selection menu will be displayed similar to the example shown below. Select the upgrade media on ISO image. There should only be one selection available, as shown in the example below. If there is more than one selection available, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F. lqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqq	
25.	MPS B: Upgrade proceeds.	The screen displays the following, indicating that the upgrade software is first running the early upgrade checks, and then proceeding with the upgrade. Replacing <seconds> with the value from the log. Starting Early Upgrade Checks at 1448399773 Running earlyUpgradeChecks() for Upgrade::EarlyPolicy::TPDEarlyChecks upgrade policy Verified server is not pending accept of previous upgrade Hardware architectures match Install products match. Whitelisted alarms: Verified alarms: Verified alarms free! Verified all raid mirrors are synced. Early Upgrade Checks Have Passed! Early Upgrade Checks finished at 1448399780 Initializing upgrade information</seconds>	
26.	<b>MPS B</b> : Upgrade proceeds.	Many informational messages will come across the terminal screen as the upgrade proceeds. Finally, after upgrade is complete, the server will reboot.	
27.	<b>MPS B</b> : Upgrade completed.	After the final reboot, Press Enter the screen will display the login prompt, as shown in the example below.	

		Starting smartd: [ OK ] Daemon is not running
		AlarmMgr daemon is not running, delaying by 1 minute
		TKLChwmgmtcli stop/pre-start, process 9750
		TPDhpDiskStatus stop/pre-start, proces
		s 9782
		Oracle Linux Server release 6.9
		Kernel 2.6.32-696.20.1.el6prerel7.6.0.0.0_88.47.0.x86_64 on an x86_64
		Arica-A login:
28.	<b>MPS B</b> : Log in to the	After upgrade, exit from the console and open new console using
	server as the user	EPAP IP and login by epapdev user.
	"epapdev".	<pre><hostname> console login: epapdev</hostname></pre>
		password: <password></password>
		Net The COULT is a feature to be the state of the second state of
		Note: The SSH login for root shall get enabled after the upgrade.
29.	<b>MPS B</b> : Verify the	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no
	Upgrade.	errors and warnings were reported.
1		Check Procedure 2, Steps 7 and 8 to determine whether it is incremental or major
1		upgrade.
		If it is major upgrade, then consider following error and warning.
		<pre>\$ grep -i error /var/TKLC/log/upgrade/upgrade.log</pre>
		Following errors shall be observed:
		1530712922::ERROR: Config file is currently checked out!
		1530712922::ERROR: LOCKED BY: platcfg 1530712922::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf
		1530712922::ERROR: ELEMENT: /var/TKLC/rcs/usr/TKLC/plat/etc/vlan.conf,v
		1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI'
		1530669414::myisamchk: error: 140 when opening MyISAM-table
		'/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI'
		1530669414::
		1530669414:: 1530669414::myisamchk: error: 140 when opening MyISAM-table
		'/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table
		1530669414::myisamchk: error: 140 when opening MyISAM-table
		'/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414::
		1530669414:: 1530669414::
		1530669414::myisamchk: error: 140 when opening MyISAM-table
		1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'
		1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'
		·
		•
		•
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
1		
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
		· ·
		•
1		1533053832::Sorry, user root is not allowed to execute '/bin/chown
		epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136.
••	ade/Installation Guide	117 of 279 August 2024

1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136.
·
530094474::libsemanage.semanage_reload_policy: load_policy returned error code
1530094474::libsemanage.semanage_reload_policy: load_policy returned error code 2.
1494304768::ERROR: Config file is currently checked out!1494304781::ERROR: LOCKED BY: platcfg1494304781::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf1494304781::ERROR: ELEMENT: /var/TKLC/plat/etc/vlan.conf,v1494304781::ERROR: Table 'mysql.innodb_index_stats' doesn't exist1496215832::Error : Table 'mysql.innodb_table_stats' doesn't exist1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist1496215832::Error : Table 'mysql.slave_master_info' doesn't exist1496215832::Error : Table 'mysql.slave_master_info' doesn't exist1496215832::Error : Table 'mysql.slave_master_info' doesn't exist1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist1496215832::Error : Table 'mysql.slave_master_info' doesn't exist1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist1496215832::Error : Table 'mysql.slave_master_info' doesn't exist
1496215832::Error : Table 'mýsql.slave_relay_log_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist
<b>Following statement for missing binary file shall be observed in upgrade.log:</b> 1530885808::/bin/df: `/mnt/ugchroot/sys': No such file or directory 1542631084::./upgrade_mysql: line 46: /usr/TKLC/epap/bin/pass_fetch: No such file or directory
[NOTE: It is observed only when MySQL upgraded from earlier version than 5.6.18 to version 5.7]
Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any error other than the above mentioned errors.
Also note that sometime a carriage return is inserted in the log file causing some of the error messages to appear truncated. This is acceptable and should be ignored.
<pre>\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log</pre>
Examine the output of the above command to determine if any warnings were reported. Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any warnings beside the following:
1488951825::warning: CAPABILITY: service_hp-asrd_disabled 1488951825::WARNING: /usr/TKLC/plat/etc/alarms/alarms.xml has been
updatedreparsing xml 1530712185::WARNING: This capability is not defined in the default capabilities.
1530712186::WARNING: Nor is it defined in the current hardware ID's capabilities.
1530712186::WARNING: CAPABILITY: servicedisabled 1530712186::WARNING: HARDWARE ID: E5APPB 1488951890::warning: erase unlink of /lib/modules/2.6.32-
573.18.1.el6prerel7. 0.3.0.0_86.44.0.x86_64/weak-updates failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32-
573.18.1.el6prerel7. 0.3.0.0_86.44.0.x86_64/modules.softdep failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32- 573.18.1.el6prerel7.
0.3.0.0_86.44.0.x86_64/modules.order failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32- 573.18.1.el6prerel7.
0.3.0.0_86.44.0.x86_64/modules.networking failed: No such file or directory 1488951902::warning: erase unlink of /lib/modules/2.6.32- 573.18.1.el6prerel7. 0.3.0.0_86.44.0.x86_64/modules.modesetting failed: No such file or directory
1 0.5.0.0_00.44.0.X00_04/modules.modesecting latted. No such the of affectory

**Upgrade/Installation Guide** 

Thecaure 18: Opgrade Se		
	1488951902::warning: erase unlink o 573.18.1.el6prerel7.	of /lib/modules/2.6.32-
	0.3.0.0_86.44.0.x86_64/modules.drm fai 1488951902::warning: erase unlink o	led: No such file or directory f /lib/modules/2.6.32-
	573.18.1.el6prerel7. 0.3.0.0_86.44.0.x86_64/modules.block f 1488951903::kexec-tools /et	ailed: No such file or directory #warning: /etc/kdump.conf created as
	/skdump.conf.rpmnew 1488952115::ca-certificates /etc/pki/tls/ce	<i>###############</i> warning:
	rts/ca-bundle.crt created as /etc/pki/ 1488952136::samhain /etc/	'tls/certs/ca-bundle.crt.rpmnew warning: /etc/samhainrc created as
	samhainrc.rpmnew 1488952138::php-common /etc/p	<pre>#warning: /etc/php.ini created as</pre>
	hp.ini.rpmnew 1488952209::initscripts /	##warning: /etc/sysctl.conf created as
	étc/sysctl.conf.rpmnew 1488952260::mysql-commercial-server /etc/my.	warning: /etc/my.cnf created as
	cnf.rpmnew 1488952291::ntp /etc/n	warning: /etc/ntp.conf created as
	tp.conf.rpmnew 1488952302::TKLCplat /usr/TKLC/plat/	<i>###############</i> warning:
	etc/pid_conf created as /usr/TKLC/plat 1488952302::#warning: /usr/TKLC/plat/e /usr/TKLC/plat/	:/etc/pid_conf.rpmnew :tc/service_conf created as
	etc/service_conf.rpmnew 1488952320::TKLCalarms /usr/TKLC/plat/etc/alarms/al	###warning:
	arms.xml saved as /usr/TKLC/plat/etc/a 1488952328::alarmMgr /usr/TKLC/plat/etc/alarmMgr/	###warning:
	alarmMgr.conf created as /usr/TKLC/pla 1488952471::WARNING: This capability i capabilities.	t/etc/alarmMgr/alarmMgr.conf.rpmnew s not defined in the default
	1488952471::WARNING: Nor is it defined capabilities	l in the current hardware ID's
	1488952471::WARNING: CAPABILITY: serv 1488952471::WARNING: HARDWARE ID: E5AP 1488952602::sudo /etc/su	
	doers.rpmnew 1488952709::WARNING: /usr/TKLC/plat/et updated	c/alarms/alarms_mps.xml has been
	.reparsing xml 1488952718::TKLCepap-HA ####################################	
	N	root of /usr/TKLC/epap/bin/dbMigration failed: 0
	such file or directory 1488952949::WARNING: Module variable E 1488952951::WARNING: CONFIG:	
	<pre>/usr/TKLC/plat/lib/Syscheck/modules/sy ig 1488952951::WARNING: Module variable E</pre>	
	1488952951::WARNING: CONFIG: /usr/TKLC/plat/lib/Syscheck/modules/sy ig	·
	If it is an incremental upgrade, warning	then consider following error and
	\$ grep -i error /var/TKLC/log/u	upgrade/upgrade.log
	Following errors shall be observed:	
	1530712922::ERROR: Config file is curr 1530712922::ERROR: LOCKED BY: platcfg 1530712922::ERROR: CONFIG: /usr/TKL 1530712922::ERROR: ELEMENT: /var/TKL	rently checked out! .C/plat/etc/vlan.conf .C/rcs/usr/TKLC/plat/etc/vlan.conf,v
	1530669414::myisamchk: error: 140 when '/var/TKLC/epap/db/pdb/mysql/columns_p 1530669414::myisamchk: error: 140 when '/var/TKLC/epap/db/pdb/mysql/columns_p 1530669414::	priv.MYI' n opening MyISAM-table

**Upgrade/Installation Guide** 

1530669414:: 1530669414:: 1530669414::myisamchk: error: 140 when opening MyISAM-table //var/TKLC/epap/db/pdb/mysql/db.MYI'
1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414::
1530669414:: 1530669414:: 1530669414::myisamchk: error: 140 when opening MyISAM-table //var/TKLC/epap/db/pdb/mysql/event.MYI'
1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
•
1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136. 1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136.
·
530094474::libsemanage.semanage_reload_policy: load_policy returned error code
1530094474::libsemanage.semanage_reload_policy: load_policy returned error code 2.
.1494304768::ERROR: Config file is currently checked out! 1494304781::ERROR: LOCKED BY: platcfg 1494304781::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf 1494304781::ERROR: ELEMENT: /var/TKLC/rcs/usr/TKLC/plat/etc/vlan.conf,v 1496215832::Error : Table 'mysql.innodb_index_stats' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist 1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist 1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't
<b>Following statement for missing binary file shall be observed in upgrade.log:</b> 1530885808::/bin/df: `/mnt/ugchroot/sys': No such file or directory 1542631084::./upgrade_mysql: line 46: /usr/TKLC/epap/bin/pass_fetch: No such file or directory [NOTE: It is observed only when MySQL upgraded from earlier version than 5.6.18 to version 5.7]
Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any error other than the above mentioned errors. Also note that sometime a carriage return is inserted in the log file causing some of the
error messages to appear truncated. This is acceptable and should be ignored.

	<pre>\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log</pre>
	Examine the output of the above command to determine if any warnings were reported. Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any warnings beside the following:
	1489042076::WARNING: /usr/TKLC/plat/etc/alarms/alarms.xml has been updatedrep arsing xml 1489042124::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 .0.0.0_88.32.0.x86_64/weak-updates failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 .0.0.0_88.32.0.x86_64/modules.order failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 .0.0.0_88.32.0.x86_64/modules.order failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 .0.0.0_88.32.0.x86_64/modules.networking failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-
	1489042136::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 0.0.0_88.32.0.x86_64/modules.modesetting failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 .0.0_88.32.0.x86_64/modules.drm failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 .0.0_88.32.0.x86_64/modules.block failed: No such file or directory 1489042197::WARNING: /usr/TKLC/plat/etc/alarms/alarms_mps.xml has been updated. .reparsing xml
	Refer to section 0 to know more about logging. <b>NOTE:</b> provRMTP core might be observed on EPAP after upgrade, if the EPAP is connected to EAGLE. The core should be ignored, it has no impact on traffic running from EPAP to EAGLE.
<b>MPS B</b> : Verify the Upgrade.	<pre>\$ grep "Upgrade returned success" /var/TKLC/log/upgrade/upgrade.log</pre>
	Verify that the message "Upgrade returned success!" is displayed. If it is not, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F.
	1400786220:: Upgrade returned success!
	After upgrade check for PDB_SUB_CAPACITY uiEdit variable value by below command:
	<b>\$ uiEdit  grep -i PDB_SUB_CAPACITY</b> "PDB_SUB_CAPACITY" is set to "528000000"
	If it is not 528000000 on compact DB architecture, set it to 528000000 using below command.
	<b>\$ uiEdit "PDB_SUB_CAPACITY" "528000000"</b> "PDB_SUB_CAPACITY" is set to "528000000"
<b>MPS B:</b> Verify that it is an Incremental Upgrade or Major upgrade	Check Procedure 2, Steps 7 and 8. If the upgrade type is a Major upgrade, proceed with the following step. If it's Incremental, proceed to step 34.
<b>MPS B</b> : Enable syscheck fs module.	Execute the following command to enable the syscheck fs module. \$ sudo syscheckAdmenable disk fs
	Upgrade. MPS B: Verify that it is an Incremental Upgrade or Major upgrade MPS B: Enable syscheck

34.	<b>MPS B</b> : Upgrade is complete. Verify Health	Execute Procedure A.1 on MPS B to verify the health of MPS B.
	of MPS B	If this is a Major Upgrade, the syscheck utility will report the "30000000000000002 – Server Internal Disk Error" alarm as the disk mirroring is in progress. The alarm will be cleared after the completion of disk mirroring.
		Also, the syscheck utility will report the "5000000000000002 - Server Application Process Error" alarm as the Epap processes are not running after the upgrade.
		Verify that no unexpected alarms are noted.
		Note: Disk mirroring does not start until the upgrade is accepted.
		If it is major upgrade Proceed with Procedure A.18 to upgrade SSL certificate.
35.	<b>MPS B:</b> Verify that if alarm to accept upgrade is	To verify alarm to accept upgrade execute following command:
	present.	<pre>\$ alarmMgralarmStatus   grep tpdServerUpgradePendingAccept</pre>
		Following output shall be observed:
		SEQ: 5 UPTIME: 112 BIRTH: 1498203542 TYPE: SET ALARM: TKSPLATMI33 tpdServerUpgradePendingAccept 1.3.6.1.4.1.323.5.3.18.3.1.3.33 32532  Processing Error Configuration Error Note: Disk mirroring does not start until the upgrade is accepted.
		Note. Disk initioning does not start until the upgrade is accepted.
36.	MPS B:	Perform following steps to disable unsecure algorithm for ssh:
	Update ssh_config to disable MD5 and	1. \$ grep "MACs hmac-md5,hmac-md5-96," /etc/ssh/ssh_config
	MAC algorithm for security	If output contains "MACs hmac-md5,hmac-md5-96", execute the below steps 2 and 3. Else go to step 4.
		<pre>2. \$ sudo rcstool co /etc/ssh/ssh_config</pre>
		3. \$ sudo sed -i -e '/MACs hmac-md5,hmac-md5-96,hmac-sha1-96/d'
		/etc/ssh/ssh_config
		4.\$ sudo rcstool ci /etc/ssh/ssh_config
		4. \$ grep "MACs hmac-sha2-256,hmac-sha2-512" /etc/ssh/sshd_config
		If no output is displayed for above command continue to next command in step 5 and 6 else skip these steps
		<pre>5. \$ sudo rcstool co /etc/ssh/sshd_config</pre>
		6. \$ sudo sed -i '\$ a \\tMACs hmac-sha2-256,hmac-sha2-512' /etc/ssh/sshd_config
		7. \$ sudo rcstool ci /etc/ssh/sshd_config
		8. \$ sudo service sshd restart
37.	Update the httpd.conf file to disable the	Perform the following steps to disable Cache control no-store policy:

	Cache control no-store policy.	1. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf		
		If the output contains "Header set Cache-Control no-store", Execute the below steps. If no output is displayed for the above command, skip the steps mentioned below.		
		2. \$ sudo sed -i '/Cache-Control no-store/c\#Header set Cache- Control no-store' /etc/httpd/conf/httpd.conf		
		3. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf		
		The output should be "#Header set Cache-Control no-store" showing that the line has been commented.		
		4. \$ sudo service httpd restart		
38.	Reconnect console cable.	On E5-APP-B card, reconnect the console cable between the serial port labeled 'S0' on E5-APP-B B card's adapter and the serial port labeled 'S1' on the E5-APP-B A card's adapter. <b>Cable part numbers - 830-1220-xx</b>		
39.	Procedure complete.	Procedure is complete.		
40.	Note down the timestamp in log.	Run the following command: \$ date		

# Procedure 19 Upgrade server A

S	This procedure upgrades the MPS-A server in the EPAP System.			
T	rins procedure upgrade	so the first of the of the differ by stell.		
Ē	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.			
P				
#	IF THIS PROCEDURE 1	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .		
1.	<b>MPS A</b> : Determine media available for	renomini roccadio mili or use un Ermi iso mage to perform apgrade.		
	upgrade.			
2.	Establish a connection to MPS A.	If access to the MPS servers is not available through an IP network, connect to the E5- APP-B card via the serial port.		
		For connecting the E5-APP-B A card, disconnect the console cable from the serial port on the E5-APP-B B card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B B card's adapter and use it for serial access. <b>Cable part numbers - 830-1220-xx</b>		
		Skip to step 6, if connected through serial console.		
3.	Create a terminal window and establish a	In a newly created terminal window labeled "MPS B", connect directly into MPS B.		
	connection by logging into MPS B.	# ssh epapdev@ <mps b=""></mps>		
	Into WI 5 D.	Password: <password></password>		
	Log in to MPS B.			
4.	MPS B: Start screen session.	Execute the following commands to start screen and establish a console session to MPS A.		
		#su - root		
Unan	agrade/Installation Cuida 123 of 270 August 2024			

is an Incremental Upgrade. or a Major Upgrade       following step. If it's Incremental, proceed to step 10.         8.       MPS A: Disable syscheck fs module.       \$ su - root Password:         Execute the following command to disable the syscheck fs module.       # syscheckAdmdisable disk fs			Password:
Image: Definition of the following command on E5-APP-B:         S sudo minicom mate         If above command fails then refer to Procedure A.27.         5.       MPS A: Login prompt is displayed.	<b>MPS B</b> : Connect to the	\$ screen -L	
If above command fails then refer to Procedure A.27.         5.       MPS A: Login prompt is displayed.         6.       MPS A: Log in to the server as the user "epapdev".         7.       MPS A: Verify that it is an Incremental Upgrade. or a Major Upgrade.       Check Procedure 2, Steps 7 and 8. If the upgrade type is Major upgrade, proceed with th following step. If it's Incremental, proceed to step 10.         8.       MPS A: Disable syscheck is module.       \$ su - root Password:         9.       MPS A: Create upgrade.con for splitting mirrors if this is a Major upgrade.       Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:         1. # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf splitting mirrors if this is a Major upgrade.       Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:         1. # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf splitting mirrors if this is a Major upgrade.       Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR (to trigger the split mirror upgrade) by executing the following steps:         1. # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf Line: BACKOUT_TYPE=SPLIT_MIRROR         NOTE: Not performing this step will prevent any successful backout.         Execute the following command to verify that the above command has been executed successfully: # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf The output should be: Iroot@MPS-B - If e cat /usr/TKLC/plat/etc/upgrade/upgrade.c		console of MPS A.	Execute the following command on E5-APP-B:
Second State       MPS A: Login prompt is displayed.         6.       MPS A: Log in to the server as the user "sepadev". <hostname> console login: epapdev password&gt;         7.       MPS A: Verify that it is an Incremental Upgrade. or a Major Upgrade.       Check Procedure 2, Steps 7 and 8. If the upgrade type is Major upgrade, proceed with th following step. If it's Incremental, proceed to step 10.         8.       MPS A: Disable syscheck fs module.       \$ su - root password:         9.       MPS A: Create upgrade.comf for splitting mirrors if this is a Major upgrade.       \$ su - root password:         1.       # vischeck damdisable disk fs         9.       MPS A: Create upgrade.comf for splitting mirrors if this is a Major upgrade.       If if ic al ready created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:         1.       # vischeckAdmdisable disk fs         9.       MPS A: Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:         1.       # vischeckAdmdisable disk fs         9.       MPS A: Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:         1.       # vischeckAdmdisable disk fs         9.       Upgrade.conf f  two is upgrade.         1.       # vischeckAdmdisable di</hostname>			\$ sudo minicom mate
□       is displayed.       Note: Hit enter if no login prompt is displayed.         6.       MPS A: Log in to the server as the user "epapdev".       shostname> console login: epapdev password: <pre><pre><pre><pre>password</pre>         7.       MPS A: Verify that it is an Incremental Upgrade. or a Major Upgrade.       Check Procedure 2, Steps 7 and 8. If the upgrade type is Major upgrade, proceed with th following step. If it's Incremental, proceed to step 10.         0       Upgrade.       Suspendev".         8.       MPS A: Disable syscheck fs module.       \$ su - root Password:         9.       MPS A: Create upgrade.conf for splitting mirrors if this is a Major upgrade.       Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR to trigger the split mirror upgrade) by executing the following steps:         1.       # vi / usr/TKLC/plat/etc/upgrade/upgrade.conf 2.1f file already contains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line:         BACKOUT_TYPE=SPLIT_MIRROR       NOTE: Not performing this step will prevent any successful backout.         Execute the following command to verify that the above command has been executed successfully:       # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf         The output should be: Iroot@MPS=M =] if cat /usr/TKLC/plat/etc/upgrade.conf BACKOUT_TYPE=SPLIT_MIRROR       \$ su - platcfg         10.       MPS A: Execute the platcfg menu.       \$ su - platcfg</pre></pre></pre>			If above command fails then refer to Procedure A.27.
a       Note: Hit enter if no login prompt is displayed.         b       mPS A: Log in to the server as the user "cpapdev".       chostname> console login: epapdev         7.       MPS A: Verify that it is in Incremental Upgrade. or a Major Upgrade. or a Major Upgrade.       Check Procedure 2, Steps 7 and 8. If the upgrade type is Major upgrade, proceed with the following step. If it's Incremental, proceed to step 10.         8.       MPS A: Disable syscheck fs module.       \$ su - root Password:         8.       MPS A: Create upgrade.conf for splitting mirrors if this is a Major upgrade.       Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:         1. # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf       # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf         2. # file already comtains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line:         BACKOUT_TYPE=SPLIT_MIRROR         NOTE: Not performing this step will prevent any successful backout.         Execute the following command to verify that the above command has been executed successfully:         # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf         The output should be:         I'root@MPS=B ~] # cat         /MPS A: Execute the platcfg menu.       \$ su - platcfg         10.       MPS A: Execute the platcfg Main Menu appears.			<hostname> console login:</hostname>
□       server as the user "epapdev". <hostname> console login: epapdev password: qaasword&gt;         7.       MPS A: Verify that it is an Incremental Upgrade. or a Major Upgrade.       Check Procedure 2, Steps 7 and 8. If the upgrade type is Major upgrade, proceed with th following step. If it's Incremental, proceed to step 10.         8.       MPS A: Disable syscheck fs module.       \$ su - root Password:         9.       upgrade.conf for splitting mirrors if this is a Major upgrade.       \$ create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:         1.       # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf         2.       If file already contains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line: BACKOUT_TYPE=SPLIT_MIRROR         NOTE: Not performing this step will prevent any successful backout.       Execute the following command to verify that the above command has been executed successfully: # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf         10.       MPS A: Execute the platcfg menu.       \$ su - platcfg         11.       MPS A: Select the       The oltacfg Main Menu appears.</hostname>		is displayed.	Note: Hit enter if no login prompt is displayed.
<ul> <li>is an Incremental Upgrade. or a Major Upgrade. or a Major Upgrade. or a Major Upgrade</li> <li>MPS A: Disable syscheck fs module.</li> <li>\$ su - root Password: Execute the following command to disable the syscheck fs module.</li> <li># syscheckAdmdisable disk fs</li> <li>MPS A: Create upgrade.conf for splitting mirrors if this is a Major upgrade.</li> <li>Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:</li> <li># vi /usr/TKLC/plat/etc/upgrade/upgrade.conf</li> <li>I. # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf</li> <li>BACKOUT_TYPE=SPLIT_MIRROR</li> <li>NOTE: Not performing this step will prevent any successful backout.</li> <li>Execute the following command to verify that the above command has been executed successfully:</li> <li># cat /usr/TKLC/plat/etc/upgrade/upgrade.conf</li> <li>The output should be: [root@MPS-B ~]# cat /usr/TKLC/plat/etc/upgrade/upgrade.conf</li> <li>MPS A: Execute the platcfg menu.</li> <li>\$ su - platcfg</li> <li>MPS A: Select the The platcfg Main Menu appears.</li> </ul>		server as the user	
Image: syscheck fs module.       \$ su - root Password: Execute the following command to disable the syscheck fs module. # syscheckAdmdisable disk fs         9.       MPS A: Create upgrade.conf for splitting mirrors if this is a Major upgrade.       Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:         1.# vi /usr/TKLC/plat/etc/upgrade/upgrade.conf 2. If file already contains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line: BACKOUT_TYPE=SPLIT_MIRROR         NOTE: Not performing this step will prevent any successful backout. Execute the following command to verify that the above command has been executed successfully: # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf The output should be: [root@MPS-B ~]# cat /usr/TKLC/plat/etc/upgrade.conf         10.       MPS A: Execute the platefg menu.       \$ su - platcfg         11.       MPS A: Select the       The platcfg Main Menu appears.		is an Incremental Upgrade. or a Major Upgrade	Check Procedure 2, Steps 7 and 8. If the upgrade type is Major upgrade, proceed with the following step. If it's Incremental, proceed to step 10.
9.       MPS A: Create upgrade.conf for splitting mirrors if this is a Major upgrade.       Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:         1.       # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf 2. If file already contains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line: BACKOUT_TYPE=SPLIT_MIRROR         NOTE: Not performing this step will prevent any successful backout.         Execute the following command to verify that the above command has been executed successfully: # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf The output should be: [root@MPS-B ~] # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf BACKOUT_TYPE=SPLIT_MIRROR         10.       MPS A: Execute the platcfg menu.       \$ su - platcfg         11.       MPS A: Select the       The platcfg Main Menu appears.	_		
upgrade.conf for splitting mirrors if this is a Major upgrade.       (to trigger the split mirror upgrade) by executing the following steps:         1. # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf       1. # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf         2. If file already contains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line:         BACKOUT_TYPE=SPLIT_MIRROR         NOTE: Not performing this step will prevent any successful backout.         Execute the following command to verify that the above command has been executed successfully:         # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf         The output should be:         [root@MPS-B ~]# cat         /usr/TKLC/plat/etc/upgrade/upgrade.conf         BACKOUT_TYPE=SPLIT_MIRROR         10.       MPS A: Execute the platcfg menu.         11.       MPS A: Select the         The platcfg Main Menu appears.			
a Major upgrade.       1. # vi /usr/TKLC/plat/etc/upgrade/upgrade.conf         2. If file already contains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line:         BACKOUT_TYPE=SPLIT_MIRROR         NOTE: Not performing this step will prevent any successful backout.         Execute the following command to verify that the above command has been executed successfully:         # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf         The output should be:         [root@MPS-B ~] # cat         /usr/TKLC/plat/etc/upgrade.conf         BACKOUT_TYPE=SPLIT_MIRROR         10.       MPS A: Execute the platcfg menu.         11.       MPS A: Select the         The platcfg Main Menu appears.		upgrade.conf for	Create a file (if not already created) and add the line "BACKOUT_TYPE=SPLIT_MIRROR" (to trigger the split mirror upgrade) by executing the following steps:
Image: Normal state in the			2.If file already contains some allow listed alarms then append bellow line at the end of the file, otherwise add it to first line:
Image: Second			
Image: successfully:       successfully:         # cat /usr/TKLC/plat/etc/upgrade/upgrade.conf         The output should be:         [root@MPS-B ~] # cat         /usr/TKLC/plat/etc/upgrade/upgrade.conf         BACKOUT_TYPE=SPLIT_MIRROR         10.       MPS A: Execute the platcfg menu.         11.       MPS A: Select the         The platcfg Main Menu appears.			NOTE: Not performing this step will prevent any successful backout.
Image: Image: Description of the second			
Image: Image			<pre># cat /usr/TKLC/plat/etc/upgrade/upgrade.conf</pre>
10.       MPS A: Execute the platcfg menu.       \$ su - platcfg         11.       MPS A: Select the       The platcfg Main Menu appears.			
platcfg menu.       \$ su - platcfg         11.       MPS A: Select the       The platcfg Main Menu appears.			/usr/TKLC/plat/etc/upgrade/upgrade.conf
			\$ su - platcfg

		Main Menu Maintenance Diagnostics Server Configuration Network Configuration Remote Consoles Exit	
	<b>MPS A</b> : Select the Upgrade submenu.	Select the Upgrade menu and press [ENTER]. Maintenance Menu Upgrade Backup and Restore View Mail Queues Restart Server Save Platform Debug Logs Exit	
13.	MPS A: Select the Early Upgrade Checks submenu.	Select the "Early Upgrade Checks" menu to verify that the system is ready for upgrade.          Upgrade Menu         Validate Media         Early Upgrade Checks         Initiate Upgrade         Copy USB Upgrade Image         Non Tekelec RPM Management         Exit         If the Early Upgrade Checks fail due to the NTP related alarms, then execute step 15.         Otherwise, skip to step 16.         Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the early upgrade checks fail, due to any other reason.	
14.	MPS A: Allow List NTP Alarms	<ol> <li>If the Early Upgrade Checks fail due to the NTP related alarms, then ignore the NTP alarms using the following commands:</li> <li>e. Exit the platcfg menu</li> <li>f. Change to root user using the "su –" command.</li> <li>g. vim /usr/TKLC/plat/etc/upgrade/upgrade.conf</li> <li>h. Edit the following line to include the NTP related alarms. EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2</li> <li>For example – To allowlist the NTP alarm "tpdNTPDaemonNotSynchronizedWarning" which has the alarm code TKLCPLATMI10, the above mentioned line should be edited as EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2, TKSPLATMI10</li> <li>Note: There should not be any space between two alarms i.e. between TKSPLATMI2 and TKSPLATMI10</li> </ol>	

		2) If the Early Upgrade Checks fail due to "Server Default Route Network Error", then this alarm shall be allowlisted in upgrade.conf file. To allowlist this alarm which has the alarm code TKSPLATMA14, the above mentioned line should be edited as EARLY_CHECK_ALARM_WHITELIST=TKSPLATMI2,TKSPLATMI10, TKSPLATMA14		
15.	<b>MPS A</b> : Select Initiate Upgrade.	Select the Initiate Upgrade menu and press [ENTER].          Upgrade Menu         Validate Media         Early Upgrade Checks         Initiate Upgrade         Copy USB Upgrade Image         Non Tekelec RPM Management         Exit		
16.	<b>MPS A</b> : Select the Upgrade Media.	The screen will display a message that it is searching for upgrade media. Once the upgrade media is found, an Upgrade Media selection menu will be displayed similar to the example shown below. Select the upgrade media on ISO image. There should only be one selection available, as shown in the example below. If there is more than one selection available, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F. lqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqq		
17.	<b>MPS A</b> : Upgrade proceeds.	The screen displays the following, indicating that the upgrade software is first running the early upgrade checks, and then proceeding with the upgrade. Replacing <seconds> with the value from the log. Starting Early Upgrade Checks at 1448399773 Running earlyUpgradeChecks() for Upgrade::EarlyPolicy::TPDEarlyChecks upgrade policy Verified server is not pending accept of previous upgrade Hardware architectures match Install products match. Whitelisted alarms: Verified server is alarm free! Verified server is alarm free! Verified all raid mirrors are synced. Early Upgrade Checks Have Passed! Early Upgrade Checks finished at 1448399780 Initializing upgrade information</seconds>		
18.	<b>MPS A</b> : Upgrade proceeds.	Many informational messages will come across the terminal screen as the upgrade proceeds. Finally, after upgrade is complete, the server will reboot.		

19.	<b>MPS A</b> : Upgrade completed.	After the final reboot, Press Enter, the screen will display the login prompt, as shown in the example below.		
		Starting smartd: [ OK ] Daemon is not running AlarmMgr daemon is not running, delaying by 1 minute TKLChwmgmtcli stop/pre-start, process 9750 TPDhpDiskStatus stop/pre-start, proces s 9782 Oracle Linux Server release 6.9 Kernel 2.6.32-696.20.1.el6prerel7.6.0.0.0_88.47.0.x86_64 on an x86_64 Arica-A login:		
20.	<b>MPS A</b> : Log in to the server as the user "epapdev".	<hostname> console login: epapdev password: <password></password></hostname>		
		Note: The SSH login for root shall get enabled after the upgrade.		
21.	<b>MPS A</b> : Verify the Upgrade.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors and warnings were reported. Check Procedure 2, Steps 7 and 8 to determine whether it is incremental or major upgrade.		
		If it is major upgrade then consider following <b>\$ grep -i error /var/TKLC/log/upgrade/upgrade.log</b>		
		Following errors shall be observed:		
		1530712922::ERROR: Config file is currently checked out! 1530712922::ERROR: LOCKED BY: platcfg 1530712922::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf 1530712922::ERROR: ELEMENT: /var/TKLC/rcs/usr/TKLC/plat/etc/vlan.conf,v		
		1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' 1530669414:: 1530669414:: 1530669414:: 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table		
		1530669414:: 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'		
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MyI'		
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'		
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'		
		1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'		
		1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136.		

1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136.	
•	
530094474::libsemanage.semanage_reload_policy: load_policy returned error code 2	
1530094474::libsemanage.semanage_reload_policy: load_policy returned error code 2.	
i Table 'mysql.innodb_index_stats' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_morker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_morker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist 1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist 1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist	
Following errors shall be observed if upgrade is performed on a setup which was converted from Prov to Non Prov:	
1529314607::Error : Table 'pdb.LicenseInfo' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.asd	
1529314607::Error : Table 'pdb.asd' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.bucketContent 1529314607::Error : Table 'pdb.bucketContent' doesn't exist 1529314607::status : Operation failed	
1529314607::pdb.bucketMap 1529314607::Error : Table 'pdb.bucketMap' doesn't exist 1529314607::status : Operation failed	
1529314607::pdb.commands 1529314607::Error : Table 'pdb.commands' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.dn	
1529314607::Error : Table 'pdb.dn' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.dn9dig	
1529314607::Error : Table 'pdb.dn9dig' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.dnB_asd	
Following statement for missing binary file shall be observed in upgrade.log: 1530885808::/bin/df: `/mnt/ugchroot/sys': No such file or directory 1542631084::./upgrade_mysql: line 46: /usr/TKLC/epap/bin/pass_fetch: No such file or directory	
[NOTE: It is observed only when MySQL upgraded from earlier version than 5.6.18 to version 5.7]	
Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any error other than the above mentioned errors. Also note that sometime a carriage return is inserted in the log file causing some of the	
error messages to appear truncated. This is acceptable and should be ignored.	
<pre>\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log</pre>	
Examine the output of the above command to determine if any warnings were reported. Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any warnings beside the following:	

Trocedure 19. Opgrade Ser		
	1488951825::WARNING: /usr/TKLC/plat/etc updatedreparsing xml	c/alarms/alarms.xml has been
	1530712185::WARNING: This capability is capabilities.	s not defined in the default
	1530712186::WARNING: Nor is it defined	in the current hardware ID's
	capabilities. 1530712186::WARNING: CAPABILITY: serv <sup>-</sup>	icedisabled
	1530712186::WARNING: HARDWARE ID: E5APP	PB assword on the command line interface can
	be insecure.	
	be insecure.	assword on the command line interface can
	1488951890::warning: erase unlink of 573.18.1.el6prerel7.	f /lib/modules/2.6.32-
	0.3.0.0_86.44.0.x86_64/weak-updates fa 1488951902::warning: erase unlink of	iled: No such file or directory f /lib/modules/2.6.32-
	573.18.1.el6prerel7. 0.3.0.0_86.44.0.x86_64/modules.softdep 1488951902::warning: erase unlink of 573.18.1.el6prerel7.	failed: No such file or directory f /lib/modules/2.6.32-
	0.3.0.0_86.44.0.x86_64/modules.order fa	ailed: No such file or directory f /lib/modules/2.6.32-
	0.3.0.0_86.44.0.x86_64/modules.network 1488951902::warning: erase unlink of 573.18.1.el6prerel7.	ing failed: No such file or directory f /lib/modules/2.6.32-
	0.3.0.0_86.44.0.x86_64/modules.modesett 1488951902::warning: erase unlink of 573.18.1.el6prerel7.	
	0.3.0.0_86.44.0.x86_64/modules.drm fai 1488951902::warning: erase unlink of 573.18.1.el6prerel7.	f /lib/modules/2.6.32-
	0.3.0.0_86.44.0.x86_64/modules.block fa 1488951903::kexec-tools /et	ailed: No such file or directory #warning: /etc/kdump.conf created as
	c/kdump.conf.rpmnew 1488952115::ca-certificates /etc/pki/tls/ce	###############warning:
	rts/ca-bundle.crt created as /etc/pki/1 1488952136::samhain /etc/	tls/certs/ca-bundle.crt.rpmnew warning: /etc/samhainrc created as
	samhainrc.rpmnew 1488952138::php-common /etc/p	<pre>#warning: /etc/php.ini created as</pre>
	hp.ini.rpmnew 1488952209::initscripts	##warning: /etc/sysctl.conf created as
	etc/sysctl.conf.rpmnew 1488952260::mysql-commercial-server /etc/my.	warning: /etc/my.cnf created as
	cnf.rpmnew 1488952291::ntp /etc/n_	warning: /etc/ntp.conf created as
	tp.conf.rpmnew 1488952302::TKLCplat	################warning:
	/usr/TKLC/plat/ etc/pid_conf created as /usr/TKLC/plat, 1488952302::#warning: /usr/TKLC/plat/ei /usr/TKLC/plat/_	/etc/pid_conf.rpmnew tc/service_conf created as
	etc/service_conf.rpmnew 1488952320::TKLCalarms	###warning:
	/usr/TKLC/plat/etc/alarms/al arms.xml saved as /usr/TKLC/plat/etc/a 1488952328::alarmMgr	larms/alarms.xml.rpmsave ###warning:
	/usr/TKLC/plat/etc/alarmMgr/ alarmMgr.conf created as /usr/TKLC/plat 1488952471::WARNING: This capability is	5
	capabilities. 1488952471::WARNING: Nor is it defined capabilities	in the current hardware ID's
	1488952471::WARNING: CAPABILITY: serv 1488952471::WARNING: HARDWARE ID: E5API	
	1488952602::sudo /etc/su	warning: /etc/sudoers created as
	doers.rpmnew 1488952709::WARNING: /usr/TKLC/plat/etc updated	c/alarms/alarms_mps.xml has been
	.reparsing xml  1488952718::TKLCepap-HA  ####################################	in _
	No such file or directory	f /usr/TKLC/epap/bin/dbMigration failed
	1488952949::WARNING: Module variable EX 1488952951::WARNING: CONFIG: /usr/TKLC/plat/lib/Syscheck/modules/sys	·
	ig 1488952951::WARNING: Module variable EX	
L I		

1488952951::WARNING: CONFIG: /usr/TKLC/plat/lib/Syscheck/modules/system/cpu/conf ig
If it is an incremental upgrade then consider following \$ grep -i error /var/TKLC/log/upgrade/upgrade.log
Following errors shall be observed:
1530712922::ERROR: Config file is currently checked out! 1530712922::ERROR: LOCKED BY: platcfg 1530712922::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf 1530712922::ERROR: ELEMENT: /var/TKLC/rcs/usr/TKLC/plat/etc/vlan.conf,v
1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' 1530669414:: 1530669414:: 1530669414:: 1530669414::myisamchk: error: 140 when opening MyISAM-table
<pre>'/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' 1530669414:: 1530669414::</pre>
1530669414:: 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI' 1530669414::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI'
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
1528826597::myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136. 1533053832::Sorry, user root is not allowed to execute '/bin/chown epapdev:epap /var/TKLC/epap/logs/queryServer.log' as root on epap136.
530094474::libsemanage.semanage_reload_policy: load_policy returned error code
<pre>2 1530094474::libsemanage.semanage_reload_policy: load_policy returned error code 2.</pre>
1494304768::ERROR: Config file is currently checked out! 1494304781::ERROR: LOCKED BY: platcfg 1494304781::ERROR: CONFIG: /usr/TKLC/plat/etc/vlan.conf 1494304781::ERROR: ELEMENT: /var/TKLC/rcs/usr/TKLC/plat/etc/vlan.conf,v 1496215832::Error : Table 'mysql.innodb_index_stats' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist 1496215832::Error : Table 'mysql.slave_master_info' doesn't exist
1496215832::Error: Table 'mysql.slave_relay_log_info' doesn't exist1496215832::Error: Table 'mysql.slave_worker_info' doesn't exist1496215832::Error: Table 'mysql.innodb_index_stats' doesn't exist1496215832::Error: Table 'mysql.slave_master_info' doesn't exist1496215832::Error: Table 'mysql.slave_master_info' doesn't exist1496215832::Error: Table 'mysql.slave_relay_log_info' doesn't exist1496215832::Error: Table 'mysql.slave_worker_info' doesn't exist1496215832::Error: Table 'mysql.slave_worker_info' doesn't exist1496215832::Error: Table 'mysql.slave_morker_info' doesn't exist1496215832::Error: Table 'mysql.slave_morker_info' doesn't exist1496215832::Error: Table 'mysql.slave_morker_info' doesn't exist1496215832::Error: Table 'mysql.innodb_index_stats' doesn't exist1496215832::Error: Table 'mysql.innodb_table_stats' doesn't exist1496215832::Error: Table 'mysql.slave_master_info' doesn't exist1496215832::Error: Table 'mysql.slave_master_info' doesn't exist

**Upgrade/Installation Guide** 

1496215832::Error : Table 'mysql.slave_relay_log_info' doesn't exist	
1496215832::Error : Table 'mysql.slave_worker_info' doesn't exist	
Following errors shall be observed if upgrade is performed on a setup which v converted from Prov to Non Prov:	was
1529314607::Error : Table 'pdb.LicenseInfo' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.asd	
1529314607::Error : Table 'pdb.asd' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.bucketContent	
1529314607::Error : Table 'pdb.bucketContent' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.bucketMap	
1529314607::Error : Table 'pdb.bucketMap' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.commands	
1529314607::Error : Table 'pdb.commands' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.dn	
1529314607::Error : Table 'pdb.dn' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.dn9dig	
1529314607::Error ː Table 'pdb.dn9dig' doesn't exist 1529314607::status : Operation failed 1529314607::pdb.dnB_asd	
Following statement for missing binary file shall be observed in upgrade.log: 1530885808::/bin/df: `/mnt/ugchroot/sys': No such file or directory 1542631084::./upgrade_mysql: line 46: /usr/TKLC/epap/bin/pass_fetch: No s file or directory	uch
[NOTE: It is observed only when MySQL upgraded from earlier version than 5.6. to version 5.7]	.18
Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any error other than the above mentioned errors.	ve-
Also note that sometime a carriage return is inserted in the log file causing some of error messages to appear truncated. This is acceptable and should be ignored.	f the
<pre>\$ grep -i warning /var/TKLC/log/upgrade/upgrade.log</pre>	
Examine the output of the above command to determine if any warnings were report Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any warnings beside the following:	orted.
1489042076::WARNING: /usr/TKLC/plat/etc/alarms/alarms.xml has been updatedrep arsing xml	
1489042124::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 .0.0.0_88.32.0.x86_64/weak-updates failed: No such file or directory	
1489042136::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 .0.0.0_88.32.0.x86_64/modules.order failed: No such file or directory	
1489042136::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 .0.0.0_88.32.0.x86_64/modules.networking failed: No such file or director	·у
1489042136::warning: erase unlink of /lib/modules/2.6.32- 642.6.2.el6prerel7.4 .0.0_88.32.0.x86_64/modules.modesetting failed: No such file or directo 1489042136::warning: erase unlink of /lib/modules/2.6.32-	ory
642.6.2.el6prerel7.4 .0.0.0_88.32.0.x86_64/modules.drm failed: No such file or directory 1489042136::warning: erase unlink of /lib/modules/2.6.32-	
642.6.2.el6prerel7.4 .0.0.0_88.32.0.x86_64/modules.block failed: No such file or directory 1489042197::WARNING: /usr/TKLC/plat/etc/alarms/alarms_mps.xml has been updated .reparsing xml	
Refer to section 0 to know more about logging.	
121 - 6 270	

		<b>NOTE:</b> provRMTP core might be observed on EPAP after upgrade, if the EPAP is connected to EAGLE. The core should be ignored, it has no impact on traffic running from EPAP to EAGLE.
22.	<b>MPS A:</b> Verify the Upgrade.	<pre>\$ grep "Upgrade returned success" /var/TKLC/log/upgrade/upgrade.log</pre>
		Verify that the message "Upgrade returned success!" is displayed. If it is not, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F.
		1400793814:: Upgrade returned success!
23.		After upgrade check for PDB_SUB_CAPACITY uiEdit variable value by below command:
		<b>\$ uiEdit  grep -i PDB_SUB_CAPACITY</b> "PDB_SUB_CAPACITY" is set to "528000000"
		If it is not 528000000 on compact DB architecture, set it to 528000000 using below command.
		<b>\$ uiEdit "PDB_SUB_CAPACITY" "528000000"</b> "PDB_SUB_CAPACITY" is set to "528000000"
24.	<b>MPS A:</b> Verify that it is an Incremental Upgrade. or Major Upgrade	Check Procedure 2, Steps 7 and 8. If the upgrade type is Major upgrade, proceed with the following step. If it's Incremental, proceed to step 26.
25.	<b>MPS A:</b> Enable syscheck fs module.	\$ su - root Password:
		Execute the following command to enable the syscheck fs module. # syscheckAdmenable disk fs
26.	<b>MPS A</b> : Upgrade is complete. Verify Health	Execute Procedure A.1 on MPS A to verify the health of MPS A.
	of MPS A	On a Provisionable(mixed-EPAP or PDBonly) MPS, expect that the syscheck utility will alarm the fact that the PDBA software is not running. This will appear as a "50000000000002 – Server Application Process Error" alarm.
		If this is a Major Upgrade, the syscheck utility will report the "30000000000000002 – Server Internal Disk Error" alarm as the disk mirroring is in progress. The alarm will be cleared after the completion of disk mirroring.
		Verify that no unexpected alarms are noted.
		If it is major upgrade, Proceed with Procedure A.18 to upgrade SSL certificate.
27.	<b>MPS A:</b> Verify that if alarm to accept upgrade is	To verify alarm to accept upgrade execute following command:
	present.	<pre>\$ alarmMgralarmStatus   grep tpdServerUpgradePendingAccept</pre>
		Following output shall be observed:
		SEQ: 5 UPTIME: 112 BIRTH: 1498203542 TYPE: SET ALARM: TKSPLATMI33 tpdServerUpgradePendingAccept 1.3.6.1.4.1.323.5.3.18.3.1.3.33 32532  Processing Error Configuration Error
		Note: Disk mirroring does not start until the upgrade is accepted.

28.	<b>MPS B:</b> Loginn as epapdev user.	<hostname> console login: epapdev password: <password></password></hostname>
29.	<b>MPS B:</b> Reboot MPS B server.	Reboot MPS-B to disable the root login. Switch to root user.
		\$ su – root Password: Reboot the server:
		<b>\$ reboot</b> Wait til the reboot gets completed.
30.	<b>MPS A:</b> Enable PDBA proxy and VIP features.	If PDBA Proxy Enabled = Yes, in the step 14 of Procedure 18, then execute Procedure A.20 to enable Epap PDBA Proxy and VIP Features. Otherwise, skip this step.
31.	MPS A: Check services	\$ epapdb -c queryservers
	for query server.	If query server is not configured i.e. INFO: No Query Server Configured, then skip this step otherwise Execute 6 to restart MYSQL service for PDB on query server.
32.	MPS A:	Perform following steps to disable unsecure algorithm for ssh:
	Update ssh_config to	1. \$ grep "MACs hmac-md5,hmac-md5-96," /etc/ssh/ssh_config
	disable MD5 and MAC algorithm for	If output contains "MACs hmac-md5,hmac-md5-96", execute the below
	security	steps 2 and 3. Else go to step 4.
		<pre>2. \$ sudo rcstool co /etc/ssh/ssh_config</pre>
		3. \$ sudo sed -i -e '/MACs hmac-md5,hmac-md5-96,hmac-sha1-96/d' /etc/ssh/ssh_config
		4.\$ sudo rcstool ci /etc/ssh/ssh_config
		<b>4. \$ grep "MACs hmac-sha2-256,hmac-sha2-512" /etc/ssh/sshd_config</b> If no output is displayed for above command continue to next command in step 5 and 6 else skip these steps
		5. \$ sudo rcstool co /etc/ssh/sshd_config
		6. \$ sudo sed -i '\$ a \\tMACs hmac-sha2-256,hmac-sha2-512' /etc/ssh/sshd_config
		7. \$ sudo rcstool ci /etc/ssh/sshd_config
22	<b>TT 1</b>	8. \$ sudo service sshd restart
33.	Update the httpd.conf file to disable the	Perform the following steps to disable Cache control no-store policy:
	Cache control no-store policy.	1. \$ grep ''Header set Cache-Control no-store'' /etc/httpd/conf/httpd.conf

	cedure 19. Opgrade Ser	
34.	<b>MPS A:</b> If HTTP was enabled for EPAP GUI before upgrade, follow this step otherwise skip it.	If the output contains "Header set Cache-Control no-store", Execute the below steps. If no output is displayed for the above command, skip the steps mentioned below. 2. \$ sudo sed -i '/Cache-Control no-store/c\#Header set Cache-Control no-store' /etc/httpd/conf/httpd.conf 3. \$ grep "Header set Cache-Control no-store" /etc/httpd/conf/httpd.conf The output should be "#Header set Cache-Control no-store" showing that the line has been commented. 4. \$ sudo service httpd restart If HTTP was enabled before upgrade, follow below mentioned steps. • Open EPAP GUI in HTTPS mode. • Navigate to User Administration tab on GUI -> HTTP(S) support -> Change Configuration. • Disable HTTP mode, if it shows HTTP mode as enabled. • Enable the HTTP mode again as shown in image below. The HTTP mode should get enabled successfully. Now you can open the EPAP GUI in HTTP mode.
		A       Change Fit F(S) Configuration         Monitoraneo       HTTP Enabled:         Debug       HTTPS Enabled:         Groups       Submit Changes         Authorized Ps       Submit Changes         Monitored Ps       Stopp: Groups         Groups Configuration       Creating Configuration         Change Password       Copyright © 2000, 2022, Oracle and/or its affiliates. All rights reserved.
		PERA       10.75.141.102       ACTIVE       Alarms       PERA       POBA       NONE       Alarms       OI:48:27 EDT       Alarms       OI:48:28 EDT       Alarms       OI:48:27 EDT       Alarms
35.	Reconnect console cable.	On E5-APP-B card, reconnect the console cable between the serial port labeled 'S0' on E5-APP-B A card's adapter and the serial port labeled 'S1' on the E5-APP-B B card's adapter. <b>Cable part numbers - 830-1220-xx</b>
36.	Procedure is complete.	Procedure is complete. Note: If upgrading an EPAP Provisionable mated pair and you have just completed this procedure for the Local MPS A and MPS B. Repeat the same procedures to upgrade the Remote Pair. See Section 0 for more information.
37.	Note down the timestamp in log.	Run the following command:
		124 -8 270

S date

#### Procedure 20 Run RTDB Converter

#### **Procedure 20: Run RTDB Converter**

S T P #	<ul> <li>This procedure runs RTDB converter to update rtdb database as per new schema. This procedure should not be run on PDBonly setup.</li> <li>Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number.</li> <li>IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.</li> <li>**Note: This step can be run on MPS A</li> </ul>	
	<b>MPS A:</b> Log in to the server as the user "epapdev".	<hostname> console login: epapdev password: <password></password></hostname>
2.	MPS A: Run RTDB converter script	<ul> <li>\$ cd /usr/TKLC/epap/bin</li> <li>If system is in compact architecture as noted in step 10 of Procedure 2 run below command:</li> <li>\$ ./ rtdbEpap164CompactToCompactConvertTool</li> <li>If system is in extreme as noted in step 10 of Procedure 2 architecture run below command:</li> <li>\$ ./ rtdbEpap164ExtremeToExtremeConvertTool</li> <li>Many informational Messages will be displayed on screen. If this script fails contact My Oracle Support.</li> </ul>
3.	Reboot Eagle cards.	Execute <b>Procedure 21</b> on the Eagle STP connected to the EPAP servers to reload SM cards.
4.	Procedure is complete	Procedure is complete.
5.	Note down the timestamp in log.	Run the following command: \$ date

# Procedure 21 Reboot EAGLE Cards

#### **Procedure 21: Reboot EAGLE Cards**

This procedure reboots EAGLE cards to reload new RTDB.		
Check off ( $\checkmark$ ) each step a	Check off ( $\checkmark$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.	
IF THIS PROCEDURE FA	AILS, CONTACT MY ORACLE SUPPORT AND <b>ASK FOR <u>UPGRADE ASSISTANCE</u>.</b>	
EAGLE: reboot all SM cards to reload new RTDB.	Note: Before rebooting EAGLE cards, check whether the EPAP software is running or not. If EPAP software is not running then start it manually by below commands. Execute the below steps on EPAP:	
	\$ service Epap status	
	Start the EPAP software, if the above command shows that software is not running. If service EPAP shows that software is running, there is no need to run next command.	
	<pre>\$ service Epap start ~~ /etc/init.d/Epap start ~~ EPAP application started.</pre>	
	Login onto the connected EAGLE.	
	Reboot 1 SM card on the EAGLE and verify that it comes back to an IS-NR/Active state.	
	Then boot the rest of the EAGLE SM cards over 4 batches (booting 1/4 of the cards at a single time).	
Procedure is complete	Procedure is complete.	
Note down the timestamp	Run the following command:	
in log.	\$ date	

## Procedure 22 Accept Upgrade

#### Note: If the upgrade is accepted, Backout cannot be performed.

#### **Procedure 22: Accept upgrade**

S	This procedure accept t	he upgrade to perform the upgrade process.
T E P #	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND <b>ASK FOR <u>UPGRADE ASSISTANCE</u></b> .	
6.	MPS: Login as Login as admusr if not already loged in.	
	admusr.	<hostname> login: admusr</hostname>
		Password:
		Note: The console logon may preced by many lines of reboot output.
7.	<b>MPS:</b> Verify if	
	alarmMgr process	\$ sudo ls /var/run/alarmMgr
	running.	If the file exists, proceed to the next step.

## Note: If the upgrade is accepted, Backout cannot be performed.

## Procedure 22: Accept upgrade

		If the file does not wist context Owerla Customer Customer Customer
		If the file does not exist, contact Oracle Customer Service.
8.	<b>MPS:</b> Execute the platcfg menu.	\$ sudo su – platcfg
9.	<b>MPS:</b> Select the Maintenance submenu.	The platcfg Main Menu appears. On the Main Menu, select Maintenance and press [ENTER]. Main Menu Maintenance Diagnostics Server Configuration Network Configuration Remote Consoles Exit
	<b>MPS</b> : Select the Upgrade submenu.	Select the Upgrade menu and press [ENTER].
11.	MPS: Select the Upgrade submenu.	If you have not already accepted the upgrade, do so now, otherwise skip this step.          Upgrade Menu         Validate Media         Early Upgrade Checks         Initiate Upgrade         Copy USB Upgrade Image         Non Tekelec RPM Management         Accept Upgrade         Reject Upgrade         Exit

#### Note: If the upgrade is accepted, Backout cannot be performed.

Procedure 22: Accept upgrade

		++ Message ++
		The accept has completed.
		Note: If you still observe the accept upgrade message even after the disks get mirrored properly after accepting the upgrade for the first time, follow the steps mentioned in APPENDIX A.30 to remove the false accept upgrade alarm from the system.
12.	Procedure is complete	Procedure is complete.
13.	Note down the timestamp in log.	Run the following command: \$ date

## Procedure 23 Keys exchange between active and standby PDB

#### Procedure 23: Keys exchange between active PDB and standby PDB

S	This procedure Exchange	ge the keys between active and remote PDB.
Т		
Ε	Check off ( $\mathbf{v}$ ) each step	as it is completed. Boxes have been provided for this purpose under each step number.
Р		
#	IF THIS PROCEDURE F	FAILS, CONTACT MY ORACLE SUPPORT AND <b>ASK FOR <u>UPGRADE ASSISTANCE</u></b> .
1.	MPS A: Login to	If not already logged-in, then login at MPS A of active PDB EPAP:
	Active PDB EPAP as	<pre><hostname> console login: epapdev</hostname></pre>
	the user "epapdev".	password: <pre>conservery page 200 pag 200 page 200 page</pre>
2.	MPS A: Verify that	Execute following command to verify that pdb entry present in known_hosts file:
	PDB entry are present	
	in known_hosts file.	\$ cat .ssh/known_hosts
		If and a large start of the second starts
		If entry is present skip next step
3.	MPS A: Exchange	Execute the following command on Active PDB:
	the keys from Active	\$ ssh epapdev@ <remote ip="" pdb=""></remote>
	PDB	Are you sure you want to continue connecting (yes/no)? < <mark>yes</mark> >
		Password:
		Snapshot for reference:
		[epapdev@Recife-A ~]\$ ssh epapdev@10.75.141.104
		FIPS integrity verification test failed.

#### Procedure 23: Keys exchange between active PDB and standby PDB

		The authenticity of host '10.75.141.104 (10.75.141.104)' can't be established. RSA key fingerprint is d4:d5:94:c6:57:1a:30:25:bc:b0:67:f9:f7:07:c6:68. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added '10.75.141.104' (RSA) to the list of known hosts. epapdev@10.75.141.104's password:
4.	<b>MPS A:</b> Login to Standby PDB EPAP as the user "epapdev".	If not already logged-in, then login at MPS A of standby PDB EPAP: <hostname> console login: epapdev password: <password></password></hostname>
5.	MPS: Exchange the keys from Standby PDB	Repeat the step 2 and step3 to exchange the keys from standby PDB as well.
6.	Procedure is complete	Procedure is complete.
7.	Note down the timestamp in log.	Run the following command: \$ date

# THIS COMPLETES THE UPGRADE

## 6. SOFTWARE RECOVERY PROCEDURES

Execute this section only if there is a problem and it is desired to revert back to the pre-upgrade version of the software.

Warning: Do not attempt to perform these backout procedures without first contacting the My Oracle Support, following the instructions on the front page or the instructions on the Appendix F.

<u>NOTE</u>: These recovery procedures are provided for the backout of an Upgrade ONLY (i.e., from a failed 16.3.y release to the previously installed 16.3.x release). Backout of an initial installation is not supported.

## **Backout Setup**

The reason to execute a backout has a direct impact on any backout preparation that must be done. Since the reason cannot be known ahead of time, no definitive procedure can be written.

My Oracle Support personnel will have to have login access to the affected MPS server, probe the server for the root cause of the problem, and execute whatever setup or cleanup is necessary in order to prepare the MPS server for backout.

#### Perform Backout

No matter the initial cause of the upgrade problem, once all necessary corrective steps have been taken to prepare for the backout, then the following procedure can be executed to perform a backout. Refer to section 0 and section 0 for the Backout process overview.

#### Procedure 24 Server B Backout

S	This procedure provi	ides instructions to perform backout on MPS B server.
Т		
Ε	Check off ( $$ ) each step	as it is completed. Boxes have been provided for this purpose under each step number.
P	Note: Execute this nre	ocedure if only MPS B has been upgraded successfully and MPS A is still at the pre-
#	upgrade release.	sectore if only will b D has been upgraded successionly and will b A is suit at the pre-
		nas been accepted, this procedure cannot be executed.
1.	Terminate all previous	If not already connected, connect to the E5-APP-B card via the serial port.
	connections (ssh).	
		For connecting the E5-APP-B B card, disconnect the console cable from the serial port
		on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connected to the seriel part labeled 'S1' on the E5_APP B. A cards adapter and use it for
		it connects to the serial port labeled 'S1' on the E5-APP-B A cards adapter and use it for serial access. <b>Cable part numbers - 830-1220-xx</b>
		Sonar access. Cable part humbers - 050-1220-XX
		Skip to step 5, if connected through serial console.

2.	Create a terminal window and establish a connection by logging into MPS A. Log in to MPS A.	In a newly created terminal window labeled "MPS B – from MPS A", connect directly into MPS A. # ssh admusr@ <mps a=""> Password: <password></password></mps>
3.	<b>MPS A:</b> Verify that the state of PDBA Proxy Feature is No.	# sudo su - epapconfig
	<b>Note:</b> Skip this step for Non-Prov and PDBonly EPAP.	/EPAP Configuration Menu\ /\   1   Display Configuration
		   2   Configure Network Interfaces Menu   
		   4   Exchange Secure Shell Keys   
		5   Change Password   
		7   Configure NTP Server   
		   9   Security   
		   11   Configure Alarm Feed
		12   Configure Query Server   
		14   Configure SNMP Agent Community 
		   e   Exit   \/
		Enter Choice: 1 EPAP A Provisioning Network IP Address = 192.168.61.115 EPAP B Provisioning Network IP Address = 192.168.61.116 Provisioning Network Netmask = 255.255.0 Provisioning Network Default Router = 192.168.61.1 EPAP A Backup Prov Network IP Address = Not configured Backup Prov Network Netmask = Not configured Backup Prov Network Default Router = Not configured Backup Prov Network Default Router = Not configured Backup Prov Network Address = 192.168.2.100 EPAP B Sync Network Address = 192.168.2.200 EPAP A Main DSM Network Address = 192.168.120.100 EPAP B Main DSM Network Address = 192.168.120.200 EPAP B Backup DSM Network Address = 192.168.121.100 EPAP B Backup DSM Network Address = 192.168.121.200

Upgrade/Installation Guide

		EPAP A HTTP Port= 80EPAP B HTTP Port= 8001EPAP B HTTP SUEXEC Port= 8001EPAP B HTTP SUEXEC Port= 8473EPAP A Banner Connection Port= 8473EPAP B Static NAT Address= Not configuredEPAP B Static NAT Address= Not configuredPDBI Port= 5873Remote MPS A Static NAT Address= Not configuredRemote MPS A HTTP Port= 80Local Provisioning VIP= 192.168.15.152Remote PDBA Address= 192.168.16.115Remote PDBA Address= 192.168.16.115Remote PDBA B Address= 192.168.16.116Time Zone= America/New_YorkPDB Database= ExistsPreferred PDB= YesAuto DB Recovery Enabled= YesPDBA Proxy Enabled = Yes then Execute Procedure A.19 on both PDBAActive and Standby for dual PDBA setup to disable EPAP VIP and PDBA proxyfeatures.Otherwise, if PDBA Proxy Enabled = No, then proceed with the next step.
4.	MPS A: Clear PDB replication logs	If PDBA Proxy Enabled = Yes then Execute Procedure A.29 to clear replication logs Otherwise, if PDBA Proxy Enabled = No, then skip this step.
5.	MPS A: Start screen session	Execute the following commands to start screen and establish a console session to MPS B. \$ screen -L
	<b>MPS A</b> : Connect to the console of MPS B.	Execute the following command on E5-APP-B: <b>\$ sudo minicom mate</b> If above command fails then refer to Procedure A.27.
6.	<b>MPS B</b> : Login prompt is displayed.	<hostname> console login: Note: Hit enter if no login prompt is displayed.</hostname>
7.	<b>MPS B</b> : Log in to the server as user "admusr".	If not already logged-in, then log in. <hostname> console login: admusr Password: <password></password></hostname>
8.	<b>MPS B:</b> Execute the platcfg menu	\$ sudo su – platcfg
9.	<b>MPS B:</b> Select the Maintenance / Upgrade submenu	The platcfg <b>Main Menu</b> appears. On the <b>Main Menu</b> , select <b>Maintenance</b> and press [ENTER]. Then select <b>Upgrade</b> menu and press [ENTER].

		Main Menu Maintenance Diagnostics Server Configuration Network Configuration Remote Consoles Exit Maintenance Menu Maintenance Menu Upgrade Backup and Restore View Mail Queues Restart Server Save Platform Debug Logs Exit
10.	MPS B: Reject Upgrade	Select the "Reject Upgrade" menu and press [ENTER].
		Validate Media         Early Upgrade Checks         Initiate Upgrade         Copy USB Upgrade Image         Non Tekelec RPM Management         Accept Upgrade         Reject Upgrade         Exit         Do you really want to reject the upgrade?         Image Image Image Image Image         NOTE: USB should be removed before initiating the backout on the server otherwise the system will not recover properly and will indicate a drive failure during backout.
11.	<b>MPS B</b> : Backout proceeds.	Many informational messages will come across the terminal screen as the backout proceeds. Finally, after backout is complete, a message will be displayed stating that a reboot is required.

		The server will be at runlevel 3 and no applications are running. Proceed to the next step to verify the backout and manually reboot the server.
12.	<b>MPS B</b> : Verify the Backout	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors were reported.
		# grep -i error /var/TKLC/log/upgrade/upgrade.log
		Examine the output of the above commands to determine if any errors were reported.
		Refer to section 0 to know more about logging.
13.	<b>MPS B</b> : Verify the Backout.	If the backout was <i>not</i> successful and errors were recorded in the logs, then contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F for further instructions.
		If the backout <i>was</i> successful, then continue with the following step.
14.	<b>MPS B</b> : Reboot the MPS.	Perform the following commands to reboot the MPS:
		# sudo init 6
15.	MPS B: Reboot completed.	After the reboot, the screen will display the login prompt, as shown in the example below.
		****
		1464603884: Upstart Job syscheck: started ####################################
		1464603884: Upstart Job tpdProvd: started ####################################
		1464603885: Upstart Job TKLCsnmp-subagent: started ####################################
		1464603886: Upstart Job ntdMgr: started ####################################
		Oracle Linux Server release 6.7 Kernel 2.6.32-573.18.1.el6prere17.0.3.0.0_86.44.0.x86_64 on an x86_64
		devloan-Ol login:
16.	<b>MPS B</b> : Verify Health of MPS B.	Execute Procedure A.1 on MPS B to verify the health of MPS B.
17.	<b>MPS B:</b> Sync the time on both MPS A and MPS	Sync the time on both MPS A and B if it is different.
	В.	Login to MPS A: <hostname> console login: epapdev Password: <password></password></hostname>
		Check date time on MPS A using following command: \$ date Sat Jul 7 01:35:18 EDT 2018
		Login to MPS B: <hostname> console login: epapdev Password: <password></password></hostname>
h		

#### **Procedure 24: Server B Backout**

		Check date time on MPS B using following command: \$ date
		Sat Jul 7 01:35:18 EDT 2018
		If both are not same then set the date time value on MPS B same as of MPS A. Use following command:
		First switch user to root: \$ su - root Password:
		Passworu:
		Execute command to set date on MPS B as bellow:
		# date -s <data-time a="" mps="" of=""></data-time>
		[root@Natal-B ~]# date -s "Sat Jul 7 02:05:41 EDT 2018" Sat Jul 7 02:05:41 EDT 2018 [root@Natal-B ~]#
		Done.
18.	MPS B: Clear MySQL replication error banner	Execute the following command to check for MySQL replication error: <b>\$ manageBannerInfo</b> -1
	message, if any	Examine the output of the above command to determine if any errors were reported related to MySQL replication such as:
		MySQL data replication error detected; Attempting to restart Attempt to restart MySQL replication failed
		Execute the following command to copy the EuiDB database from B server to A server to clear any of the above observed MySQL replication error.
		Note: This utility should be executed only with epapdev user.
		<pre>\$ /usr/TKLC/epap/config/resetReplication </pre>
		Resetting MySql Replication This script will fix EuiDB replication by copying the database from
		one side of the pair to the other side and then resetting
		the MySql replication pointers.
		Are you sure you want to reset replication? (y/n) y Which side do you want to copy FROM? (A/B) [B]: B
		Copy the EuiDB from B to A? (y/n) y
		Removing the index and info files from EPAP A Replication files successfully removed from the mate
		server.
		Connecting to local DB Connecting to mate DB
		Copying EuiDB to mate
		Stopping local slave
		Stopping mate slave
		Resetting local master Resetting mate master
		Resetting local slave
		Resetting mate slave
		Starting local slave
		Starting mate slave

#### **Procedure 24: Server B Backout**

		Resetting MySql Replication Completed
		If there is a failure in resetReplication, execute following commands:
		\$ mysql -uroot -peLapRoot -e "GRANT ALL ON EuiDB.* to elapdev@localhost IDENTIFIED by ' <password>'"</password>
		\$ mysql -uroot -peLapRoot -e "GRANT ALL ON EuiDB.* to elapdev@mate IDENTIFIED by ' <password>'"</password>
		Execute the following command to verify that the banner messages related to the replication error are cleared after some time. <b># manageBannerInfo -1</b>
19.	MPS B: Verify Health of MPS B	Execute Procedure A.1 on MPS B to verify the health of MPS B. If backout of major upgrade was performed, the syscheck utility will report the "300000000000002 – Server Internal Disk Error" alarm as the disk mirroring is in progress. The alarm will be cleared after the completion of disk mirroring.
20.	Reconnect console cable.	On E5-APP-B card, reconnect the console cable between the serial port labeled 'S0' on E5-APP-B B card's adapter and the serial port labeled 'S1' on the E5-APP-B A card's adapter. <b>Cable part numbers - 830-1220-xx</b>
21.	Procedure complete.	This procedure is complete.
22.	Note down the timestamp in log.	Run the following command: \$ date

The application should now be running at the original software release level

### Procedure 25 Backout both Server A and B

S T		des instructions to perform backout on both MPS A and MPS B servers.	
Ε	Check off ( $\mathbf{V}$ ) each step as it is	completed. Boxes have been provided for this purpose under each step number.	
P #	Note: Execute this procedure only if both MPS A and MPS B have been upgraded or partially upgraded and you wish to backout both servers to the previous version.		
	Note: If the upgrade h	as been accepted, this procedure cannot be performed.	
	Note: Database chang procedure	es post upgrade and before backout might be lost after performing backout	
1.	Terminate all previous connections (ssh).	If not already connected, connect to the E5-APP-B card via the serial port.	
		For connecting the E5-APP-B A card, disconnect the console cable from the serial port	
		on the E5-APP-B B card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B B card's adapter and use it for	
		serial access. Cable part numbers - 830-1220-xx	

		Skip to step 6, if connected through serial console.
2.	Create a terminal window and establish a connection by logging into MPS B.	In a newly created terminal window labeled "MPS A – from MPS B", connect directly into MPS B.
	Log into MPS B.	# ssh admusr@ <mps b=""> Password: <password></password></mps>
3.	<b>MPS B</b> : Start screen session.	Execute the following commands to start screen and establish a console session to MPS A.
		\$ screen -L
	<b>MPS B</b> : Connect to the console of MPS A.	Execute the following command on E5-APP-B:
	console of Wir 5 A.	<b>\$ sudo minicom mate</b> If above command fails then refer to Procedure A.27.
4.	<b>MPS A</b> : Login prompt is displayed.	<hostname> console login: Note: Hit enter if no login prompt is displayed.</hostname>
5.	<b>MPS A:</b> Log in to the server as user "admusr".	Log in as 'admusr' <hostname> console login: admusr Password: <password></password></hostname>
6.	<b>MPS A:</b> Verify that the state of PDBA Proxy Feature is No.	# sudo su - epapconfig
	<b>Note:</b> Skip this step for Non-Prov and PDBonly EPAP.	

EPAP Configuration Menu\
1   Display Configuration
2   Configure Network Interfaces Menu
3   Set Time Zone
4   Exchange Secure Shell Keys
5   Change Password
6   Platform Menu
7   Configure NTP Server
8   PDB Configuration Menu
9   Security
 10   SNMP Configuration
11   Configure Alarm Feed
12   Configure Query Server
13   Configure Query Server Alarm Feed
14   Configure SNMP Agent Community
15   Mate Disaster Recovery
e   Exit   /
ter Choice: 1 AP A Provisioning Network IP Address = 192.168.61.115 AP B Provisioning Network IP Address = 192.168.61.116 ovisioning Network Netmask = 255.255.255.0 ovisioning Network Default Router = 192.168.61.1 AP A Backup Prov Network IP Address = Not configured AP B Backup Prov Network IP Address = Not configured Ckup Prov Network Netmask = Not configured AP A Sync Network Default Router = Not configured AP A Sync Network Address = 192.168.2.200 AP A Main DSM Network Address = 192.168.120.100 AP B Main DSM Network Address = 192.168.120.100 AP A Backup DSM Network Address = 192.168.121.100 AP B Backup DSM Network Address = 192.168.121.200 AP A Backup DSM Network Address = 192.168.121.200 AP A HTTP Port = 80 AP A HTTP Port = 80 AP A HTTP SUEXEC PORT = 8001 AP A Banner Connection Port = 8473 AP B Banner Connection Port = 8473 AP B Static NAT Address = Not configured BI Port = 5873 mote MPS A Static NAT Address = Not configured BI Port = 80 cal Provisioning VIP = 192.168.15.152 mote Provisioning VIP = 192.168.15.152 mote Provisioning VIP = 192.168.15.152 = 192.168.15.152 = 192.168.15.115

		Remote PDBA Address= 192.168.16.115Remote PDBA B Address= 192.168.16.116Time Zone= America/New_YorkPDB Database= ExistsPDB Database= Ctardbuck
		Preferred PDB = Standby Allow updates from alternate PDB = Yes
		Auto <u>DB Recovery Enabled</u> = Yes
		PDBA Proxy Enabled   = Yes
		If PDBA Proxy Enabled = Yes then Execute Procedure A.19 on both PDBA
		Active and Standby for dual PDBA setup to disable EPAP VIP and PDBA proxy
		features.
		Otherwise, if PDBA Proxy Enabled = No, then proceed with the next step.
7.	MPS A:	
	Clear PDB replication logs	If PDBA Proxy Enabled = Yes then Execute Procedure A.29 to clear replication logs
	1085	Otherwise, if PDBA Proxy Enabled = No, then skip this step.
		oulerwise, if i DDr i loxy Endoled – 100, dien skip uns step.
8.	MPS A: Execute the	\$ sudo su – platcfg
	platcfg menu	
9.	MPS A: Select the Maintenance / Upgrade submenu	The platcfg <b>Main Menu</b> appears. On the <b>Main Menu</b> , select <b>Maintenance</b> and press [ENTER]. Then select <b>Upgrade</b> menu and press [ENTER].
		Main Menu Maintenance Diagnostics Server Configuration Network Configuration Remote Consoles Exit
		Maintenance Menu
		Upgrade
		Backup and Restore
		View Mail Queues
		Restart Server
		Save Platform Debug Logs
		Exit
10.	MPS A: Reject Upgrade	
	in or reject opgrade	Select the "Reject Upgrade" menu and press [ENTER].
		l

		Upgrade Menu         Validate Media         Early Upgrade Checks         Initiate Upgrade         Copy USB Upgrade Image         Non Tekelec RPM Management         Accept Upgrade         Reject Upgrade         Exit         Do you really want to reject the upgrade?
		<b>NOTE:</b> USB should be removed before initiating the backout on the server otherwise the system will not recover properly and will indicate a drive failure during backout.
11.	<b>MPS A</b> : Backout proceeds.	Many informational messages will come across the terminal screen as the backout proceeds.
		Finally, after backout is complete, a message will be displayed stating that a reboot is required. The server will be at runlevel 3 and no applications are running. Proceed to the next step
10		to verify the backout and manually reboot the server.
12.	<b>MPS A</b> : Verify the Backout.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors were reported.
		# grep -i error /var/TKLC/log/upgrade/upgrade.log # grep -i error /var/TKLC/log/upgrade/ugwrap.log
		Examine the output of the above commands to determine if any errors were reported.
		Refer to section 0 to know more about logging.
13.	<b>MPS A</b> : Verify the Backout.	If the backout was <i>not</i> successful and errors were recorded in the logs, then contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F for further instructions.
		If the backout <i>was</i> successful, then enter continue with the following steps:
14.	<b>MPS A</b> : Reboot the MPS.	<b>Perform this step only on a backout of an incremental upgrade.</b> Perform the following commands to reboot the MPS:
		# init 6
15.	MPS A: Backout completed.	After the reboot, the screen will display the login prompt, as shown in the example below.

		***************
		1464603884: Upstart Job syscheck: started ####################################
		1464603884: Upstart Job tpdProvd: started ####################################
		1464603885: Upstart Job TKLCsnmp-subagent: started ####################################
		1464603886: Upstart Job ntdMgr: started ####################################
		Oracle Linux Server release 6.7 Kernel 2.6.32-573.18.1.el6prere17.0.3.0.0_86.44.0.x86_64 on an x86_64 devloan-01 login:
16.	<b>MPS A</b> : Verify Health of	Execute Procedure A.1 on MPS A to verify the health of MPS A
	MPS A.	The syscheck utility may report the "5000000000000002 - Server Application Process Error" for PDBA, if the pdba software is not running.
17.	Terminate all previous connections (ssh).	If not already connected, connect to the E5-APP-B card via the serial port.
	connections (son).	For connecting the E5-APP-B B card, disconnect the console cable from the serial port on the E5-APP-B A card's adapter. The cable should be disconnected at the point where it connects to the serial port labeled 'S1' on the E5-APP-B A cards adapter and use it for serial access.
		Skip to step 21, if connected through serial console.
18.	Create a terminal window and establish a connection by logging into MPS A.	In a newly created terminal window labeled "MPS B – from MPS A", connect directly into MPS A.
	Log into MPS A.	# ssh epapdev@ <mps a=""> Password: <password></password></mps>
19.	MPS A: Start screen session.	Execute the following commands to start screen and establish a console session to MPS B.
		\$ screen -L
	MPS A: Connect to	Execute the following command on E5-APP-B:
	the console of MPS B.	<b>\$ sudo minicom mate</b> If above command fails then refer to Procedure A.27.
20.	MPS B: Login prompt is	<hostname> console login:</hostname>
	displayed.	Note: Hit enter if no login prompt is displayed.
21.	<b>MPS B:</b> Log in to the server as user "epapdev".	<hostname> console login: admusr Password: <password></password></hostname>
22.	<b>MPS B:</b> Execute the platcfg menu	\$ sudo su - platcfg
	ade/Installation Guide	151 of 279 August 2024

23.	MPS B: Select the Maintenance / Upgrade	The platcfg Main Menu appears. On the Main Menu, select Maintenance and press [ENTER]. Then select Upgrade menu
	submenu	and press [ENTER].
		Main Menu Maintenance Diagnostics Server Configuration Network Configuration Remote Consoles Exit
		Maintenance Menu Upgrade Backup and Restore View Mail Queues Restart Server Save Platform Debug Logs Exit
24.	MPS B: Reject Upgrade	Select the "Reject Upgrade" menu and press [ENTER].
		Vpgrade Menu Validate Media Early Upgrade Checks Initiate Upgrade Copy USB Upgrade Image Non Tekelec RPM Management Accept Upgrade Reject Upgrade Exit No you really want to reject the upgrade?
		<b>NOTE:</b> USB should be removed before initiating the backout on the server otherwise the system will not recover properly and will indicate a drive failure during backout.
25.	MPS B: Backout proceeds.	Many informational messages will come across the terminal screen as the backout proceeds.

31.	<b>MPS A</b> : Rejoin previous screen session on MPS B	Execute the following command to disconnect and then rejoin previous screen session: <b>\$ screen -dr</b>
30.	Create a terminal window and establish a connection by logging into MPS A. Log into MPS A	In a newly created terminal window labeled "MPS B – from MPS A", connect directly into MPS A. # ssh epapdev@ <mps a=""> Password: <password></password></mps>
		Oracle Linux Server release 6.7 Kernel 2.6.32-573.18.1.el6prerel7.0.3.0.0_86.44.0.x86_64 on an x86_64
		1464603885: Upstart Job TKLCsmmp-subagent: started ####################################
		1464603884: Upstart Job tpdProvd: started ####################################
		######################################
29.	<b>MPS B</b> : Login to MPS B.	After the reboot, the screen will display the login prompt, as shown in the example below.
28.	<b>MPS B</b> : Reboot the MPS.	Perform the following commands to reboot the MPS: <b>\$ init 6</b>
		If the backout <i>was</i> successful, then enter continue with the following steps:
27.	<b>MPS B</b> : Verify the Backout.	If the backout was <i>not</i> successful and errors were recorded in the logs, then contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F for further instructions.
		Examine the output of the above commands to determine if any errors were reported. Refer to section 0 to know more about logging.
		# grep -i error /var/TKLC/log/upgrade/upgrade.log # grep -i error /var/TKLC/log/upgrade/ugwrap.log
26.	<b>MPS B</b> : Verify the Backout.	Examine the upgrade logs in the directory /var/TKLC/log/upgrade and verify that no errors were reported.
		The server will be at runlevel 3 and no applications are running. Proceed to the next step to verify the backout and manually reboot the server.
		Finally, after backout is complete, a message will be displayed stating that a reboot is required.

32.	<b>MPS B:</b> Sync the time	Syne the time on both MDS A and D if it is different
	on both MPS A and MPS	Sync the time on both MPS A and B if it is different.
	В.	Login to MPS A: <hostname> console login: epapdev Password: <password></password></hostname>
		Check date time on MPS A using following command: \$ date
		Sat Jul 7 01:35:18 EDT 2018
		Login to MPS B: <hostname> console login: epapdev Password: <password></password></hostname>
		Check date time on MPS B using following command: \$ date Sat Jul 7 01:35:18 EDT 2018
		If both are not same then set the date time value on MPS B same as of MPS A. Use following command:
		First switch user to root: \$ su - root Password:
		Execute command to set date on MPS B as bellow:
		# date -s <data-time a="" mps="" of=""></data-time>
		[root@Natal-B ~]# date -s "Sat Jul 7 02:05:41 EDT 2018" Sat Jul 7 02:05:41 EDT 2018 [root@Natal-B ~]#
		Done.
33.	<b>MPS B:</b> Log in to the server as user "epapdev".	<hostname> console login: epapdev Password: <password></password></hostname>
34.	<b>MPS B</b> : Clear MySQL replication error banner message, if any	Execute the following command to check for MySQL replication error: <b>\$ manageBannerInfo -1</b>
		Examine the output of the above command to determine if any errors were reported related to MySQL replication such as:
		MySQL data replication error detected; Attempting to restart Attempt to restart MySQL replication failed
		Execute the following command to copy the EuiDB database from B server to A server to clear any of the above observed MySQL replication error.
		Note: This utility should be executed only with epapdev user
		<pre>\$ /usr/TKLC/epap/config/resetReplication Resetting MySql Replication</pre>
		This script will fix EuiDB replication by copying the database from one side of the pair to the other side and then resetting the MySql replication pointers.
		Are you sure you want to reset replication? (y/n) y Which side do you want to copy FROM? (A/B) [B]: B Copy the EuiDB from B to A? (y/n) y

		Removing the index and info files from EPAP A Replication files successfully removed from the mate server. Connecting to local DB Conpying EuiDB to mate DB Copying EuiDB to mate Stopping local slave Stopping mate slave Resetting local master Resetting local slave Resetting local slave Starting mate slave Starting mate slave Starting mate slave Resetting MySql Replication Completed If there is a failure in resetReplication, execute following commands: <b>\$ mysql -uroot -peLapRoot -e "GRANT ALL ON EuiDB.* to elapdev@localhost IDENTIFIED by '<password>'" <b>\$ mysql -uroot -peLapRoot -e "GRANT ALL ON EuiDB.* to elapdev@mate IDENTIFIED by '<password>'" Execute the following command to verify that the banner messages related to the replication error are cleared after some time. <b>\$ manageBannerInfo -1</b></password></b></password></b>
35.	MPS B: Verify Health of MPS B	Execute Procedure A.1 on MPS B to verify the health of MPS B.
		Encente des fallentines commend to de state DTDD and DDD detabase lander
36.	MPS A: Check if RTDB and PDBA databases are synchronized update this Note: Skip this step for PDBonly setup.	Execute the following command to check the RTDB and PDB database levels: \$ sudo dbstattoo1 The outlook may look like: DBSTATTOOL Platform=EPAP
37.	Reboot EAGLE Cards.	If the DB levels on EPAP and EAGLE matches and there is no alarm on EAGLE related to "RTDB reload is required", go to step 37.
		Reboot 1 SM card on the EAGLE and verify that it comes back to an IS-NR/Active state.
		If this is a Non-Provisionable EPAP, boot the rest of the EAGLE SM cards over 4 batches (booting 1/4 of the cards at a single time).

		If this is a Provisionable(mixed EPAP or PDBonly) EPAP, and the second MPS A on which backout has been executed, reboot the rest of the cards on both local and remote sides over 4 batches (booting 1/4 of the cards at a single time).
38.	Procedure is complete.	This procedure is complete.
39.	Note down the timestamp in log.	Run the following command: \$ date

#### The application should now be running at the original software release level

# Procedure 26 Stop the Pdba software

**Procedure 26: Stop the PDBA Software** 

S	This procedure stop the PDBA software before major upgrade.
Т	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.
E P #	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.

If backout has been performed, then execute this procedure ONLY after backout on all MPS servers in the entire set of El Otherwise, skip this procedure until all MPS servers have been backed out.

1. [		<hostname> console login: epapdev Password: <password></password></hostname>
2. [	MPS A: Verify Health of MPS A.	If not done already, execute Procedure A.1 on MPS A to verify the health of MPS A. Expect that the syscheck utility will report the 'Server Application Process Error' alarm for the fac software is not running. Besides the PDBA not running alarm, verify that no other abnormalities a
3. C	MPS A: Verify that Pdba software running or not.	Execute the command below to find if the pdba is running or not: <b>\$ ps -aef   grep pdba   grep -v "grep"</b> If the output contains an entry for the pdba, as shown below, then move to the next step. [epapdev@MPS A ~]\$ ps -eaf   grep "pdba"   grep -v "grep" epapdev 14165 11068 0 02:59 ? 00:00:07 /opt/TKLCappl/bin/pdba Otherwise, skip the next step as Pdba software already stopped.
4. C	MPS A: Turn off the PDBA_REMOTE_PD BI_ALLOWED flag to stop provisioning during upgrade.	Execute the command below to find the current status of PDBA_REMOTE_PDBI_ALLOWED fla [epapdev@Natal-A ~]\$ uiEdit   grep -i PDBA_REMOTE_PDBI_ALLOWED Skip this step if output of the above command is "PDBA_REMOTE_PDBI_ALLOWED" is set to

Procedure 26: Stop the PDBA Software

· · · · · ·		
	Note: This step must	Turn off the PDBA_REMOTE_PDBI_ALLOWED flag by running below command if output of p
	be performed in case	command is blank or not set to "OFF"
	of upgrade and	[epapdev@Natal-A ~]\$ uiEdit PDBA_REMOTE_PDBI_ALLOWED OFF
	PDBA software	"PDBA_REMOTE_PDBI_ALLOWED" is set to "OFF"
	needs to be	
	restarted, for this	
	change to take	
	effect.	
5.	MPS A: Stop the Pdba	Run the following command:
	software.	
		[epapdev@Natal-A ~]\$ service Pdba stop
		~~ /etc/init.d/Pdba stop ~~
		PDBA application stopped.
6.	MPS A: Verify that Pdba	
	software running or not	Repeat above step 3.
7.	Procedure complete.	This procedure is complete.
8.	Note down the timestamp	Run the following command:
	in log.	¢ data
		\$ date

# Procedure 27 Restart PDBA Software (Post-Backout and Post-Upgrade)

When upgrade is initiated on the first MPS-B, the PDBA software process is stopped on the MPS-A servers configured as **Provisionable**(mixed-EPAP or PDBonly). The PDBA software is intentionally left stopped, and so the operator performing the upgrade must restart the PDBA software after all MPS servers in a set of EPAP systems have been upgraded.

**WARNING:** If a backout of the MPS A and B units is conducted sometime after an upgrade has successfully completed and after Provisioning has been re-enabled, then the only method of PDB restoration is from backup file. In this case, any new data provisioned since the successful completion of the upgrade will be lost and will need to be re-provisioned.

#### Procedure 27: Restart the PDBA Software Post-Backout and Post-Upgrade

Ungr	ado/Installation Cuido	157 of 279	August 2024
3.	MPS A: Turn on the PDBA_REMOTE_PD	Execute the command below to find the curre	nt status of PDBA_REMOTE_PDBI_ALLOWED fla
2.	<b>Local MPS A</b> : Verify Health of MPS A.		MPS A to verify the health of MPS A. e 'Server Application Process Error' alarm for the fac ot running alarm, verify that no other abnormalities a
1.	<b>Local MPS A:</b> Log in to the server as user "epapdev".	<hostname> console login: epapdev Password: <password></password></hostname>	
		ned, then execute this procedure ONLY afte are until all MPS servers have been backed	r backout on all MPS servers in the entire set of E out.
#		·	
Р	IE THIS PROCEDUR	E FAILS CONTACT MV ORACLE SUPPO	ORT AND ASK FOR UPGRADE ASSISTANCE
T E	Check off ( $\checkmark$ ) each step as it is a	completed. Boxes have been provided for this purpose under	each step number.
S	This procedure restar	ts the PDBA software after upgrade of all a	associated MPS systems has been completed.

Upgrade/Installation Guide

	<b>BI_ALLOWED</b> flag to enable PDB to accept	[epapdev@Natal-A ~]\$ uiEdit   grep -i PDBA_REMOTE_PDBI_ALLOWED
	updates from remote PDBI.	Turn on the PDBA_REMOTE_PDBI_ALLOWED flag. Skip this step if output of the above comn "PDBA_REMOTE_PDBI_ALLOWED" is set to "ON" or no output is displayed
	Note: This step must be performed in case of upgrade and PDBA software needs to be restarted, for this change to take effect.	[epapdev@Natal-A ~]\$ uiEdit PDBA_REMOTE_PDBI_ALLOWED ON "PDBA_REMOTE_PDBI_ALLOWED" is set to "ON"
4.	<b>Local MPS A:</b> Restart the PDBA software.	Execute the command below to find if the pdba is running or not:
	On the menu, click PDBA->Process	<ul> <li>\$ ps -aef   grep pdba   grep -v "grep"</li> <li>If the output contains an entry for the pdba, as shown below, then skip to the next step.</li> </ul>
	Control->Start PDBA software	[epapdev@MPS A ~]\$ ps -aef   grep pdba  grep -v "grep" epapdev 23890 10248 0 Apr07 ? 00:01:18 /opt/TKLCappl/bin/pdba Otherwise, Login to EPAP GUI by uiadmin user and start PDBA software.
		A
		Are you sure you want to start the PDBA software?
		Start PDBA Software Tue June 20 2017 06:42:43 EDT
		Copyright © 2000, 2017, Oracle and/or its affiliates. All rights reserved.
5.	<b>Local MPS A</b> : Verify PDBA is running.	Execute Procedure A.1 on MPS A to verify the health of MPS A Verify that syscheck does <i>not</i> sho PDBA is <i>not</i> running.
6.	<b>Remote MPS A:</b> Log in to the server as user "epapdev".	<hostname> console login: epapdev Password: <password></password></hostname>
7.		
	<b>Remote MPS A</b> : Verify Health of MPS A.	
	Verify Health of MPS A. Remote MPS A: Restart the PDBA	Expect that the syscheck utility will alarm the fact that the PDBA software is not running. This wi "500000000000002 Server Application Process Error" alarm. Besides the PDBA not run verify that no other abnormalities are noted. Execute the command below to find if the pdba is running or not:
8.	Verify Health of MPS A. Remote MPS A:	Expect that the syscheck utility will alarm the fact that the PDBA software is not running. This wi "5000000000000002 Server Application Process Error" alarm. Besides the PDBA not run verify that no other abnormalities are noted.
8.	Verify Health of MPS A. Remote MPS A: Restart the PDBA software. On the menu, click PDBA->Process	Expect that the syscheck utility will alarm the fact that the PDBA software is not running. This wi "500000000000002 Server Application Process Error" alarm. Besides the PDBA not run verify that no other abnormalities are noted. Execute the command below to find if the pdba is running or not:
8.	Verify Health of MPS A. Remote MPS A: Restart the PDBA software. On the menu, click	Expect that the syscheck utility will alarm the fact that the PDBA software is not running. This wi "500000000000002 Server Application Process Error" alarm. Besides the PDBA not run verify that no other abnormalities are noted. Execute the command below to find if the pdba is running or not: \$ ps -aef   grep pdba   grep -v "grep"

#### Procedure 27: Restart the PDBA Software Post-Backout and Post-Upgrade

# Procedure 27: Restart the PDBA Software Post-Backout and Post-Upgrade

		A Start PDB
		Are you sure you want to start the PDBA software?
		Start PDBA Software
	, I	Tue June 20 2017 06:42:43 EDT
		Copyright © 2000, 2017, Oracle and/or its affiliates. All rights reserved.
9.	Remote MPS A:	Execute Procedure A.1 on MPS A to verify the health of MPS A. Verify that syscheck does not sh
	Verify PDBA is	PDBA is <i>not</i> running.
	running.	
10.	Procedure complete.	This procedure is complete.
	-	1 1
11.	Note down the timestamp	Run the following command:
	in log.	
	- 6	\$ date

# THIS COMPLETES THE BACKOUT

# APPENDIX A GENERIC PROCEDURES

# Procedure A.1 Perform System Health Check

### Appendix A.1 Perform System Health Check

S	This procedure performs a system health check on any MPS server.	
T E	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.	
Р		
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .	
1.	Log in as the admusr user.	<hostname> console login: admusr</hostname>
		<hostname> console login: admusr Password: <password></password></hostname>
2.	Execute the platcfg menu.	¢ sude su platofa
		\$ sudo su - platcfg
3.	Select the Diagnostics	The platcfg Main Menu appears.
	submenu.	On the Main Menu, select Diagnostics and press [ENTER].
		hain henu
		Maintenance
		Diagnostics
		Server Configuration Security
		Remote Consoles
		Network Configuration
		Exit
4.	Select the Online	Select the Online Diagnostics submenu and press [ENTER].
	Diagnostics submenu.	Diagnostics Menu
		Online Diagnostics
		Network Diagnostics
		View Upgrade Logs
		Alarm Manager Platform Revision
		Exit
5.	Select the Non-	Select the Non-Verbose option and press [ENTER].
	Verbose option.	- Online Diagnostics Menu
		I online plagnopolop nena
		Non Verbose
		Verbose Exit
		EXIC
6.	Examine the output of	Example output shown below. Examine the actual output of the Online Diagnostics.
	the Online Diagnostics.	

	Appendix A.1 Po	erform System Health Check
		Copyright (C) 2003, 2018, Oracle and/or its affiliates. All rights reserved. Hostname: DBExpan-Nidhi-VM77
		Online Diagnostics Output Running modules in class disk
		Running modules in class hardware OK
		Running modules in class net OK
		<pre>Running modules in class proc * run: FAILURE:: MINOR::50000000000002 Server Application Process Error * run: FAILURE:: MINOR::500000000000002 Server Application Process Error * run: FAILURE:: Only 0 instance(s) of epapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: MINOR::500000000000002 Server Application Process Error * run: FAILURE:: Only 0 instance(s) of epapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: Only 0 instance(s) of epapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: Only 0 instance(s) of epapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: Only 0 instance(s) of epapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: Only 0 instance(s) of epapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: Only 0 instance(s) of epapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: Only 0 instance(s) of epapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: Only 0 instance(s) of epapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: Only 0 instance(s) of epapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: ONLY 0 INSTANCE 0 EpapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: ONLY 0 INSTANCE 0 EpapSnmpAgent running. 1 instance(s) required! * run: FAILURE:: ONLY 0 INSTANCE 0 EpapSnmpAgent running. 1 INSTANCE 0 EpapSnmpAge</pre>
		Running modules in class upgrade OK
		Forward Backward Top Bottom Exit Use arrow keys to move between options   <enter> selects</enter>
7.	System Check	Exit from the above menu.
Ш	Successful.	If the System Check was successful, return to the procedure that you came here from.
		If the "Server Disk Space Shortage Error" was there in the output, proceed to step 8 to clean up the '/' directory.
	System Check Failure.	If any other failures were detected by System Check, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F.
8.	Server clean-up to	Execute the following command:
Ш	create space.	\$ df -h /var/TKLC
		The output may look like:
		<pre>[admusr@hostname ~]\$ df -h /var/TKLC Filesystem Size Used Avail Use% Mounted on /dev/mapper/vgroot-plat_var_tklc</pre>
		Verify that there is at least 600M in the Avail column. If not, clean up files until there is space available.
		CAUTION: Make sure you know what files you can remove safely before cleaning up. It is recommended that you only clean up files in the /var/TKLC/upgrade directory as this is a platform owned directory that should only contain ISO images. This directory should not be expected to contain images for any length of time as they can get purged.
		Also, execute the following command to check space in '/lib/module' directory.
		\$ df -h /lib/modules
		[admusr@hostname ~]\$ df -h /lib/modules Filesystem Size Used Avail Use% Mounted on /dev/mapper/vgroot-plat root
	ade/Installation Guide	161 of 279 August 2024

		976M 397M 529M 43% /
		Verify that the Use% column does not exceed the value 80%.
9.	Procedure complete.	Return to the procedure that you came here from.
10.	Note down the timestamp in log.	Run the following command: \$ date

#### Appendix A.1 Perform System Health Check

# Procedure A.2 Validate Upgrade Media

This procedure is used to execute a validation of the Upgrade Media (typically an ISO image) separately from executing an upgrade. The upgrade process automatically validates the upgrade media. However, sometime the user may wish to perform just a validation before proceeding with upgrade, thus the reason for this separate process.

Validation could be performed on MPS A or B, however, this procedure specifies MPS X for simplicity.

#### Appendix A.2 Validate the Upgrade Media

S T E	This procedure provides instructions to perform a validation of the upgrade media on the MPS X server. This procedure assumes that the E5-APP-B card IPM procedure has been executed and the user has an EPAP Upgrade ISO image available.		
P #	Check off ( $\checkmark$ ) each step as it is a	Check off ( $\checkmark$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.	
	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND <b>ASK FOR <u>UPGRADE</u></b> ASSISTANCE.		
1.	MPS X: If necessary, log in to the server as the user "admusr".	If not already logged in to the MPS server, then login as user "admusr". <hostname> console login: admusr</hostname>	
		password: <password></password>	
2.	<b>MPS X:</b> Execute the platcfg menu.	\$ sudo su - platcfg	
3.	<b>MPS X</b> : Select the Maintenance submenu.	The platefg Main Menu appears. On the Main Menu, select Maintenance and press [ENTER]. Main Menu Maintenance Diagnostics Server Configuration Network Configuration Remote Consoles Exit	
4.	MPS X: Select the Upgrade submenu.	Select the Upgrade menu and press [ENTER].  Maintenance Menu  Upgrade Backup and Restore View Mail Queues Restart Server Save Platform Debug Logs Exit	

# Appendix A.2 Validate the Upgrade Media

5.	MPS X: Select the Validate Media selection.	Select the Validate Media menu and press [ENTER].
6.	MPS X: Output from the Validate Media selection.	The screen will display a message that it is searching for upgrade media. Once the upgrade media is found, an Upgrade Media selection menu will be displayed similar to the example shown below. If the upgrade media is not found, follow <b>Procedure A.12</b> to copy the upgrade ISO. Select the upgrade media or ISO image. There should only be one selection available, as shown in the example below. If there is more than one selection available, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F 1qqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqq
7.	MPS X: View the Validation results.	The results of the validation will be displayed, similar to the example below. Press the "enter" key to continue.

	Appendix A.2 Va	alidate the Upgrade Media
		Validating cdrom Validating cdrom Validating cdrom Validating cdrom Validating validate Utility v2.3.4, (c)Tekelec, May 2020 Validating /var/TKLC/upgrade/EPAP-16.4.0.0.0_163.4.0-x86_64.iso DatesTime: 2020-04-13 05:33:26 Volume ID: 16.4.0.0.0_163.4.0 Part Number: N/A Version: 16.4.0.0.0_163.4.0 Disc Label: EPAP Disc description: EPAP The media validation is complete, the result is: PASS CDROM is Valid
8.	<b>MPS X</b> : Select the Exit option.	PRESS ANY KEY TO RETURN TO THE PLATCFG MENU.         Select the Exit option, and keep selecting the Exit option, until you reach the command line prompt or you return to another menu that you wish to use.         lqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqqq
9.	<b>MPS X</b> : Procedure complete.	Media Validation is complete. Return to the procedure that you came here from.
10.	Note down the timestamp in log.	Run the following command: \$ date

# Procedure A.3 System Configuration Backup

	Appendix A.3	System Configuration Backup
S T	This procedure per	forms configuration backup on an MPS Server.
E	Check off ( $\checkmark$ ) each ste	ep as it is completed. Boxes have been provided for this purpose under each step number.
P #	IF THIS PROCEDUR	E FAILS, CONTACT MY ORACLE SUPPORT AND <b>ASK FOR <u>UPGRADE ASSISTANCE</u>.</b>
1.	MPS X: If necessary,	If not already logged in to the MPS server, then login as user "admusr".
	log in to the server as the user "epapdev".	<hostname> console login: admusr password: <password></password></hostname>
2.	<b>MPS X:</b> Execute the	
	platcfg menu.	\$ sudo su – platcfg
3.	<b>MPS X</b> : Select the Maintenance submenu.	The platcfg <b>Main Menu</b> appears. On the <b>Main Menu</b> , select <b>Maintenance</b> and press [ENTER].
		Main Menu Maintenance Diagnostics Server Configuration Security Remote Consoles Network Configuration Exit
4.	MPS X: Select the Backup Platform submenu.	Select the <b>Backup and Restore</b> menu and press [ENTER].
		Maintenance Menu         Upgrade         Patching         Backup and Restore         Restart Server         Save Platform Debug Logs         Platform Data Collector         Exit
5.	MPS X: Select the Backup Platform submenu.	Select the Backup Platform (USB) submenu and press [ENTER].

	Appendix A.3	System Configuration Backup
		Backup And Restore Menu Backup Platform(USB) Backup Platform(CD/DVD) Restore Platform Restore USB Archive Exit
6.	<b>MPS X</b> : Backup continues.	The backup continues. The following busy screen may appear.          System Busy         Loading default backup configuration.         Please wait
7.	<b>MPS X</b> : Select the Build TGZ file only selection.	Select the Build TGZ file only selection and press [ENTER].  Backup TekServer Menu Select Backup Type (plat-app) View Index Table of Contents Select Backup Device( none) Build TGZ file only Backup Eject device Exit
8.	MPS X: Backup complete – select exit. MPS X: Transfer the	Once the TGZ has been created, the " <b>Backup TekServer Menu</b> " will be displayed again. Select the Exit option, and keep selecting the Exit option, until you reach the command line prompt. The backup file is in the /var/TKLC/bkp directory and will have a name like
	backup file.	<pre><hostname>-plat-app-[date][time].tgz Execute the following command to view the backup file: \$ 1s -1 /var/TKLC/bkp [admusr@Recife-a bkp]\$ 1s -1 /var/TKLC/bkp/ total 5836 -rw-rw 1 root sys 5972128 Sep 11 09:04 Recife-a-plat-app-201809110904.tgz</hostname></pre>
	<b>MPS X:</b> Transfer file to remote machine.	<pre>Using SFTP (secure-FTP), transfer the ISO to a remote, customer-provided computer. Enter "yes" when prompted if you want to continue to connect. \$ cd /var/TKLC/bkp \$ sftp <ip address="" computer="" of="" remote=""> Connecting to <ip address="" computer="" of="" remote=""> The authenticity of host '<ip address="" computer="" of="" remote="">' can't be established.</ip></ip></ip></pre>

	Appendix A.3	System Configuration Backup
		DSA key fingerprint is 58:a5:7e:1b:ca:fd:1d:fa:99:f2:01:16:79:d8:b4:24. Are you sure you want to continue connecting (yes/no)? <b>yes</b> Warning: Permanently added <ip address="" computer="" of="" remote="">' (DSA) to the list of known hosts.</ip>
		<pre>root@<ip address="" computer="" of="" remote="">'s password:</ip></pre>
		sftp> cd <target directory=""></target>
		<pre>sftp&gt; put <hostname>-plat-app-[date][time].tgz Uploading <hostname>-plat-app-[date][time].tgz to <hostname>-plat- app-[date][time].tgz sftp&gt; bye</hostname></hostname></hostname></pre>
		If no customer provided remote computer for backups exist, transfer the backup file to the mate using the following command:
		<pre>\$ sudo chmod 667 /var/TKLC/bkp/<tgz file=""> \$ su - epapdev \$ scp /var/TKLC/bkp/<tgz file=""> epapdev@mate:/var/TKLC/epap/free/</tgz></tgz></pre>
11.	Procedure complete.	Return to the procedure that you came here from.
12.	Note down the timestamp in log.	Run the following command: \$ date

# Procedure A.4 Execute parse9Dig script

Appendix A.4 Execute parse9Dig script

S T	This procedure perfe	This procedure performs the Execution of parse9Dig script.	
I E	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.		
P			
#	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.	
1.	MPS A: Login as the	If not already logged-in, then login at MPS A:	
	user "epapdev" on standalone PDB.	<pre><hostname> console login: epapdev</hostname></pre>	
	standarone i DD.	password: <password></password>	
2.	MPS A: Check if "parse9Dig" script is	Check whether "parse9Dig" script is present on setup or not.	
	present on setup.	Execute following command:	
		<pre>\$ ls -lrt /usr/TKLC/epap/config/parse9Dig</pre>	
		[epapdev@Natal-a-PDBonly ~]\$ ls -lrt	
		/usr/TKLC/epap/config/parse9Dig	
		-rwxr-xr-x 1 epapdev epap 12162 Oct 10 16:23 /usr/TKLC/epap/config/parse9Dig	
		/usi/ikic/epap/config/parsesbig	
		If output is same as above then proceed to step 4 otherwise proceed with following step.	
-			
3.	<b>MPS A:</b> Execute the "parse9Dig" script on	Note: Stop the Pdba software before executing this script.	
	standalone PDB.		
		Execute the "parse9Dig" script and examine the result.	
1			

		\$/usr/TKLC/epap/config/parse9Dig all u
		<pre>[epapdev@Osorna-1B-PDBonly config]\$ /usr/TKLC/epap/config/parse9Dig all u</pre>
		This utility will retrieve all digits for DB and parse them into 9Dig entries.
		*****
		Utility Start Time: 06/13/18-21:24:31
		Parsing DN digits into 9digits
		INFO: DN 9dig count 2.
		REPLACE INTO dn9dig VALUES (UNHEX("0500000000"),1),(UNHEX("0600000000"),1);
		Parsing IMSI digits into 9digits
		INFO: IMSI 9dig count: 9.
		REPLACE INTO imsi9dig VALUES (UNHEX("0D001234567"),3), (UNHEX("0600000000"),1), (UNHEX("07000000 09"),1), (UNHEX("0800000044"),1), (UNHEX("0800000023"),2), (UNHEX("05000000000"),1), (UNHEX("080000 00077"),1), (UNHEX("0800000099"),1), (UNHEX("0800000088"),1);
		Parsing IMEI digits into 9digits
		INFO: IMEI 9dig count: 1.
		REPLACE INTO imei9dig VALUES (UNHEX("0E012345678"),2);
		Utility End Time: 06/13/18-21:24:31
		-
4.	MPS A: Procedure is	This procedure is complete.
	complete.	
5.	Note down the	Run the following command:
	timestamp in log.	
		\$ date

# Procedure A.5 Increase rtVolume size for Non-prov

S	This procedure increas	e rtVolume size for Non-prov.	
Т	1		
Ε	Check off ( $$ ) each step as	s it is completed. Boxes have been provided for this purpose under each step number.	
Р			
#	IF THIS PROCEDURE FA	AILS, CONTACT MY ORACLE SUPPORT AND <b>ASK FOR <u>UPGRADE ASSISTANCE</u></b> .	
	<b>^ ^</b>	mixed EPAP and standalone EPAP.	
1.	<b>MPS A:</b> Log in to the server.	If not already logged-in, then login at MPS A: <hostname> console login: epapdev Password: <password></password></hostname>	
2.	MPS A: Execute "rtdir_300gb" script for E5-APP-B cards with 300GB drive modules.	If EPAP is running on an E5-APP-B card with 300GB drive modules, execute this step. If instead, EPAP is running on an E5-APP-B card with 480GB drive modules, skip this step and go to step 3. Download the rtdir_300gb script zip file from My Oracle Support(MOS) ( <u>https://support.oracle.com</u> ). The zip file is available on MOS under Oracle Communications EAGLE Application Processor 16.3.0.0.0. Place the zip file in the /tmp directory. Unzip the file: <b>\$ unzip <zip file="" from="" mos="" name=""></zip></b> <b>\$ cat Readme.txt</b> Follow the directions in the Readme.txt file. Execute the following script: <b>\$ sudo /usr/TKLC/epap/bin/rtdir_300gb</b>	

	Appendix A.5	Increase rtVolume size for Non-prov
		Warning: This utility would increase rtVolume for non-prov setup and this action is irreversible.
		Are you sure you want to continue?[Yes/No]: Yes
		INFO: Increasing rt volume size for Non-provisionable EPAP. Please wait
		INFO: db space increased on 'A'.
		INFO: Stopping Epap, mysqlapp and mysqlpdb services Done.
		INFO: Starting Epap, mysqlapp and mysqlpdb services Done.
		INFO: Successfully configured Non-provisionable EPAP.
		Following error related to MyISAM table shall be observed on CLI while executing rtdir script:
		<pre>myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' e2fsck 1.43-WIP (20-Jun-2013) File descriptor 7 (socket:[102707]) leaked on lvreduce invocation. Parent PID</pre>
		25006: sh resize2fs 1.43-WIP (20-Jun-2013) File descriptor 7 (socket:[102707]) leaked on vgdisplay invocation. Parent PID
		25350: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25359: sh
		resize2fs 1.43-WIP (20-Jun-2013) File descriptor 7 (socket:[102707]) leaked on vgdisplay invocation. Parent PID 25410: sh
		File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25416: sh myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
		FIPS integrity verification test failed. FIPS integrity verification test failed.
		.WARNING: Reducing active logical volume to 8.00 GiB. THIS MAY DESTROY YOUR DATA (filesystem etc.).
		Skip step 3 and continue with step 4.
3.	MPS A: Execute "rtdir" script for E5-APP-B cards with 480GB drive modules.	If EPAP is running on an E5-APP-B card with 300GB drive modules, do not execute this step. Instead, execute step 2. If EPAP is running on an E5-APP-B card with 480GB drive modules, execute this step.
	modules.	Execute the following script: \$ sudo /usr/TKLC/epap/bin/rtdir
		Warning: This utility would increase rtVolume for non-prov setup and this action is irreversible.
		Are you sure you want to continue?[Yes/No]: Yes
		INFO: Increasing rt volume size for Non-provisionable EPAP. Please wait
		INFO: db space increased on 'A'. INFO: Stopping Epap, mysqlapp and mysqlpdb services
		Done. INFO: Starting Epap, mysqlapp and mysqlpdb services Done.

		INFO: Successfully configured Non-provisionable EPAP.
		Following error related to MyISAM table shall be observed on CLI while executing rtdir script:
		<pre>myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' e2fsck 1.43-WIP (20-Jun-2013) File descriptor 7 (socket:[102707]) leaked on lvreduce invocation. Parent PID 25006: sh resize2fs 1.43-WIP (20-Jun-2013) File descriptor 7 (socket:[102707]) leaked on vgdisplay invocation. Parent PID 25350: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID 25359: sh resize2fs 1.43-WIP (20-Jun-2013) File descriptor 7 (socket:[102707]) leaked on vgdisplay invocation. Parent PID 25359: sh resize2fs 1.43-WIP (20-Jun-2013) File descriptor 7 (socket:[102707]) leaked on vgdisplay invocation. Parent PID 25410: sh File descriptor 7 (socket:[102707]) leaked on lvextend invocation. Parent PID</pre>
		25416: sh myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI'
		FIPS integrity verification test failed. FIPS integrity verification test failed.
		WARNING: Reducing active logical volume to 8.00 GiB. THIS MAY DESTROY YOUR DATA (filesystem etc.).
4.	<b>MPS A</b> : Verify rtVolume size using command "df -h".	[epapdev@Arica-1A ~]\$ df -h Filesystem Size Used Avail Use% Mounted on /dev/mapper/vgroot-plat root
		976M 288M 637M 32% / tmpfs 3.9G 0 3.9G 0% /dev/shm
		/dev/md1 244M 40M 192M 18% /boot /dev/mapper/vgroot-plat_tmp
		976M 2.0M 923M 1% /tmp /dev/mapper/vgroot-plat_usr
		3.9G 2.5G 1.2G 68% /usr /dev/mapper/vgroot-plat_var
		976M 206M 720M 23% /var /dev/mapper/vgroot-plat_var_tklc
		3.9G 1.8G 1.9G 49% /var/TKLC /dev/mapper/vgroot-db
		5.8G 4.3G 1.2G 79% /var/TKLC/epap/db /dev/mapper/vgroot-free
		320G 5.3G 298G 2% /var/TKLC/epap/free /dev/mapper/vgroot-logs 20G 89M 19G 1% /var/TKLC/epap/logs
		/dev/mapper/vgroot-rt 82G 3.3G 75G 5% /var/TKLC/epap/rt
		[enandew@lrics_11 ~10]
		Vgroot-rt size should be greater than 80G.
5.	MPS B: Execute "rtdir" or "rtdir_300gb" script.	After successfully converted rtVolume size on MPS A, repeat steps 2, 3, and 4 on MPS B.

**Upgrade/Installation Guide** 

6.	MPS B: Procedure completed.	This procedure is completed.	
7.	Note down the timestamp in log.	Run the following command: \$ date	

# Appendix A.5 Increase rtVolume size for Non-prov

# Procedure A.6 PDB Backup

# Appendix A.6 PDB Backup

6		
S T E P #	This procedure performs a PDB backup on the EPAP server configured as a Provisionable (mixed-EPAP or PDBonly) node. This procedure should only be performed on the active PDBA. Note: Only one PDB Backup is allowed, to be stored. In case another backup is required, workaround is to setup the remote transfer of the existing pdb backup and then delete it.	
	Check off ( $\mathbf{V}$ ) each step	as it is completed. Boxes have been provided for this purpose under each step number.
		FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR <u>UPGRADE ASSISTANCE</u> .
1.	<b>MPS A:</b> Log in to the server.	If not already logged-in, then login at MPS A: <hostname> console login: epapdev Password: <password></password></hostname>
2.	Run syscheck.	Execute the following Command: \$ syscheck
3.	Verify the System Check executed successfully. In particular, verify that the PDBA process is running by noting that syscheck does not generate an alarm against the PDBA process.	Running modules in class disk Running modules in class net Running modules in class proc Running modules in class proc Running modules in class system OK Running modules in class hardware OK The log is available at: >/var/TKLC/log/syscheck/fail_log If the syscheck utility reports the "5000000000002 – Server Application Process Error" alarm, restart the PDBA and execute syscheck again. The above alarm should be removed. If the above alarm is not removed, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F.
4.	System Check Verifies that PDBA is running.	If the syscheck does not report any errors, proceed to the next step. Otherwise, if any other failures were detected by System Check, contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F.
5.	Log into epapconfig.	\$ su - admusr \$ sudo su - epapconfig
6.	Main menu is displayed. Select Platform Menu.	Menu for mixed-EPAP: /EPAP Configuration Menu\   1   Display Configuration 

**Upgrade/Installation Guide** 

	Appendix A.6 PI	DB Backup
		5 Change Password
		6 Platform Menu
		7 Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10   SNMP Configuration
		11   Configure Alarm Feed
		12   Configure Query Server
		13   Configure Query Server Alarm Feed
		14 Configure SNMP Agent Community
		15   Mate Disaster Recovery
		e   Exit
		Enter Choice: 6
7.	Platform menu is displayed. Select PDB	Menu for standard EPAP designation:
	Backup.	/EPAP Platform Menu-\
		/\   1   Initiate Upgrade
		2   Reboot MPS
		4   RTDB Backup 
		5   PDB Backup 
		e   Exit    \/
		Enter Choice: 5
		Menu for PDB-only designation:
		/EPAP Platform Menu-\
		/\    1   Initiate Upgrade
		2   Reboot MPS
		    3   MySQL Backup
		   4   PDB Backup
		e   Exit   \/
		Enter Choice: 4
8.	Menu will prompt for a	Are you sure you want to backup the PDB to
	"yes" to continue. Enter a <b>Y</b> .	<pre>/var/TKLC/epap/free/pdbBackup_DBExpPdbOnly_20180613055813_DBBirthd ate 20180613072847GMT DBLevel 6507 v7.50.bkp.tar.gz? [N]:</pre>
9.	While the backup is	
	begin performed, the following output will be	Successfully started backup of PDB. Status will be displayed on the GUI banner.
	displayed to the screen.	Press return to continue
	Note: Only one PDB Backup is allowed, to be	
	stored.	Note: If following error is displayed instead of success, then you need to delete all pdbBackup from free directory in order to
		schedule new pdbBackup.
L		

	Appendix A.6 PDB Backup			
		E1058: An internal error in the EPAP occurred: pdbBackup already exists in free directory. Press return to continue		
10.	Exit this menu and return to the login prompt.	Enter Choice: e Note: If this menu is not exited properly, then the SSH login with root shall remain enabled.		
11.	Monitor GUI banner.	Monitor the GUI banner. When the backup has completed successfully, continue to the next step.		
12.	Use SFTP to transfer the backup file to a remote customer provided computer.	Using SFTP (secure-FTP), transfer the PDB backup file to a remote, customer-provided computer. Enter "yes" when prompted if you want to continue to connect. <b>\$ cd /var/TKLC/epap/free</b>		
		<pre>\$ sftp <ip address="" computer="" of="" remote=""> Connecting to <ip address="" computer="" of="" remote=""> The authenticity of host '<ip address="" computer="" of="" remote="">' can't be established. DSA key fingerprint is 58:a5:7e:1b:ca:fd:1d:fa:99:f2:01:16:79:d8:b4:24. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added <ip address="" computer="" of="" remote="">' (DSA) to the list of known hosts. root@<ip address="" computer="" of="" remote="">'s password: sftp&gt; cd <target directory=""> sftp&gt; put pdbBackup_<hostname>_20140530151806_DBBirthdate_ 20140530144717GMT_DBLevel_<dblevel>.bkp.tar.gz Uploading pdbBackup_<hostname>_20140530151806_DBBirthdate_ 20140530144717GMT_DBLevel_<dblevel>.bkp.tar.gz to pdbBackup_<hostname>_ 20140530151806_DBBirthdate_20140530144717GMT_DBLevel_<dblevel>.bkp .tar.gz sftp&gt; bye If no customer provided remote computer for backups exist, transfer the backup file to the mate using the following command \$ su - epapdev \$ scp /var/TKLC/epap/free/<pdb backup="" file=""> epapdev@mate:/var/TKLC/epap/free/<pdb backup="" file=""> epapdev@mate:/var/TKLC/epap/free/</pdb></pdb></dblevel></hostname></dblevel></hostname></dblevel></hostname></target></ip></ip></ip></ip></ip></pre>		
13.	Procedure complete.	Return to the procedure that you came here from.		
14.	Note down the timestamp in log.	Run the following command: \$ date		

# Procedure A.7 RTDB Backup

Note: Skip this procedure for PDBonly setup.

S	This procedure perfor	-	
Т	This procedure performs an RTDB backup on the EPAP server.		
E P	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.		
#		FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.	
1.	<b>MPS :</b> Log in to the server.	If not already logged-in, then login to the MPS server. <hostname> console login: admusr Password: <password></password></hostname>	
2.	Enter the epapconfig menu.	Execute the following command: <b>\$ sudo su - epapconfig</b>	
3.	Main menu is displayed.		
	Select Platform Menu.	/EPAP Configuration Menu\ /\	
		1   Display Configuration	
		   2   Configure Network Interfaces Menu	
		   3   Set Time Zone	
		   4   Exchange Secure Shell Keys	
		   5   Change Password	
		   6   Platform Menu	
		   7   Configure NTP Server   	
		   8   Security   	
		   9   SNMP Configuration   	
		10   Configure Alarm Feed	
		11   Configure SNMP Agent Community	
		12   Mate Disaster Recovery	
		e   Exit   \/	
		Enter Choice: 6	
4.	Platform menu is displayed. Select RTDB	/EPAP Platform Menu-\	
	Backup.	/\   1   Initiate Upgrade	
		   2   Reboot MPS	
		   3   MySQL Backup	
		   4   RTDB Backup	
		   5   PDB Backup	
		   e   Exit   \/	
		Enter Choice: 4	
	l		

	Appendix A.7 KIDB Backup			
5.	The Application software must be stopped.	If the EPAP application software is running, you will be prompted to stop the software for the RTDB backup. Select with a "Y". EPAP software is running. Stop it? [N]: Y		
6.	Menu will prompt for a "yes" to continue. Enter a <b>Y</b> .	Are you sure you want to backup the PDB to /var/TKLC/epap/free/ rtdbBackup_Recife-A_20140530151806.tar.gz? [N]:		
7.	While the backup is begin performed, the following output will be displayed to the screen.	Successfully started backup of RTDB. Status will be displayed on the GUI banner. Press return to continue		
8.	Exit this menu and return to the login prompt. Continue exiting until you get to the login prompt.	Enter Choice: e Enter Choice: e Note: If this menu is not exited properly, then the SSH login with root shall remain enabled.		
9.	Monitor GUI banner.	Monitor the GUI banner. When the backup has completed successfully, continue to the next step.		
10.	Restart the EPAP Software.	Restart the EPAP application software. <pre>\$ sudo /etc/init.d/Epap start</pre>		
11.	Use SFTP to transfer the backup file to a remote customer provided computer.	<pre>Using SFTP (secure-FTP), transfer the RTDB backup file to a remote, customer- provided computer. Enter "yes" when prompted if you want to continue to connect. \$ cd /var/TKLC/epap/free \$ sftp <ip address="" computer="" of="" remote=""> Connecting to <ip address="" computer="" of="" remote=""> The authenticity of host '<ip address="" computer="" of="" remote="">' can't be established. DSA key fingerprint is 58:a5:7e:1b:ca:fd:1d:fa:99:f2:01:16:79:d8:b4:24. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added '<ip address="" computer="" of="" remote="">' (DSA) to the list of known hosts. root@<ip address="" computer="" of="" remote="">'s password: sftp&gt; cd <target directory=""> sftp&gt; put rtdbBackup_<hostname>_20140530151806.tar.gz Uploading rtdbBackup_<hostname>_20140530151806.tar.gz to rtdbBackup_<hostname>_20140530151806.tar.gz to rtdbBackup_<hostname>_20140530151806.tar.gz sftp&gt; bye</hostname></hostname></hostname></hostname></target></ip></ip></ip></ip></ip></pre>		
12.	Procedure complete.	Return to the procedure that you came here from.		
13.	Note down the timestamp in log.	Run the following command: \$ date		

# Appendix A.7 RTDB Backup

# Procedure A.8 EuiDB Backup

	Appendix A.8 E	uiDB Backup	
S T	This procedure performs a backup of the User database on the MPS server.		
Ε	<b>E</b> Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.		
P       #       IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSIS			
1.	<b>MPS A:</b> Log in to the server as user "admusr".	<hostname> console login: admusr Password: <password></password></hostname>	
2.	Enter the epapconfig menu.	Execute the following Command:	
		\$ sudo su - epapconfig	
3.	Master menu is displayed. Select	/EPAP Configuration Menu\ /\	
	Platform Menu.	1   Display Configuration	
		2   Configure Network Interfaces Menu   	
		3   Set Time Zone   	
		4   Exchange Secure Shell Keys   	
		   5   Change Password   	
		   6   Platform Menu   	
		   7   Configure NTP Server   	
		   8   PDB Configuration Menu   	
		   9   Security   	
		10   SNMP Configuration	
		   11   Configure Alarm Feed   	
		12   Configure Query Server	
		   13   Configure Query Server Alarm Feed	
		   14   Configure SNMP Agent Community	
		   15   Mate Disaster Recovery	
		   e   Exit	
		\/	
4.	Platform menu is	Enter Choice: 6	
	displayed. Select MySQL Backup.	/EPAP Platform Menu-\ /\	
		1   Initiate Upgrade   	
		2   Reboot MPS   	
		3   MySQL Backup   	
		4   RTDB Backup	
		5   PDB Backup	

# Appendix A.8 EuiDB Backup

**Upgrade/Installation Guide** 

	Appendix A.8 E	uiDB Backup
		e   Exit   \/
		Enter Choice: 3
5.	You will then be prompted to verify that you want to backup the MySQL Database.	Are you sure you want to backup the MySQL database on MPS A? [N]:
6.	Type "Y" and press enter.	Press Y
7.	While the backup is begin performed, the following output will be displayed to the screen.	NPDB Backed up Successfully to /var/TKLC/appl/free/ <file name=""></file>
8.	Exit this menu and return to the Unix login prompt. Continue	Enter Choice: e
	exiting until you get to the Unix login prompt.	Note: If this menu is not exited properly, then the SSH login with root shall remain enabled.
9.	Use SFTP to transfer the backup file to a remote customer provided computer.	Using SFTP (secure-FTP), transfer the NPDB backup file to a remote, customer- provided computer. Enter "yes" when prompted if you want to continue to connect. \$ cd /var/TKLC/epap/free
		<pre>\$ sftp <ip address="" computer="" of="" remote=""> Connecting to <ip address="" computer="" of="" remote=""> The authenticity of host '<ip address="" computer="" of="" remote="">' can't be established. DSA key fingerprint is 58:a5:7e:1b:ca:fd:1d:fa:99:f2:01:16:79:d8:b4:24. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added '<ip address="" computer="" of="" remote="">' (DSA) to the list of known hosts. root@<ip address="" computer="" of="" remote="">'s password: sftp&gt; cd <target directory=""> sftp&gt; put npdbBackup_<hostname>_20140530151806.sql.gz Uploading npdbBackup_<hostname>_20140530151806.sql.gz to npdbBackup_<hostname>_20140530151806.sql.gz sftp&gt; bye</hostname></hostname></hostname></target></ip></ip></ip></ip></ip></pre> If no customer provided remote computer for backups exist, transfer the backup file to the mate using the following command \$ su - epapdev \$ scp /var/TKLC/epap/free/ <npdb backup="" file=""> epapdev @mate:/var/TKLC/epap/free</npdb>
10.	Procedure complete.	Return to the procedure that you came here from.
11.	Note down the timestamp in log.	Run the following command: \$ date

**Upgrade/Installation Guide** 

# Procedure A.9 RTDB Reload from PDBA

	Appendix A.9	RTDB Reload from PDBA
S T	This procedure prov	ides instructions to reload RTDB from PDBA.
E P	Check off ( $$ ) each step	as it is completed. Boxes have been provided for this purpose under each step number.
#	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.
1.	EPAP A: Log in to the web GUI as user "uiadmin".	EPAP 16.4.0.0.0 User Interface
2.	<b>EPAP A:</b> Put EPAP in Force Standby Mode.	A Change Forced Standby Status
	Expand the "Maintenance" Folder.	i INFO: The STANDBY restriction is NOT currently in place for EPAP A.
	Expand the "Force Standby" Folder.	CAUTION: This action will prevent this EPAP from updating the RTDB until the STANDBY restriction is removed (by executing this menu item again).
	Select the "Change Status" link.	Activate STANDBY Restriction
	Click on "Activate STANDBY Restriction" Button.	A Change Forced Standby Status ✓ SUCCESS: The STANDBY restriction is now ON.
3.	<b>EPAP A:</b> Reload RTDB from PDBA.	A Reload RTDB from PDBA
	Expand the "RTDB" Folder. Expand the "Maintenance" Folder. Select the "Reload from PDBA" link. Click on the "Reload" Button.	CAUTION: This action will cause the selected RTDB to be completely reloaded from the PDBA. Once the action is started, the RTDB will be unusable until the reload is completed. It is necessary for this EPAP to be in Forced Standby mode to ensure that it will not attempt to become ACTIVE while the reload is in progress. Continue with the reload only if you are sure. Reload
		A Reload RTDB from PDBA
	Observe the "SUCCESS" Status.	SUCCESS: The reload has been initiated. You can check its progress by viewing the RTDB status. Also, an informational message has been added to the Banner. The message will be cleared when the reload is complete.

	Appendix A.9	RTDB Reload from PDBA
4.	<b>EPAP A:</b> Wait for completion. Observe the GUI informational message and wait for the RTDB Reload completion message before proceeding.	
5.	<b>EPAP A:</b> Remove EPAP from Force Standby Mode.	A Change Forced Standby Status
	Expand the "Maintenance" Folder.	i INFO: The STANDBY restriction is currently in place for EPAP A.
	Expand the "Force Standby" Folder.	<b>CAUTION:</b> This action will allow this EPAP to resume updating the RTDB.
	Select the "Change Status" link.	Remove STANDBY Restriction
	Click on "Remove STANDBY Restriction" Button.	A Change Forced Standby Status
		SUCCESS: The STANDBY restriction is now OFF.
6.	<b>EPAP A:</b> Verify RTDB status.	A View RTDB Status
	Expand the "RTDB"	Local RTDB Status
	Folder. Select the "View	DB Status: Coherent Audit Enabled: Yes
	RTDB Status" link.	RTDB Level: 1 RTDB Birthday: 05/22/2014 14:57:49 GMT
		PDB Level:1PDB Birthday:05/09/2014 07:51:44 GMTCounts:IMSIs=0, DNs=0, DN Blocks=0, NEs=1, ASDs=0
		Counts:IMISIS=0, DINS=0, DIN BIOCKS=0, NES=1, ASDS=0Tables:IMSI=0, DN=0, IMEI=0, ASD=0
		DB Size: 3 M MinDsmSz: 0 MB (0) Reload: None
		The RTDB Status must be Coherent.
7.	Procedure complete.	Return to the procedure that you came here from.
8.	AT . 1	
	Note down the timestamp in log.	Run the following command:

# Procedure A.10 RTDB Restore

	Appendix A.10 F	ATDB Restore	
S T	This procedure prov	ides instructions to restore RTDB from a backup file.	
E P	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.		
#	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.	
1.	<b>EPAP A:</b> Log in to the web GUI as user "uiadmin".		
2.	<b>EPAP A:</b> Stop Software.	CEPAP A: uiadmin     Select Mate     Process Control     State Software	
	On the menu, click Process Control->Stop Software. Click "Stop EPAP Software" Button	Stap Software       Stap Software         Maintenance       CAUTION: The action will stop all EPAP software processes, and will prevent the selected EPAP from updating the RTDB until the EPAP software is re- started (by executing the Start Software mensi iem).         Maintenance       C Check if you want the software to automatically start on reboot.         Maintenance       PDBA         Reload from RPBA       Reload from RPBA         Reload from RPBA       Check if you want to stop the PDBA software to automatically start on reboot.         Configure Record Delay       Check if you want to stop the EPAP software?         Debug       Stop EPAP Software         Public       Stop EPAP Software         Users Administration       Stop EPAP Software         Users Administration       The January 06 2015 10127103 EST         Copyright © 2000, 2014, Oncle and/or its affiliates. All rights reserved.	
		Authorized IPs Terminate UI Sessions Change Password Logout A Stop EPAP Software	
		SUCCESS: The EPAP Software has been stopped.	
		Tue January 06 2015 10:29:53 EST	
		Copyright © 2000, 2014, Oracle and∕or its affiliates. All rights reserved.	
3.	<b>EPAP A:</b> Restore RTDB.	EPAP A: uiadmin     Select Mate     Process Control	
	On the menu, click RTDB->Maintenance- >Restore RTDB	Start Software Please specify the sub directory (default is /var/TKLC/epap/free) Maintenance View RTDB Status Maintenance Kalo down PDBA	
		Reload from Remote     Backup RTDB     Tue Januazy 06 2015 10:30:40 EST     Copyright © 2000, 2014, Oracle and/or its affliates. All rights reserved.     Configure Record Delay	
	Select the backup file, then click "Restore RTDB from the Selected File" Button	Cettrave Records      Debug      Platform      PloBA      Change Password	
		A Restore the RTDB	
		CAUTION: This action will restore the RTDB from the specified file on the selected EPAP. The EPAP software must be stopped on the selected EPAP in order for the restore to be allowed.	
		Select         Type         Originating Host         File Name         File Size         Creation Time           Image: TrdbBackup         Recifie-A         rtdbBackup Recifie-A         577K bytes         Tue January 06 2015 10:25:35 EST	
		Restore RTDB from the Selected File.	
	Click "Confirm RTDB Restore" Button		

	Appendix A.10 F	RTDB Restore
		A Restore the RTDB
		AUTION: This backup file may be incompatible with your system.
		Are you sure that you want to restore the RTDB from the file rtdbBackup_Cusco-A_20181128103003_DBBirthdate_20141015030619GMT_DBLevel_78687002_v4.72.bkp.tar.gz ?
		Confirm RTDB Restore
		NOTE: Caution message regarding "incompatible file" is displayed in above snapshot as
		the backup file is taken on RTDB version 4 and is being restored on RTDB version 5.
		Restore successfully started:
		A Restore the RTDB
		SUCCESS: Successfully started restore of RTDB from file rtdbBackup_Floater- 03_20170510021047_v4.72.bkp.tar.gz . Restore status will be displayed on Banner message window.
		Wed June 13 2018 16:38:09 EDT
		Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
4.	<b>EPAP A:</b> Make EPAP down.	Conferming that Restore RTDB in progress:
	An IM alarm should be observed with	A Informational Messages
	informational message on EPAP GUI	
	confirming that restore RTDB is in progress.	Informational Messages
	r B	Restore RTDB in progress
	An IM alarm should be	Wed June 13 2018 16:39:09 EDT
	observed with informational message	Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
	on EPAP GUI confirming that restore	
	RTDB completed	
	successfully.	
	Click "Confirm RTDB Restore" Button	

	Appendix A.10 F	<b>RTDB Restore</b>	
		Conferming that	t Restore RTDB is completed successfully:
		A	Informational Messages
			<b>Informational Messages</b> Restore RTDB completed successfully
			5 2018 00:30:27 EDT
		Сору	rright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
5.	<b>EPAP A:</b> RTDB converter is started.	This step is perf	formed only to support EAGLE release 46.7.0.0.0 (On the setup where
	An IM alarm should be observed with informational message on EPAP GUI confirming that RTDB Conversion in progress.	DB Architecture	e is eXtreme): Informational Messages
	An IM alarm should be observed with informational message		Informational Messages RTDB Conversion in progress
	on EPAP GUI confirming that RTDB Conversion completed successfully.		3 2018 16:55:42 EDT right © 2000, 2018, Oracle and/or its affiliates. All rights reserved.

	Appendix A.10 F	RTDB Restore
		A Informational Messages
		Informational Messages
		RTDB conversion completed successfully
		Fri June 15 2018 00:37:57 EDT
		Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
6.	Procedure complete.	Return to the procedure that you came here from.
7.	Note down the timestamp in log.	Run the following command: \$ date

# Procedure A.11 RTDB Reload from Remote

Appendix A.11 RTDB Reload from Remote

S	This procedure prov	ides instructior	ns to restore RTDB from a backup file.
T E P #	· · ·	•	d. Boxes have been provided for this purpose under each step number. CT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.
п 1.	<b>EPAP B:</b> Log in to the		
	web GUI as user "uiadmin".		EPAP 16.4.0.0.0 User Interface
2.	EPAP B: Stop Software.		
	On the menu, click Process Control->Stop Software. Click "Stop EPAP Software" Button	EPAP 8: uiadmin     Select Mae     Start Schwei     Start Schwei     Start Schwei     Start Schwei     Start Schwei     Deken     Deken     Deken     Charge Password     Logout	B Stop EPAP Software  Comparison of the states will use at EPAP software processes, and will prevent the velocited EPAP from updating the KIDB unit the EPAP software is re- Comparison of the State Software mean item).  C Check if you want the software to automatically start on reboot.  State Parameters want to stop the EPAP software.  State Parameters of 2000 State State Software at the software state software is re- Comparison of the State Software software is resourced.  State Software Software Software Software Software software is re- Comparison of the State Software software software is re- Comparison of the State Software software software is re- Comparison of the State Software software is re- Comparison of the State Software s

		B Stop EPAP Software
		SUCCESS: The EPAP Software has been stopped.
		Tue January 06 2015 11:22:17 EST
3.	<b>EPAP B:</b> Reload RTDB from Remote. On the menu, click RTDB->Maintenance- >Reload from Remote	NOTE: If reload is attempted from a remote Non-Prov site, kindly exchange the keys between this Non-Prov and the Non-Prov from where reload is being attempted. If reload is from mate, no need to do anything. B Reload RTDB from Remote
	Select Mate.	This action will copy the RTDB from the specified source machine to the local machine. The EPAP software must be stopped
	Click "Begin RTDB Reload from Remote" Button	on both the source and destination machine in order for the copy to be allowed. Source EPAP:
	Click "Confirm RTDB Reload from Remote"	Begin RTDB Reload from Remote Tue March 01 2016 09:18:31 EST Copyright © 2000, 2015, Oracle and/or its affiliates. All rights reserved.
	Button	B Reload RTDB from Remote
		Are you sure that you want to reload the RTDB from the mate? Confirm RTDB Reload from Remote
4.	<b>EPAP B:</b> Reload RTDB from Mate	
	An IM alarm should be observed with informational message on EPAP GUI confirming the start of the reload process An informational alarm should be displayed with informational message when the reload is complete	B Informational Messages Informational Messages Reload RTDB from mate in progress Tue June 12 2018 18:57:47 EDT Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
		B Informational Messages
		Informational Messages Reload RTDB from mate completed successfully
		Tue June 12 2018 19:01:21 EDT
		Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.

Appendix A.11 RTDB Reload from Remote

-		
5.	MPS A and B: Restart the GUI Server process.	Login to EPAP cli as epapdev user: Login: epapdev Password: <epapdev_password> Run following commands to restart GUI server process \$ pkill gs \$ ssh mate pkill gs</epapdev_password>
6.	MPS B: Start the Epap software on EPAP A and B.	<pre>\$ ssh mate /etc/init.d/Epap start ~~ /etc/init.d/Epap start ~~ EPAP application started. \$ service Epap start ~~ /etc/init.d/Epap start ~~ EPAP application started.</pre>
7.	MPS B: Checking the RTDB Status Log onto the GUI of the B server and select	\$ pkill gs B View RTDB Status Local RTDB Status
	RTDB, View RTDB Status. Verify that the DB status for the local and the mate is Coherent	DB Status:CoherentAudit Enabled:YesRTDB Level:8PDB Birthday:12/31/2014 15.01/20 GMTPDB Level:8PDB Birthday:12/31/2014 15.02.16 GMTCounts:IMSI=0, DN=7, DN Blocks=0, NEs=1, ASD=0Tables:IMSI=0, DN=1, IMEI=0, ASD=0DB Size:403 MMinDsmSz14/36 MB (1105 on epap240m)Reload:UnknownVesBirthday: 12/31/2014 15.01/20 GMTDB Status:CoherentAudit Enabled:PDB Level:8PDB Birthday:12/31/2014 15.01/20 GMTPDB Level:8PDB Birthday:12/31/2014 15.01/20 GMTPDB Level:8PDB Birthday:12/31/2014 15.02/16 GMTCounts:IMSIs=0, DN=7, DN Blocks=0, NEs=1, ASD=0Tables:IMSIs=0, DN=1, IMEI=0, ASD=0DB Size:403 MMinDsmSzPDS Size:403 MMinDsmSzReload:Unknown
8.	Procedure complete.	Procedure Complete.
9.	Note down the timestamp in log.	Run the following command: \$ date

#### Appendix A.11 RTDB Reload from Remote

# Procedure A.12 ISO Image download from Oracle Software Delivery Cloud

This procedure defines the step to download the ISO from OSDC and copy to the test server at specific path.

#### Appendix A.12 ISO Image download from OSDC

S	This procedure provid	des instructions to download an ISO image from OSDC and copy to the required
Т	server.	
Ε	,	
Р	Check off ( $$ ) each step a	as it is completed. Boxes have been provided for this purpose under each step number.
#		
	IF THIS PROCEDURE F	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.
1.	MPS X: Log in to the	[hostname] consolelogin: admusr
	server as the "admusr"	password: <admusr_password></admusr_password>
	user.	

	Appendix A.12 IS	O Image download from OSDC
2.	<b>MPS X:</b> Run syscheck to make sure there is no error.	Execute the following command: <b>\$ sudo syscheck</b>
	enor.	The output should look like:
		[admusr@hostname ~]\$ syscheck
		Running modules in class disk
		OK Running modules in class hardware
		OK
		Running modules in class net
		OK
		Running modules in class proc
		OK Running modules in class system
		OK
		Running modules in class upgrade
		OK
		LOG LOCATION: /var/TKLC/log/syscheck/fail_log
3.	<b>MPS X:</b> Verify ISO image doesn't already exist.	Execute the following command to perform directory listing: <b>\$ ls -alrt /var/TKLC/upgrade</b>
	CAISt.	The output should look like as follows (There is no ISO is present in following example):
		[admusr@Osorna-B-PDBonly ~]\$ ls -alrt /var/TKLC/upgrade/
		total 12
		drwxrwxr-x. 3 root admgrp 4096 Feb 19 21:43 . dr-xr-xr-x. 22 root root 4096 Jun 15 2018
		dr-xr-xr-x. 22 root root 4096 Jun 15 2018
		If an ISO image exists, remove it by executing the following command:
		<pre>\$ rm -f /var/TKLC/upgrade/<iso image=""></iso></pre>
4.	Download the ISO image from OSDC.	Download the ISO image from OSDC(Oracle Software Delivery Cloud).
5.	Copy the ISO from source path to destination path.	NOTE: Skip this step if same ISO is already present on destination folder.
		Copy the ISO image from source path to destination path using scp/ftp command.
		Execute the following command on destination server:
		\$ sudo scp <source_username>@<source_server_ip>:/<source_path>/xyz.iso /var/TKLC/upgrade</source_path></source_server_ip></source_username>
		Password: <enter source="" userpassword=""></enter>
		OR,
		Execute the following command on source server:
		\$ scp / <source_path>/<xyz.iso> admusr@<destination_server_ip>:/var/TKLC/upgrade</destination_server_ip></xyz.iso></source_path>
		Password: <enter admusr="" password=""></enter>

#### Appendix A.12 ISO Image download from OSDC

#### Appendix A.12 ISO Image download from OSDC

6.	<b>MPS X:</b> Verify ISO image copied on destination path.	Execute the following command to perform directory listing: <b>\$ ls -alrt /var/TKLC/upgrade</b>
		The output should look like: [admusr@hostname ~]\$ ls -alrt /var/TKLC/upgrade
		total 1599016
		-rr 1 root root 925388800 Aug 23 02:15 EPAP- 16.3.0.0.0_163.12.0-x86_64.iso
		dr-xr-xr-x. 22 root root 4096 Aug 23 02:31
		drwxrwxr-x. 3 root admgrp 4096 Sep 11 04:38 .
		Repeat this procedure from step 1 if EPAP ISO file is not as expected.
7.	<b>MPS X:</b> Validate ISO file.	Validate ISO file using Procedure A.2.
8.	Procedure complete.	This procedure is complete.
9.	Note down the timestamp	Run the following command:
	in log.	\$ date

#### Procedure A.13 IPM MPS Server with TPD 7.6.2

#### Note: Both the MPS-A and MPS-B servers can be IPM'ed at the same time.


Appendix A.13 IPM with TPD 7.6.2

C	TT1 · 1 · 11 TT	
S	This procedure will le	PM the E5-APP-B Server.
Т		
Е	Check off (1) each step	as it is completed. Boxes have been provided for this purpose under each step number.
	Check on () each step	as it is completed. Doxes have been provided for this purpose under each step number.
Р		
#	IF THIS PROCEDURE F	FAILS, CONTACT MY ORACLE SUPPORT AND <b>ASK FOR <u>UPGRADE ASSISTANCE</u>.</b>
1.	MPS X:	Reboot server
	-	# reboot
	Insert TPD 7.6.2 USB	# reboot
	media into the USB	
	port (E5-APP-B)	

Appendix A.13 IPM with TPD 7.6.2 🚰 10.250.78.106 - PuTTY 2. \_ 🗆 X MPS X: Main Main Advanced PCIPnP Boot Security Chipset Exit Press 'del' key to \* Use [ENTER], [TAB] System Overview enter the BIOS, set \* or [SHIFT-TAB] to \*\*\*\*\*\* System Time to GMT \* AMIBIOS \* select a field. Version :08.00.15 time, and System \* Build Date:02/17/12 \* ID :0ACAA002 \* Use [+] or [-] to \* configure system Time. Date. Processor Intel(R) Xeon(R) CPU L5238 0 2.66GHz Speed :2666MHz Count :1 \* \* System Memory Select Screen :8192MB \* \*\* Select Item Size \* +-Change Field 105:56:321 \* Tab Select Field [Thu 06/21/2012] \* F1 System Date General Help \* F10 Save and Exit \* ESC Exit v02.61 (C)Copyright 1985-2006, American Megatrends, Inc. 3. MPS X: 10.250.78.106 - PuTTY . 🗆 🗡 Select *Boot*  $\rightarrow$  *Hard* . Advanced PCIPnP Boot Security Main Chipse \*\*\*\*\* \*\*\*\*\* Disk Drives option Specifies the Boot Settings \*\*\*\*\* \* Boot Device \* Boot Settings Configuration \* Priority sequence \* from available \* \* Boot Device Priority Hard Drives. \* \* Select Screen \* \*\* \* \*\* Select Item \* Enter Go to Sub Screen \* F1 General Help \* F10 Save and Exit \* ESC Exit an Megatr 4. MPS X: \_ 🗆 🗙 🖥 root@greenlantern-a:/usr/TKLC/epap/bin Press 'Enter' key and • Boot select USB as the 1st \*\*\*\*\*\* Hard Disk Drives \* Specifies the boot Drive available devices. [HDD:P1-INTEL SSDSA] 2nd Drive 3rd Drive [HDD:PO-INTEL SSDSA] \* \* Select Screen \* \*\* Select Item \* +-Change Option \* F1 General Help \* F10 Save and Exit \* ESC Exit \*\*\*\*\*\*\*\* .61 (C)Copyright 1985-2006, American Megatrends, Inc

5.	MPS X: Press 'Esc' key and select Boot Device Priority	Poot@greenlantern-a:/usr/TKLC/epap/bin         Main       Advanced       PCIPnP       Boot       Security       Chipset       Exit         * Boot Settings       * Specifies the       *         * totation       * Specifies the       *         * Boot Settings Configuration       * Priority sequence.       *         * Boot Device Priority       *       *         * Hard Disk Drives       *       *         * *       *       *         * *       *       *         * *       *       *         * *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         *       *       *         * <td< th=""></td<>
6.	MPS X: Verify that the 1 <sup>st</sup> Boot Device is set to USB.	<pre>* * * * * * * * * * * * * * * * * * *</pre>
7.	<b>MPS X:</b> Press 'Esc' key and select <i>Exit</i> $\rightarrow$ <i>Save</i>	<pre>* * menu. * * menu. * * * * * * * * * * * * * * * * * * *</pre>
	Changes and Exit option	<pre>* Exit Options * Exit system setup * * *********************************</pre>

8.		
	MPS X: Select [OK] to save the configuration changes. The server will reboot and TPD boot prompt will appear.	✓ root@greenlantern-a:/usr/TKLC/epap/bin       ▲         Main       Advanced       PCIPnP       Boot       Security       Chipset       Exit       ▲         * Exit Options       *       Exit system setup       *
9.	MPS X:	
	Start the IPM process by entering the TPDIvm command at the boot prompt.	<pre>Bibts18041abs.ncttkelec.com PUTTV</pre>
10.	MPS X:	
	After a few seconds, additional messages will begin scrolling by on the screen as the Linux kernel boots, and then the drive formatting and file system creation steps will begin.	



	After a few minutes,	Package Installation
	you will see a screen	rackage instartation
	similar to that at right,	
	showing the status of	58%
	the package	
	installation step. For	Packages completed: 549 of 818
	each package, there	
	will be a status bar at	Installing selinux-policy-TPD-1.4.0-7.3.0.0.0_88.26.0.noarch (900 KB)
	the top indicating	Tekelec SELinux policy modules.
	how much of the	
	package has been	
	installed, with a	
	cumulative status bar	
	at the bottom	
	indicating how many	
	packages remain. In	
	the middle, you will	
	see text statistics	
	indicating the total	
	number of packages,	
	the number of	
	packages installed,	
	the number	
	remaining, and	
	current and projected	
	time estimates.	
13.	MPS X:	
	-	
	Once all the packages	
	have been	Welcome to Oracle Linux Server for x86_64
	successfully installed,	
	the screen at right will	
	appear letting you	
	know the installation	Complete
	process is complete.	Congratulations, your Oracle Linux Server installation is complete.
		congravatations, your orabic binan server insolatiation is compresely
		Please reboot to use the installed system. Note that updates may
		be available to ensure the proper functioning of your system and
	On E5-APP-B server	be available to ensure the proper functioning of your system and
	remove the	be available to ensure the proper functioning of your system and
	remove the installation media	be available to ensure the proper functioning of your system and installation of these updates is recommended after the reboot.
	remove the installation media (USB) and press	be available to ensure the proper functioning of your system and installation of these updates is recommended after the reboot.
	remove the installation media (USB) and press <enter> to reboot</enter>	be available to ensure the proper functioning of your system and installation of these updates is recommended after the reboot.
	remove the installation media (USB) and press <enter> to reboot the system and</enter>	be available to ensure the proper functioning of your system and installation of these updates is recommended after the reboot.
	remove the installation media (USB) and press <enter> to reboot the system and continue with the</enter>	be available to ensure the proper functioning of your system and installation of these updates is recommended after the reboot.
	remove the installation media (USB) and press <enter> to reboot the system and</enter>	be available to ensure the proper functioning of your system and installation of these updates is recommended after the reboot.

Appendix A.13 IPM with TPD 7.6.2 🚰 10.250.78.106 - PuTTY 14. \_ 🗆 × MPS X: Main Adv Main Advanced PCIPnP Boot Security Chipset Exit Press 'del' key to \* Use [ENTER], [TAB] System Overview enter the BIOS, set \*\*\*\*\*\*\*\*\*\* or [SHIFT-TAB] to correct System Time \* AMIBIOS \* select a field. Version :08.00.15 in GMT and System \* Build Date:02/17/12 \* ID :0ACAA002 \* Use [+] or [-] to \* configure system Time. Date. Processor Intel(R) Xeon(R) CPU L5238 0 2.66GHz Speed :2666MHz Count :1 \* \* System Memory Select Screen :8192MB \* \*\* Select Item Size \* +-Change Field 105:56:321 \* Tab Select Field [Thu 06/21/2012] \* F1 System Date General Help \* F10 Save and Exit \* ESC Exit v02.61 (C)Copyright 1985-2006, American Megatrends, Inc. 15. MPS X: 10.250.78.106 - PuTTY - 🗆 🗵 Select *Boot*  $\rightarrow$  *Hard* Chipset Exit . Main Advanced PCIPnP Disk Drives option Boot Settings Specifies the \* Boot Settings Configuration \* Priority sequence \* from available \* Hard Drives. \* Boot Device Priority \* \* Select Screen \* \*\* Select Item \* Enter Go to Sub Screen \* F1 General Help \* F10 Save and Exit \* ESC Exit American Megatren 16. MPS X: Putty - 192.168.58.183 - Putty \_ 🗆 🗡 Press 'Enter' key and \* Boot select HDD:P0 as the \*\*\*\*\*\* Hard Disk Drives \* Specifies the boot 1<sup>st</sup> Drive \* sequence from the available devices. [HDD:P1-INTEL SSDSA] 2nd Drive 3rd Drive [USB:SMART USB] \* \* Select Screen \* \*\* Select Item \* +-Change Option \* F1 General Help \* F10 Save and Exit \* ESC Exit \*\*\*\*\*\*\* 61 (C)Copyright 1985-2006, American Megatrends, Inc

	Appendix A.13 II	PM with TPD 7.6.2
17.	MPS X:	
	Press 'Esc' key and select Boot Device Priority	Imain       Advanced       PCIPnP       Boot       Security       Chipset       Exit         * Main       Advanced       PCIPnP       Boot       Security       Chipset       Exit         * Boot       Settings       * Specifies the       *         * Boot       Settings       * Specifies the       *         * * Boot       Settings       * Priority sequence.       *         * * Boot       Device       *       *         * * Boot       Device       *       *         * * Hard       Disk       *       *       *         * *       *       *       *       *         * *       *       *       *       *
		*       *       *       *         *       *       *       *         *       *       *       *         *       *       Select Screen       *         *       *       Select Item       *         *       *       Select Item       *         *       *       Select Item       *         *       *       *       Select Item       *         *       *       *       Select Item       *         *       *       *       *       *         *       *       *       *       *         *       *       *       *       *       *         *       *       *       *       *       *       *         *       *       *       *       *       *       *       *         *       *       *       *       *       *       *       *       *       *         *<
18.	MPS X: Verify that the 1 <sup>st</sup> Boot Device is set to HDD:P0.	Boot         * Boot Device Priority         * Boot Device Priority         * Ist Boot Device         [HD:PO-INTEL SSDSA]         * A device enclosed in         * A device enclosed in         * available devices.         *         * A device enclosed in         * available devices.         *         * A device enclosed in         * available devices.         *         * disabled in the         *
19.	MPS X: Press 'Esc' key and select <i>Exit</i> → <i>Save</i> <i>Changes and Exit</i> option	Main Advanced PCIPhP Boot Security Chipset Exit          * Exit Options          * Save Changes and Exit          * Discard Changes          * Discard Changes          * Discard Changes          * Load Optimal Defaults          * Load Failsafe Defaults          * *          * *          * *          *          *          *          *          *          *          *          *          *          *          *          *          *          *

20.	MPS X: Select [OK] to save the configuration changes. The server will reboot. Remove USB media from USB drive.	Image: Solution of the second seco
21. □	MPS X: Log in to the server as the user "admusr"	console login: admusr password: <admusr_password></admusr_password>
22. □	MPS X: Verify that the platform revision is same as the TPD DVD or ISO used.	<b>\$ getPlatRev</b> 7.6.2.0.0-y.z.0
23.	MPS X: Verify the system date.	\$ date -u         Wed Mar 21 11:04:54 UTC 2018         Verify that the output time matches the time set in step 14. If mismatch is found, then Refer to Appendix F for instructions on accessing My Oracle Support.
24.	Procedure complete.	Return to the procedure that you came here from.
25.	Note down the timestamp in log.	Run the following command: \$ date

### Procedure A.14 Standalone PDB Segmented Configuration

Note: All the networks (Prov, GUI and OAM) should be in different subnets. The networks can be a mix of IPv4 and IPv6 IPs.

Appendix A.14Standalone PDB Segmented Configuration

S	This procedure will configure the standalone PDB in segmented configuration.
Т	

# Appendix A.14 Standalone PDB Segmented Configuration

E P #	Check off (√) each step as it is completed. Boxes have been provided for this purpose under each step number. IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND <b>ASK FOR <u>UPGRADE ASSISTANCE</u></b> .	
1.	<b>MPS A:</b> Log on Server A.	[hostname] consolelogin: admusr password: <i>password</i>
2.	<b>MPS A:</b> Switch user to epapconfig.	\$ sudo su – epapconfig
3.	<b>MPS A:</b> A note of caution appears. Press Return to continue.	Caution: This is the first login of the text user interface. Press return to continue
4.	<b>MPS A:</b> Upon pressing Return you can now abort or proceed with the initial configuration. To continue with the configuration, enter Y.	Are you sure you wish to continue? [N]:Y
5.	<b>MPS A:</b> Enter the System Number and Network Configuration Type as "Segmented".	<pre>Building the initial database on side A.    Stopping local slave No preexisting EuiDB database was detected. Set EPAP System Number: <enter here="" number="" system="" the=""> Enter the Network Configuration Type (1 for Single, 2 for Segmented): 2</enter></pre>
6.	MPS A: The EPAP Configuration Menu is displayed. Select choice 2, Configure Network Interfaces Menu.	

	Appendix A.14 S	tandalone PDB Segmented Configuration
		/EPAP Configuration Menu\
		/\   1   Display Configuration   
		2   Configure Network Interfaces Menu   
		3   Set Time Zone
		4   Exchange Secure Shell Keys   
		   5   Change Password   
		   6   Platform Menu   
		7   Configure NTP Server
		8   PDB Configuration Menu
		9   Security
		10   SNMP Configuration
		11   Configure Alarm Feed
		12   Configure Query Server
		13   Configure Query Server Alarm Feed
		14   Configure SNMP Agent Community
		15   DB Architecture Menu
		e   Exit
		Enter Choice: 2
7.	<b>MPS A:</b> The Configure Network Interfaces	/Configure Network Interfaces Menu\
	Menu is displayed.	1   Configure Provisioning Network
	Select choice 1, Configure Provisioning	2   Configure GUI Network
	Network.	3 Configure Operations and Maintenance Network
		4 Configure Backup Provisioning Network
		5 Configure Static NAT Addresses
		e   Exit
		Enter Choice: 1

	II	
		/Configure Provisiong Network Menu-\ /)
	Note: Enter choice "1" for IPv4 configuration.	1   IPv4 Configuration
	Otherwise, enter choice "2" for IPv6	2   IPv6 Configuration
	configuration.	   e   Exit
		e   Exit   \/
		Enter Choice:
		Example output Standalone PDB in IPv4 configuration:
		EPAP & provisioning network IP Address: 192.168.61.35 EPAP provisioning network netmask: 255.255.255.0
		EPAP provisioning network default router: 192.168.61.250
		Select choice e to exit to the "Configure Network Interfaces" menu.
8.	MPS A: The Configure Network Interfaces	/Configure Network Interfaces Menu\
	Menu is displayed. Select choice 2,	/\    1   Configure Provisioning Network   
	Configure GUI	2   Configure GUI Network
	Network.	3 Configure Operations and Maintenance Network
		4 Configure Backup Provisioning Network
		5   Configure Static NAT Addresses
		e   Exit
		Enter Choice: 2
		/Configure GUI Network-\
	Note: Enter choice "1"	/\   1   IPv4 Configuration
	for IPv4 configuration.	   2   IPv6 Configuration
	Otherwise, enter choice "2" for IPv6	
	configuration.	e   Exit   \/
		Enter Choice: 1
		Example output Standalone PDB in IPv4 configuration:
		EPAP A GUI network IP Address: 192.168.59.27
		EPAP GUI network netmask: 255.255.255.0 EPAP GUI network route: 192.168.59.250
		Select choice e to exit to the "Configure Network Interfaces" menu.
9.	<b>MPS A:</b> The Configure Network Interfaces	/Configure Network Interfaces Menu\
<b>—</b>	Menu is displayed.	/\   1   Configure Provisioning Network
	Select choice 3, Configure Operations	2   Configure GUI Network
	and Maintenance Network.	3 Configure Operations and Maintenance Network

Appendix A.14 Standalone PDB Segmented Configuration

	Appendix A.14 St	andalone PDB Segmented Configuration
		5   Configure Static NAT Addresses
	Note: Enter choice "1" for IPv4 configuration. Otherwise, enter choice "2" for IPv6 configuration.	Enter Choice: 3 /Configure Operations and Maintenance Network-/ /
		Enter Choice: 1 EPAP & Operations and Maintenance network IP Address: 192.168.60.26 EPAP Operations and Maintenance network netmask: 255.255.255.0 EPAP Operations and Maintenance network route: 192.168.60.250 Select choice e to exit to the "Configure Network Interfaces" menu.
10.	<b>MPS A:</b> Select choice e to exit from the epapconfig menu.	/Configure Network Interfaces Menu

#### Appendix A.14 Standalone PDB Segmented Configuration

	Appendix A.14	Standalone PDB Segmented Configuration
		/EPAP Configuration Menu\ /\
		1   Display Configuration
		2   Configure Network Interfaces Menu
		3   Set Time Zone
		4   Exchange Secure Shell Keys
		   5   Change Password
		   6   Platform Menu
		7   Configure NTP Server
		   8   PDB Configuration Menu
		9   Security
		10   SNMP Configuration
		11   Configure Alarm Feed
		12   Configure Query Server
		13   Configure Query Server Alarm Feed
		   14   Configure SNMP Agent Community
		15   DB Architecture Menu
		   e   Exit
		\/ Enter Choice: 2
		Enter Choice: e
		Note: If this menu is not exited properly, then the SSH login with root shall remain enabled.
11.	<b>MPS A:</b> Procedure is complete.	Procedure is complete.
12.	Note down the timestamp in log.	Run the following command:
	unicoump in log.	\$ date

#### Password change for EPAP System Users Procedure A.15

Appendix A.15 Password change for EPAP System Users


S	This procedure will change the password for the EPAP System User(s).		
Т			
Ε	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.		
Р			
	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.		
Ungr	Ungrade/Installation Guide 200 of 279 August 2024		

# Appendix A.15 Password change for EPAP System Users

#		
1.	<b>MPS A:</b> Log on Server A with the EPAP System User for which the password is to be changed.	[hostname]: <epap system="" user=""> password: <epapdev <i="">password&gt;</epapdev></epap>
2.	<b>MPS A:</b> Change Password for an EPAP system user	Execute the command to change to password of an existing EPAP user. <b>\$ passwd</b> Changing password for user <epap system="" user="">. Changing password for <epap system="" user="">. (current) UNIX password: <b><enter current="" here="" password="" the=""></enter></b> New password: <b><enter here="" new="" password="" the=""></enter></b> Retype new password: <b><retype here="" new="" password="" the=""></retype></b> passwd: all authentication tokens updated successfully. Note: The Linux "passwd" command used to change the password of Linux users, follows the Linux PAM rules. Refer to the Linux manual for the PAM rules. <b># man pam_cracklib</b></epap></epap>
3.	MPS B: Change Password	Repeat steps 1 and 2 on MPS B also. Note: The new password on MPS A and B should be same.
4.	MPS A: Procedure Complete	This procedure is complete.
5.	Note down the timestamp in log.	Run the following command: \$ date

# Procedure A.16 E5-APP-B Halt/Shutdown

	Appendix A.16 Es	5-APP-B Halt/Shutdown		
S	This procedure will have	This procedure will halt the E5-APP-B hardrware.		
T E P	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number			
#	IF THIS PROCEDURE H	FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.		
1.	<b>E5APPB Card:</b> Slide the ejector switch	On the APP-B card, slide the Ejector switch (4) up to the UNLOCKED position. Refer to Figure 7.		
		Caution: If the Ejector switch goes from locked to unlocked and the E5-APP-B card is in service, the card will halt.		
2.	<b>E5APPB Card:</b> Monitor the Eject Status LED	WAIT for the E5-APP-B Eject Status LED to go from blinking red to a steady red.		
3.	E5APPB Card: Lever Release	Grasp the upper and lower card Inject/Eject (I/E) lever release (3) just underneath the I/E lever, and press it to meet the I/E lever. This is the mechanical interlock for the card. Refer to Figure 8.		
4.	<b>E5APPB Card:</b> Pull out the levers	While holding the I/E interlock and lever, pull the levers (2) away from the shelf until they are parallel to the floor. Refer to Figure 8.		
5.	<b>E5APPB Card:</b> Slide the ejector switch	Remove the E5-APP-B card from the EAGLE shelf.		
6.	MPS A: Procedure Complete	This procedure is complete.		
7.	Note down the timestamp in log.	Run the following command:		
		\$ date		



#### **Figure 7: Slide the Ejector Switch**




Figure 8: Release Lever

# Procedure A.17 Procedure to Configure EPAP switch ports and EAGLE SM cards to support 1G EPAP-to-Eagle RTDB download speed

Note: This needs to be done in coordination with the EAGLE team.

#### Appendix A.17 Procedure to Configure EPAP switch ports and EAGLE SM cards to support 1G EPAP-to-Eagle RTDB download speed

S This procedure will configure EPAP Switch ports and Eagle SM cards to support 1G EPAP-to-EAGLE download speed.
 E Note: Estimated time of completion is 20 minutes.
 P
 #

1.	<b>E5-APP-B A/B:</b> Configure the SM ports on EPAP switch to 1000 Mbps.	Follow Procedure 9 to Configure the SM ports on EPAP switch to 1000 Mbps
2.	<b>EAGLE:</b> Configure Ethernet port on EAGLE SM cards that connects to EPAP to Auto-negotiate.	Eagle Command to configure an Ethernet port on EAGLE SM cards that connects to EPAP: CHG-IP-LNK:LOC= <sm card="" location="">:PORT=<port>:IPADDR=<ip Address&gt;:SUBMASK=<subnet mask="">:MCAST=YES:AUTO=YES</subnet></ip </port></sm>
3.	<b>EAGLE:</b> Verify the auto negotiation status of the Ethernet ports on EAGLE SM cards that connects to EPAP. Make sure the ports are getting auto-negotiated to 1000Mbps/Full Duplex.	Eagle Command to verify auto negotiation status of an Ethernet port on EAGLE SM cards that connects to EPAP: PASS: LOC= <sm card="" location="">:CMD="NETSTAT -I" Please go through the "Identifying the Ethernet port status on SM cards using "NETSTAT -I" display" section below. If ports on SM cards are getting auto-negotiated to 1000Mbps/Full Duplex correctly, then stop here. Otherwise continue with next step.</sm>
4.	<b>E5-APP-B</b> A/B: Configure the SM ports on EPAP switch to auto-negotiate.	Follow Procedure 9 to Configure the SM ports on EPAP switch to 'auto'.
5.	<b>EAGLE:</b> Verify the auto negotiation status of a Ethernet port on EAGLE SM cards that connects to EPAP. Make sure the ports are getting auto-negotiated to 1000Mbps/Full Duplex.	Eagle Command to verify auto negotiation status of an Ethernet port on EAGLE SM cards that connects to EPAP: PASS: LOC= <sm card="" location="">:CMD="NETSTAT -I" Please go through the "Identifying the Ethernet port status on SM cards using "NETSTAT -I" display" section below</sm>
6.	Note down the timestamp in log.	Run the following command: \$ date

#### Identifying the Ethernet port status on SM cards using "NETSTAT -I" display:

SM8G-B card running SCCPHC:

gei (unit number 2) = ExAP Port A
gei (unit number 3) = ExAP Port B

SM8G-B card running SCCPHC:

```
gei (unit number 2) = ExAP Port A
gei (unit number 3) = ExAP Port B
```

> rept-stat-card:mode=full:loc=1307

eagle1 17-05-04 16:43	:49 MST	EAGLE 46.5	.0.0.0-70.29.0		
CARD VERSION T	YPE	GPL	PST	SST	AST
1307 140-029-000 D	SM	SCCPHC	IS-ANR	MPS Unavl	
ALARM STATUS	= No Al	arms.			
BLMCAP GPL version	= 140 - 0	29-000			
IMT BUS A	= Conn				
IMT BUS B	= Disc				
CLOCK A	= Fault				
CLOCK B	= Activ	re			
CLOCK I	= Idle				
MBD BIP STATUS	= Valid	l			
MOTHER BOARD ID	= SMXG	В			

```
DBD STATUS
                            = Valid
      DBD TYPE = None
DBD MEMORY SIZE = 8192M
      HW VERIFICATION CODE= ----
      FPGA VERSION= 9BIOS VERSION= 0ABSV01
      PSOC VERSION = 0.1
      CURRENT TEMPERATURE = 34C ( 94F)
PEAK TEMPERATURE: = 34C ( 94F)
                                                 [17-05-04 15:49]
      SCCP % OCCUP
                             = 0%
      SCCP SM DATA TYPE = DN
      APPLICATION SERVICING
                                             MFC
                                                            MFC
           SNM
                  REQ STATUS = 24 hr: ---, 5 min: ---

        INM
        REQ STATUS =
        24 hr: ---, 5 min: ---

        MTP3
        REQ STATUS =
        24 hr: ---, 5 min: ---

        SFLOG
        REQ STATUS =
        24 hr: ---, 5 min: ---

       IPLNK STATUS
           A 192.168.120.21 DOWN
B 192.168.121.21 DOWN
IP CONNECTION
                                                    PST
OOS-MT
                                                      OOS-MT
       DSM IP CONNECTION
           PORT PST
                                    SST
                   OOS-MT
                                    Unavail
           А
                   OOS-MT
           R
                                    Unavail
    Command Completed.
;
> pass:loc=1307:cmd="netstat -i"
    eagle1 17-05-04 16:44:26 MST EAGLE 46.5.0.0.0-70.29.0
    SDS Shell Output
    -> tklc ifShow
    lo (unit number 0):
          Flags: (0x48049) UP LOOPBACK MULTICAST TRAILERS ARP RUNNING INET UP
          Type: SOFTWARE LOOPBACK
          inet: 127.0.0.1
          Netmask 0xff000000 Subnetmask 0xff000000
          Metric is 0
          Maximum Transfer Unit size is 1536
          0 packets received; 1 packets sent
          0 multicast packets received
          0 multicast packets sent
          0 input errors; 0 output errors
          0 collisions; 0 dropped
          0 output queue drops
    DPLend (unit number 0):
          Flags: (0x20043) UP BROADCAST ARP RUNNING
          Type: ETHERNET CSMACD
          Ethernet address is 00:00:00:00:00:00
          Metric is 0
          Maximum Transfer Unit size is 485
          0 octets received
          0 octets sent
          0 unicast packets received
          0 unicast packets sent
          0 non-unicast packets received
          0 non-unicast packets sent
          0 incoming packets discarded
          0 outgoing packets discarded
          0 incoming errors
          0 outgoing errors
          0 unknown protos
          0 collisions; 0 dropped
          0 output queue drops
```

```
gei (unit number 2):
         Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
         PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
         Type: ETHERNET CSMACD
         inet: 192.168.120.21
         Broadcast address: 192.168.120.255
         Netmask 0xfffff00 Subnetmask 0xfffff00
         Ethernet address is 00:00:17:0e:b7:d2
         Metric is 0
         Maximum Transfer Unit size is 1500
         250214 octets received
         122200 octets sent
         0 unicast packets received
         0 unicast packets sent
         0 multicast packets received
         0 multicast packets sent
         2075 broadcast packets received
         940 broadcast packets sent
         0 incoming packets discarded
         0 outgoing packets discarded
         0 incoming errors
         0 outgoing errors
         0 unknown protos
         0 collisions; 0 dropped
         0 output queue drops
    gei (unit number 3):
         Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
         PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
         Type: ETHERNET CSMACD
         inet: 192.168.121.21
         Broadcast address: 192.168.121.255
         Netmask 0xfffff00 Subnetmask 0xfffff00
         Ethernet address is 00:00:17:0e:b7:d3
         Metric is 0
         Maximum Transfer Unit size is 1500
         248920 octets received
         121290 octets sent
         0 unicast packets received
         0 unicast packets sent
         0 multicast packets received
         0 multicast packets sent
         2062 broadcast packets received
         933 broadcast packets sent
         0 incoming packets discarded
         0 outgoing packets discarded
         0 incoming errors
         0 outgoing errors
         0 unknown protos
         0 collisions; 0 dropped
         0 output queue drops
   value = 26 = 0x1a
    eagle1 17-05-04 16:44:36 MST EAGLE 46.5.0.0.0-70.29.0
   NETSTAT command complete
SM8G-B card running SCCP64:
gei (unit number 4) = ExAP Port A
gei (unit number 5) = ExAP Port B
> rept-stat-card:mode=full:loc=1307
```

```
Upgrade/Installation Guide
```

```
eagle1 17-05-04 17:00:01 MST EAGLE 46.5.0.0.0-70.29.0
                                                                  AST
   CARD
         VERSION TYPE GPL PST
                                                         SST
                                                     MPS Unavl -----
          140-029-000 DSM
   1307
                                SCCP64
                                          IS-ANR
     ALARM STATUS = No Alarms.
     BLDC64 GPL version = 140-029-000
     IMT BUS A
                       = Conn
     IMT BUS B
                        = Disc
     CLOCK A
                        = Fault
                        = Active
     CLOCK B
     CLOCK I
                        = Idle
                      = Valid
     MBD BIP STATUS
     MOTHER BOARD ID = SMXG B
     DBD STATUS
                        = Valid
     DBD TYPE
                        = None
     DBD MEMORY SIZE = 8192M
     HW VERIFICATION CODE= ----
     FPGA VERSION = 9
                  = 0ABSV01
= 0.1
     BIOS VERSION
     PSOC VERSION
     CURRENT TEMPERATURE = 34C ( 94F)
     PEAK TEMPERATURE: = 34C (94F)
                                        [17-05-04 15:49]
     SCCP % OCCUP
                       = 0%
     SCCP SM DATA TYPE = DN
     APPLICATION SERVICING
                                     MFC
                                                 MFC
                REQ STATUS = 24 hr: ---, 5 min: ---
         SNM
               REQ STATUS = 24 hr: ---, 5 min: ---
         TNM
                REQ STATUS = 24 hr: ---, 5 min: ---
         MTP3
         SFLOG
                REQ STATUS = 24 hr: ---, 5 min: ---
     IPLNK STATUS
                                STATUS PST
DOWN OOS-MT
-- OOS-MT
         IPLNK IPADDR
               192.168.120.21
         А
               192.168.121.21
                                DOWN
         В
     DSM IP CONNECTION
                               SST
         PORT PST
                OOS-MT
                               Unavail
         А
               OOS-MT
                              Unavail
         В
   Command Completed.
> pass:loc=1307:cmd="netstat -i"
   eagle1 17-05-04 17:00:14 MST EAGLE 46.5.0.0.0-70.29.0
   SDS Shell Output
   shellLib: unknown LED mode vi.
   -> tklc ifShow
   lo0 Link type:Local loopback Queue:none
    inet 127.0.0.1 mask 255.255.255.255
       inet6 unicast fe80::1%lo0 prefixlen 64 automatic
       inet6 unicast ::1 prefixlen 128
       UP RUNNING LOOPBACK MULTICAST NOARP ALLMULTI
       MTU:1500 metric:1 VR:0 ifindex:1
       RX packets:761 mcast:3 errors:0 dropped:0
       TX packets:761 mcast:3 errors:0
       collisions:0 unsupported proto:0
       RX bytes:85k TX bytes:85k
               Link type:Ethernet HWaddr 00:00:17:0e:b7:d2 Queue:none
   gei4
       capabilities: TXCSUM TX6CSUM
       inet 192.168.120.21 mask 255.255.255.0 broadcast 192.168.120.255
       inet6 unicast fe80::200:17ff:fe0e:b7d2%gei4 prefixlen 64 automatic
       UP RUNNING SIMPLEX BROADCAST MULTICAST
```

```
Upgrade/Installation Guide
```

```
MTU:1500 metric:1 VR:0 ifindex:2
        RX packets:791 mcast:0 errors:0 dropped:0
        TX packets:386 mcast:6 errors:0
         collisions:0 unsupported proto:0
         RX bytes:92k TX bytes:48k
    gei5
                  Link type:Ethernet HWaddr 00:00:17:0e:b7:d3 Queue:none
         capabilities: TXCSUM TX6CSUM
         inet 192.168.121.21 mask 255.255.255.0 broadcast 192.168.121.255
         inet6 unicast fe80::200:17ff:fe0e:b7d3%gei5 prefixlen 64 automatic
         UP RUNNING SIMPLEX BROADCAST MULTICAST
        MTU:1500 metric:1 VR:0 ifindex:3
        RX packets:783 mcast:0 errors:0 dropped:0
        TX packets:386 mcast:6 errors:0
         collisions:0 unsupported proto:0
         RX bytes:91k TX bytes:48k
    gei (unit number 4):
         PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    gei (unit number 5):
         PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    value = 1 = 0x1
SM8G-B card running ENUMHC/DEIRHC/SIPHC:
gei (unit number 2) = ExAP Port
gei (unit number 3) = Signaling Port
> rept-stat-card:mode=full:loc=1317
    eagle1 17-05-04 15:46:06 MST EAGLE 46.5.0.0.0-70.29.0
    CARDVERSIONTYPEGPLPSTSSTAST1317140-029-000DSMENUMHCIS-ANRMPS Unavl-----
      ALARM STATUS = No Alarms.
      BLMCAP GPL version = 140-029-000
      IMT BUS A = Conn
IMT BUS B = Disc
      CLOCK A
                           = Fault
      CLOCK B
                            = Active
      CLOCK I = Idle
MBD BIP STATUS = Valid
MOTHER BOARD ID = SMXG B
DBD STATUS = Valid
DBD TYPE
      DBD TYPE = None
DBD MEMORY SIZE = 8192M
      HW VERIFICATION CODE= ----
      FPGA VERSION= 9BIOS VERSION= 0ABSV01
      PSOC VERSION = 0.1
      \begin{array}{rcl} & & & - & 0.1 \\ \text{CURRENT TEMPERATURE} & & 34\text{C} & (94\text{F}) \\ \text{PEAK TEMPERATURE:} & & 34\text{C} & (94\text{F}) \\ \text{ENUM SM DATA TYPE} & & \text{DN} \end{array}
      IPLNK STATUS
               TATUS
NK IPADDR STATUS
192.168.120.13 UP
10.75.49.21 UP
           IPLNK IPADDR
                                                   PST
                                                   IS-NR
           А
                                                    IS-NR
           B
           С
                                                     ____
                  _____ ____
                                                     ____
           D
      DSM IP CONNECTION
      PORT PST SST
A OOS-MT Unavail
D OOS-MA Ueq
ENUM CONNECTION STATUS
                                 PROT
          CNAME
                                           STATUS
    Command Completed.
```

```
Upgrade/Installation Guide
```

```
> pass:loc=1317:cmd="netstat -i"
Command Accepted - Processing
    eagle1 17-05-04 15:46:46 MST EAGLE 46.5.0.0.0-70.29.0
    pass:loc=1317:cmd="netstat -i"
    Command entered at terminal #13.
;
    eagle1 17-05-04 15:46:46 MST EAGLE 46.5.0.0.0-70.29.0
    PASS: Command sent to card
;
    eagle1 17-05-04 15:46:46 MST EAGLE 46.5.0.0.0-70.29.0
    SDS Shell Output
    -> tklc ifShow
    lo (unit number 0):
         Flags: (0x48049) UP LOOPBACK MULTICAST TRAILERS ARP RUNNING INET UP
         Type: SOFTWARE LOOPBACK
         inet: 127.0.0.1
         Netmask 0xff000000 Subnetmask 0xff000000
         Metric is 0
         Maximum Transfer Unit size is 1536
         0 packets received; 1 packets sent
         0 multicast packets received
         0 multicast packets sent
         0 input errors; 0 output errors
         0 collisions; 0 dropped
         0 output queue drops
    DPLend (unit number 0):
         Flags: (0x20043) UP BROADCAST ARP RUNNING
         Type: ETHERNET CSMACD
         Ethernet address is 00:00:00:00:00:00
         Metric is 0
         Maximum Transfer Unit size is 485
         0 octets received
         0 octets sent
         0 unicast packets received
         0 unicast packets sent
         0 non-unicast packets received
         0 non-unicast packets sent
         0 incoming packets discarded
         0 outgoing packets discarded
         0 incoming errors
         0 outgoing errors
         0 unknown protos
         0 collisions; 0 dropped
         0 output queue drops
    gei (unit number 2):
         Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET_UP
         PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
         Type: ETHERNET CSMACD
         inet: 192.168.120.13
         Broadcast address: 192.168.120.255
         Netmask 0xfffff00 Subnetmask 0xfffff00
         Ethernet address is 00:00:17:0e:b7:d2
         Metric is 0
         Maximum Transfer Unit size is 1500
         16128 octets received
         102048 octets sent
         0 unicast packets received
         0 unicast packets sent
         0 multicast packets received
         0 multicast packets sent
         252 broadcast packets received
```

```
Upgrade/Installation Guide
```

```
786 broadcast packets sent
        0 incoming packets discarded
        0 outgoing packets discarded
        0 incoming errors
        0 outgoing errors
        0 unknown protos
        0 collisions; 0 dropped
        0 output queue drops
    gei (unit number 3):
        Flags: (0x70043) UP BROADCAST ARP RUNNING INET UP
        PHY Flags: (0x12012) AUTONEG 1000MB FDX DIX
        Type: ETHERNET CSMACD
        inet: 10.75.49.21
        Broadcast address: 10.75.49.255
        Netmask 0xff000000 Subnetmask 0xfffff00
        Ethernet address is 00:00:17:0e:b7:d3
        Metric is 0
        Maximum Transfer Unit size is 1500
        0 octets received
        128 octets sent
        0 unicast packets received
        0 unicast packets sent
        0 multicast packets received
        0 multicast packets sent
        0 broadcast packets received
        2 broadcast packets sent
        0 incoming packets discarded
        0 outgoing packets discarded
        0 incoming errors
        0 outgoing errors
        0 unknown protos
         0 collisions; 0 dropped
        0 output queue drops
    value = 26 = 0x1a
;
    eagle1 17-05-04 15:46:56 MST EAGLE 46.5.0.0.0-70.29.0
;
    eagle1 17-05-04 15:46:56 MST EAGLE 46.5.0.0.0-70.29.0
   NETSTAT command complete
;
SM8G-B card running ENUM64/DEIR64/SIP64:
gei (unit number 4) = ExAP Port
gei (unit number 5) = Signaling Port
> rept-stat-card:mode=full:loc=1317
    eagle1 17-05-04 15:23:31 MST EAGLE 46.5.0.0.0-70.29.0
   CARDVERSIONTYPEGPLPST1317140-029-000DSMENUM64IS-ANR
                                                           SST
                                                                      AST
          140-029-000 DSM
                                                           MPS Unavl -----
     ALARM STATUS = ** 0080 Shelf FAN bit is OFF
     BLDC64 GPL version = 140-029-000
     IMT BUS A
                        = Conn
     IMT BUS B
                         = Disc
     CLOCK A
                         = Fault
     CLOCK B
                         = Active
                        = Idle
     CLOCK I
     MBD BIP STATUS
                       = Valid
     MOTHER BOARD ID
                        = SMXG B
```

```
Upgrade/Installation Guide
```

```
DBD STATUS
                        = Valid
      DBD TYPE = None
DBD MEMORY SIZE = 8192M
      HW VERIFICATION CODE= ----
     FPGA VERSION= 9BIOS VERSION= 0ABSV01PSOC VERSION= 0.1
     CURRENT TEMPERATURE = 34C (94F)
PEAK TEMPERATURE: = 34C (94F) [17-05-02 09:31]
ENUM SM DATA TYPE = DN
             IPLNK STATUS
         IPLNK IPADDR
          А
          B
          С
          D
      DSM IP CONNECTION
     PORT PST SST
A OOS-MT Unavail
D OOS-MA Ueq
ENUM CONNECTION STATUS
CNAME PROT STATUS
    Command Completed.
;
> pass:loc=1317:cmd="netstat -i"
    eagle1 17-05-04 15:23:59 MST EAGLE 46.5.0.0.0-70.29.0
    SDS Shell Output
    shellLib: unknown LED mode vi.
    -> tklc ifShow
    100 Link type:Local loopback Queue:none
        inet 127.0.0.1 mask 255.255.255.255
        inet6 unicast fe80::1%lo0 prefixlen 64 automatic
        inet6 unicast ::1 prefixlen 128
        UP RUNNING LOOPBACK MULTICAST NOARP ALLMULTI
        MTU:1500 metric:1 VR:0 ifindex:1
        RX packets:885990 mcast:3 errors:0 dropped:0
        TX packets:885990 mcast:3 errors:0
        collisions:0 unsupported proto:0
        RX bytes:99M TX bytes:99M
    gei4
                Link type:Ethernet HWaddr 00:00:17:0e:b7:d2 Queue:none
        capabilities: TXCSUM TX6CSUM
        inet 192.168.120.13 mask 255.255.255.0 broadcast 192.168.120.255
        inet6 unicast fe80::200:17ff:fe0e:b7d2%gei4 prefixlen 64 automatic
        UP RUNNING SIMPLEX BROADCAST MULTICAST
        MTU:1500 metric:1 VR:0 ifindex:2
        RX packets:35807 mcast:0 errors:0 dropped:0
        TX packets:877952 mcast:12 errors:0
        collisions:0 unsupported proto:0
        RX bytes:2148k TX bytes:110M
    gei5
                Link type:Ethernet HWaddr 00:00:17:0e:b7:d3 Queue:none
        capabilities: TXCSUM TX6CSUM
        inet 10.75.49.21 mask 255.255.255.0 broadcast 10.75.49.255
        inet6 unicast fe80::200:17ff:fe0e:b7d3%gei5 prefixlen 64 automatic
        UP RUNNING SIMPLEX BROADCAST MULTICAST
        MTU:1500 metric:1 VR:0 ifindex:3
        RX packets:526 mcast:0 errors:0 dropped:0
        TX packets:7 mcast:6 errors:0
        collisions:0 unsupported proto:0
        RX bytes:57k TX bytes:510
```

gei (unit number 4):

```
PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    gei (unit number 5):
          PHY Flags: (0x12012) AUTONEG 1000MB FDX DIX
    value = 1 = 0x1
;
    eagle1 17-05-04 15:24:09 MST EAGLE 46.5.0.0.0-70.29.0
;
    eagle1 17-05-04 15:24:09 MST EAGLE 46.5.0.0.0-70.29.0
    NETSTAT command complete
;
SLIC card running SCCPHC:
gei (unit number 2) is ExAP Port A
gei (unit number 0) is ExAP Port B
> REPT-STAT-CARD:MODE=FULL:LOC=1307
    eagle1 17-05-04 15:10:21 MST EAGLE 46.5.0.0.0-70.29.0
    CARDVERSIONTYPEGPLPST1307140-029-000SLICSCCPHCIS-ANR
                                                                   SST
                                                                               AST
                                                                               98%
                                                                   Standby
      ALARM STATUS = ** 0080 Shelf FAN bit is OFF
      BLSLC32 GPL version = 140-029-000
      IMT BUS A = Conn
      IMT BUS B
                            = Disc
                            = Fault
      CLOCK A
      CLOCK B
                           = Active
      CLOCK I
                           = Idle
                         = Valid
= SLIC
      MBD BIP STATUS
      MOTHER BOARD ID
                            = SLIC
      DBD STATUS
                            = Valid
      DBD TYPE
                           = None
      DBD MEMORY SIZE = 16384M
      HW VERIFICATION CODE= ----
      FPGA VERSION = 9400036
                          = 0ACFP00
= 1.0
      BIOS VERSION
      PSOC VERSION
      CURRENT TEMPERATURE = 40C (104F)
      PEAK TEMPERATURE: = 40C (104F) [17-05-04 15:05]
                            = 0%
      SCCP % OCCUP
      SCCP SM DATA TYPE = DN
      APPLICATION SERVICING
                                            MFC
                                                         MFC
                  REQ STATUS = 24 hr: ---, 5 min: ---
           SNM

        INM
        REQ STATUS =
        24 hr: ---, 5 min: ---

        MTP3
        REQ STATUS =
        24 hr: ---, 5 min: ---

        SFLOG
        REQ STATUS =
        24 hr: ---, 5 min: ---

      IPLNK STATUS
          IPLNK IPADDR
                                       STATUS
                                                   PST

        192.168.120.21
        DOWN

        192.168.121.21
        DOWN

                                                  OOS-MT
           А
                                                   OOS-MT
          B
      DSM IP CONNECTION
           PORT PST
                                   SST
                 OOS-MT Unavail
OOS-MT Unavail
           А
           В
    Command Completed.
;
> PASS:LOC=1307:CMD="NETSTAT -I"
```

```
eagle1 17-05-04 15:10:27 MST EAGLE 46.5.0.0.0-70.29.0
SDS Shell Output
-> tklc ifShow
lo (unit number 0):
     Flags: (0x48049) UP LOOPBACK MULTICAST TRAILERS ARP RUNNING INET UP
    Type: SOFTWARE LOOPBACK
     inet: 127.0.0.1
    Netmask 0xff000000 Subnetmask 0xff000000
    Metric is 0
    Maximum Transfer Unit size is 1536
     0 packets received; 1 packets sent
    0 multicast packets received
     0 multicast packets sent
     0 input errors; 0 output errors
     0 collisions; 0 dropped
    0 output queue drops
DPLend (unit number 0):
    Flags: (0x20043) UP BROADCAST ARP RUNNING
     Type: ETHERNET CSMACD
    Ethernet address is 00:00:00:00:00:00
    Metric is 0
    Maximum Transfer Unit size is 485
    0 octets received
    0 octets sent
    0 unicast packets received
    0 unicast packets sent
    0 non-unicast packets received
     0 non-unicast packets sent
     0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     0 collisions; 0 dropped
     0 output queue drops
gei (unit number 2):
     Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
    PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    Type: ETHERNET CSMACD
    inet: 192.168.120.21
    Broadcast address: 192.168.120.255
    Netmask 0xfffff00 Subnetmask 0xfffff00
    Ethernet address is 00:10:e0:bb:26:d2
    Metric is 0
    Maximum Transfer Unit size is 1500
     0 octets received
    2014 octets sent
    0 unicast packets received
     0 unicast packets sent
     0 multicast packets received
     0 multicast packets sent
     0 broadcast packets received
    16 broadcast packets sent
    0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     0 collisions; 0 dropped
    0 output queue drops
gei (unit number 0):
     Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET_UP
     PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    Type: ETHERNET_CSMACD
     inet: 192.168.121.21
    Broadcast address: 192.168.121.255
```

```
Netmask 0xfffff00 Subnetmask 0xfffff00
          Ethernet address is 00:10:e0:bb:26:d0
          Metric is 0
          Maximum Transfer Unit size is 1500
          0 octets received
          1884 octets sent
          0 unicast packets received
          0 unicast packets sent
          0 multicast packets received
          0 multicast packets sent
          0 broadcast packets received
          15 broadcast packets sent
          0 incoming packets discarded
          0 outgoing packets discarded
          0 incoming errors
          0 outgoing errors
          0 unknown protos
          0 collisions; 0 dropped
          0 output queue drops
    value = 26 = 0 \times 1a
;
    eagle1 17-05-04 15:10:37 MST EAGLE 46.5.0.0.0-70.29.0
    NETSTAT command complete
;
SLIC card running SCCP64:
gei (unit number 0) = ExAP Port A
gei (unit number 2) = ExAP Port B
> REPT-STAT-CARD:MODE=FULL:LOC=1307
    eagle1 17-05-04 14:55:03 MST EAGLE 46.5.0.0.0-70.29.0
CARD VERSION TYPE GPL PST
1307 140-029-000 SLIC SCCP64 IS-ANR
                                                                       SST AST
                                                                       MPS Unavl -----
      ALARM STATUS = ** 0080 Shelf FAN bit is OFF
      BLSLC64 GPL version = 140-029-000
      IMT BUS A
                              = Conn
                              = Disc
      IMT BUS B
      CLOCK A
                             = Fault
      CLOCK B
                             = Active
      CLOCK I = Idle
MBD BIP STATUS = Valid
MOTHER BOARD ID = SLIC
      DBD STATUS
                            = Valid
      DBD TYPE
                             = None
      DBD MEMORY SIZE = 16384M
      HW VERIFICATION CODE= ----
      FPGA VERSION= 9400036BIOS VERSION= 0ACFP00PSOC VERSION= 1.0
      CURRENT TEMPERATURE = 36C (97F)
PEAK TEMPERATURE: = 38C (101F) [17-05-04 14:47]
      \begin{array}{rcl} \text{SCCP } \% & \text{OCCUP} & = & 0 \% \\ \text{SCCP } & \text{SM } & \text{DATA } & \text{TYPE} & = & \text{DN} \end{array}
      APPLICATION SERVICING
                                             MFC
                                                            MFC
                   REQ STATUS = 24 hr: ---, 5 min: ---
           SNM
                    REQ STATUS = 24 hr: ---, 5 min: ---
REQ STATUS = 24 hr: ---, 5 min: ---
           INM
           MTP3
           SFLOG REQ STATUS = 24 hr: ---, 5 min: ---
       IPLNK STATUS
           IPLNK IPADDR
                                          STATUS
                                                      PST
Upgrade/Installation Guide
                                          214 of 279
```

```
August 2024
```

```
192.168.120.21 DOWN
                                              OOS-MT
          Α
                192.168.121.21
                                  DOWN
                                               OOS-MT
          В
      DSM IP CONNECTION
          PORT PST
                                 SST
                 OOS-MT
                                 Unavail
          А
                OOS-MT
                               Unavail
          В
    Command Completed.
;
> PASS:LOC=1307:CMD="NETSTAT -I"
Command Accepted - Processing
    eagle1 17-05-04 14:56:03 MST EAGLE 46.5.0.0.0-70.29.0 PASS:LOC=1307:CMD="NETSTAT -I"
    Command entered at terminal #11.
:
    eagle1 17-05-04 14:56:03 MST EAGLE 46.5.0.0.0-70.29.0
    PASS: Command sent to card
    eagle1 17-05-04 14:56:03 MST EAGLE 46.5.0.0.0-70.29.0
    SDS Shell Output
    shellLib: unknown LED mode vi.
    -> tklc ifShow
    100 Link type:Local loopback Queue:none
        inet 127.0.0.1 mask 255.255.255.255
        inet6 unicast fe80::1%lo0 prefixlen 64 automatic
        inet6 unicast ::1 prefixlen 128
       UP RUNNING LOOPBACK MULTICAST NOARP ALLMULTI
       MTU:1500 metric:1 VR:0 ifindex:1
       RX packets:2213 mcast:3 errors:0 dropped:0
        TX packets:2213 mcast:3 errors:0
        collisions:0 unsupported proto:0
        RX bytes:247k TX bytes:247k
    gei0
                Link type:Ethernet HWaddr 00:10:e0:bb:26:d0 Queue:none
        capabilities: TXCSUM TX6CSUM VLAN_MTU VLAN_TXHWTAG VLAN_RXHWTAG
        inet 192.168.120.21 mask 255.255.255.0 broadcast 192.168.120.255
        inet6 unicast fe80::210:e0ff:febb:26d0%gei0 prefixlen 64 automatic
        UP RUNNING SIMPLEX BROADCAST MULTICAST
       MTU:1500 metric:1 VR:0 ifindex:2
        RX packets:695 mcast:0 errors:0 dropped:0
        TX packets:634 mcast:12 errors:0
        collisions:0 unsupported proto:0
        RX bytes:74k TX bytes:79k
                Link type:Ethernet HWaddr 00:10:e0:bb:26:d2 Queue:none
    gei2
        capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
        inet 192.168.121.21 mask 255.255.255.0 broadcast 192.168.121.255
        inet6 unicast fe80::210:e0ff:febb:26d2%gei2 prefixlen 64 automatic
        UP RUNNING SIMPLEX BROADCAST MULTICAST
       MTU:1500 metric:1 VR:0 ifindex:3
        RX packets:702 mcast:0 errors:0 dropped:0
        TX packets:639 mcast:6 errors:0
        collisions:0 unsupported proto:0
RX bytes:75k TX bytes:80k
    gei (unit number 0):
         PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    gei (unit number 2):
         PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    value = 1 = 0x1
```

```
eagle1 17-05-04 14:56:13 MST EAGLE 46.5.0.0.0-70.29.0
    NETSTAT command complete
;
SLIC card running ENUMHC/DEIRHC/SIPHC:
gei (unit number 2) = ExAP Port A
gei (unit number 0) = Signaling Port #1
gei (unit number 3) = Signaling Port #2
gei (unit number 1) = ExAP Port B
> rept-stat-card:mode=full:loc=1317
    eagle1 17-05-04 17:34:35 MST EAGLE 46.5.0.0.0-70.29.0
                                                                     SST AST
    CARD
           VERSION TYPE GPL
                                                 PST
                                                   IS-ANR MPS Unavl -----
           140-029-000 SLIC
                                       ENUMHC
    1317
      ALARM STATUS = No Alarms.
      BLSLC32 GPL version = 140-029-000
      IMT BUS A
                            = Conn
      IMT BUS B
                             = Disc
      CLOCK A
                            = Fault
      CLOCK B
                             = Active
      CLOCK I
                              = Idle
      CLOCK I= IdleMBD BIP STATUS= ValidMOTHER BOARD ID= SLICDBD STATUS= ValidDBD TYPE= None
      DBD TYPE = None
DBD MEMORY SIZE = 16384M
      HW VERIFICATION CODE= ----
      FPGA VERSION = 9400036
      BIOS VERSION = 0ACFP00
PSOC VERSION = 1.0
      CURRENT TEMPERATURE = 43C (110F)
PEAK TEMPERATURE: = 43C (110F) [17-05-04 17:27]
ENUM SM DATA TYPE = DN
      IPLNK STATUS

    IPLNK
    IPADDR
    STATUS
    PST

    A
    192.168.120.13
    UP
    IS-N

    B
    10.75.49.21
    DOWN
    OOS-

    C
    10.75.50.21
    UP
    IS-N

    D
    192.168.121.13
    UP
    IS-N

                                                     IS-NR
                                                      OOS-MT
                                                      IS-NR
                                                     IS-NR
       DSM IP CONNECTION
                                    SST
           PORT PST
                   OOS-MTUnavailOOS-MTUnavail
           А
           D
    Command Completed.
;
> pass:loc=1317:cmd="netstat -i"
Command Accepted - Processing
    eagle1 17-05-04 17:34:52 MST EAGLE 46.5.0.0.0-70.29.0
    pass:loc=1317:cmd="netstat -i"
    Command entered at terminal #13.
;
    eagle1 17-05-04 17:34:52 MST EAGLE 46.5.0.0.0-70.29.0
    PASS: Command sent to card
;
    eagle1 17-05-04 17:34:52 MST EAGLE 46.5.0.0.0-70.29.0
```

```
Upgrade/Installation Guide
```

```
-> tklc ifShow
lo (unit number 0):
     Flags: (0x48049) UP LOOPBACK MULTICAST TRAILERS ARP RUNNING INET UP
    Type: SOFTWARE LOOPBACK
    inet: 127.0.0.1
    Netmask 0xff000000 Subnetmask 0xff000000
    Metric is 0
    Maximum Transfer Unit size is 1536
    0 packets received; 1 packets sent
    0 multicast packets received
     0 multicast packets sent
     0 input errors; 0 output errors
     0 collisions; 0 dropped
    0 output queue drops
DPLend (unit number 0):
    Flags: (0x20043) UP BROADCAST ARP RUNNING
    Type: ETHERNET CSMACD
    Ethernet address is 00:00:00:00:00:00
    Metric is 0
    Maximum Transfer Unit size is 485
    0 octets received
    0 octets sent
    0 unicast packets received
    0 unicast packets sent
    0 non-unicast packets received
    0 non-unicast packets sent
     0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     0 collisions; 0 dropped
     0 output queue drops
gei (unit number 2):
     Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
     PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    Type: ETHERNET CSMACD
    inet: 192.168.120.13
    Broadcast address: 192.168.120.255
    Netmask 0xfffff00 Subnetmask 0xfffff00
    Ethernet address is 00:10:e0:bb:26:d2
    Metric is 0
    Maximum Transfer Unit size is 1500
    13736 octets received
    16118 octets sent
     0 unicast packets received
    0 unicast packets sent
    0 multicast packets received
     0 multicast packets sent
    128 broadcast packets received
    125 broadcast packets sent
     0 incoming packets discarded
    0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     0 collisions; 0 dropped
     0 output queue drops
gei (unit number 0):
     Flags: (0x70043) UP BROADCAST ARP RUNNING INET UP
     PHY Flags: (0x2012) DIX
    Type: ETHERNET_CSMACD
     inet: 10.75.49.21
    Broadcast address: 10.75.49.255
    Netmask 0xff000000 Subnetmask 0xfffff00
    Ethernet address is 00:10:e0:bb:26:d0
```

```
Upgrade/Installation Guide
```

SDS Shell Output

```
Metric is 0
    Maximum Transfer Unit size is 1500
     0 octets received
     0 octets sent
    0 unicast packets received
    0 unicast packets sent
     0 multicast packets received
     0 multicast packets sent
     0 broadcast packets received
     0 broadcast packets sent
     0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     0 collisions; 0 dropped
     0 output queue drops
gei (unit number 3):
     Flags: (0x70043) UP BROADCAST ARP RUNNING INET UP
     PHY Flags: (0x12012) 100MB FDX DIX
     Type: ETHERNET CSMACD
     inet: 10.75.50.21
    Broadcast address: 10.75.50.255
    Netmask 0xff000000 Subnetmask 0xfffff00
    Ethernet address is 00:10:e0:bb:26:d3
    Metric is 0
    Maximum Transfer Unit size is 1500
    25708 octets received
    128 octets sent
    0 unicast packets received
     0 unicast packets sent
     0 multicast packets received
     0 multicast packets sent
    214 broadcast packets received
     2 broadcast packets sent
     0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     0 collisions; 0 dropped
    0 output queue drops
gei (unit number 1):
     Flags: (0x78043) UP BROADCAST MULTICAST ARP RUNNING INET UP
     PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
    Type: ETHERNET CSMACD
    inet: 192.168.121.13
    Broadcast address: 192.168.121.255
    Netmask 0xffffff00 Subnetmask 0xfffff00
    Ethernet address is 00:10:e0:bb:26:d1
    Metric is 0
    Maximum Transfer Unit size is 1500
    13544 octets received
    16118 octets sent
    0 unicast packets received
    0 unicast packets sent
     0 multicast packets received
     0 multicast packets sent
     125 broadcast packets received
    125 broadcast packets sent
     0 incoming packets discarded
     0 outgoing packets discarded
     0 incoming errors
     0 outgoing errors
     0 unknown protos
     0 collisions; 0 dropped
     0 output queue drops
value = 26 = 0x1a
```

```
Upgrade/Installation Guide
```

```
;
    eagle1 17-05-04 17:35:02 MST EAGLE 46.5.0.0.0-70.29.0
;
    eagle1 17-05-04 17:35:02 MST EAGLE 46.5.0.0.0-70.29.0
    NETSTAT command complete
;
SLIC card running DEIR64/ENUM64/SIP64:
gei (unit number 0) = ExAP Port A
gei (unit number 2) = Signaling Port #1
gei (unit number 1) = Signaling Port #2
gei (unit number 3) = ExAP Port B
> rept-stat-card:mode=full:loc=1317
Command Accepted - Processing
    eagle1 17-05-04 16:20:40 MST EAGLE 46.5.0.0.0-70.29.0
    rept-stat-card:mode=full:loc=1317
    Command entered at terminal #13.
;
    eagle1 17-05-04 16:20:40 MST EAGLE 46.5.0.0.0-70.29.0
                                            PST
           VERSION TYPE GPL
                                                                             AST
    CARD
                                                PST SST AST
IS-ANR MPS Unavl -----
                                                                 SST
          140-029-000 SLIC
                                    ENUM64
    1317
      ALARM STATUS = No Alarms.
      BLSLC64 GPL version = 140-029-000
      IMT BUS A
                           = Conn
      IMT BUS B
                           = Disc
      CLOCK A
                           = Fault
                           = Active
      CLOCK B
      CLOCK I
                          = Idle
                        = Valid
= SLIC
      MBD BIP STATUS
      MOTHER BOARD ID
      DBD STATUS
                           = Valid
      DBD TYPE = None
DBD MEMORY SIZE = 16384M
      HW VERIFICATION CODE= ----
      FPGA VERSION = 9400036
      BIOS VERSION
                           = 0ACFP00
      PSOC VERSION = 1.0
      CURRENT TEMPERATURE = 40C (104F)
      PEAK TEMPERATURE: = 42C (108F) [17-05-04 15:51]
      ENUM SM DATA TYPE = DN
      IPLNK STATUS
          IPLNK IPADDR
                                      STATUS
                                                  PST

        IIIADDR
        SIAIOS

        192.168.120.13
        UP

        10.75.49.21
        DOWN

        10.75.50.21
        DOWN

        192.168.121.13
        UP

                                                  IS-NR
          А
          В
                                                  OOS-MT
          С
                                                 OOS-MT
          D
                                                  IS-NR
      DSM IP CONNECTION
                                   SST
          PORT PST
                 OOS-MT
                                  Unavail
          Α
                 OOS-MT
                                  Unavail
          D
    Command Completed.
;
> pass:loc=1317:cmd="netstat -i"
```

```
Upgrade/Installation Guide
```

```
Command Accepted - Processing
   eagle1 17-05-04 16:25:06 MST EAGLE 46.5.0.0.0-70.29.0
   pass:loc=1317:cmd="netstat -i"
   Command entered at terminal #13.
;
   eagle1 17-05-04 16:25:06 MST EAGLE 46.5.0.0.0-70.29.0
   PASS: Command sent to card
   eagle1 17-05-04 16:25:06 MST EAGLE 46.5.0.0.0-70.29.0
   SDS Shell Output
   shellLib: unknown LED mode vi.
    -> tklc ifShow
   lo0 Link type:Local loopback Queue:none
       inet 127.0.0.1 mask 255.255.255.255
       inet6 unicast fe80::1%lo0 prefixlen 64 automatic
       inet6 unicast ::1 prefixlen 128
       UP RUNNING LOOPBACK MULTICAST NOARP ALLMULTI
       MTU:1500 metric:1 VR:0 ifindex:1
       RX packets:1487 mcast:3 errors:0 dropped:0
       TX packets:1487 mcast:3 errors:0
       collisions:0 unsupported proto:0
       RX bytes:165k TX bytes:165k
               Link type:Ethernet HWaddr 00:10:e0:bb:26:d0 Queue:none
   aei0
       capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
       inet 192.168.120.13 mask 255.255.255.0 broadcast 192.168.120.255
       inet6 unicast fe80::210:e0ff:febb:26d0%gei0 prefixlen 64 automatic
       UP RUNNING SIMPLEX BROADCAST MULTICAST
       MTU:1500 metric:1 VR:0 ifindex:2
       RX packets:929 mcast:0 errors:0 dropped:0
       TX packets:745 mcast:6 errors:0
       collisions:0 unsupported proto:0
       RX bytes:101k TX bytes:93k
               Link type:Ethernet HWaddr 00:10:e0:bb:26:d2 Queue:none
   gei2
       capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
       inet 10.75.49.21 mask 255.255.255.0 broadcast 10.75.49.255
       inet6 unicast fe80::210:e0ff:febb:26d2%gei2 prefixlen 64 automatic
       UP RUNNING SIMPLEX BROADCAST MULTICAST
       MTU:1500 metric:1 VR:0 ifindex:3
       RX packets:37 mcast:0 errors:0 dropped:0
       TX packets:7 mcast:6 errors:0
       collisions:0 unsupported proto:0
       RX bytes:4596 TX bytes:510
               Link type:Ethernet HWaddr 00:10:e0:bb:26:d1 Queue:none
   gei1
       capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
       inet 10.75.50.21 mask 255.255.255.0 broadcast 10.75.50.255
       inet6 unicast fe80::210:e0ff:febb:26d1%gei1 prefixlen 64 tentative automatic
       UP SIMPLEX BROADCAST MULTICAST
       MTU:1500 metric:1 VR:0 ifindex:4
       RX packets:0 mcast:0 errors:0 dropped:0
       TX packets:0 mcast:0 errors:0
       collisions:0 unsupported proto:0
       RX bytes:0 TX bytes:0
               Link type:Ethernet HWaddr 00:10:e0:bb:26:d3 Queue:none
   aei3
       capabilities: TXCSUM TX6CSUM VLAN MTU VLAN TXHWTAG VLAN RXHWTAG
       inet 192.168.121.13 mask 255.255.255.0 broadcast 192.168.121.255
       inet6 unicast fe80::210:e0ff:febb:26d3%gei3 prefixlen 64 automatic
       UP RUNNING SIMPLEX BROADCAST MULTICAST
       MTU:1500 metric:1 VR:0 ifindex:5
       RX packets:921 mcast:0 errors:0 dropped:0
       TX packets:745 mcast:6 errors:0
```

```
Upgrade/Installation Guide
```

;

```
collisions:0 unsupported proto:0
RX bytes:101k TX bytes:93k
gei (unit number 0):
        PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
gei (unit number 2):
        PHY Flags: (0x12012) 100MB FDX DIX
gei (unit number 1):
        PHY Flags: (0x2012) DIX
gei (unit number 3):
        PHY Flags: (0x12114) AUTONEG 1000MB FDX DIX
value = 1 = 0x1
eagle1 17-05-04 16:25:16 MST EAGLE 46.5.0.0.0-70.29.0
NETSTAT command complete
```

;

;

# Procedure A.18 Upgrade SSL certificate from SHA-1 to SHA-512

	Appendix A.18 Upg	grade SSL certificate from SHA-1 to SHA-512		
S T	This procedure upgrade SSL certificate from SHA-1 to SHA-512.			
E P	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.			
#		AILS, CONTACT MY ORACLE SUPPORT AND <b>ASK FOR <u>UPGRADE ASSISTANCE</u>.</b>		
1.	<b>MPS :</b> Log in to the server.	If not already logged-in, then login at MPS : <hostname> console login: epapdev Password: <password> Change to root user. \$ su - root</password></hostname>		
2.	Verify SSL certificate	To verify SSL certificate execute the following command:		
		<pre># /usr/bin/openssl x509 -in /usr/TKLC/plat/etc/ssl/server.crt -text -noou   grep "Signature Algorithm" Signature Algorithm: sha512WithRSAEncryption Signature Algorithm: sha512WithRSAEncryption If signature algorithm is SHA 512 skip this procedure,otherwise proceed with the following step.</pre>		
3.	Find the IP for which the certificate has been generated in server.crt	<pre># openssl verify /usr/TKLC/plat/etc/ssl/server.crt /usr/TKLC/plat/etc/ssl/server.crt: CN = 10.248.11.14 error 18 at 0 depth lookup:self signed certificate OK</pre>		
4.	Upgrade to SHA-512 in server.crt	Note: The IP Address to be used in the below command is the IP displayed in the output of step 3. To upgrade SHA-1 to SHA-512 execute the following command: # /usr/bin/openssl req -x509 -sha512 -nodes -days 4015 -subj "/CN= <ip Addr&gt;" -newkey rsa:2048 -keyout /usr/TKLC/plat/etc/ssl/server.key -out /usr/TKLC/plat/etc/ssl/server.crt Generating a 2048 bit RSA private key </ip 		
5.	Find the IP for which the certificate has been generated in server_dual.crt	<pre># openssl verify /usr/TKLC/plat/etc/ssl/server_dual.crt /usr/TKLC/plat/etc/ssl/server_dual.crt: CN = 10.248.11.14 error 18 at 0 depth lookup:self signed certificate OK</pre>		
6.	Upgrade to SHA-512 in server_dual.crt	Note: The IP Address to be used in the below command is the IP displayed in the output of step 5. To upgrade SHA-1 to SHA-512 execute the following command: <b># /usr/bin/openssl req -x509 -sha512 -nodes -days 4015 -subj "/CN=<ip< b=""> Addr&gt;" -newkey rsa:2048 -keyout /usr/TKLC/plat/etc/ssl/server_dual.key - out /usr/TKLC/plat/etc/ssl/server_dual.crt Generating a 2048 bit RSA private key </ip<></b>		

7.	Restart httpd service	Restart httpd service to reflect IP correctly. Use following command to restart httpd service:
		<pre>\$ service httpd restart [root@Natal-A ~]# service httpd restart Stopping httpd: [ OK ] Starting httpd: [Fri Jul 06 23:26:09 2018] [warn] _default_ VirtualHost overlap on port 8002, the first has precedence [Fri Jul 06 23:26:09 2018] [warn] _default_ VirtualHost overlap on port 443, the first has precedence</pre>
8.	Exit from root user	Exit from root user. Use following command:
		\$ exit
9.	Procedure Complete.	Return to the procedure that you came here from.
10.	Note down the timestamp	Run the following command:
	in log.	\$ date

# Procedure A.19 Disable Epap VIP And Deactivate PDBA Proxy Feature

Disable Epap VIP And Deactivate PDBA Proxy Feature

If PDBA Proxy feature is NOT enabled and VIP is NOT configured, this procedure can be skipped.

#### Ensure the provisioning activity has been halted before proceeding!!!

Appendix A.19

S T P #	This procedure outlines the ste Estimated time: 5 minutes	eps to disable the PDBA proxy feature.
	MPS A: Choose option "8" to display "PDB Configuration Menu.	<pre>MPS Side A: /EPAP Configuration Menu</pre>

2		MPS Side A:	
2.	MPS A:		
IП	Choose option "6" to	/Configure PDB Menu\ /\	
	"Change PDBA Proxy State".	1   Configure PDB Network	
		2   RTDB Homing Menu	
		   3   Change MPS Provisionable State	
		   4   Create PDB	
		5   Change Auto DB Recovery State	
		e   Exit   \/	
		Enter Choice: 6	
3.		PDBA PROXY is currently ENABLED.	
	MPS A: Enter "Y" to stop PDBA / EPAP software and disable	Do you want to DISABLE PDBA Proxy? [N]: Y	
4.	PDBA Proxy.	MPS Side A:	
	<b>MPS A</b> : Enter "1" to "Display		
	Configuration"	/EPAP Configuration Menu\	
		1   Display Configuration	
		2   Configure Network Interfaces Menu	
		3 Set Time Zone	
		4   Exchange Secure Shell Keys	
		5   Change Password	
		6   Platform Menu	
		7   Configure NTP Server	
		8   PDB Configuration Menu   	
		9   Security   	
		10   SNMP Configuration   	
		11   Configure Alarm Feed   	
		12   Configure Query Server	
		13   Configure Query Server Alarm Feed   	
		15   Mate Disaster Recovery	
		   e   Exit	
		\/	
		Enter Choice: 1	
5.	MPS A:	MPS Side A:	
	Verify that the state of PDBA Proxy Feature is No.	EPAP A Provisioning Network IP Address = 192.168.61.115	
		EPAP B Provisioning Network IP Address = 192.168.61.116	
		Provisioning Network Netmask = 255.255.255.0	
		Provisioning Network Default Router =	
		192.168.61.1 EPAP A Backup Prov Network IP Address = Not	
		configured ЕРАР В Backup Prov Network IP Address = Not	
		configured	

	Backup Prov Network Netmask	= Not
	configured	Net
	Backup Prov Network Default Router	= NOT
	configured	
	EPAP A Sync Network Address	=
	192.168.2.100	
	EPAP B Sync Network Address	=
	192.168.2.200	
	EPAP A Main DSM Network Address 192.168.120.100	=
	EPAP B Main DSM Network Address	=
	EPAP A Backup DSM Network Address	=
	192.168.121.100	=
	EPAP B Backup DSM Network Address	=
	192.168.121.200	-
		= 80
	EPAP A HTTP Port EPAP B HTTP Port EPAP A HTTP SUExec Port EPAP B HTTP SUExec Port EPAP A Banner Connection Port EPAP B Banner Connection Port EPAP A Static NAT Address	- 80
	EDAD A HTTD SUEVAC Port	- 8001
	EPAP A HITP SUEVEC POIL	= 8001
	EPAP & Banner Connection Port	- 8473
	EPAP A Banner Connection Port	= 8473
	EPAP A Static NAT Address	= Not
	configured	
	EPAP B Static NAT Address	= Not
	configured	
	PDBI Port	= 5873
	Remote MPS A Static NAT Address	
	configured	noe
	Remote MPS A HTTP Port	= 80
	Local Provisioning VIP	=
	192.168.15.152	
	Remote Provisioning VIP	=
	192.168.15.172	
	Local PDBA Address	=
	192.168.15.115	
	Remote PDBA Address	=
	192.168.16.115	
	Remote PDBA B Address	=
	192.168.16.116	
	Time Zone	=
	America/New_York	-
	PDB_Database	= Exists
	Preferred PDB	= Standby
	Allow updates from alternate PDB	= Yes
	Auto DB Recovery Enabled	= Yes
	Preferred PDB Allow updates from alternate PDB Auto DB Recovery Enabled ODBA Proxy Enabled	⊃ No
	Press return to continue	
· · · · · · · · · · · · · · · · · · ·		

6.	MPS A:	MPS Side A:
	Choose option "2" to enter	/EPAP Configuration Menu\ /
	the "Configure Network Interfaces Menu".	1   Display Configuration
		2   Configure Network Interfaces Menu
		3   Set Time Zone
		4   Exchange Secure Shell Keys
		   5   Change Password
		   6   Platform Menu
		7   Configure NTP Server
		   8   PDB Configuration Menu
		   9   Security
		   10   SNMP Configuration
		   11   Configure Alarm Feed
		   12   Configure Query Server
		   13   Configure Query Server Alarm Feed
		   14   Configure SNMP Agent Community
		15   Mate Disaster Recovery
		   e   Exit
		Enter Choice: 2
7.	MPS A:	MPS Side A:
	Choose option "7" to enter	/Configure Network Interfaces Menu\
	the "Configure Provisioning VIP Addresses Menu".	1   Configure Provisioning Network
		2 Configure Sync Network
		3   Configure DSM Network
		4 Configure Backup Provisioning Network
		5   Configure Forwarded Ports
		6 Configure Static NAT Addresses
		7   Configure Provisioning VIP Addresses
		     e   Exit   \/
		Enter Choice: 7
8.	MPS A:	Verifying root connectivity with mate
		EPAP local provisioning Virtual IP Address [192.168.15.152]: 0.0.0.0
		EPAP remote provisioning Virtual IP Address [192.168.15.172]: 0.0.0.0

	Remove the local provisioning VIP and remote provisioning VIP, by entering 0.0.0.0.	
9.	MPS A:	MPS Side A:
	Choose option "e" to exit.	/Configure Network Interfaces Menu\
		1   Configure Provisioning Network
		2 Configure Sync Network
		3   Configure DSM Network
		   4   Configure Backup Provisioning Network
		5   Configure Forwarded Ports
		6 Configure Static NAT Addresses
		7   Configure Provisioning VIP Addresses
		   e   Exit
		Criter Choice: e
10.		Enter Choice: e MPS Side A:
	MPS A:	
	Choose option "1" to "Display Configuration.	/EPAP Configuration Menu\
	Display Configuration.	1   Display Configuration
		2   Configure Network Interfaces Menu
		3   Set Time Zone
		4   Exchange Secure Shell Keys
		5   Change Password   
		6   Platform Menu   
		7   Configure NTP Server   
		8   PDB Configuration Menu
		9   Security
		10   SNMP Configuration
		11   Configure Alarm Feed   
		12   Configure Query Server   
		14   Configure SNMP Agent Community
		11
		15   Mate Disaster Recovery   
		Enter Choice: 1
11.	MPS A:	MPS Side A:
	Verify VIP addresses are set	EPAP A Provisioning Network IP Address =
	to <b>0.0.0.0</b> .	192.168.61.115 EPAP B Provisioning Network IP Address =
		192.168.61.116 Provisioning Network Netmask =
		255.255.255.0
192.168.61.1 EPAP A Backup Prov Network configured		
		EPAP A Backup Prov Network IP Address = Not configured EPAP & Backup Brow Network IB Address = Not
		ЕРАР В Backup Prov Network IP Address = Not configured Backup Prov Network Netmask = Not
		configured
		Backup Prov Network Default Router = Not configured
		EPAP Ā Sync Network Address = 192.168.2.100

EPAP B Sync Network Address 192.168.2.200	=
EPAP A Main DSM Network Address	=
192.168.120.100	
EPAP B Main DSM Network Address 192.168.120.200	=
	=
EPAP A Backup DSM Network Address 192.168.121.100	=
EPAP B Backup DSM Network Address	=
192.168.121.200	
EPAP A HTTP Port	= 80
EPAP B HTTP Port	= 80
EPAP A HTTP SUExec Port	= 8001
EPAP B HTTP SuExec Port	= 8001
FPAP A Banner Connection Port	= 8473
EPAP B Banner Connection Port	= 8473
EPAP B HTTP SUEXEC Port EPAP A Banner Connection Port EPAP B Banner Connection Port EPAP A Static NAT Address	= Not
configured	- 1102
EPAP B Static NAT Address	= Not
configured	= NOC
PDBI Port	= 5873
Remote MPS A Static NAT Address	= 3075
configured Remote MPS <u>A HTTP Port</u>	= 80
Remote MPS A HITP Port	
LOCAL PROVISIONING VIP	= 0.0.0.0 = 0.0.0.0
LOCAT FDBA Address	=
192.168.15.115	
Remote PDBA Address	=
192.168.16.115	
Remote PDBA B Address	=
192.168.16.116	
Time Zone	=
America/New_York	
PDB Database	= Exists
Preferred PDB	= Standby
Allow updates from alternate PDB	= Yes
Auto DB Recovery Enabled	= Yes
Preferred PDB Allow updates from alternate PDB Auto DB Recovery Enabled PDBA Proxy Enabled	= NO
Press return to continue	

12.	MPS A:	MPS Side A:		
	Choose "e" to exit.			
		/EPAP Configuration Menu\ /		
		/ 1   Display Configuration		
		2   Configure Network Interfaces Menu		
		3   Set Time Zone		
		4   Exchange Secure Shell Keys		
		   5   Change Password		
		   6   Platform Menu		
		   7   Configure NTP Server		
		8   PDB Configuration Menu		
		9   Security		
		10   SNMP Configuration		
		11   Configure Alarm Feed		
		12   Configure Query Server		
		13   Configure Query Server Alarm Feed		
		14   Configure SNMP Agent Community		
		15   Mate Disaster Recovery		
		e   Exit		
		Enter Choice: e		
13.	Return to the procedure that ye	ou came here from.		
14.	Note down the timestamp in	Run the following command:		
	log.	\$ date		

# Procedure A.20 Enable EPAP PDBA Proxy and EPAP VIP Optional Features

Ensure the provisioning activity has been halted before proceeding!!!

Appendix A.20

Enable EPAP PDBA Proxy and EPAP VIP Optional Feature

S	This procedure outlines the steps for provisioning the PDBA proxy VIP.
E	Estimated time: 10 minutes
Р #	

1.	<b>MPS A</b> : Login as epapdev to 1A server.	Login: <b>epapdev</b> Password: <b><epapdev_password></epapdev_password></b>
2.	MPS A: Perform "syscheck" on the 1A server.	<pre>\$ syscheck Running modules in class hardware OK Running modules in class proc OK Running modules in class net Running modules in class disk Running modules in class services OK Running modules in class system OK LOG LOCATION: /var/TKLC/log/syscheck/fail_log #</pre>
3.	MPS A: SSH to EPAP 1B.	\$ssh mate
4.	MPS B: Perform "syscheck" on the 1B.	<pre>\$ syscheck Running modules in class hardware OK Running modules in class proc Running modules in class net Running modules in class disk Running modules in class services OK Running modules in class system OK LOG LOCATION: /var/TKLC/log/syscheck/fail_log #</pre>
5.	MPS B: Exit back to the 1A server	\$ exit
6.	MPS A: Log into epapconfig	\$su - epapconfig Password:
7.	MPS A: Choose option "1" to display Configuration.	MPS Side A:

	/	-EPAP Configuration Menu	\
	/		`\ 
			 111
	\		/
MPS A: Verify that the VIP is not configured.	EPAP A EPAP B Provis Provis EPAP A EPAP B Backup EPAP A EPAP B EPAP B E EPAP B E EPAP B E E I I I I I I I I I I I I I I I I I I	Provisioning Network IP Address Provisioning Network IP Address ioning Network Netmask ioning Network Default Router Backup Prov Network IP Address Backup Prov Network IP Address Prov Network Netmask Prov Network Netmask Prov Network Address Sync Network Address Sync Network Address Sync Network Address Main DSM Network Address Backup DSM Network Address Backup DSM Network Address Backup DSM Network Address HTTP Port HTTP SuExec Port HTTP SuExec Port Banner Connection Port Static NAT Address Static NAT Address Static NAT Address Ort MPS A Static NAT Address MPS A HTTP Port Provisioning VIP PDBA Address PDBA Address PDBA B Address One tabase red PDB	= 192.168.61.116 = 255.255.255.0 = 192.168.61.1 = Not configured = Not configured = Not configured
	Verify that the VIP is not	2345678101112131415141514158PAP APAP APAP BBackup <td>2       Configure Network Interfaces Mer         3       Set Time Zone         4       Exchange Secure Shell Keys         5       Change Password         6       Platform Menu         7       Configure NTP Server         8       PDB Configuration Menu         9       Security         10       SNMP Configuration         11       Configure Query Server         12       Configure Query Server Alarm Feed        </td>	2       Configure Network Interfaces Mer         3       Set Time Zone         4       Exchange Secure Shell Keys         5       Change Password         6       Platform Menu         7       Configure NTP Server         8       PDB Configuration Menu         9       Security         10       SNMP Configuration         11       Configure Query Server         12       Configure Query Server Alarm Feed

9.	MPS A:	MPS Side A:
9.	MPS A: Choose option "2" to enter the "Configure Network Interfaces Menu".	/EPAP Configuration Menu
		5Change Password6Platform Menu7Configure NTP Server8PDB Configuration Menu9Security10SNMP Configuration11Configure Alarm Feed12Configure Query Server13Configure Query Server Alarm Feed14Configure SNMP Agent Community15Mate Disaster Recovery
10.	MPS A:	   e   Exit \/ Enter Choice: 2 MPS Side A: /Configure Network Interfaces Menu\
	Choose option "6" to enter the "Configure Provisioning VIP Addresses Menu".	1       Configure Provisioning Network         2       Configure Sync Network         3       Configure DSM Network         4       Configure Backup Provisioning Network         5       Configure Static NAT Addresses         6       Configure Provisioning VIP Addresses         e       Exit
11.	MPS A: Enter "Y" to stop PDBA / EPAP software then enter VIP address for the local and remote PDBA sites.	Enter Choice: 6 Verifying root connectivity with mate EPAP software and PDBA are running. Stop them? [N]: Y EPAP software is running on mate MPS. Stop it? [N]: Y EPAP local provisioning Virtual IP Address [0.0.0.0]: <b>192.168.15.152</b> EPAP remote provisioning Virtual IP Address [0.0.0.0]: <b>192.168.15.172</b>

12.	MPS A:	MPS Side A:
	Choose option "e"	/Configure Network Interfaces Menu\
	to exit.	1   Configure Provisioning Network
		2 Configure Sync Network
		3   Configure DSM Network
		   4   Configure Backup Provisioning Network
		5   Configure Static NAT Addresses
		6   Configure Provisioning VIP Addresses
		   e   Exit
		\/ Enter Choice: e
13.	MPS A:	MPS Side A:
	Choose option "1" to "Display Configuration.	
	8	/EPAP Configuration Menu\
		1   Display Configuration
		2   Configure Network Interfaces Menu
		3   Set Time Zone
		4 Exchange Secure Shell Keys
		5   Change Password
		6 Platform Menu
		7   Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10   SNMP Configuration
		11   Configure Alarm Feed
		12   Configure Query Server
		13   Configure Query Server Alarm Feed
		14   Configure SNMP Agent Community
		15   Mate Disaster Recovery
		   e   Exit \/
		Enter Choice: 1
14.	MPS A:	MPS Side A:
	Verify VIP	EPAP A Provisioning Network IP Address = 192.168.61.115 EPAP B Provisioning Network IP Address = 192.168.61.116
	addresses	Provisioning Network Netmask = 255.255.255.0
		EPAP A Backup Prov Network IP Address = Not configured
		-1 $-1$ $-1$ $-1$ $-1$ $-1$ $-1$ $-1$
		EPAP A Sync Network Address = 192.168.2.100 EPAP B Sync Network Address = 192.168.2.200
		EPAP A Main DSM Network Address = 192.168.120.100 EPAP B Main DSM Network Address = 192.168.120.100 EPAP B Main DSM Network Address = 192.168.20.00
		EPAP B Backup DSM Network Address = 192.168.120.200 EPAP B Backup DSM Network Address = 192.168.121.100 EPAP B Backup DSM Network Address = 192.168.121.200
14.		Enter Choice: 1 MPS Side A: EPAP A Provisioning Network IP Address = 192.168.61.115 EPAP B Provisioning Network IP Address = 192.168.61.116 Provisioning Network Netmask = 255.255.255.0 Provisioning Network Default Router = 192.168.61.1 EPAP A Backup Prov Network IP Address = Not configured Backup Prov Network Netmask = Not configured Backup Prov Network Netmask = Not configured Backup Prov Network Default Router = Not configured Backup Prov Network Default Router = Not configured Backup Prov Network Address = 192.168.2.100 EPAP A Main DSM Network Address = 192.168.120.100 EPAP B Main DSM Network Address = 192.168.120.200

**Upgrade/Installation Guide** 

		EPAP A HTTP Port= 80EPAP B HTTP Port= 80EPAP A HTTP SUExec Port= 8001EPAP A HTTP SUExec Port= 8001EPAP B BANNER CONNECTION PORT= 8473EPAP B Banner Connection Port= 8473EPAP A Static NAT Address= Not configuredEPAP B Static NAT Address= Not configuredPDBI Port= 5873Remote MPS A Static NAT Address= Not configuredRemote MPS A HTTP Port= 80Local Provisioning VIP= 192.168.15.152Remote PDBA Address= 192.168.15.115Remote PDBA Address= 192.168.16.115Remote PDBA B Address= 192.168.16.116Time Zone= America/New_YorkPDB Database= Exists
		Preferred PDB = Standby Allow updates from alternate PDB = Yes Auto DB Recovery Enabled = Yes PDBA Proxy Enabled = No
15.	MPS A: Choose "e" to exit	Press return to continue /EPAP Configuration Menu\
		1       Display Configuration         2       Configure Network Interfaces Menu         3       Set Time Zone         4       Exchange Secure Shell Keys         5       Change Password         6       Platform Menu         7       Configure NTP Server         8       PDB Configuration Menu         9       Security         10       SNMP Configuration         11       Configure Alarm Feed
16.	MPS A: Verify that you can ping both VIP addresses.	<pre>\$ ping <local vip=""> \$ ping <remote vip=""></remote></local></pre>
17.	MPS A: Log into epapconfig	\$ su - epapconfig

18.	MPS A:	
8	Enter "1" to	
	"Display Configuration"	/EPAP Configuration Menu\
		/\   1   Display Configuration
		2 Configure Network Interfaces Menu
		3 Set Time Zone
		4   Exchange Secure Shell Keys
		5 Change Password
		6 Platform Menu
		7   Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10   SNMP Configuration
		11   Configure Alarm Feed
		12 Configure Query Server
		13 Configure Query Server Alarm Feed
		14 Configure SNMP Agent Community
		15 Mate Disaster Recovery
		e   Exit
		Enter Choice: 1
19.	MPS A:	MPS Side A:
19.	MPS A: Verify that the state of PDBA Proxy Feature is No.	EPAP A Provisioning Network IP Address= 192.168.61.115EPAP B Provisioning Network NEP Address= 192.168.61.116Provisioning Network Default Router= 255.255.0Provisioning Network Default Router= 192.168.61.1EPAP A Backup Prov Network IP Address= Not configuredBackup Prov Network NEP Address= Not configuredBackup Prov Network Netmask= Not configuredBackup Prov Network Address= 192.168.2.100EPAP A Sync Network Address= 192.168.120.100EPAP B Main DSM Network Address= 192.168.120.200EPAP A Backup DSM Network Address= 192.168.120.200EPAP A Backup DSM Network Address= 192.168.121.100EPAP B Backup DSM Network Address= 192.168.121.200EPAP A HTTP Port= 80EPAP B HTTP Port= 80EPAP A Banner Connection Port= 8001EPAP A Banner Connection Port= 8001EPAP B Banner Connection Port= 8073EPAP B Static NAT Address= Not configuredEPAP A Static NAT Address= Not configuredEPAP B Static NAT Address= Not configuredEPAP B Address= 192.168.61.115Remote PPS A HTTP Port= 80Cocal Provisioning VIP= Not configuredLocal Provisioning VIP= Not configuredLocal Provisioning VIP= Not configuredRemote PDBA Address= 192.168.61.115Remote PDBA Address= 192.168.61.1181Remote PDBA Address= 192.168.61.182Time Zone= America/New_YorkPDB Database<

		Auto DB Recovery Enabled = Yes PDBA Proxy Enabled = No
20		Press return to continue MPS Side A:
20.	MPS A: Choose option "8" to display "PDB Configuration Menu	MPS Side A:         /EPAP Configuration Menu
21.	MPS A:	Enter Choice: 8 MPS Side A:
	Choose option "6" to "Change PDBA Proxy State".	/Configure PDB Menu
22.	MPS A: Enter "Y" to stop PDBA / EPAP software and enable PDBA Proxy.	EPAP software and PDBA are running. Stop them? [N]: Y EPAP software is running on mate MPS. Stop it? [N]: Y PDBA PROXY is currently DISABLED. Do you want to ENABLE PDBA Proxy? [N]: Y

23.	MPS A:	MPS Side A:
25.	Enter "e" to exit	/Configure PDB Menu\
		/\   1   Configure PDB Network
		   2   RTDB Homing Menu
		3   Change MPS Provisionable State
		4 Create PDB
		6   Change PDBA Proxy State
		e   Exit   \/
		Enter Choice: e
24.	MPS A:	
	Enter "1" to	
	"Display Configuration"	
25		MPS Side A
25.	MPS A: Verify that the	EPAP A Provisioning Network IP Address = 192.168.61.115
	state of PDBA	EPAP B Provisioning Network IP Address = 192.168.61.116 Provisioning Network Netmask = 255.255.255.0
	Proxy Feature is	Provisioning Network Default Router = 192.168.61.1 EPAP A Backup Prov Network IP Address = Not configured
	Yes.	
		EPAP B Backup Prov Network IP Address= Not configuredBackup Prov Network Netmask= Not configuredBackup Prov Network Default Router= Not configuredEPAP A Sync Network Address= 192.168.2.100EPAP B Sync Network Address= 192.168.2.200EPAP A Main DSM Network Address= 192.168.120.100EPAP B Main DSM Network Address= 192.168.120.200EPAP A Backup DSM Network Address= 192.168.121.100EPAP B Backup DSM Network Address= 192.168.121.200EPAP A HTTP Port= 80
		EPAP A Sync Network Address= 192.168.2.100EPAP B Sync Network Address= 192.168.2.200
		EPAP A Main DSM Network Address= 192.168.120.100EPAP B Main DSM Network Address= 192.168.120.200
		EPAP A Backup DSM Network Address = 192.168.121.100 EPAP B Backup DSM Network Address = 192.168.121.200
		EPAP A HTTP Port = 80 EPAP B HTTP Port = 80
		EPAP A HTTP SUEXec Port = 8001 EPAP B HTTP SUEXec Port = 8001
		EPAP A Banner Connection Port = 8473
		EPAP B Banner Connection Port= 8473EPAP A Static NAT Address= Not configured
		EPAP B Static NAT Address = Not configured PDBI Port = 5873
		Remote MPS A Static NAT Address = Not configured Remote MPS A HTTP Port = 80
		Local Provisioning VIP = 192.168.15.152 Remote Provisioning VIP = 192.168.15.172
		Local PDBA Address = 192.168.15.115
		Remote PDBA B Address = 192.168.16.116
		Time Zone = America/New_York PDB Database = Exists
		Preferred PDB = Standby Allow updates from alternate PDB = Yes
		Auto DB Recovery Enabled = Yes PDBA Proxy Enabled = Yes
		MPS side A:
26.	MPS A: Enter "e" to exit	
		/EPAP Configuration Menu\ /\
		1   Display Configuration
		2   Configure Network Interfaces Menu
		3 Set Time Zone
<u> </u>		

**Upgrade/Installation Guide** 

	r	
		4   Exchange Secure Shell Keys 
		6   Platform Menu
		7   Configure NTP Server
		8 PDB Configuration Menu
		9 Security
		10   SNMP Configuration
		11   Configure Alarm Feed
		12   Configure Query Server
		13   Configure Query Server Alarm Feed
		14   Configure SNMP Agent Community
		15   Mate Disaster Recovery
		e   Exit
		Enter Choice: e
27.	MPS A: EPAP A: Log in to the web GUI as user "uiadmin".	
28.	MPS A: Start	A Start EPAP Software
	EPAP and PDBA Software.	PDBA S Check if you want to start the PDBA software along with the EPAP software.
		Are you sure you want to start the EPAP software?
	On the menu,	Start EPAP Software Tue June 09 2020 07:21:32 EUT
	click Process	Copyright © 2000, 2020, Oracle and/or its affiliates. All rights reserved.
	Control->Stap Software.	
	Click "Stop EDAD	
	Click "Stap EPAP Software" Button	~
		\$ syscheck
29.	MPS A:	Running modules in class hardware
	Perform "syscheck" on	OK Running modules in class proc
	MPS-A.	OK Running modules in class net
		OK Running modules in class disk
		OK Running modules in class services
		OK Running modules in class system
		OK
		LOG LOCATION: /var/TKLC/log/syscheck/fail_log
30.	MPS A:	\$ ssh mate
<u> </u>	SSH to MPS 1B.	\$ service Epap start
31.	MPS B: Start Epap	~~ /etc/init.d/Epap start ~~
	տասերսթ	
	software on MPS 1B.	"EPAP_RELEASE" is set to "0.613" EPAP application start Successful

32.	MPS B: Perform "syscheck" on MPS 1B.	<pre>\$ syscheck Running modules in class hardware OK Running modules in class proc Running modules in class net Running modules in class disk Running modules in class services OK Running modules in class system OK LOG LOCATION: /var/TKLC/log/syscheck/fail_log</pre>
33.	Return to the proce	dure that you came here from.
34.	Note down the timestamp in log.	Run the following command: \$ date

# Procedure A.21 Configure DSM Min Mem Size

Appendix A.21

Configure DSM Min Mem Size

S	This procedure configures DSM Min Mem Size on standalone PDB server.		
т		mpleted. Boxes have been provided for this purpose under each step number.	
E	eneer on (weather to his completed. Boxes have been provided for this purpose under each step humber.		
	IF THIS PROCEDURE FAILS, C	CONTACT MY ORACLE SUPPORTAND ASK FOR INSTALL ASSISTANCE.	
Р			
#			
1.	Standalone PDB :	Login: <b>epapdev</b> <b>Password:</b> <epapdev_password></epapdev_password>	
	Login as epapdev to standalone PDB server.		
2.	Execute getDsmMinMemSize.pl	Go to the bin directory to execute the getDsmMinMemSize.pl perl script	
		<pre>\$ cd /usr/TKLC/epap/bin</pre>	
		Execute getDsmMinMemSize.pl script	
		\$./getDsmMinMemSize.pl	
3.	Restart the pdb Software.	<pre>\$ service Pdba stop ~~ /etc/init.d/Pdba stop ~~</pre>	
		PDBA application stopped.	
		\$ service Pdba start	
		~~ /etc/init.d/Pdba start ~~	
		PDBA application started.	
		\$ service Pdba status	
		~~ /etc/init.d/Pdba status ~~	
		PDBA application is running.	
4.	Verify that the uiEdit "DSM_MIN_MEM_SIZE"	\$ uiEdit   grep DSM_MIN_MEM_SIZE	
	variable is added and updated		
	correctly.	"DSM_MIN_MEM_SIZE" is set to "12046"	

5.	Procedure Complete	Procedure is complete.
6.	Note down the timestamp in log.	Run the following command:
		\$ date

# Procedure A.22 Restart Mysql service for PDB on Query Server

#### Appendix A.22 Restart MySQL service for PDB on Query Server

#### NOTE: The MySQL services should be started as non-root admin user only.

		-	
This procedure restarts the MySQL service for PDB on Query Server.			
Check off ( $$ )each step as it is c	Check off ( $$ )each step as it is completed. Boxes have been provided for this purpose under each step number.		
IF THIS PROCEDURE FAILS,	CONTACT MY ORACLE SUPPORTAND ASK FOR INSTALL ASSISTANCE.		
Login to EAGLE QS as QS	login: <b><admin_user></admin_user></b>		
admin.	Password: <admin_password></admin_password>		
Start the mysqlpdb service.	<pre>\$ sudo service mysqlpdb stop</pre>		
	Waiting for mysqlpdb to stop		
Verify that mysqlpdb service is	<pre>\$ sudo service mysqlpdb start</pre>		
running.	Waiting for mysqlpdb to start done		
Start the mysqlpdb service.	<pre>\$sudo service mysqlpdb status</pre>		
5-11	PID:8841 mysqlpdb is running.		
Procedure Complete	Procedure is complete.		
Note down the timestamp in	Run the following command:		
log.	\$ date		

# Procedure A.23 Get parse9Dig file from EPAP 16.3 ISO

Appendix A.23 Get parse9Dig file from EPAP 16.3 ISO

S	This procedure extract parse9	Dig script file from EPAP 16.3 ISO.	
т	Check off ( $$ )each step as it is c	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.	
Е	IF THIS PROCEDURE FAILS,	CONTACT MY ORACLE SUPPORTAND ASK FOR INSTALL ASSISTANCE.	
Р			
#			
1.	MPS A: Login as admusr.	login: <admin_user></admin_user>	
		Password: <admin_password></admin_password>	
2.	MPS A: Copy ISO on MPS A.	Perform Procedure in Procedure A.12 or copy EPAP 16.3 ISO to	
		/var/TKLC/upgrade directory.	
	MDS A. Switch to root user	Switch to root user	
3.	<b>MPS A:</b> Switch to root user.	Switch to root user.	
Ingr	ade/Installation Guide	240 of 279 August 2024	

### Appendix A.23 Get parse9Dig file from EPAP 16.3 ISO

		\$ su – root
		Password:
4.	MPS A: Create directory	Create /mnt/iso directory using following command:
	using mkdir.	
		# mkdir /mnt/iso
5	MPS A: Mount ISO on	Mount ISO on above created path.
5.	above path	
	I I	# mount -o loop <16.3.a.0.0-b.b.b ISO with full path which is copied in step
		2> <full 4="" created="" directory="" in="" of="" path="" step=""></full>
		As follows:
		# mount -o loop /var/TKLC/upgrade/EPAP-16.3.0.0.0_163.8.0-x86_64.iso
		/mnt/iso/
6.	MPS A: Extract TKLCepap	Copy TKLCepap rpm at /tmp directory.
	rpm from the ISO.	# cp <directory 4="" created="" in="" step="">/Packages/<tklcepap rpm,="" same<="" th="" the=""></tklcepap></directory>
		version which is copied in step 2>/tmp
		version which is copied in step 2> / and
		As follows:
		# cp /mnt/iso/Packages/TKLCepap-163.0.8-16.3.0.0.0_163.8.0.x86_64.rpm
		/tmp/
7.	MPS A: Change directory	Change directory to /tmp using following command:
	to /tmp.	
		# cd /tmp
	<b>MPS A:</b> Extract parse9Dig	Extract desired file parse9Dig from rpm:
8.	script file from rpm.	
		<pre># rpm2cpio <tklcepap 6="" extracted="" in="" rpm="" step="">   cpio -idmv <parse9dig></parse9dig></tklcepap></pre>
		As follows:
		# rpm2cpio TKLCepap-163.0.8-16.3.0.0_163.8.0.x86_64.rpm   cpio -
		idmv ./usr/TKLC/epap/config/parse9Dig
		<pre>[root@Natal-A tmp]# rpm2cpio TKLCepap-163.0.8-16.3.0.0.0_163.8.0.x86_64.rpm   cpio -idmv ./usr/TKLC/epap/config/parse9Dig ./usr/TKLC/epap/config/parse9Dig</pre>
		318312 blocks
	MPS A: Copy extracted	Copy extracted parse9Dig file at path: /usr/TKLC/epap/config
9.	parse9Dig at desired path.	Use following path:
		# cp /tmp/usr/TKLC/epap/config/parse9Dig /usr/TKLC/epap/config
	MPS A: Change the	Change mode of file parseQDig to 755 and ownership to apandowener
10.	<b>MPS A:</b> Change the permission of parse9Dig file	Change mode of file parse9Dig to 755 and ownership to epapdev:epap. Use following command:
	as required.	
	-	# cd /usr/TKLC/epap/config
		# chmod 755 parse9Dig
		# chown epapdev:epap parse9Dig
		List the file and check the permissions. It should be same as follows:
		# 11 parse9Dig

### Appendix A.23 Get parse9Dig file from EPAP 16.3 ISO

		[root@Natal-A config]# ll parse9Dig
		-rwxr-xr-x 1 epapdev epap 12162 Jul 9 21:39 parse9Dig
11.	<b>MPS A:</b> Snapshot of all above executed commands to extract parse9Dig file.	Verify that all steps executed successfully as follows: <pre>[rootBMatal-A -]#</pre> [rootBMatal-A -]# mkdir /mnt/iso [rootBMatal-A -]# [rootBMatal-A tmp]# [root
12.	<b>MPS A:</b> Remove all temporary files from /tmp directory.	Remove parse9Dig file and TKLCepap rpm from /tmp directory. Execute following command on CLI: # rm -f /tmp/usr/TKLC/epap/config/parse9Dig # rm -f /tmp/TKLCepap-163.0.12-16.3.0.0.0_163.12.0.x86_64.rpm
13.	<b>MPS A:</b> Umount the mounted ISO.	Umount the ISO which was mounted in step 5. Execute below command: # umount /mnt/iso/
14.	MPS A: Remove ISO directory.	Remove directory /mnt/iso. Execute below command: # rmdir /mnt/iso/
15.	Procedure Complete	Procedure is complete.
16.	Note down the timestamp in	Run the following command:
10.	log.	
		\$ date

# Procedure A.24 PDB Restore

### Appendix A.24 PDB Restore

S	This procedure prov	vides instructions to restore PDB from a backup file.
T E P	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.	
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.	
1.	<b>EPAP A:</b> Log in to the CLI as user "admusr".	If not already logged in, then login as 'admusr': [hostname] consolelogin: admusr password: password

epapdev user.	-	Appendix A.24	
is should be readable for epapdev user       [epapdev@DBExp-VM77 free]\$ 11 pdbBackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bxp.tar.gz -rx-rx+rx+rx = 1 epapdev epap 1182165 Jul 16 03:32 pdbBackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bxp.tar.gz         #       EPAP A: Statt restore from CLL       Note: Skip this step if the PDB backup is taken on EPAP 16.3 release.         #       EPAP A: Statt restore from CLL       Note: Skip this step if the PDB backup is taken on EPAP 16.3 release.         #       EPAP A: Statt restore from CLL       Note: Skip this step if the PDB backup is taken on EPAP 16.3 release.         #       EPAP A: Statt restore from CLL       Note: Skip this step if the PDB backup is taken on EPAP 16.3 release.         #       Epapdev@DExp-VM77 free]\$ /usr/TKL/c/epap/config/restore_pdb -force7       If backup is taken on EPAP 16.2, then use following command to start restore process: S /usr/TKL/c/epap/config/restore_pdbforce Mon Jul 16 07:22:15 DET 2018         This script will replace the existing PDB with one provided from a backup and co Are you sure you want to do continue? (y/n) Y         Enter the name of the backup tar.gz file. /var/TKL/c/epap/free/pdbBackup_Matal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bpt_tar.gz         Iocallp = 10.75.138.77 Iocallp = 10.75.138.77 Iocallp = 0.0.0.0 No remote site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n) Y         Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space	2.		
readable for epapter       [espadew0DEExp=VM77 free1s 11 pdDEackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bbp.tar.gz =rw=rw=rw = 1 epaptev epap 1182165 Jul 16 03:32 pdDEackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bbp.tar.gz         #       EPAP A: Start restore from CLI.       If permission and ownership of tar file is not same as above then use following command: Change mode of tar file: \$ chmod 666 <pdb backup="" file="" tar="">         #       EPAP A: Start restore from CLI.       Note: Skip this step if the PDB backup is taken on EPAP 16.3 release. If backup is taken on EPAP 16.1, then use following command to start restore process: \$ /usr/TKLC/epap/config/restore_pdb-force7         If backup is taken on EPAP 16.2, then use following command to start restore process: \$ /usr/TKLC/epap/config/restore_pdb -force         Screenshot after initiating PDB restore from CLI as below (NOTE: Provided the user input accordingly): [espadew1DEExp=VM77 free18 /usr/TKLC/epap/free/opdDeackup_Matal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bbp.tar.gz locall p = 10.75.138.77 localMame=DExp=VM77 remoteIp = 0.0.0.0 No remote site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you surt to restore Stats database? (y/n) Y Running with force option! Skip compatibility check Scopping local PDBA ~ /etc/init.d/rzdba stop ~~</pdb>	3.		Check mode and ownership of PDB backup tar file. It should be as follows:
<pre>commad: Change mode of tar file: \$ chmod 666 <pdb backup="" file="" tar=""> 4. EPAP A: Start restore from CLI. 14. EPAP A: Start restore from CLI. 15. Start restore process: 16. Support to the part of the PDB backup is taken on EPAP 16.1, then use following command to start restore process: 17. Start restore process:</pdb></pre>		readable for epapdev	<pre>a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bkp.tar.gz -rw-rw-rw- 1 epapdev epap 1182165 Jul 16 03:32 pdbBackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v</pre>
restore from CLI. If backup is taken on EPAP 16.1, then use following command to start restore process: \$ /usr/TKLC/epap/config/restore_pdb -force7 If backup is taken on EPAP 16.2, then use following command to start restore process: \$ /usr/TKLC/epap/config/restore_pdb -force Screenshot after initiating PDB restore from CLI as below (NOTE: Provided the user input accordingly): [epapdev@DBExp=VM77 free]\$ /usr/TKLC/epap/config/restore_pdbforce Mon Jul 16 07:24:57 EDT 2018 This script will replace the existing PDB with one provided from a backup and co Are you sure you want to do continue? (y/n) Y Enter the name of the backup tar.gz file. /var/TKLC/epap/free/pdbBackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bkp.tar.gz localTp = 10.75.138.77 localName=DBExp=VM77 remote Site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n)Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIP = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~			command: Change mode of tar file:
restore from CLI. If backup is taken on EPAP 16.1, then use following command to start restore process: \$ /usr/TKLC/epap/config/restore_pdb -force7 If backup is taken on EPAP 16.2, then use following command to start restore process: \$ /usr/TKLC/epap/config/restore_pdb -force Screenshot after initiating PDB restore from CLI as below (NOTE: Provided the user input accordingly): [epapdev@DBExp=VM77 free]\$ /usr/TKLC/epap/config/restore_pdbforce Mon Jul 16 07:24:57 EDT 2018 This script will replace the existing PDB with one provided from a backup and co Are you sure you want to do continue? (y/n) Y Enter the name of the backup tar.gz file. /var/TKLC/epap/free/pdbBackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bkp.tar.gz localTp = 10.75.138.77 localName=DBExp=VM77 remote Site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n)Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIP = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~	4.	FDAD A. Start	Note: Skin this stan if the PDB backun is taken on FPAP 16.3 release
<pre>If backup is taken on EPAP 16.2, then use following command to start restore process: \$ /usr/TKLC/epap/config/restore_pdb -force Screenshot after initiating PDB restore from CLI as below (NOTE: Provided the user input accordingly): [epapdev@DBExp-VM77 free]\$ /usr/TKLC/epap/config/restore_pdbforce Mon Jul 16 07:24:57 EDT 2018 This script will replace the existing PDB with one provided from a backup and co Are you sure you want to do continue? (y/n) Y Enter the name of the backup tar.gz file. /var/TKLC/epap/free/pdbBackup_Natal- a_20180713022216 pDBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bkp.tar.gz localIp = 10.75.138.77 localName=DBExp-VM77 remoteIp = 0.0.0.0 No remote site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n)Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIp = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~</pre>	1.		
<pre>\$ /usr/TKLC/epap/config/restore_pdb -force Screenshot after initiating PDB restore from CLI as below (NOTE: Provided the user input accordingly): [epapdev@DEExp-VM77 free]\$ /usr/TKLC/epap/config/restore_pdbforce Mon Jul 16 07:24:57 EDT 2018 This script will replace the existing PDB with one provided from a backup and co Are you sure you want to do continue? (y/n) Y Enter the name of the backup tar.gz file. /var/TKLC/epap/free/pdbBackup_Natal- a_20180713022216 DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bkp.tar.gz localIp = 10.75.138.77 localMame=DEExp=VM77 remoteIp = 0.0.0.0 No remote site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n) Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIP = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~</pre>			\$ /usr/TKLC/epap/config/restore_pdb –force7
Screenshot after initiating PDB restore from CLI as below (NOTE: Provided the user input accordingly): [epapdev@DBExp-VM77 free]\$ /usr/TKLC/epap/config/restore_pdbforce Mon Jul 16 07:24:57 EDT 2018 This script will replace the existing PDB with one provided from a backup and co Are you sure you want to do continue? (y/n) Y Enter the name of the backup tar.gz file. /var/TKLC/epap/free/pdbBackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bkp.tar.gz local.p = 10.75.138.77 localName=DBExp=VM77 remoteIp = 0.0.0.0 No remote site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n)Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIp = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~			If backup is taken on EPAP 16.2, then use following command to start restore process:
<pre>input accordingly: [epapdev@DBExp-VM77 free]\$ /usr/TKLC/epap/config/restore_pdbforce Mon Jul 16 07:24:57 EDT 2018 This script will replace the existing PDB with one provided from a backup and co Are you sure you want to do continue? (y/n) Y Enter the name of the backup tar.gz file. /var/TKLC/epap/free/pdbBackup_Natal- a_20180713022216 DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bkp.tar.gz localIp = 10.75.138.77 localName=DBExp-VM77 remoteIp = 0.0.0.0 No remote site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n)Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIp = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~</pre>			\$ /usr/TKLC/epap/config/restore_pdb –force
<pre>/usr/TKLC/epap/config/restore_pdbforce Mon Jul 16 07:24:57 EDT 2018 This script will replace the existing PDB with one provided from a backup and co Are you sure you want to do continue? (y/n) Y Enter the name of the backup tar.gz file. /var/TKLC/epap/free/pdbBackup_Natal- a_20180713022216 DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bkp.tar.gz localIp = 10.75.138.77 localName=DBExp=VM77 remoteIp = 0.0.0.0 No remote site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n)Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIp = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~</pre>			
<pre>/var/TKLC/epap/free/pdbBackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v 7.50.bkp.tar.gz localIp = 10.75.138.77 localName=DBExp-VM77 remoteIp = 0.0.00 No remote site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n)Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIp = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~</pre>			/usr/TKLC/epap/config/restore_pdbforce Mon Jul 16 07:24:57 EDT 2018 This script will replace the existing PDB with one provided from a backup and co
<pre>7.50.bkp.tar.gz localIp = 10.75.138.77 localName=DBExp-VM77 remoteIp = 0.0.0.0 No remote site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n)Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIp = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~</pre>			
<pre>localIp = 10.75.138.77 localName=DBExp-VM77 remoteIp = 0.0.0.0 No remote site WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n)Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIp = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~</pre>			a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v
<pre>WARNING : If this backup is from EPAP 16.1 or earlier release please use option Are you sure this backup is taken on EPAP 16.2 release? (y/n)Y Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIp = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~</pre>			<pre>localIp = 10.75.138.77 localName=DBExp-VM77 remoteIp = 0.0.0.0</pre>
Do you want to restore Stats database? (y/n) Y Running with force option! Skip disk space check remoteBIp = There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~			WARNING : If this backup is from EPAP 16.1 or earlier release please use option
There is no remote B PDB Unzipping backup file. This may take a while Running with force option! Skip compatibility check Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~			Do you want to restore Stats database? (y/n) $\mathbf{Y}$ Running with force option! Skip disk space check
Stopping local PDBA ~~ /etc/init.d/Pdba stop ~~			There is no remote B PDB Unzipping backup file. This may take a while
-			Stopping local PDBA
			-

### Appendix A.24 PDB Restore

Appendix A.24	PDB Restore
	Stopping local PDB mysql daemon Waiting for mysqlpdb to stop done
	No need to create backup directory
	Running ibbackup tool to restore DB
	/bin/chown: changing ownership of
	<pre>`/usr/TKLC/epap/logs/queryServer.log': Operation not</pre>
	permitted
	Starting restore
	backup/
	backup/meta/
	backup/meta/backup_content.xml
	backup/meta/backup_content.xml
	Starting mysqlpdb
	Waiting for mysqlpdb to start done
	Removing local pdba status file.
	PDB RTDB SYNC Param updated successfully
	TDD_KIDD_DINC falam updated successfully
	Restore completed successfully.
	Mon Jul 16 07:45:33 EDT 2018
	"Restore completed successfully" message displayed on CLI after completed restore.
	Following error shall be observed on CLI during restore:
	myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI'
	myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI'
	myisamchk: error: 140 when opening MyISAM-table
	'/var/TKLC/epap/db/pdb/mysql/event.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'
	myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' myisamchk: error: 140 when opening MyISAM-table
	'/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI'
	myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI'
	myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI'
	myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'

			llowing the instructions on the front page or the F, if the output contains any error other than the above
5.	<b>EPAP A:</b> Log in to the web GUI as user "uiadmin".	User name: <i>uiadmin</i> Password:	
	Note: Move to step 9 if the PDB backup is taken on EPAP 16.2 or earlier release.		
6.	EPAP A: Stop Software. On the menu, click Process Control- >Stop Software. Click "Stop EPAP Software" Button	Mathematical Sector (1) (1) (2) (2) (2) (2) (2) (2) (2) (2) (2) (2	Copyright © 2000, 2014, Oracle and/or its affiliates. All rights reserved.
7.	<b>EPAP A:</b> Restore PDB.	EPAP A: uiadmin     Process Control     Maintenance	Restore the PDB
	On the menu, click PDBA- >Maintenance- >Backup->Restore the PDB Select the backup file, then click "Restore PDB from the Selected File" Button	Debug     Platform     Please sg     PDBA     Select Other PDBA     Switchover PDBA State     Process Control     View PDBA Status     OK	ecify the sub directory (default is /var/TKLC/epap/free) y 16 2018 03:26:01 EDT Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.

		A Restore the PDB
	Click "Confirm	CAUTION: Restoring the PDB will prevent the PDBA from receiving update and query requests until the restore is complete.
	PDB Restore" Button	Select         Type         Originating Host         File Name         File Size         Creation Time           O         pdbBackup         Natal-a         pdbBackup_Natal-a         1.2M bytes         Fri July 13 2018 02:22:16 EDT
		Restore PDB from the Selected File.
		A Restore the PDB
		Are you sure that you want to restore the PDB from the file pdbBackup_Natal-a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v7.50.bkp.tar.gz ? Confirm PDB Restore
		Restore successfully started:
		A Restore the PDB
		SUCCESS: Successfully started restore of PDB from /var/TKLC/appl/free/pdbBackup_Natal- a_20180713022216_DBBirthdate_20180713055242GMT_DBLevel_18_v7.50.bkp.tar.gz. Restore status will be displayed on Banner message window.
8.	<b>EPAP A:</b> An IM alarm should be observed with informational message on EPAP GUI confirming that restore PDB is	Confirming that Restore PDB in progress:
		Informational Messages
		Informational Messages
	in progress.	Restore PDB in progress
		Tue July 17 2018 02:31:52 EDT
	An IM alarm should be observed with informational message on EPAP GUI confirming that restore PDB completed successfully.	Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.

Appendix A.24 PDB Restore

	Confirming that Restore PDB is completed successfully:
	Informational Messages
	Informational Messages
	Informational Messages
	Restore PDB completed successfully
	icestore i DD completed successiony
	Tue July 17 2018 02:38:51 EDT
	Copyright © 2000, 2018, Oracle and/or its affiliates. All rights reserved.
	Similar logs as mentioned below, shall be observed in restore PDB logs, which
	should be ignored:
	Error : Table 'mysql.innodb_index_stats' doesn't exist
	status : Operation failed
	mysql.innodb_table_stats
	Error : Table 'mysql.innodb_table_stats' doesn't exist
	status : Operation failed.
	mysql.slave_worker_info
	Error : Table 'mysql.slave_worker_info' doesn't exist
	status : Operation failed
	Repairing tables
	mysql.engine_cost
	Error : Table 'mysql.engine_cost' doesn't exist
	status : Operation failed
	mysql.slave_worker_info
	Error : Table 'mysql.slave_worker_info' doesn't exist
	status : Operation failed
	Found outdated sys schema version 1.5.1.
	Upgrading the sys schema.
	Checking databases.
Procedure	Return to the procedure that you came here from.

### Appendix A.24 PDB Restore

10.	Note down the	Run the following command:
	timestamp in log.	\$ date

# Procedure A.25 Conversion from Prov(mixed EPAP) to Non-Prov

#### Appendix A.25 Conversion from Prov(mixed EPAP) to Non-prov

S	This procedure convert provis	ionable mixed EPAP to Non-provisionable EPAP.
т	Check off ( $$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.	
Е	IF THIS PROCEDURE FAILS,	CONTACT MY ORACLE SUPPORTAND ASK FOR INSTALL ASSISTANCE.
Р		
#		
1.	MPS A: Login as admusr.	login: < <b>admin_user&gt;</b> Password: < <b>admin_password&gt;</b>
2.	<b>MPS A:</b> Perform PDB backup on MPS A.	Note: Skip this step if PDB backup is already taken. Check Procedure A.6 to perform PDB backup.
3.	<b>MPS A:</b> Perform RTDB backup on MPS A.	Note: Skip this step if RTDB backup is already taken. Check Procedure A.7 to perform RTDB backup.
4.	<b>MPS A:</b> Switch user to epapconfig.	\$ sudo su - epapconfig
5.	<b>MPS A:</b> The EPAP Configuration Menu is displayed. Select choice 8, PDB Configuration Menu.	EPAP Configuration Menu for mixed EPAP:

		r
		/EPAP Configuration Menu\ /\
		1   Display Configuration
		2   Configure Network Interfaces Menu   
		   3   Set Time Zone   
		   4   Exchange Secure Shell Keys   
		   5   Change Password   
		   6   Platform Menu   
		   7   Configure NTP Server   
		   8   PDB Configuration Menu   
		   9   Security   
		   10   SNMP Configuration   
		   11   Configure Alarm Feed   
		   12   Configure Query Server   
		   13   Configure Query Server Alarm Feed   
		   14   Configure SNMP Agent Community   
		   15   Mate Disaster Recovery   
		=   Exit     =   Exit
		·/
		Enter Choice: 8
6.	MPS A: The PDB Configuration Menu is displayed. Select choice 3, Change MPS Provisionable State	Configure PDB Menu displayed:
	Note: You may need to stop PDBA software.	

### Appendix A.25 Conversion from Prov(mixed EPAP) to Non-prov

Appendix A.25 Conversion from Prov(mixed EPAP) to Non-prov

```
/-----Configure PDB Menu------\
/-----\
 1 | Configure PDB Network
                               1
|----|
| 2 | RTDB Homing Menu
                               - 1
  ---|-----|
  3 | Change MPS Provisionable State |
 - 1
| 4 | Create PDB
|----|
| 5 | Change Auto DB Recovery State |
|----|
| 6 | Change PDBA Proxy State
                                1
|----|
| e | Exit
\-----/
Enter Choice: 3
PDBA software is running. Stop it? [N]: Y
The provisioning architecture of the EPAP software
allows for
exactly 2 customer provisionable sites. Additional
sites that
are to receive the data provisioned to the
provisionable sites
should answer 'N' here.
If there are only 2 mated sites, it is safe to
answer `Y' here.
Choosing 'N' here shall make this MPS Non-
Provisionable and this action is irreversible.
Is this site provisionable? [Y]:N
INFO: Increasing rt volume size for Non-
provisionable EPAP. Please wait...
INFO: db space increased on 'A'.
INFO: Stopping Epap, mysqlapp and mysqlpdb
services...
Done.
INFO: Starting Epap, mysqlapp and mysqlpdb
services...
Done.
INFO: Stopping Epap, mysqlapp and mysqlpdb
services...
Done.
INFO: Starting Epap, mysqlapp and mysqlpdb
services...
Done.
INFO: Successfully configured Non-provisionable
EPAP.
Following error shall be observed in cgi.dbg log file:
```

	Appendix A.25 Convers	sion from Prov(mixed EPAP) to Non-prov		
		myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/alarmInfo.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/bannerinfo.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/appconfig/EuiDB/econfig.MYI'		
		myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/columns_priv.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/db.MYI' myisamchk: error: 140 when opening MyISAM-table '/var/TKLC/epap/db/pdb/mysql/event.MYI'		
		Contact My Oracle Support following the instructions on the front page or the instructions on the Appendix F, if the output contains any errors beside the above.		
	MDC A. Marifre at Valance			
7.	<b>MPS A</b> : Verify rtVolume size using command "df - h".	[epapdev@Arica-1A ~]\$ df -h Filesystem Size Used Avail Use% Mounted on /dev/mapper/vgroot-plat root		
		976M 288M 637M 32% /		
		tmpfs 3.9G 0 3.9G 0% /dev/shm		
		/dev/md1 244M 40M 192M 18% /boot		
		/dev/mapper/vgroot-plat_tmp 976M 2.0M 923M 1%/tmp /dev/mapper/vgroot-plat usr		
		/dev/mapper/vgroot-plat_usr 3.9G 2.5G 1.2G 68% /usr /dev/mapper/vgroot-plat var		
		/dev/mapper/vgroot-plat var tklc		
		3.9G 1.8G 1.9G 49% /var/TKLC /dev/mapper/vgroot-db		
		5.8G 4.3G 1.2G 79% /var/TKLC/epap		
		/dev/mapper/vgroot-free 320G 5.3G 298G 2% /var/TKLC/epap		
		/dev/mapper/vgroot-logs 20G 89M 19G 1%/var/TKLC/epap		
		/dev/mapper/vgroot-rt		
		82G 3.3G 75G 5% /var/TKLC/epap [enandew@lrics_11 ~19		
		Vgroot-rt size should be greater than 80G.		
8.	<b>MPS A:</b> Presence of PDB folder after converting from Prov to Non-Prov	Pdb directory shall be present after converting from Prov to Non Prov. /var/TKLC/epap/db/pdb/pdb		
9.	MPS B: Login as admusr.	login: < <b>admin_user&gt;</b> Password: < <b>admin_password&gt;</b>		
10.	MPS B: Verify rtVolume	Repeat step 7 on MPS B to verify rtVolume size.		
	size using command "df - h".	Vgroot-rt size should be greater than 80G.		

#### Appendix A.25 Conversion from Prov(mixed EPAP) to Non-prov

11.	MPS A: Restore RTDB backup.	Note: Restore RTDB backup taken in step 3. Check Procedure A.10 to perform RTDB Restore.
12.	<b>MPS B:</b> Perform reload from mate on MPS B.	Check Procedure A.11 to perform reloade from mate.
13.	MPS B: Procedure completed.	This procedure is completed.
14.	Note down the timestamp in log.	Run the following command: \$ date

### Procedure A.26 Conversion from mixed EPAP to StandalonePDB+Non-Prov EPAP

#### Appendix A.26 Conversion from mixed EPAP to StandalonePDB+Non-Prov EPAP

**Note:** A new card would be needed for this conversion. The conversion can be done through various way where one of them is described below.

#### Assuming, there is a mixed EPAP on 16.2/16.3 release.

Execute the below mentioned steps to perform this conversion:

#### On Mixed EPAP:

- 1. Take PDB backup. Refer to Procedure A.6 to perform PDB backup.
- 2. Take RTDB backup. Refer to Procedure A.7 to perform RTDB backup.
- 3. Perform upgrade from existing release EPAP 16.2 or 16.3 to target release of EPAP 16.4. Refer to section 3.1.3 to perform upgrade on mixed EPAP.
- 4. Convert Prov (mixed EPAP) to Non-Prov EPAP. Refer to Procedure A.25 to perform this conversion.

#### **On PDBonly (fresh installation on new card)**

- 5. Install EPAP 16.4 ISO on new card. Refer to section 3.1.2 to perform installation.
- 6. Attach this PDBonly with Non-Prov EPAP (converted in step 4) and any Non-Prov EPAP connected with Mixed setup (converted in step 4).
- 7. Restore PDB backup (taken in step 1) on PDBonly setup. Refer to Procedure A.24 to restore the PDB backup.

#### **On Non-Prov setup:**

- 8. Restore RTDB backup (taken in step 2) on Non-Prov MPS-A. Refer to Procedure A.10 to restore RTDB backup.
- 9. Perform reload from mate on Non-Prov MPS-B. Refer to Procedure A.11 to perform reload from mate.
- 10. Restart Epap and Pdba services once restores are done.

**Note:** While changing the PDB IP on old Non-Provs if Mysql replication error is observed on either MPS-A/B then execute Procedure 25, step 34 to step 36 to reset the replication on MPS servers and do health check and replication status.

So far, all three setups are in COMPACT mode. Refer to section 4 to change the DB Architecture from COMPACT to eXtreme.

### Procedure A.27 Procedure to add/edit the /etc/minirc.mate file

NOTE: This procedure is needed in following cases:

- 1. If "minicom mate" fails due to data curroption or some body deleted the file /etc/minirc.mate. Or,
- 2. If ttyS1 is not working, then edit the file /etc/minirc.mate to use ttyS3 or ttyS4.

#### Appendix A.27Procedure to add/edit the /etc/minirc.mate file

S	This procedure will add/edit the file /etc/minirc.mate.			
T				
E P	Check off ( $\checkmark$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.			
#	IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR UPGRADE ASSISTANCE.			
1.	MPS: Log on Server.	[hostname] consolelogin: admusr password: <i>password</i>		
2.	<b>MPS:</b> Switch user to root.	\$ su - root Password:		
3.	<b>MPS:</b> Verify that the file present on server.	Verify that the file /etc/minirc.mate is present on server: Execute the following command:		
		<pre>\$ ls -1 /etc/minirc.mate</pre>		
		<pre>[root@Recife-a ~]# ls -l /etc/minirc.mate -rw-r 1 root root 658 Sep 7 03:35 /etc/minirc.mate</pre>		
		Move to step 5 if output is same as above otherwise continue to next step.		
4.	<b>MPS:</b> Cretae the file using vi editor.	Create the file /etc/minirc.mate using vi editor as follows: \$ vi /etc/minirc.mate		
		Add following lines in file /etc/minirc.mate and save the file:		
		<pre># # minirc file generated by remoteConsole Mon Sep 10 09:53:54 2018 pr port /dev/ttyS1 pu baudrate 115200 pu bits 8 pu parity N pu stopbits 1 pu rtscts No pu minit pu mreset pu mhangup pu pname1 YUNYY pu pname2 YUNYY pu pname3 YUNYN pu pname4 NDNYY pu pname5 NDNYY pu pname6 YDNYN pu pname8 NDYNN pu pname8 NDYNN pu pname8 NDYNN pu pname9 YUNYN pu fselw No pu askdndir No</pre>		
5.	<b>MPS:</b> Edit the file /etc/minirc.mate	If ttS1 is not working then edit the file /etc/minirc.mate and update ttyS1 to ttyS2 or ttyS1 to ttyS3 and change the serial cable connectivity accordingly.		

	Appendix A.2/				
		In following example, we have updated the file /etc/minirc.mate and changed the port value from ttyS1 to ttyS2.			
		\$ vi /etc/minirc.mate			
		<pre># # minirc file generated by remoteConsole Mon Sep 10 09:53:54 2018 pr port /dev/ttyS2 pu baudrate 115200 pu bits 8 pu parity N pu stopbits 1 pu rtscts No pu minit pu mreset pu mhangup pu pname1 YUNYY pu pname2 YUNYY pu pname3 YUNYN pu pname4 NDNYY pu pname5 NDNYY pu pname6 YDNYN pu pname7 YUYNN pu pname8 NDYNN pu pname8 NDYNN pu pname9 YUNYN pu zauto pu fselw No pu askdndir No</pre>			
		NOTE: In order to make this changes working we must need to change the serial cable connectivity with lsmspri and lsmssec. In following figure we have changed the serial connectivity from ttyS0(lsmspri) <-> ttyS1(lsmssec) to ttyS0(lsmspri) <-> ttyS2(lsmssec) and			
		ttyS0(lsmssec) <-> ttyS1(lsmspri) to ttyS0(lsmssec) <-> ttyS2(lsmspri)			
		lsmspri lsmssec			
		ttyS0 ttyS1 ttyS2 ttyS3 ttyS3			
		Here, broken line showing the old connectivity and bold line for the new connecrtivity.			
6					
6.	<b>MPS:</b> Run "minicom mate" on the server.	Run the following command: \$minicom mate			
		It should be successfully switched to mate server.			
7.	MPS: Procedure completed	This procedure is complete.			
		•			

Procedure to add/edit the /etc/minirc.mate file

**Upgrade/Installation Guide** 

Appendix A.27

#### Appendix A.27 P

rocedure to	add/edit	the /etc/	/minir	c.mate	file
Toccuure to	auu/cun	ine /eiu/	11111111	c.mate	me

8.	Note down the	Run the following command:
	timestamp in log.	\$ date

#### Procedure A.28 Configure the Auto Backup

This procedure configures auto backup for PDB and RTDB on all the Non-PROVs that are homed to the PDBA.

EPAP software on all Non-PROVs homed to the PDBA should be running for successful auto RTDB backup on the Non-PROVs.

#### Appendix A.28 Configure the Auto Backup

S		This procedure enables the auto backup feature for the Provisioning Database.				
Т		-	-			
Е	1A	Estimated time: 5 mi	Estimated time: 5 minutes			
Ρ						
#						
1.		MPS 1A:	A	Automatic PDB/RTDB Backup		
		Navigate to the		<u>`</u>		
		main Maintenance	Backup Type (Select None to Cancel Backups)	-select- V		
		menu selection	Time of the day to start the Backup			
		and select	Frequency	-select- 🗸		
		"Automatic	File Path (Directory only)			
		PDB/RTDB	Select required IP version:	● IPv4 ○ IPv6		
		Backup".	Remote Machine IP Address (IPV4=xxx.yyy.yyy.yyy)			
		Баскир.	(IPV6=xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx)			
			Login Name Password			
		Specify the	Save the local copies in the default path	Ves No		
		required fields and	Do you want to delete the old backups			
		press the Submit Schedule button.	(Local and Mate only) Note: If you select Yes, only the last three backup files will be retained	System Yes No		
				Submit Schedule		
			The March 01 2016 00:24.50 PCT			
		Tue March 01 2016 09:34:59 EST Copyright © 2000, 2015, Oracle and/or its affiliates. All rights reserved.				
			Note: Kindly note that the p	asswords having certain special characters like \$, @, #		
			are not allowed while config	guring passwords for automatic backup transfer to remote		
			server.	·		
2.		Note down the	Run the following command	1:		
		timestamp in log.	\$ date			

This procedure is complete!

### Procedure A.29 STOP ACTIVE PDBA AND VERIFY REPL LOGS

This procedure shall be executed on Active PDBA (2A). If REPL log in not empty, part of the procedure will be executed in Standby PDBA (1A) as well.

Appendix A.29	Procedure to add/edit the /etc/minirc.mate file
---------------	---

S	This procedure stops the PDBA software.
Т	Estimated time: 5 minutes.
Ε	

### Appendix A.29Procedure to add/edit the /etc/minirc.mate file

D				
P #				
1.	MPS 2A:	NOTE:		
	Stop the Customer provisioning in to the	Contact customer provisioning and verify provisioning has been deactivated.		
2.	active PDB.			
	MPS 2A: Log on Server.	[hostname] consolelogin: admusr password: <i>password</i>		
3.	<b>MPS 2A:</b> Switch user to root.	\$ su - root Password:		
4.	<b>MPS 2A:</b> Stop the PDBA process	<pre># service Pdba stop ~~ /etc/init.d/Pdba stop ~~ PDBA application stopped.</pre>		
5.	MPS 2A: Stop the EPAP process	<pre># service Epap stop ~~ /etc/init.d/Epap stop ~~ EPAP application stopped.</pre>		
6.	_   MPS ZA: Clear the   \$ mysqr a root p s/ var rine c/ cpup/ as/ pus/ mysqusoch \$			
	MPS 2A: Login to the mysql database and verify that there are no updates to be sent to the standby PDB. If any REPL log exists, follow steps 8 to 12. Otherwise jump to step 13	<pre>\$ mysql -u root -p -S/var/TKLC/epap/db/pdb/mysql.sock pdb Enter password: <mysql_root_password> On the MySQL prompt, execute the following commands: mysql&gt; select * from replLog; Empty set (0.00 sec) mysql&gt; select * from requests; Empty set (0.00 sec) mysql&gt; quit Bye</mysql_root_password></pre>		
8.	<b>MPS 1A:</b> Start the PDBA and EPAP at the Standby site (1A)	<pre># service Pdba start ~~ /etc/init.d/Pdba start ~~ PDBA application started. # service Epap start ~~ /etc/init.d/Epap start ~~ EPAP application started. Note : Skip the following step on Standalone PDB # ssh mate ''service Epap start'' ~~ /etc/init.d/Epap start ~~ EPAP application started.</pre>		
9.	MPS 2A: Start the PDBA at the Active site (2A)	<pre># service Pdba start ~~ /etc/init.d/Pdba start ~~ PDBA application started. # service Epap start ~~ /etc/init.d/Epap start ~~ EPAP application started. Note : Skip the following step on Standalone PDB # ssh mate ''service Epap start'' ~~ /etc/init.d/Epap start ~~ EPAP application started.</pre>		
10.	MPS 2A:	<pre>\$ mysql -u root -p -S/var/TKLC/epap/db/pdb/mysql.sock pdb Enter password: <mysql_root_password> On the MySQL prompt, execute the following commands:</mysql_root_password></pre>		
	a da/Installation Cuida	On the MySQL prompt, execute the following commands.		

**Upgrade/Installation Guide** 

11.	Wait a minute for the updates to sync between Active and Standby PDBA. Check in intervals of 1 minute till all updates are sent from Active PDBA to Standby PDBA. Move to next stepONLY after checking that output of replLog and requests tables shows "Empty set". MPS 2A:	<pre>mysql&gt; select * from replLog; Empty set (0.00 sec) mysql&gt; select * from requests; Empty set (0.00 sec) mysql&gt; quit Bye</pre>
		~~ /etc/init.d/Pdba stop ~~
	Stop the PDBA and EPAP processes.	PDBA application stopped.
		# service Epap stop
		~~ /etc/init.d/Epap stop ~~
		EPAP application stopped.
12.	MPS 1A:	# service Pdba stop
	Stop the PDBA and	~~ /etc/init.d/Pdba stop ~~ PDBA application stopped.
	EPAP processes.	
		# service Epap stop
		~~ /etc/init.d/Epap stop ~~
		EPAP application stopped.
13.	MPS 2A:	\$ exit
	Exit as root user	
14.	Note down the	Run the following command:
	timestamp in log.	\$ date

### Appendix A.29 Procedure to add/edit the /etc/minirc.mate file

#### PROCEDURE A.30 Resolve the false accept upgrade alarm situation

This procedure is used to resolve the false accept upgrade alarm situation from the system.

Check off ( $\checkmark$ ) each step as it is completed. Boxes have been provided for this purpose under each step number.

#### IF THIS PROCEDURE FAILS, CONTACT MY ORACLE SUPPORT AND ASK FOR ASSISTANCE.

1. Blankout the /etc/motd file	>/etc/motd
2.Add an entry "export POST_UPGRADE_ACTION=A CCEPT" in the upgrade info file.	echo "export POST_UPGRADE_ACTION=ACCEPT" >> /var/TKLC/log/upgrade/upgrade.info
3.Clear the false alarm "TKSPLATMI33"	You will see the following alarm in alarmStatus. a. alarmMgralarmStatus [One output example below:] SEQ: 7 UPTIME: 356 BIRTH: 1524100682 TYPE: SET ALARM: TKSPLATMI33 tpdServerUpgradePendingAccept 1.3.6.1.4.1.323.5.3.18. 3.1.3.33 3253 2 Processing Error Configuration Error b. To clear the alarm, run the following command: alarmMgrclear TKSPLATMI33

### APPENDIX B INTERCONNECTION DIAGRAM




Figure 9: Interconnectivity Diagram for Sync Network Redundancy (Eth04 used for Sync Network)





Figure 10: Default Interconnectivity Diagram (Eth04 used for Backup Provisioning Network)


# APPENDIX C TELCO TO CISCO SWITCH REPLACEMENT

### SWITCH REPLACEMENT


S	This proced	ure is for replacing the Telco switch with the Cisco switch.	
Т	Charle off (1)	)each step as it is completed. Boxes have been provided for this purpose under each step	
E P	number.		
#			
		CEDURE FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.	
The	tonowing toor	s are required to perform this procedure:	
		rap (Wrist or Heel)	
		Screwdriver	
	• #3 Phillips	Screwdriver	
		Driver or Socket Driver or Socket	
		Vire Cutter (to cut Tie-wraps)	
	<ul> <li>Multi Mete</li> </ul>		
	Tie Wraps		
	Electrical		
	Cable Tage	s/Marker (to label all cables)	
1.	Disable and	Tools required: Ground Strap, #2 Phillips Screwdriver, Multi Meter, and Diagonal Wire Cutter	
	disconnect	Tools required. Ground Strap, "2 I minps Serewariver, Marin Meter, and Diagonal Whe Catter	
	switch	a. At the fuse panel, locate the fuse positions for the switch being removed. To power down	
	power	the Switch, remove the fuses for both A and B feeds.	
		b. Once the switch is off, unscrew and remove the terminal-block insulator covers from both	
		<ul><li>terminals blocks A and B.</li><li>c. With covers removed, using a Multi Meter, ensure that there is no power.</li></ul>	
		<ul><li>c. With covers removed, using a Multi Meter, ensure that there is no power.</li><li>d. Ensure that the power leads are marked -48V &amp; RTN.</li></ul>	
		e. With the cables marked, one at a time, remove the power cable and tape the terminal ring.	
		Repeat these steps until all power connections are removed.	
		Insulator screws	
		Note: This procedure will reference replacing the Switch #1 location (top). Same procedure	
		is applicable for other switch locations.	

		Note: For the replacement switch, if required, more cable slack/length can be added if the cable-ties are cut from the Tie-rod. See Step 8.
2.	Disconnect ground cable from switch	<ul> <li>Tools required: Ground Strap and 5/16" Nut Driver or Socket</li> <li>a. Remove the Switch Ground Wire from the grounding point, by loosening and removing Hex nut, Flat washer, and External tooth washer.</li> <li>b. Leave Ground Wire dangling. Do not disconnect ground wire attached to cabinet/frame.</li> <li>Note: Hardware removed, nut, and washers are NOT required on the replacement switch.</li> </ul>
3.	Disconnect Front ENET and Console Cables	<ul> <li>Tools required: Diagonal Wire Cutters</li> <li>Note: This procedure will reference replacing the Switch #1 location (Top). The same procedure used for other switch locations.</li> <li>a. Make sure that all the cables are labeled and are in the correct position that they are terminated at. If not, ensure to mark or label before starting any removal.</li> <li>b. Disconnect the Console and Ethernet cables from Telco switch being replaced. Leave the cables dangling.</li> <li>c. (Optional) If cable management tie-rod is mounted to the switch being replaced, it may be necessary to cut or remove the cable-ties, holding the cables from the Tie-rod.</li> </ul>





		Note: If Tie-rod was removed in step 4, reattach at this time.
7.	Reattach the ground cable	Tools required: Ground Straps and #2 Phillips Screwdriver         Reattach the chassis ground wire (from Step 3) to switch where shown. Use Screws provided with replacement Cisco Switch.         Image: Contrast of the system of
8.	Connect power to the replacement Cisco Switch	Tools required: Ground Strap and 1/4" Nut Driver         a. Remove terminal block cover.         Image: Construct of the state of



## SWITCH CONFIGURATION

S	This procedure Configures the Cisco Switches on an Installed E5-APP-B EPAP Server Pair.				
T E	Check off ( $$ ) each ster	p as it is completed. Boxes have been provided for this purpose under each step number.			
P		y call step as it is completed. Doxes have been provided for this purpose under each step number.			
#	IF THIS PROCEDURE	FAILS, CONTACT MY ORACLE SUPPORTAND ASK FOR ASSISTANCE.			
1.	Make the cross-over				
	cable connections.	NOTE: THIS IS IMPORTANT.			
		a. CONNECT the cross-over cable from <b>Port 1</b> of <b>Switch1A</b> to <b>Port 1</b> of			
		<ul><li>Switch1B.</li><li>b. DISCONNECT the cross-over cable from Port 2 of Switch1A to Port 2 of</li></ul>			
		5. DISCONNECT the cross-over cable from Port 2 of Switch1A to Port 2 of Switch1B.			
		Similarly, while Configuring Switch1C and Switch1D, disconnect the cable from port 24 and connect back post configuration is done.			
		Note:			
		Switch configuration should only be attempted by a skilled technician and not			
		by all.			
		• All uplinks should be removed while switch configuration.			
		<ul><li>There should not be any loop in the switches during their configuration.</li><li>Switch1B must be configured first.</li></ul>			
		• Switchild hust be conligued hist.			
2	Do minicom to enter	[root@Donut-B epapall]#			
	the Cisco switch				
		[root@Donut-B epapall]# minicom switch1B			
	console. Command –	[root@Donut-B epapall]# minicom switch1B			
	console. Command – "minicom	[root@Donut-B epapall]# minicom switch1B			
	console. Command –	[root@Donut-B epapall]# minicom switch1B			
	console. Command – "minicom switch1A" for the console cable connected to MPS-A	[root@Donut-B epapall]# minicom switch1B			
	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console	[root@Donut-B epapall]# minicom switch1B			
	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to	[root@Donut-B epapall]# minicom switch1B			
	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console	[root@Donut-B epapall]# minicom switch1B			
	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to MPS-B use	[root@Donut-B epapall]# minicom switch1B			
3	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to MPS-B use "minicom switch1B". MPS X: Do not	[root@Donut-B epapall]# minicom switch1B Autoinstall will terminate if any input is detected on console			
3	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to MPS-B use "minicom switch1B". MPS X: Do not enter in the initial				
	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to MPS-B use "minicom switch1B". <b>MPS X:</b> Do not enter in the initial config dialog in the	Autoinstall will terminate if any input is detected on console			
	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to MPS-B use "minicom switch1B". MPS X: Do not enter in the initial	Autoinstall will terminate if any input is detected on console System Configuration Dialog			
	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to MPS-B use "minicom switch1B". <b>MPS X:</b> Do not enter in the initial config dialog in the freshly connected Cisco switch.	Autoinstall will terminate if any input is detected on console System Configuration Dialog Would you like to enter the initial configuration dialog? [yes/no]:no			
4	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to MPS-B use "minicom switch1B". <b>MPS X:</b> Do not enter in the initial config dialog in the freshly connected Cisco switch. <b>MPS X:</b> Enter an	Autoinstall will terminate if any input is detected on console         System Configuration Dialog         Would you like to enter the initial configuration dialog? [yes/no]:no         The enable secret is a password used to protect access to privileged EXEC and			
	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to MPS-B use "minicom switch1B". <b>MPS X:</b> Do not enter in the initial config dialog in the freshly connected Cisco switch. <b>MPS X:</b> Enter an Enable secret key :-	Autoinstall will terminate if any input is detected on console         System Configuration Dialog         Would you like to enter the initial configuration dialog? [yes/no]:no         The enable secret is a password used to protect access to privileged EXEC and configuration modes. This password, after entered, becomes encrypted in			
4	console. Command – "minicom switch1A" for the console cable connected to MPS-A and for console cable connected to MPS-B use "minicom switch1B". <b>MPS X:</b> Do not enter in the initial config dialog in the freshly connected Cisco switch. <b>MPS X:</b> Enter an	Autoinstall will terminate if any input is detected on console         System Configuration Dialog         Would you like to enter the initial configuration dialog? [yes/no]:no         The enable secret is a password used to protect access to privileged EXEC and			

r				
		The secret should be of minimum 10 characters and maximum 32 characters with at least 1 upper case, 1 lower case, 1 digit, and should not contain [cisco].		
		Enter enable secret:OracleSwitchC1 Confirm enable secret: OracleSwitchC1		
5	MPS X: Press 2 and enter	The following configuration command script was created: enable secret 9 \$9\$TsBinkhqCyICKE\$.kVHrY3IJTaqJEb.T9yJjjjmzcRSu426mSirX4U3a1k ! end [0] Go to the IOS command prompt without saving this config. [1] Return back to the setup without saving this config. [2] Save this configuration to nvram and exit. Enter your selection [2]: 2		
6	<b>MPS X:</b> Initial configuration building is done	Building configuration [OK] Use the enabled mode 'configure' command to modify this configuration. Press RETURN to get started!		
	MPS X: Write "enable" and password set in step 3, which is "OracleSwitchC1"	Switch>enable Password:		
8	<b>MPS X:</b> Once the switch is enabled to take configuration > sign changes to the # sign	Switch>enable Password: Password: Switch#		
9	MPS X: Write command – "Configure terminal"	switch# configure terminal Enter configuration commands, one per line. End with CNTL/Z. switch(config)#		
10	MPS X: Here are the attached configs to be used for Eth04 used for Backup Provisioning Network	CiscoSwitch1C.txt CiscoSwitch1B.txt CiscoSwitch1A.txt CiscoSwitch1D.txt		

11	MPS X: Here are the attached configs to be used for EPAP Sync Network Redundancy (Eth04 used for Sync Network).	CiscoSwitch1C.sync.t CiscoSwitch1B.sync.tx CiscoSwitch1A.sync.t CiscoSwitch1D.sync.t xt t xt xt xt		
	<b>MPS X:</b> Open the attached config in notepad for the switch we want to configure.	Open in notepad and press Ctrl+A and then Ctrl+C.		
	MPS X: Paste all the copied config to the switch. Shown example for Switch1A.	Switch# configure terminal Enter configuration commands, one per line. End with CNTL/Z. Switch(config)#hostname switch1A switch1A(config)#enable secret EnAbLe switch1A(config)#sestamps log datetime msec localtime show- timezone switch1A(config)#no service pad switch1A(config)#service timestamps debug uptime switch1A(config)#service timestamps log uptime switch1A(config)#service password-encryption switch1A(config)#service password-encryption switch1A(config)#logging on switch1A(config)#logging trap errors switch1A(config)#logging facility loca16 switch1A(config)#logging facility loca16 switch1A(config)#line console 0 switch1A(config)=line)#exit switch1A(config)# switch1A(config)# switch1A(config)# switch1A(config)# switch1A(config)# switch1A(config)# switch1A(config)# switch1A(config)# switch1A(config)# switch1A(config)# switch1A(config)# switch1A(config)# switch1A(config)# name default switch1A(config)# switch1A(con		
		<pre>switch1A(config)#interface vlan 1 switch1A(config-if)#ip address 192.168.2.1 255.255.255.0 switch1A(config-if)#no shutdown</pre>		

I	
	switch1A(config-if)#exit
	switch1A(config)#
	switch1A(config)#interface gigabitEthernet1/0/1
	<pre>switch1A(config-if)# switchport mode trunk</pre>
	<pre>switch1A(config-if)#switchport trunk allowed vlan add 1</pre>
	switch1A(config-if)#switchport trunk allowed vlan add 2
	switch1A(config-if)# channel-group 1 mode on
	Creating a port-channel interface Port-channel 1
	switch1A(config-if)# description Link_to_Switch B
	switch1A(config-if)#shutdown
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	switch1A(config-if)#interface gigabitEthernet1/0/2
	<pre>switch1A(config-if)# switchport mode trunk</pre>
	switch1A(config-if)#switchport trunk allowed vlan add 1
	switch1A(config-if)#switchport trunk allowed vlan add 2
	<pre>switch1A(config-if)# channel-group 1 mode on</pre>
	<pre>switch1A(config-if)# description Link_to_Switch B</pre>
	<pre>switch1A(config-if)#shutdown</pre>
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/3</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	switch1A(config-if)# description EPAP_A DSM A
	<pre>switch1A(config-if)# flowcontrol receive on</pre>
	switch1A(config-if)#shutdown
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/4</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	switch1A(config-if)# description EPAP_B DSM A
	<pre>switch1A(config-if)# flowcontrol receive on</pre>
	switch1A(config-if)#shutdown
	switch1A(config-if)#no shutdown
	switch1A(config-if)#
	switch1A(config-if)#interface gigabitEthernet1/0/5
	<pre>switch1A(config-if)# switchport mode access</pre>
	switch1A(config-if)# switchport access vlan 2
	switch1A(config-if)# description EAGLE_A_port
	switch1A(config-if)# duplex full

<b></b>	
	<pre>switch1A(config-if)#speed 1000</pre>
	<pre>switch1A(config-if)#shutdown in http://www.incommons.com/action/act</pre>
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/6</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	<pre>switch1A(config-if)#shutdown</pre>
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/7</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	<pre>switch1A(config-if)#shutdown</pre>
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/8</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	<pre>switch1A(config-if)#shutdown</pre>
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/9</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	switch1A(config-if)#shutdown
	<pre>switch1A(config-if)#no shutdown</pre>
	switch1A(config-if)#
	switch1A(config-if)#interface gigabitEthernet1/0/10
	<pre>switch1A(config-if)# switchport mode access</pre>
	switch1A(config-if)# switchport access vlan 2

<b></b>	cwitch1A(config if)# description FACLE A part
	<pre>switch1A(config-if)# description EAGLE_A_port switch1A(config if)# dupley full</pre>
	<pre>switch1A(config-if)# duplex full switch1A(config if)#snood 1000</pre>
	<pre>switch1A(config-if)#speed 1000 switch1A(config if)#shutdown</pre>
	<pre>switch1A(config-if)#shutdown is h11(config-if)#shutdown</pre>
	switch1A(config-if)#no shutdown
	switch1A(config-if)#
	switch1A(config-if)#interface gigabitEthernet1/0/11
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	switch1A(config-if)#shutdown
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/12</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	switch1A(config-if)#shutdown
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/13</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	<pre>switch1A(config-if)#shutdown</pre>
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/14</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	switch1A(config-if)#shutdown
	<pre>switch1A(config-if)#no shutdown</pre>
	switch1A(config-if)#
	switch1A(config-if)#interface gigabitEthernet1/0/15

<pre>switch1A(config-if)# switchport mode access</pre>
<pre>switch1A(config-if)# switchport access vlan 2</pre>
<pre>switch1A(config-if)# description EAGLE_A_port</pre>
<pre>switch1A(config-if)# duplex full</pre>
<pre>switch1A(config-if)#speed 1000</pre>
switch1A(config-if)#shutdown
<pre>switch1A(config-if)#no shutdown</pre>
<pre>switch1A(config-if)#</pre>
<pre>switch1A(config-if)#interface gigabitEthernet1/0/16</pre>
<pre>switch1A(config-if)# switchport mode access</pre>
<pre>switch1A(config-if)# switchport access vlan 2</pre>
<pre>switch1A(config-if)# description EAGLE_A_port</pre>
<pre>switch1A(config-if)# duplex full</pre>
<pre>switch1A(config-if)#speed 1000</pre>
switch1A(config-if)#shutdown
<pre>switch1A(config-if)#no shutdown</pre>
<pre>switch1A(config-if)#</pre>
<pre>switch1A(config-if)#interface gigabitEthernet1/0/17</pre>
<pre>switch1A(config-if)# switchport mode access</pre>
<pre>switch1A(config-if)# switchport access vlan 2</pre>
<pre>switch1A(config-if)# description EAGLE_A_port</pre>
<pre>switch1A(config-if)# duplex full</pre>
<pre>switch1A(config-if)#speed 1000</pre>
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
<pre>switch1A(config-if)#</pre>
<pre>switch1A(config-if)#interface gigabitEthernet1/0/18</pre>
<pre>switch1A(config-if)# switchport mode access</pre>
<pre>switch1A(config-if)# switchport access vlan 2</pre>
<pre>switch1A(config-if)# description EAGLE_A_port</pre>
<pre>switch1A(config-if)# duplex full</pre>
switch1A(config-if)#speed 1000
switch1A(config-if)#shutdown
switch1A(config-if)#no shutdown
<pre>switch1A(config-if)#</pre>
<pre>switch1A(config-if)#interface gigabitEthernet1/0/19</pre>
<pre>switch1A(config-if)# switchport mode access</pre>
<pre>switch1A(config-if)# switchport access vlan 2</pre>
<pre>switch1A(config-if)# description EAGLE_A_port</pre>
<pre>switch1A(config-if)# duplex full</pre>
<pre>switch1A(config-if)#speed 1000</pre>
<pre>switch1A(config-if)#shutdown</pre>
<pre>switch1A(config-if)#no shutdown</pre>

[]	
	switch1A(config-if)#
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/20 </pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	switch1A(config-if)#shutdown
	switch1A(config-if)#no shutdown
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/21</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	<pre>switch1A(config-if)#shutdown</pre>
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/22</pre>
	<pre>switch1A(config-if)# switchport mode access</pre>
	<pre>switch1A(config-if)# switchport access vlan 2</pre>
	<pre>switch1A(config-if)# description EAGLE_A_port</pre>
	<pre>switch1A(config-if)# duplex full</pre>
	<pre>switch1A(config-if)#speed 1000</pre>
	<pre>switch1A(config-if)#shutdown</pre>
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	<pre>switch1A(config-if)#interface gigabitEthernet1/0/23</pre>
	<pre>switch1A(config-if)# switchport mode trunk</pre>
	switch1A(config-if)#switchport trunk allowed vlan add 1
	switch1A(config-if)#switchport trunk allowed vlan add 2
	<pre>switch1A(config-if)# channel-group 2 mode on</pre>
	Creating a port-channel interface Port-channel 2
	<pre>switch1A(config-if)# description Link_to_Switch C</pre>
	switch1A(config-if)#shutdown
	<pre>switch1A(config-if)#no shutdown</pre>
	<pre>switch1A(config-if)#</pre>
	switch1A(config-if)#interface gigabitEthernet1/0/24
	<pre>switch1A(config-if)# switchport mode trunk</pre>
	switch1A(config-if)#switchport trunk allowed vlan add 1
	switch1A(config-if)#switchport trunk allowed vlan add 2

es to 192.168.2.1, timeout 2 sec, delay 0 sec:				
168.2.4, 192.168.2.100, 192.168.2.200), till you see an 100% success rate.				
teted switches to the mentioned IP address $(192.168.2.1, 168.2.4, 102.168.2.100, 102.168.2.200)$ till you see an				
7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 <b>11 12 13 14 15 16 17 18 19 20 21</b> 22 23 24 <b>21 22 23 24</b> <b>21 22 23 24</b> <b>21 22 23 24</b> <b>23 24</b> <b>24 25 24</b>				
per the switch location.				
0 and repeat steps 2 to 12. Ensure to select the exact				
host 192.168.2.100				
<pre>switch1A(config-line)# switch1A(config-line)#ntp server 192.168.2.100 switch1A(config)#</pre>				
ogin				
ssword ConsolE				
ansport input telnet ssh				
ne vty 5 15				
ogin				
ssword ConsolE				
ansport input telnet ssh				
ne vty 0 4				
ogin				
assword Console				
n 0				
i un				
run				
יוננף שבו עבו				
p http server				
hutdown				
down				
nnel-group 2 mode on cription Link_to_Switch C				
cr				

address 192.168.2.2       IIIII         associated with       Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms         switch1B, jp       switch1D#ping 192.168.2.2         address 192.168.2.3       Sending 5, 100-byte ICMP Echoes to 192.168.2.2, timeout 2 sec, delay 0 sec:         press Esc for break       IIIII         Switch1D       Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms         switch1D       Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms         switch1D#ping 192.168.2.3       Sending 5, 100-byte ICMP Echoes to 192.168.2.3, timeout 2 sec, delay 0 sec:         Press Esc for break       IIIII         Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms       switch1D#ping 192.168.2.4         Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec:       Press Esc for break         IIIII       Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms         switch1D#ping 192.168.2.100       Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec:         Press Esc for break       IIIII         Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms       switch1D#ping 192.168.2.200         Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec:       Press Esc for break         IIIII       Success rate is 100 percent (5/5), round-trip min/avg/max = 0			
Switch1B, ip address 192.168.2.3 with Switch1C and ip addressswitch1D#ping 192.168.2.2 Sending 5, 100-byte ICMP Echoes to 192.168.2.2, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.3 Sending 5, 100-byte ICMP Echoes to 192.168.2.3, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip mi		address 192.168.2.2	11111
address 192.168.2.3 with Switch1C and ip addressSending 5, 100-byte ICMP Echoes to 192.168.2.2, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!192.168.2.4 with Switch1D.Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.3 Sending 5, 100-byte ICMP Echoes to 192.168.2.3, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200		associated with	Success rate is 100 percent (5/5), round-trip min/avg/max = $0/0/0$ ms
address 192.168.2.3 with Switch1C and ip addressSending 5, 100-byte ICMP Echoes to 192.168.2.2, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!192.168.2.4 with Switch1D.Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.3 Sending 5, 100-byte ICMP Echoes to 192.168.2.3, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200		Switch1B, ip	switch1D#ping 192.168.2.2
with Switch1C and ip addressPress Esc for break192.168.2.4 with Switch1D.Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.3 Sending 5, 100-byte ICMP Echoes to 192.168.2.3, timeout 2 sec, delay 0 sec: Press Esc for break 11111 Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break 11111 Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break 11111 Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break 11111 Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break 11111 Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break 11111 Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break 11111 Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200		· •	
ip address!!!!!192.168.2.4 with Switch1D.Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.3 Sending 5, 100-byte ICMP Echoes to 192.168.2.3, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200			
192.168.2.4 with Switch1D.Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.3 Sending 5, 100-byte ICMP Echoes to 192.168.2.3, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			11111
Switch1D.switch1D#ping 192.168.2.3 Sending 5, 100-byte ICMP Echoes to 192.168.2.3, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#		*	
Sending 5, 100-byte ICMP Echoes to 192.168.2.3, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!!Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200			
Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break IIIII Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200		Switchid.	
<ul> <li>IIIII</li> <li>Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4</li> <li>Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break</li> <li>IIIII</li> <li>Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100</li> <li>Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break</li> <li>IIIII</li> <li>Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200</li> <li>Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break</li> <li>IIIII</li> <li>Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200</li> <li>Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec:</li> <li>Press Esc for break</li> <li>IIIII</li> <li>Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms</li> <li>switch1D#ping 192.168.2.200</li> </ul>			
Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
<pre>switch1D#ping 192.168.2.4 Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200</pre>			
Sending 5, 100-byte ICMP Echoes to 192.168.2.4, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			1 1 0
Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
<pre>!!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.200</pre>			
Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
switch1D#ping 192.168.2.100 Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
Sending 5, 100-byte ICMP Echoes to 192.168.2.100, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
!!!!!Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 msswitch1D#ping 192.168.2.200Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec:Press Esc for break!!!!!Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 msswitch1D#			
Success rate is 100 percent (5/5), round-trip min/avg/max = 0/1/5 ms switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
switch1D#ping 192.168.2.200 Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
Sending 5, 100-byte ICMP Echoes to 192.168.2.200, timeout 2 sec, delay 0 sec: Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
Press Esc for break !!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
<pre>!!!!! Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#</pre>			
Success rate is 100 percent (5/5), round-trip min/avg/max = 0/0/0 ms switch1D#			
switch1D#			
$\square Procedure complete Procedure is complete.$			
	17	Procedure complete	Procedure is complete.

## APPENDIX D SWOPS SIGN OFF.

	Discrepancy List				
Date	Test Case	Description of Failures and/or Issues. Any CSR's / RMA's issued during Acceptance. Discrepancy	Resolution and SWOPS Engineer Responsible	Resolution Date:	

### **Discrepancy List**

### APPENDIX E CUSTOMER SIGN OFF

#### Sign-Off Record

#### \*\*\* Please review this entire document. \*\*\*

This is to certify that all steps required for the upgrade successfully completed without failure.

Sign your name, showing approval of this procedure, and email this page and the above completed Table to Oracle, email: <u>upgrades@tekelec.com</u>.

Customer: Company Name:	Date:
Site: Location:	
Customer :(Print)	Phone:
	Fax:

Start Date: \_\_\_\_\_

Completion Date: \_\_\_\_\_

This procedure has been approved by the undersigned. Any deviations from this procedure must be approved by both Oracle and the customer representative. A copy of this page should be given to the customer for their records. The SWOPS supervisor will also maintain a signed copy of this completion for future reference.

Oracle Signature:	Date:	
0		

Customer Signature: \_\_\_\_\_ Date:

Date: \_\_\_\_\_

## APPENDIX F MY ORACLE SUPPORT

My Oracle Support (<u>https://support.oracle.com</u>) is your initial point of contact for all product support and training needs. A representative at Customer Access Support can assist you with My Oracle Support registration.

Call the Customer Access Support main number at 1-800-223-1711 (toll-free in the US), or call the Oracle Support hotline for your local country from the list at <u>http://www.oracle.com/us/support/contact/index.html</u>. When calling, make the selections in the sequence shown below on the Support telephone menu:

- For Technical issues such as creating a new Service Request (SR), select 1.
- For Non-technical issues such as registration or assistance with My Oracle Support, select 2.
- For Hardware, Networking and Solaris Operating System Support, select 3.

You are connected to a live agent who can assist you with My Oracle Support registration and opening a support ticket.

My Oracle Support is available 24 hours a day, 7 days a week, 365 days a year.