

Oracle® Auto Service Request

Quick Installation Guide for Oracle Exadata Database Machine



22.1
F29247-08
May 2022

The Oracle logo, consisting of a solid red square with the word "ORACLE" in white, uppercase, sans-serif font centered within it.

ORACLE®

Oracle Auto Service Request Quick Installation Guide for Oracle Exadata Database Machine, 22.1

F29247-08

Copyright © 2015, 2022, Oracle and/or its affiliates.

Primary Author: Peter Fusek

Contributing Authors: Vira Goorah, Zheren Zhang

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, then the following notice is applicable:

U.S. GOVERNMENT END USERS: Oracle programs (including any operating system, integrated software, any programs embedded, installed or activated on delivered hardware, and modifications of such programs) and Oracle computer documentation or other Oracle data delivered to or accessed by U.S. Government end users are "commercial computer software" or "commercial computer software documentation" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, reproduction, duplication, release, display, disclosure, modification, preparation of derivative works, and/or adaptation of i) Oracle programs (including any operating system, integrated software, any programs embedded, installed or activated on delivered hardware, and modifications of such programs), ii) Oracle computer documentation and/or iii) other Oracle data, is subject to the rights and limitations specified in the license contained in the applicable contract. The terms governing the U.S. Government's use of Oracle cloud services are defined by the applicable contract for such services. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle, Java, and MySQL are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Inside are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Epyc, and the AMD logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information about content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services unless otherwise set forth in an applicable agreement between you and Oracle. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services, except as set forth in an applicable agreement between you and Oracle.

Contents

Preface

Audience	v
Documentation Accessibility	v
Diversity and Inclusion	v
Conventions	vi

1 Getting Started with Oracle ASR Installation

About Oracle ASR	1-1
Recommended Configuration for Oracle ASR	1-2
Prerequisites for Oracle ASR	1-2
Server and Network Requirements for Oracle ASR	1-2
Oracle Auto Service Request (ASR) Software Requirements	1-3
Qualified Exadata Products	1-4

2 Configure Fault Notification Destinations

Fault Telemetry Options	2-1
Adding SNMP Trap Destinations Using OEDA	2-2
Configuring the SNMP Subscriber for Fault Notification on Release 12.x or Later	2-3
Configuring the SNMP Subscriber on Release 11.x	2-6

3 Enabling Automatic DiagPack Upload for Oracle ASR

Enable HTTP Access on Oracle ASR Manager	3-3
Enabling HTTPS/SSL on Oracle ASR Manager	3-4

4 Activating Nodes on Oracle ASR Manager

5 Upgrading to Oracle ASR SNMP v3

6 Validating SNMP Trap Configurations on Exadata Database Machine

Validating the Database Server Configuration	6-1
Validating the Storage Server Configuration	6-2
Database Server SNMP Validation	6-2
Storage Server SNMP Validation	6-3

7 Configuring Switches for Oracle ASR

Configuring Cisco Switches for Oracle ASR	7-1
Configuring InfiniBand Switches for Oracle ASR	7-3

A Additional Resources for Oracle Auto Service Request (ASR)

B Third-Party Licenses for Oracle ASR

Preface

Oracle Auto Service Request (ASR) is a feature of Oracle Premier Support for Systems and Oracle/Sun Limited Warranty that is designed to automatically request Oracle service when specific hardware faults occur. Oracle ASR is designed to enable faster problem resolution by eliminating the need to initiate contact with Oracle Support Services for hardware failures, reducing both the number of phone calls needed and overall phone time required.

For complete information about Oracle ASR, see <https://oracle.com/asr>.

- [Audience](#)
- [Documentation Accessibility](#)
- [Diversity and Inclusion](#)
- [Conventions](#)

Audience

This document is intended for Oracle customers and partners who have Oracle products qualified for Oracle Auto Service Request (ASR) with Oracle Premier Support for Systems or Hardware Warranty service plans.

Documentation Accessibility

For information about Oracle's commitment to accessibility, visit the Oracle Accessibility Program website at <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=docacc>.

Access to Oracle Support

Oracle customers that have purchased support have access to electronic support through My Oracle Support. For information, visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=info> or visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=trs> if you are hearing impaired.

Diversity and Inclusion

Oracle is fully committed to diversity and inclusion. Oracle respects and values having a diverse workforce that increases thought leadership and innovation. As part of our initiative to build a more inclusive culture that positively impacts our employees, customers, and partners, we are working to remove insensitive terms from our products and documentation. We are also mindful of the necessity to maintain compatibility with our customers' existing technologies and the need to ensure continuity of service as Oracle's offerings and industry standards evolve. Because of these technical constraints, our effort to remove insensitive terms is ongoing and will take time and external cooperation.

Conventions

The following text conventions are used in this document:

Convention	Meaning
boldface	Boldface type indicates graphical user interface elements associated with an action, or terms defined in text or the glossary.
<i>italic</i>	Italic type indicates book titles, emphasis, or placeholder variables for which you supply particular values.
monospace	Monospace type indicates commands within a paragraph, URLs, code in examples, text that appears on the screen, or text that you enter.

1

Getting Started with Oracle ASR Installation

This document describes how to install and configure Oracle Auto Service Request (ASR) for Exadata Database Machine.

Topics:

- [About Oracle ASR](#)
Oracle Auto Service Request (ASR) is a secure, scalable, customer-installable software feature of warranty and Oracle Support Services. Oracle ASR provides auto-case generation for common hardware component faults.
- [Recommended Configuration for Oracle ASR](#)
This section describes the Oracle ASR configuration.
- [Prerequisites for Oracle ASR](#)
This section describes the prerequisites for Oracle Auto Service Request (ASR).

About Oracle ASR

Oracle Auto Service Request (ASR) is a secure, scalable, customer-installable software feature of warranty and Oracle Support Services. Oracle ASR provides auto-case generation for common hardware component faults.

Oracle ASR simplifies support operations by automatically generating support records for common component faults. Oracle ASR auto-case generation also accelerates problem resolution by eliminating the need for you to contact Oracle Support Services for common failures. Auto-case generation reduces both the number of phone calls that you make to obtain support and the phone time required for problem resolution. Oracle ASR does not provide system management or monitoring. Oracle ASR is designed to generate Oracle service requests automatically when certain types of faults are detected on Oracle products that are qualified for Oracle ASR.

Oracle ASR works only for specific component faults. Most of the common components, such as disks, fans, and power supplies, are covered. However, some components are not covered. For example, Oracle ASR does not cover RDMA Network Fabric events; there are specific images and specific firmware for the RDMA Network Fabric switch that you must use. You cannot upgrade these components independently.

Oracle ASR is easy to install and deploy. To ensure security, you have complete control over Oracle ASR.



Note:

Oracle recommends that you implement a system management and monitoring solution in addition to Oracle ASR, such as Oracle Enterprise Manager Cloud Control or Oracle Enterprise Manager Ops Center.

 **Caution:**

The commands in this document are provided for your convenience. However, the copy and paste functionality can paste different content than what is published in the guide. To ensure that the command text that you paste is identical to the text that you copy, confirm that your console session is set to receive data as UTF-8.

Recommended Configuration for Oracle ASR

This section describes the Oracle ASR configuration.

Oracle recommends that you install Oracle ASR Manager on an external, standalone server. This server receives fault telemetry information from Exadata Database Machine servers. This server must run an Oracle Solaris or Oracle Linux operating system.

 **Note:**

While not recommended, you can install Oracle ASR Manager on one of the Exadata Database Machine servers.

Prerequisites for Oracle ASR

This section describes the prerequisites for Oracle Auto Service Request (ASR).

Topics:

- [Server and Network Requirements for Oracle ASR](#)
Ensure that the following conditions are met before installing Oracle Auto Service Request (ASR).
- [Oracle Auto Service Request \(ASR\) Software Requirements](#)
You need `root` access to install the software and to configure Oracle ASR Manager.
- [Qualified Exadata Products](#)
Oracle Exadata Database Machine is qualified for Oracle Auto Service Request (ASR).

Server and Network Requirements for Oracle ASR

Ensure that the following conditions are met before installing Oracle Auto Service Request (ASR).

- Ensure that you have access to Oracle Support Services. Also ensure that your contact information is current and correct.
- Ensure that all of your assets have an assigned contact and that the contact information is current and correct.
- Identify and designate a system to serve as the Oracle ASR Manager.

- Identify and verify all of your Oracle ASR assets.
- Ensure connectivity to the Internet using HTTPS.
- Ensure the network connectivity of the operating system to the designated Oracle ASR Manager. Network connectivity is required for Oracle Exadata assets, Integrated Lights Out Manager (ILOM), and `eth0`.
- For IPv6, enable the Oracle ASR Manager server for dual stack IPv6 and IPv4. Oracle ASR Manager supports using IPv6 connections to and from assets that are configured for Oracle ASR. The traffic that is outbound from the Oracle ASR Manager to `transport.oracle.com` currently only supports IPv4 traffic.
- If you are using SNMP V3, you must be using Oracle ASR release 4.3 or higher.

Related Topics

- [My Oracle Support](#)

Oracle Auto Service Request (ASR) Software Requirements

You need `root` access to install the software and to configure Oracle ASR Manager.

- **Oracle ASR Manager:** To install Oracle ASR Manager on a standalone server that is running either Linux or Solaris, refer to "Installing and Registering Oracle ASR Manager Software" in *Oracle Auto Service Request (ASR) Manager User's Guide*.
- **Database Server:** Oracle Exadata System Software release 11.2.1.3.1 or later.
- **Oracle Exadata System Software:**
 - Release 12.1.2.1.1 and later
 - Release 11.2.1.3.1 and later
- To configure trap destinations, use one of the following options:
 - **Oracle Exadata Deployment Assistant (OEDA):** OEDA prompts you for information used to configure Oracle ASR. OEDA configures the traps and activates the Oracle ASR assets.
 - **dcli Utility:** Refer to the `dcli` utility chapter in *Oracle Exadata System Software User's Guide* for instructions about enabling SSH for the `dcli` utility.
- **Port 162 Availability:** Port 162 is the SNMP port. Use the SNMP port to configure fault telemetry destinations. You can assign this port to a different port address based on your network requirements. In a managed environment, you may need to must the port from the default port assignment for Oracle ASR to work correctly.
- **The dcli Utility:** While not required for Oracle ASR, the `dcli` utility enables you to simultaneously configure all of the servers. You can also use `dcli` to configure the storage servers at the same time.

Refer to the topic "Setting User Equivalence" in *Oracle Exadata Database Machine Extending and Multi-Rack Cabling Guide* for instructions about enabling SSH for the `dcli` utility. Depending on your environment restrictions, it is possible that the `dcli` utility is not configured. See *Oracle Exadata System Software User's Guide* for more information about the `dcli` utility.

The `dcli` utility commands in this document run commands that require equivalency with the `root` or `celladmin` user, depending on the command. Ensure that the user account that runs the `dcli` utility command is configured with the correct equivalency.

Related Topics

- *Oracle Auto Service Request (ASR) Manager User's Guide*
- *Oracle Exadata Database Machine Extending and Multi-Rack Cabling Guide*
- *Oracle Exadata System Software User's Guide*

Qualified Exadata Products

Oracle Exadata Database Machine is qualified for Oracle Auto Service Request (ASR).

The following additional Oracle Exadata Database Machine products are qualified for Oracle ASR:

- All newer versions of Oracle Exadata Database Machine, Oracle Exadata Storage Expansion Rack, and Oracle Zero Data Loss Recovery Appliance
- Oracle Exadata Storage Expansion Rack X5-2, X5-8, X5-2, Oracle Zero Data Loss Recovery Appliance X5
- Oracle Exadata Storage Expansion Rack X4-2, X4-8, X4-2, Oracle Zero Data Loss Recovery Appliance X4
- Oracle Exadata Storage Expansion Rack X3-2, X3-8, X3-2
- Oracle Exadata Storage Expansion Rack X2-2, X2-8, X2-2

2

Configure Fault Notification Destinations

Use the following procedures to configure fault telemetry destinations on Oracle Exadata Storage Server and Oracle Exadata Database Server.

Topics:

- [Fault Telemetry Options](#)
You can configure the fault notification destinations using various methods.
- [Adding SNMP Trap Destinations Using OEDA](#)
You can add SNMP trap destinations using Oracle Exadata Deployment Assistant (OEDA).
- [Configuring the SNMP Subscriber for Fault Notification on Release 12.x or Later](#)
Use the `ALTER CELL` or `ALTER DBSERVER` commands to configure SNMP trap destinations for servers running Oracle Exadata System Software release 12.x or later.
- [Configuring the SNMP Subscriber on Release 11.x](#)
Use the `dcli` utility to configure SNMP trap destinations for servers running Oracle Exadata System Software release 11.x.

Fault Telemetry Options

You can configure the fault notification destinations using various methods.

Adding SNMP trap destinations using Oracle Exadata Deployment Assistant (OEDA) is the recommended method for new installations. After the initial configuration with OEDA, you can modify or add new fault notification destinations using the command line utilities, such as DBMCLI, CellCLI, `dcli`, or `exadcli`.

To configure fault notification destinations, modify the SNMP subscriber attribute on the database or storage servers. The information you provide defines the SNMP trap destination.



Note:

Oracle ASR can only use the management network. Ensure that the management network is configured to enable Oracle ASR to run on either `eth0` on the interfaces, or `net0` on the rear of the server.

SNMP Subscriber Options

When configuring the SNMP subscriber, you set some or all of the following options:

- **host=[ASR Manager host name or IP]** is the Oracle ASR Manager host name or IP address. The Oracle ASR Manager host name can be used when DNS is enabled for the site. If DNS is not running, then the IP address is preferred. However, you can use the Oracle ASR Manager host name if the entry is added to the `/etc/hosts` file.
- **type=asr represents** the Oracle ASR Manager being a special type of SNMP subscriber.

- **community=public** is the required value of the community string. This value varies for each implementation because you can modify it to be a different string based on your network requirements.
- **port=162** is the SNMP port. This port value is customer-dependent. You can configure it as a different port based on your network requirements. Or, you may need to change the port value in order for Oracle ASR to work correctly in a managed environment.
- **asrmPort** is an optional element that supports automatic diagnostic package uploads for Service Requests (SR). The default value is 16161. If you plan to use HTTP for upload, then the value should match the HTTP port configured on Oracle ASR Manager. If you plan to use HTTPS for upload, then the value should match the HTTPS port configured on Oracle ASR Manager. The value should be set to the same value as displayed for "HTTP Port" or "HTTPS/SSL Port" in the output of the command `asr show_http_receiver` on the Oracle ASR Manager host.
- **fromIP** enables you to specify an IP address from which the trap is sent. If this field is not specified, then it defaults to the IP address associated with `eth0`. To support automatic diagnostic package uploads, you must set `fromIP` on the database nodes to the value of the IP address of the `eth0` network interface. Otherwise, use this field if the default IP address is not registered with Oracle ASR Manager. Oracle ASR Manager only processes SNMP traps that are sent from IP addresses that Oracle ASR Manager recognizes.

The **fromIP** field is allowed only for `snmpSubscribers` whose type is either `ASR` or `v3ASR`.

Related Topics

- [How to configure Datacenter InfiniBand Switch 36 & QDR InfiniBand Gateway Switches for ASR \(My Oracle Support Doc ID 1902710.1\)](#)

Adding SNMP Trap Destinations Using OEDA

You can add SNMP trap destinations using Oracle Exadata Deployment Assistant (OEDA).

If this is your initial deployment of Exadata Database Machine, then OEDA automatically configures SNMP settings when you run the latest version of OEDA.

To

1. Download the latest OEDA zip file for your platform.
Oracle Exadata Deployment Assistant Downloads on Oracle Technology Network
2. Run the `config` program.

OEDA performs the SNMP configuration for Oracle ASR using the information you provide on the Automatic Service Request page of OEDA.

3. Confirm that OEDA has correctly configured the trap destinations after the configuration has been deployed on your Exadata rack.

Verify that the host and ports point to the Oracle ASR server.

- a. If you are running Oracle Exadata System Software release 12.1.2.x or later, then use the following command to check the database servers:

Run this command as `root` or an equivalent user on all of the database servers.

```
# dbmcli -e list dbserver attributes snmpSubscriber
```

- b. To check the configuration on the storage servers, use `dcli` and the `LIST CELL` command.

Run this command as `celladmin` or an equivalent user on the storage servers.

```
# dcli -g cell_group -l celladmin "cellcli -e list cell attributes snmpsubscriber"
```

Related Topics

- Using Oracle Exadata Deployment Assistant

Configuring the SNMP Subscriber for Fault Notification on Release 12.x or Later

Use the `ALTER CELL` or `ALTER DBSERVER` commands to configure SNMP trap destinations for servers running Oracle Exadata System Software release 12.x or later.

1. Configure the SNMP subscriber on each database server.
 - a. Log in to the first database server as the `root` user.
 - b. Retrieve the current SNMP subscriber configuration for the server.

If the SNMP subscriber has not been configured, the operating system prompt reappears without displaying any information.

```
# dbmcli -e list dserver attributes snmpsubscriber
#
```

Caution:

When modifying the `snmpSubscriber` attribute for a server, the value you specify replaces the current value. If `snmpSubscriber` is already configured, and you want to add to the list of SNMP targets, then ensure that you include the already configured values in your command.

- c. Modify the `snmpSubscriber` attribute for the server.

If you want to add only a single SNMP subscriber for Oracle ASR, then enter a command similar to the following:

```
# dbmcli -e alter dserver
snmpSubscriber=((host='asrm1.example.com',port=162,
community=public,type=asr,fromIP=eth0_IP_addr,
asrmPort=ASR_Mgr_http_or_https_port))
```

Note:

To support automatic diagnostic package uploads, you must set `fromIP` on the database nodes to the value of the IP address of the `eth0` network interface.

If you need to add multiple fault notification destinations, then specify multiple SNMP subscribers using a comma-delimited list.

```
# dbmcli -e alter dserver
snmpSubscriber=((host='asrm1.example.com',port=162,
community=public,type=asr,fromIP=eth0_IP_addr,asrmPort=ASR_Mgr_ht
tp_or_https_port),
(host='asrm2.example.com',
port=162,community=public,type=asr,fromIP=eth0_IP_addr,
asrmPort=ASR_Mgr_http_or_https_port))
```

- d. Verify the SNMP subscriber attribute has been updated on the server.

```
# dbmcli -e list dserver attributes snmpsubscriber
```

- e. Repeat the previous substeps on each database server.

2. Configure the SNMP subscriber on each Oracle Exadata Storage Server.

- a. Log in to a storage server as `celladmin`, or an equivalent user.
- b. Retrieve the current SNMP subscriber configuration for the server.

If the SNMP subscriber has not been configured, the operating system prompt reappears without displaying any information.

```
# cellcli -e list cell attributes snmpsubscriber
#
```

 **Caution:**

When modifying the `snmpSubscriber` attribute for a server, the value you specify replaces the current value. If `snmpSubscriber` is already configured, and you want to add to the list of SNMP targets, then ensure that you include the already configured values in your command.

- c. Modify the `snmpSubscriber` attribute for the server.

If you want to add only a single SNMP subscriber for Oracle ASR, then enter a command similar to the following:

```
# cellcli -e alter cell
snmpSubscriber=(host='asrm1.example.com',port=162,
community=public,type=asr,fromIP=eth0_IP_addr,
asrmPort=ASR_Mgr_http_or_https_port))
```

 **Note:**

To support automatic diagnostic package uploads, you must set `fromIP` on the database nodes to the value of the IP address of the `eth0` network interface.

If you need to add multiple fault notification destinations, then specify multiple SNMP subscribers using a comma-delimited list.

```
# cellcli -e alter cell
snmpSubscriber=(host='asrm1.example.com',port=162,
community=public,type=asr,fromIP=eth0_IP_addr,asrmPort=ASR_Mgr_http_or
_https_port),
(host='asrm2.example.com',
port=162,community=public,type=asr,fromIP=eth0_IP_addr,
asrmPort=ASR_Mgr_http_or_https_port))
```

- d. Verify the SNMP subscriber attribute has been updated on the server.

```
# cellcli -e list cell attributes snmpsubscriber
```

- e. Repeat the previous substeps on each storage server.

Alternatively, you can use the `exadcli` utility to run the command on a specified group of servers. If you have not used `exadcli` before, see [Using exadcli for the First Time](#).

For example, you might use the following `exadcli` commands to query or update all database servers with a single command:

```
# exadcli -c dbnode01,dbnode02 -l dbnodeadmin list dbserver attributes
snmpsubscriber

# exadcli -c dbnode01,dbnode02 -l dbnodeadmin alter dbserver
snmpSubscriber=
((host='asrm2.example.com',port=162,community=public,type=asr,
fromIP=10.1.1.1,asrmPort=16161),(host='asrm1.example.com',port=162,
community=public,type=asr,fromIP=10.1.1.1,asrmPort=16161))

# exadcli -c cell101,cell102,cell103 -l celladmin list cell attributes
snmpsubscriber

# exadcli -c cell101,cell102,cell103 -l celladmin alter cell
snmpSubscriber=
((host='asrm1.example.com',port=162,community=public,type=asr,
fromIP=10.1.1.1,asrmPort=16161),(host='asrm2.example.com',port=162,
community=public,type=asr,fromIP=10.1.1.1,asrmPort=16161))
```

Configuring the SNMP Subscriber on Release 11.x

Use the `dcli` utility to configure SNMP trap destinations for servers running Oracle Exadata System Software release 11.x.

1. Log into a database server as `root`.
2. Run one of the following commands, depending on your environment, where the `db_group` file identifies the database servers to configure:
 - Oracle Exadata System Software release 11.2.2.4.0 or earlier:

```
# dcli -g db_group -l root "/opt/oracle.cellos/compmon/
exadata_mon_hw_asr.pl -set_snmp_subscribers \"(type=asr,host=
ASR Manager host name or IP,port=162,community=public)\""
```

- Oracle Exadata System Software later than release 11.2.2.4.0:

```
# dcli -g db_group -l root "fromip=\$(ifconfig eth0 | awk '/
inet addr/
{print \$2}' | cut -d: -f2);/opt/oracle.cellos/compmon
/exadata_mon_hw_asr.pl -set_snmp_subscribers
\"(type=asr,host=[ASR
Manager host name or
IP],fromip=\$fromip,port=162,community=public)\""
```


 **Note:**

Integrated Lights Out Manager (iLOM)s are set up by Exadata Database Machine utilities. Do not configure iLOMs manually.

3. Log in to a storage server as `celladmin` or an equivalent user.
4. Review the current setting of the `snmpSubscriber` attribute on all of the storage servers.

In the following example, the `cell_group` file identifies the storage servers that you plan to configure:

```
# dcli -g cell_group -l celladmin "cellcli -e list cell attributes
snmpSubscriber"
```

In some cases, SNMP entries can already be configured for monitoring. (For example: SNMPS configured for Oracle Enterprise Manager Cloud Control).

5. Modify the `snmpSubscriber` attribute on the storage servers.

If the `snmpSubscriber` attribute was already configured, include the previous information in the following command:

```
# dcli -g cell_group -l celladmin "cellcli -e alter cell snmpsubscriber=
\(\(prior_configuration_information),\(\(host='ASR-Manager-host-name-or-
IP',
port=162,community=public,type=asr\)\)\)"
```

6. Verify the `snmpSubscriber` attribute was modified on the servers.

For storage servers:

```
# dcli -g cell_group -l celladmin "cellcli -e list cell attributes
snmpSubscriber"
```

Related Topics

- Overview of the dcli Utility

3

Enabling Automatic DiagPack Upload for Oracle ASR

You can upload diagnostic packages to Oracle ASR automatically.

In Oracle Exadata System Software release 12.2.1.1.0, Management Server (MS) communicates with Oracle ASR Manager to upload a diagnostic package containing information relevant to the Oracle ASR automatically. MS provides support to automatically upload diagpacks over HTTPS starting with Oracle Exadata System Software release 19.1.0.

For Oracle ASR Manager release 5.7 or later, the `http_receiver` is enabled by default, but the HTTPS/SSL configuration might not be. If you want to use HTTP to upload the diagnostic packages, then verify that `HTTP Port` has the same value as `asrmPort` on database and storage servers. If you want to use HTTPS to upload the diagnostic packages, then verify that HTTPS/SSL configuration is enabled and that `HTTPS/SSL Port` has the same value as `asrmPort` on database and storage servers. If you are using a release earlier than Oracle ASR Manager release 5.7, then you must upgrade to release 5.7 or later to use the Automatic DiagPack Upload feature.

1. Verify the `http_receiver` is enabled and determine the port being used.

Run the following command from Oracle ASR Manager:

```
asr show_http_receiver
```

The following example shows the output with HTTPS enabled:

```
HTTP Receiver configuration:
```

```
HTTP Receiver Status: Enabled  
Host Name: exa-asr.example.com  
SFB forward: true  
HTTP Port: 16161  
HTTPS/SSL Port: 8701  
HTTPS/SSL: Enabled
```

To register an ASR Manager or Solaris 11 server to this ASR Manager Relay, use:

```
ASR Manager: asr register -e http://exa-  
asr.example.com:16161/asr
```

```
Solaris: asradm register -e http://exa-asr.example.com:16161/asr
```

```
ASR Manager: asr register -e https://exa-asr.example.com:8701/asr  
Solaris: asradm register -e https://exa-asr.example.com:8701/asr
```

The following example shows the output with only HTTP enabled:

```

HTTP Receiver configuration:

HTTP Receiver Status: Enabled
Host Name: 10.65.41.141
HTTP Port: 16161
HTTPS/SSL configuration is not enabled.

To register an ASR Manager or Solaris 11 server to this ASR
Manager
Relay, use:
ASR Manager: asr register -e http://
10.65.41.141:16161/asr
Solaris: asradm register -e http://10.65.41.141:16161/asr

```

2. Verify the port used by `http_receiver` for Oracle ASR is the same as the `asrmPort` set for the `snmpSubscriber` on the database servers and storage servers.

- a. Check the `asrmPort` for the `snmpSubscriber` on the database servers:

```
dbmcli -e list dbserver attributes snmpSubscriber
```

The output will be similar to the following:

```
((host=engsys-asr1.example.com,port=162,community=public,
type=asr,fromIP=10.242.00.55,asrmPort=16161))
```

- b. Check the `asrmPort` for the `snmpSubscriber` on the storage servers:

```
cellcli -e list cell attributes snmpSubscriber
```

The output will be similar to the following:

```
((host=engsys-asr1.example.com,port=162,community=public,
type=asr,fromIP=10.242.00.55,asrmPort=16161))
```

3. If necessary, enable the `http_receiver` or change the port to match the `asrmPort` value.

Oracle Exadata Deployment Assistant (OEDA) automatically enables HTTPS/SSL for Oracle ASR Manager and imports the certificate on database and storage servers. However, it is still possible that you may need to manually enable HTTPS/SSL for Oracle ASR Manager under some circumstances. Refer to [Enabling HTTPS/SSL on Oracle ASR Manager](#) for instructions on how to configure HTTPS uploads for Oracle ASR Manager.

If the `http_receiver` port is not the same, you can either disable `http_receiver` and enable it again using the same port as `asrmPort`, or you can set the `asrmPort` of `snmpSubscriber` to match that of `http_receiver`.

To enable `http_receiver`, use a command similar to the following, where *port* is the port the `http_receiver` listens on for either HTTP or HTTPS.

```
asr enable_http_receiver -p port
```

 **Note:**

The port specified for the `http_receiver` has to be the same as the `asrmPort` specified for the `snmpSubscriber` on the database servers and storage servers for the automatic DiagPack upload feature to work.

4. If the `snmpSubscriber` was configured on the database or storage server before enabling HTTPS/SSL for Oracle ASR Manager, then restart MS.

The MS on the database and storage servers need to be restarted before you can use HTTPS to upload the diagnostic packages. If HTTPS/SSL was enabled on for Oracle ASR Manager before configuring `snmpSubscriber` on the database and storage servers, then you do not need to restart MS.

- [Enable HTTP Access on Oracle ASR Manager](#)
You can send Oracle Auto Service Request (ASR) fault events and telemetry to Oracle Support Services using XML over HTTP to the Oracle ASR Manager.
- [Enabling HTTPS/SSL on Oracle ASR Manager](#)
You can use either a root-signed certificate or a self-signed certificate to enable HTTPS/SSL on Oracle ASR Manager.

Related Topics

- [Automatic Diagpack Upload for Oracle ASR](#)

Enable HTTP Access on Oracle ASR Manager

You can send Oracle Auto Service Request (ASR) fault events and telemetry to Oracle Support Services using XML over HTTP to the Oracle ASR Manager.

Select a port for the HTTP receiver that is appropriate for your network environment and does not conflict with other network services.

1. View the current HTTP receiver configuration port and status.

```
asr> show_http_receiver
```

2. If HTTP is not already configured, enable the HTTP receiver.

```
asr> enable_http_receiver -p port_number
```

If you see the following error and DNS is not available, then you will need to configure the HTTP receiver manually:

```
Unable to determine the fully qualified domain name for this ASR  
Manager via DNS. Please refer to the Oracle ASR Installation and
```

Operations
Guide for troubleshooting information.

To configure HTTP receiver manually, perform the following steps:

- a. Set the IP address of Oracle ASR Manager.

```
/opt/asrmanager/bin/asr set_property org.osgi.service.http.host  
IP_address_of_ASR_manager
```

- b. Set the HTTP port.

```
/opt/asrmanager/bin/asr set_property org.osgi.service.http.port  
http_port
```

- c. Enable HTTP.

```
/opt/asrmanager/bin/asr set_property  
org.apache.felix.http.enable true
```

- d. Restart the Oracle ASR Manager.

3. Verify the HTTP receiver is up and running.

In a browser, enter the following address:

```
http://asr_manager_host:port_number/asr
```

You should see a message indicating that the HTTP receiver is up and running.

Enabling HTTPS/SSL on Oracle ASR Manager

You can use either a root-signed certificate or a self-signed certificate to enable HTTPS/SSL on Oracle ASR Manager.

Generate and install the SSL Certificate into the Key Store specific to the Java/JDK used by Oracle ASR Manager.

1. Generate the Certificate Signing Request.

- a. Go to the `/java/bin` directory and create the keystore file.

```
# keytool -genkey -alias aliasName -keyalg keyAlgorithm  
-keysize keySize -sigalg signatureAlgorithm  
-keystore keyStoreFile.jks
```

- b. Enter the valid key store password and specify the key password.
- c. Enter the Country, Locality, Organization and Common Name.

If prompted for the first and last name, enter the host name of the machine where Oracle ASR Manager is installed.

- d. Enter the following command:

```
# keytool -certreq -alias aliasName -keystore keyStoreFile.jks -  
sigalg signatureAlgorithm  
-file certRequestFile.cer
```

- e. Enter the valid key store password and specify the key password.
 - f. Submit the Certificate Signing Request *certRequestFile.cer* to the Certificate Authority, and request a Certificate.
2. Install the Certificate after you receive it from the Certificate Authority.

```
# keytool -import -trustcacerts -alias aliasName -file certFileFromCA  
-keystore keyStoreFile.jks
```

After running the `keytool -import` command, enter the valid key store password and specify the key password.

3. When the SSL certificate from a trusted authority has been loaded into keystore, perform the following tasks on Oracle ASR Manager:

Trust Store information is same as the Key Store information.

- a. Set the IP address.

```
# asr  
asr> set_property org.osgi.service.http.host IP_address_of_ASR_manager
```

- b. Set the HTTPS port.

 **Note:**

The value of `org.osgi.service.http.port.secure` should match the HTTPS port configured on Oracle ASR Manager. The value should be set to the same value as displayed for "HTTP Port" or "HTTPS/SSL Port" in the output of the command:

```
asr show_http_receiver
```

```
asr> set_property org.osgi.service.http.host set_property  
org.osgi.service.http.port.secure https_port
```

- c. Set the path to the keystore file.

```
asr> set_property org.apache.felix.https.keystore https_keystore
```

- d. Set keystore password.

```
asr> set_property org.apache.felix.https.keystore.password  
https_keystore_password
```

- e. Set the key password.

```
asr> set_property org.apache.felix.https.keystore.key.password  
https_keystore_key_password
```

- f. Set the path of the truststore to the same as the keystore file.

```
asr> set_property org.apache.felix.https.truststore  
https_truststore
```

- g. Set the truststore password on the same keystore password value.

```
asr> set_property org.apache.felix.https.truststore.password  
https_truststore_password
```

- h. Enable HTTPS for Oracle ASR Manager.

```
asr> set_property org.apache.felix.https.enable true
```

The passwords in the above commands can be plain text or obfuscated, as shown in the following example:

```
jar -xvf /opt/asrmanager/lib/com.oracle.asr.http.receiver.jar  
  
java -classpath org.apache.felix.http.bundle-2.2.0.jar  
org.mortbay.jetty.security.Password plain-text-password
```

After running these Java commands, the output shows the obfuscated password. Obfuscated password values are denoted by the prefix `OBF:`. Copy and paste the output line starting with `OBF:` (including the text 'OBF:') into the above Oracle ASR commands instead of the plain text password. The following is an example of the output.

```
2018-05-04 09:34:17.429:INFO::main: Logging initialized @118ms  
password  
OBF:1v2j20771x1b206z  
MD5:5f4dcc9ac6b3e1a84cebb7b40329cf99
```

4. Restart Oracle ASR Manager.

```
$ service asrm restart
```

5. Verify the SSL setup by accessing the following URL from a browser:

```
https://<asr_manager_host>/asr
```

6. Import the certificate used to enable HTTPS/SSL on each database server and storage server.

```
keytool -import -trustcacerts -keystore /usr/java/default/jre/lib/  
security/cacerts
```

```
-storepass keystore_password -noprompt -alias cert_alias_name -file  
cert_file_path
```

7. Verify the certificate has been imported.

```
keytool -list -v -keystore /usr/java/default/jre/lib/security/cacerts  
-storepass keystore_password
```


4

Activating Nodes on Oracle ASR Manager

Use this procedure to activate nodes on Oracle ASR Manager.

 **Note:**

- Run the commands listed in this section only on Oracle ASR Manager hosts, not on Exadata Database Machine servers.
- Repeat these commands for each Exadata Database Machine server that you attach to Oracle ASR.

1. Run the following command to validate Integrated Lights Out Manager (ILOM) auto-activation and to determine whether the network and ILOM are correctly configured:

```
# asr list_asset
```

The output should be similar to the following:

IP_ADDRESS SOURCE	HOST_NAME PRODUCT_NAME	SERIAL_NUMBER	ASR	PROTOCOL
----- -----	----- -----	-----	-----	-----
10.111.44.111 ILOM	scac01ce108-c SUN SERVER X4-2L	12345abcde	Enabled	SNMP
10.222.33.111 ILOM	scac01ce110-c SUN SERVER X4-2L	43315abcde	Enabled	SNMP
10.333.11.111 ILOM	scac01ce109-c SUN SERVER X4-2L	51423abcde	Enabled	SNMP
10.133.22.111 EXADATA-SQ,ADR	scac01ce108 SUN SERVER X4-2L	12345EDBCA	Enabled	SNMP,HTTP
10.133.11.111 EXADATA-SQ,ADR	scac01ce110 SUN SERVER X4-2L	12345BACDE	Enabled	SNMP,HTTP
10.444.33.111 EXADATA-SQ,ADR	scac01db06 SUN SERVER X4-2	12345XXAAX	Enabled	SNMP,HTTP

- If all of the ILOMs for Oracle Exadata Database Machine servers are in the list, then skip to Step 3.
 - If some of the ILOMs are missing from the list, then proceed with Step 2.
2. Activate ILOM and run one of the following commands:
 - ILOM IP address

```
# asr activate_asset -i Node ILOM IP
```

- ILOM host name

```
# asr activate_asset -h Node ILOM host name
```

 **Note:**

If the activation did not work, then confirm that you used the IP address of the ILOM and not the server.

3. Activate the Exadata Database Machine operating system side of Oracle ASR by running one of the following commands:

- ```
asr activate_exadata -i Node-IP-address -h Node-host-name -l Node-ILOM-IP
```

- ```
# asr activate_exadata -i Node-IP-address -h Node-host-name -n Node-ILOM-hostname
```

4. Run the following command to verify that all of the Exadata Database Machine servers are visible on Oracle ASR Manager:

```
# asr list_asset
```

5. Approve and assign contacts to the Exadata Database Machine servers.

Related Topics

- [How To Manage and Approve Pending Oracle ASR Assets In My Oracle Support \(My Oracle Support Doc ID 1329200.1\)](#)

5

Upgrading to Oracle ASR SNMP v3

Simple Network Management Protocol (SNMP) v3 is supported on Oracle Exadata Storage Servers and Oracle Exadata Database Servers starting with Oracle Exadata System Software release 12.1.2.1.0.

To use SNMP v3 you must be using Oracle ASR release 4.3 or later.

1. Choose a user or define a new user for SNMP v3.
2. Modify the user's SNMP subscriber information:
 - On a storage server, use CellCLI commands similar to the following:

```
ALTER CELL snmpUser=((name=v3user,authprotocol=SHA,
authpassword=*,privprotocol=AES,privpassword=*))
```

```
ALTER CELL snmpsubscriber=((host=asrhost, port=162, SnmpUser=
v3user, type=v3asr))
```

- On a database server, use DBMCLI commands similar to the following:

```
ALTER DBSERVER snmpUser=((name=v3user,authprotocol=SHA,
authpassword=*,privprotocol=AES,privpassword=*))
```

```
ALTER DBSERVER snmpsubscriber=((host=asrhost, port=162, SnmpUser=
v3user, type=v3asr))
```

CellCLI or DBMCLI prompts you for a password when adding the `snmpUser`.

The Integrated Lights Out Manager (ILOM) SNMP user for Oracle ASR and its notification rules are automatically set in the storage server or database server ILOM when `snmpSubscriber` is added with type `v3ASR`.

3. From Oracle ASR Manager, reference the same user name, protocols and passwords to add the v3 user.

```
asr> add_snmpv3_user -u v3user_name -e engineId
[,engineId2, ...] -pp AES
```

You must include both server (cell or compute) and ILOM engine IDs. By default, engine IDs are the cell name or compute node name. ILOM engine IDs are the cell name or compute node name with a `-m` suffix, for example, `mycell` and `mycell-m`.

You are prompted to create both authentication and privacy passwords for the v3 user. The passwords you specify must match the passwords set on the cells and compute nodes.

Oracle ASR Manager only supports the SHA protocol for authentication and the AES protocol for privacy and encryption with ILOM.

Related Topics

- ALTER CELL
- ALTER DBSERVER
- *Oracle Auto Service Request ASR Manager User's Guide for Linux and Solaris*

6

Validating SNMP Trap Configurations on Exadata Database Machine

Use these examples when validating SNMP trap configurations.

- [Validating the Database Server Configuration](#)
Use `dcli` or `dbmcli` to validate the database server configuration.
- [Validating the Storage Server Configuration](#)
Use `dcli` or `CellCLI` to validate the configuration of the storage servers.
- [Database Server SNMP Validation](#)
Use `dbmcli` to validate the SNMP configuration for database servers.
- [Storage Server SNMP Validation](#)
Use `dcli` or `CellCLI` to validate the SNMP configuration on each storage server.

Validating the Database Server Configuration

Use `dcli` or `dbmcli` to validate the database server configuration.

- To verify your node configuration using the `dcli` utility, run the following command on a database server. Run this command from an account that has equivalency with the `root` user on all the database servers listed in the `db_group` file:

- Oracle Exadata System Software release 12.1.2.x or later:

```
# dcli -g db_group -l root -n "dbmcli -e list dbserver attributes snmpSubscriber"
```

- Oracle Exadata System Software release earlier than 12.1.2.x:

```
# dcli -g db_group -l root -n "/opt/oracle.cellos/compmon/exadata_mon_hw_asr.pl -get_snmp_subscribers -type asr"
```

- To verify the configuration when the `dcli` utility is not available, run the following command on each database server:

- If your Oracle Exadata System Software is release 12.1.2.x or later:

```
# dbmcli -e list dbserver attributes snmpSubscriber
```

- If your Oracle Exadata System Software release is earlier than 12.1.2.x:

```
# /opt/oracle.cellos/compmon/exadata_mon_hw_asr.pl -get_snmp_subscribers -type asr
```

Validating the Storage Server Configuration

Use `dcli` or CellCLI to validate the configuration of the storage servers.

- To validate your server configuration using the `dcli` utility, run the following command on the first storage server. Run this command from an account that has equivalency with the `celladmin` user on the cells listed in the `cell_group` file):

```
# dcli -g cell_group -l celladmin "cellcli -e list cell attributes snmpsubscriber"
```

- To validate your server configuration when the `dcli` utility is not available, run the following command as the `celladmin` user on **each** storage server:

```
# cellcli -e "list cell attributes snmpsubscriber"
```

Database Server SNMP Validation

Use `dbmcli` to validate the SNMP configuration for database servers.

- For a system with Oracle Exadata System Software release 12.1.2.x or later, run the following command on each database server:

```
# dbmcli -e alter dbserver validate snmp type=asr
```

With Oracle Exadata System Software release 12.2.1.1.0, when `dbmcli` validates the SNMP trap configurations, it also validates whether an `snmpSubscriber` supports automatic diagnostic package uploads or not. A new message is displayed when the previous command is run if an `snmpSubscriber` is not accessible or doesn't support automatic diagnostic package uploads. The message is similar to the following:

```
ASR Manager(s) on Host01 are not accessible or do not support
automatic diagnostic package upload.
Diagnostic packages will not be automatically uploaded for Service
Requests.
DBServer db01 successfully altered
```

- For a system with Oracle Exadata System Software that is **earlier** than 12.1.2.x:
 - To validate your node configuration using the `dcli` utility, run the following command on a database server:

```
# dcli -g dbs_group -l root "/opt/oracle.cellos/compon/
exadata_mon_hw_asr.pl
-validate_snmp_subscriber -type asr"
```

- To validate your database server configuration when the `dcli` utility is not available, run the following command on **each** database server:

```
# /opt/oracle.cellos/common/exadata_mon_hw_asr.pl -  
validate_snmp_subscriber -type asr
```

Storage Server SNMP Validation

Use `dcli` or CellCLI to validate the SNMP configuration on each storage server.

- To validate your storage node SNMP using the `dcli` utility, run the following command on **each** Oracle Exadata Storage Server host:

```
dcli -g cell_group -l celladmin "cellcli -e alter cell validate snmp  
type=asr"
```

- To validate your storage node SNMP when the `dcli` utility is not available, run the following command on **each** Oracle Exadata Storage Server host:

```
# cellcli -e "alter cell validate snmp type=asr"
```

After validation, Oracle sends e-mail notifications from each of the nodes to:

- The Oracle ASR Manager registration user specified in the Oracle ASR Manager `asr register` command.
- The asset contact that is assigned in My Oracle Support.
- The distribution e-mail list that is assigned in My Oracle Support (optional).

When deploying Oracle ASR, you **must** run the `asrexachck` script as described in My Oracle Support Document 2103715.1 to verify the Oracle ASR deployment.

A Service Request (SR) **must** be filed with Oracle Support Services to validate that the Oracle ASR installation is correct from end-to-end. Include the output of the `asrexachck` script when you file the SR.

Related Topics

- [Engineered Systems ASR Configuration Check tool \(asrexacheck version 4.x\) \(My Oracle Support Doc ID 2103715.1\)](#)

7

Configuring Switches for Oracle ASR

- [Configuring Cisco Switches for Oracle ASR](#)
This topic describes how to configure and activate Cisco switches for Oracle Auto Service Request (ASR).
- [Configuring InfiniBand Switches for Oracle ASR](#)
This topic describes how to configure and activate InfiniBand switches for Oracle Auto Service Request (ASR).

Configuring Cisco Switches for Oracle ASR

This topic describes how to configure and activate Cisco switches for Oracle Auto Service Request (ASR).

Commencing with Oracle Exadata System Software release 21.2.0, when you use the Patch Manager utility (`patchmgr`) to upgrade the Cisco switch firmware, a new monitoring component is also installed on the Cisco switch. The new monitoring component propagates switch alerts to Oracle ASR, enabling automated problem detection and resolution. This capability covers the Management Network Switch and RoCE Network Fabric switches present in X8M and later systems. It also covers Management Network Switch model 9348 present in earlier X8 and some X7 systems.

After installation, the switch monitoring component must be configured to send alerts to the Oracle ASR manager. Perform the following configuration once for each switch:

1. Access the switch using SSH, and log in as the `admin` user with the administrator password.

Note:

If SSH has not been configured, then use Telnet to access the switch as the `admin` user.

2. On Management Network Switch model 9348 switches only, configure the switch to use virtual routing (`vrf`) by default.

```
Switch# python bootflash:scripts/asr/bin/asr set vrf=default
```

WARNING:

Do not run this command on any switch other than Management Network Switch model 9348.

3. If the Oracle ASR manager endpoint location uses HTTPS, copy the certificate from the Oracle ASR manager to the switch.

The certificate must be copied to `bootflash:scripts/asr/.run/ca.pem` on the switch.

For example, you could use the following commands on a host that has SSH access to the switch and the Oracle ASR manager:

```
# openssl s_client -showcerts -servername ASR_host -connect
ASR_host:port </dev/null 2>/dev/null|openssl x509 -outform PEM >
ca.pem
# scp ca.pem switch:bootflash:scripts/asr/.run/ca.pem
```

In the preceding commands:

- `ASR_host` - Specifies the Oracle ASR manager host name or IP address.
- `port` - Specifies the port number for the Oracle ASR manager endpoint. Typically, port 16161 is used.
- `switch` - Specifies the hostname or IP address of the switch.

4. Set the Oracle ASR manager endpoint location.

```
Switch# python bootflash:scripts/asr/bin/asr set
endpoint="ASR_endpoint"
```

In the command, specify the URL for the Oracle ASR manager endpoint.

For example:

```
Switch# python bootflash:scripts/asr/bin/asr set endpoint="https://
192.0.2.108:16161"
```

5. Enable the Oracle ASR manager endpoint.

```
Switch# python bootflash:scripts/asr/bin/asr set state=enabled
```

6. Verify the configuration.

```
Switch# python bootflash:scripts/asr/bin/asr show
```

The following is an example of the expected command output:

```
...
ASR Properties:
    status : Registered
    state  : enabled
    send-event :
        endpoint : http://192.0.2.108:16161
...
```

7. Send a test event to Oracle ASR.

```
Switch# python bootflash:scripts/asr/bin/asr set send-event=test
```

Confirm that the test event is received by Oracle ASR.

8. Exit the switch terminal session.

```
Switch# exit
```

Related Topics

- [Upgrading RoCE Network Fabric Switch Firmware](#)
- [Patchmgr Syntax for RoCE Network Fabric Switches](#)
- [Patchmgr Syntax for the Management Network Switch](#)

Configuring InfiniBand Switches for Oracle ASR

This topic describes how to configure and activate InfiniBand switches for Oracle Auto Service Request (ASR).

To configure Sun Datacenter InfiniBand Switch 36 and QDR InfiniBand Gateway Switches for Oracle ASR, follow the instructions outlined in My Oracle Support Document 1902710.1.

Related Topics

- [How to configure Datacenter InfiniBand Switch 36 & QDR InfiniBand Gateway Switches for ASR \(My Oracle Support Doc ID 1902710.1\)](#)

A

Additional Resources for Oracle Auto Service Request (ASR)

Refer to these sections for additional resources to configure and run Oracle ASR.

Oracle ASR

- Oracle ASR product page:
<http://www.oracle.com/asr>
- Oracle Exadata products qualified for Oracle ASR:
Auto Service Request Qualified Engineered Systems Products
- Oracle ASR user documentation:
See the Oracle ASR documentation at http://docs.oracle.com/cd/E37710_01/nav/products.htm
- Download Oracle ASR software (My Oracle Support login required): [Oracle Auto Service Request \(ASR\) \[My Oracle Support Note 1185493.1\]](#)
- [How To Manage and Approve Pending ASR Assets In My Oracle Support \[My Oracle Support Note 1329200.1\]](#)

Oracle Exadata Database Machine Documentation

- CellCLI command reference: *Oracle Exadata System Software User's Guide*
- dcli command reference: *Oracle Exadata System Software User's Guide*
- DBMCLI command reference: *Oracle Exadata Database Machine Maintenance Guide*

My Oracle Support

- <https://support.oracle.com>

B

Third-Party Licenses for Oracle ASR

Oracle Auto Service Request (ASR) includes third-party products.

For a complete list of the licensed third-party products, refer to Appendix C, "Third-Party Licenses" in *Oracle Auto Service Request (ASR) Manager User's Guide*.

Related Topics

- *Oracle Auto Service Request (ASR) Manager User's Guide*