

# Command Quick Reference

## Introduction

This document is a quick reference for Oracle Hardware Management Pack command line interface (CLI) commands. Unless otherwise specified, listed subcommands and options are specific to each command. For more information, view the man pages or refer to the *Oracle Server CLI Tools User's Guide*.

To determine if a command is supported for your system, refer to the support matrices:

<https://www.oracle.com/goto/ohmp>

 **Note:**

Most commands require root or administrator permissions.

## Common Command Options

These options are common to most commands.

Short Option	Long Option	Description
-?, -h	--help	Displays help information.
-V	--version	Displays the tool version.
-q	--quiet	Suppresses informational message output and returns only error codes.
-y	--yes	Automatically confirms an operation. Does not prompt user for manual confirmation during command execution.

## biosconfig Command Syntax

View and configure BIOS information for servers that only support Legacy BIOS.

Task	CLI Command
Get the version of this tool.	<code>biosconfig -get_version [filename.xml]</code>
Get the boot devices list.	<code>biosconfig -get_boot_order [filename.xml]</code>
Set the boot devices list.	<code>biosconfig -set_boot_order [filename.xml]</code>
Get setup configuration from CMOS.	<code>biosconfig -get_bios_settings [filename.xml]</code>
Set CMOS configuration.	<code>biosconfig -set_bios_settings [filename.xml]</code>
Get 256 bytes CMOS setup data from BIOS.	<code>biosconfig -get_CMOS_dump [[filename.xml]]</code>
Set 256 bytes of CMOS setup data to BIOS.	<code>biosconfig -set_CMOS_dump [filename.xml]</code>

## fwupdate Automatic Mode Command Syntax

Utilize a metadata XML file that comes with the patch download package to update component firmware. Recommended update method.

Task	CLI Command
List component information based on available metadata.	<code>fwupdate list target --xml=filename.xml [--device_name=devicename] [--output_xml=filename] [--quick] [--verbose]</code>
To list updatable targets that support metadata, use the <code>list_supported-targets</code> command.	
To find the <code>devicename</code> for a target, use the <code>list all</code> command.	
Update a component or components based on available metadata and command-line directives.	<code>fwupdate update target --xml=filename.xml [--quick] [--dry-run] [--output=filename] [--start-priority=value] [--end-priority=value] [--silent-reboot] [--silent-no-reboot] [--fail-without-interconnect]</code>
<b>Note:</b> The reboot options are only supported with metadata that includes a power cycle.	

Task	CLI Command
<p>Update a service processor based on available metadata and command-line directives over a network.</p> <p><b>Note:</b> SSL certificate checking is used for network access by default. For this feature to work, you must have installed a client-side certificate for the target SP and you must use the Common Name for the --remote-hostname option.</p>	<pre>fwupdate update target --xml=filename.xml --remote-hostname=remote_sp_ip --remote-username=username [--dry-run] [--output=filename] [--start-priority=value] [--end-priority=value] [--silent-reboot] [--silent-no-reboot] [--fail-without-interconnect] [--cert-dir=pathname] [--no-cert-check] [--intfname=interface] [--remote-intfname-fallback=interface]</pre>

## fwupdate Manual Mode Command Syntax

Use a component-specific image file that comes with the patch download package to update component firmware. For advanced users or when no metadata XML file is available.

Task	CLI Command
<p>List component information.</p> <p>To list updatable image targets, use the <code>list supported-images</code> command.</p> <p>To find the <code>devicename</code> for a target, use the <code>list all</code> command.</p>	<pre>fwupdate list target [--device_name=devicename] [--output=filename] [--verbose]</pre>
<p>Update a component or components based on available metadata and command-line directives.</p>	<pre>fwupdate update target --filename=fw_image_file --device_name devicename [--dry-run] [--output=filename] [--reset] [--fail-without-interconnect]</pre>
<p>Update a service processor based on available metadata and command-line directives over a network.</p> <p><b>Note:</b> The <code>sp-bios-firmware</code> image target is for x86 systems and <code>sysfw-firmware</code> is for SPARC.</p> <p><b>Note:</b> SSL certificate checking is used for network access by default. For this feature to work, you must have installed a client-side certificate for the target SP and you must use the Common Name for the --remote-hostname option.</p>	<pre>fwupdate update sp-bios-firmware sysfw-firmware --filename=fw_image_file --device_name devicename --remote-hostname=remote_sp_ip --remote-username=username [--dry-run] [--output=filename] [--reset] [--fail-without-interconnect] [--cert-dir=pathname] [--no-cert-check] [--intfname=interface] [--remote-intfname-fallback=interface]</pre>

## hwmgmtcli Command Syntax

View system information including event logs.

Task	CLI Command
List subsystem information (for subsystem, all will list all subsystems).	hwmgmtcli list subsystem [--details]
View open problems.	hwmgmtcli list open_problems
Export subsystem information to an XML file.	hwmgmtcli export all --filename <i>filename.xml</i>

## ilomconfig Command Syntax

View system information and configure the Oracle Integrated Lights Out Manager (ILOM) service processor.

Task	CLI Command
Export the Oracle ILOM configuration to an XML file.	ilomconfig export config --xmlfile= <i>filename.xml</i> [-y]
Import an Oracle ILOM configuration from an XML configuration file.	ilomconfig import config --xmlfile= <i>filename.xml</i> [-y]
Show a system summary.	ilomconfig list system-summary
List users.	ilomconfig list user [--username= <i>username</i> ] [--xmlfile= <i>filename.xml</i> ]
List SNMP communities.	ilomconfig list snmp-community [--snmp-community= <i>communityname</i> ] [--xmlfile= <i>filename.xml</i> ]
List IPv4 network settings.	ilomconfig list network [--xmlfile= <i>filename.xml</i> ]
List IPv6 network settings.	ilomconfig list network-ipv6 [--xmlfile= <i>filename.xml</i> ]
List service processor identification information.	ilomconfig list identification [--xmlfile= <i>filename.xml</i> ]
List DNS information.	ilomconfig list dns [--xmlfile= <i>filename.xml</i> ]
List clock information.	ilomconfig list clock [--xmlfile= <i>filename.xml</i> ]
Create users.	ilomconfig create user <i>username</i> [--role= <i>role</i> ] [--xmlfile= <i>filename.xml</i> ]
Delete users.	ilomconfig delete user <i>username</i> [--xmlfile= <i>filename.xml</i> ]
Create SNMP communities.	ilomconfig create snmp-community <i>communityname</i> [--permission=ro rw] [--xmlfile= <i>filename.xml</i> ]

Task	CLI Command
Modify users.	<code>ilomconfig modify user <i>username</i> [-p] [--role=<i>role</i>] [--xmlfile=<i>filename.xml</i>]</code>
Modify IPv4 network settings.	<code>ilomconfig modify network [--ipdiscovery=static dhcp] [--ipaddress=<i>ipaddress</i>] [--netmask=<i>netmask</i>] [--gateway=<i>gateway</i>] [--state=enabled disabled] [--mgmtport=<i>port</i>] [--xmlfile=<i>filename.xml</i>]</code>
Modify IPv6 network settings.	<code>ilomconfig modify network-ipv6 [--static-ipaddress=<i>IPv6_address</i>] [--autoconfig=disabled stateless dhcpv6_stateful dhcpv6_stateless] [--state=enabled disabled]   [--xmlfile=<i>filename.xml</i>]</code>
Modify system identification information.	<code>ilomconfig modify identification [--hostname=<i>hostname</i>] [--system-contact=<i>system_contact</i>] [--system-location=<i>system_location</i>] [--system-identifier=<i>system_identifier</i>] [--xmlfile=<i>filename.xml</i>]</code>
Modify DNS information.	<code>ilomconfig modify dns [--nameservers=<i>name_server_list</i>] [--autodns=enabled disabled] [--retries=<i>retries</i>] [--searchpath=<i>search_path_list</i>] [--timeout=<i>timeout</i>] [--xmlfile=<i>filename.xml</i>]</code>
Reset Oracle ILOM settings to factory defaults.	<code>ilomconfig reset config</code>
List the Host-to-ILOM interconnect settings.	<code>ilomconfig list interconnect</code>
Enable Host-to-ILOM interconnect.	<code>ilomconfig enable interconnect [--ipaddress=<i>ip_address</i>] [--netmask=<i>netmask</i>] [--hostipaddress=<i>host_ip_address</i>]</code>
Disable Host-to-ILOM interconnect.	<code>ilomconfig disable interconnect</code>
Modify Host-to-ILOM interconnect.	<code>ilomconfig modify interconnect [--ipaddress=<i>ip_address</i>] [--netmask=<i>netmask</i>] [--hostipaddress=<i>host_ip_address</i>]</code>
List ILOM watchdog settings.	<code>ilomconfig list ilomwatchdog</code>
Enable ILOM watchdog.	<code>ilomconfig enable ilomwatchdog</code>
Disable ILOM watchdog.	<code>ilomconfig disable ilomwatchdog</code>

Task	CLI Command
Modify ILOM watchdog settings.	ilomconfig modify ilomwatchdog [--timer-action=action] [--number-sp-reset=num_sp_reset] [--query-interval=query_interval]
Reset ILOM watchdog settings to factory defaults.	ilomconfig reset ilomwatchdog-config
List host watchdog settings.	ilomconfig list hostwatchdog
Enable host watchdog settings.	ilomconfig enable hostwatchdog
Disable host watchdog settings.	ilomconfig disable hostwatchdog
Modify host watchdog settings.	ilomconfig modify hostwatchdog [--timer-action=action] [--timer-value=timer_value] [--reset-period=query_interval]
Reset host watchdog settings to factory defaults.	ilomconfig reset hostwatchdog-config
Show a system summary.	ilomconfig list system-summary
Configure Oracle ILOM over a network. <b>Note:</b> SSL certificate checking is used for network access by default. For this feature to work, you must have installed a client-side certificate for the target SP and you must use the Common Name for the --remote-hostname option.	ilomconfig subcommand target --xmlfile=filename.xml options --remote-hostname=remote_sp_ip --remote-username=username [--cert-dir=pathname] [--no-cert-check] [--intfname=interface] [--remote-intfname-fallback=interface]

## itpconfig Command Syntax

Forward Oracle ILOM SNMP traps to a host. Only used with the Hardware Management Agent (hwmgmtd).

Task	CLI Command
List Host-to-ILOM Interconnect settings.	itpconfig list interconnect
Enable Host-to-ILOM Interconnect.	itpconfig enable interconnect [--ipaddress=ip_address] [--netmask=netmask] [--hostipaddress=host_ip_address]
Modify Host-to-ILOM Interconnect settings.	itpconfig modify interconnect [--ipaddress=ip_address] [--netmask=netmask] [--hostipaddress=host_ip_address]
Disable Host-to-ILOM Interconnect.	itpconfig disable interconnect
List Oracle ILOM trap forwarding proxy settings.	itpconfig list trapforwarding

Task	CLI Command
Enable Oracle ILOM trap forwarding proxy.	<code>itpconfig enable trapforwarding [--ipaddress=<i>ip_address</i>] [--port=<i>port</i>] [--community=<i>community</i>]</code>
Modify Oracle ILOM trap forwarding proxy settings.	<code>itpconfig modify trapforwarding [--ipaddress=<i>ip_address</i>] [--port=<i>port</i>] [--community=<i>community</i>]</code>
Disable trap forwarding.	<code>itpconfig disable trapforwarding</code>

## nvmeadm Command Syntax

View and configure NVMe storage.

Task	CLI Command
List controller information.	<code>nvmeadm list [--verbose] [<i>controllername</i>]</code>
List namespace information.	<code>nvmeadm namespace [--namespace <i>namespace</i>] [--verbose] [<i>controllername</i>]</code>
List error information.	<code>nvmeadm getlog --error <i>error_log_number</i> [<i>controllername</i>]</code>
Generate error logs. This command generates nlog and eventlog files for Intel NVMe devices, and generates crash dump and memory dump files for Samsung NVMe devices.	<code>nvmeadm getlog --vendor_specific / <i>dest_path</i> [<i>controllername</i>]</code>
Save vendor information to a file.	<code>nvmeadm list --vendor_specific / <i>dest_path</i> [<i>controllername</i>]</code>
List features of an NVMe controller.	<code>nvmeadm getfeature [<i>controllername</i>]</code>
Format NVMe media.	<code>nvmeadm format --format --all -- metadatasize <i>metadatasize</i> -- blocksize <i>blocksize</i> [<i>controllername</i>]</code>
List supported LBA formats (block and metadata sizes).	<code>nvmeadm format --list [<i>controllername</i>]</code>
Erase NVMe media.	<code>nvmeadm erase --all [<i>controllername</i>]</code>
Securely erase NVMe media.	<code>nvmeadm erase --secure [<i>controllername</i>]</code>
Export the NVMe SSD configuration to a file.	<code>nvmeadm export --filename <i>filename.xml</i> [<i>controllername</i>]</code>
Import the NVMe SSD configuration (block and metadata size only) from a file.	<code>nvmeadm import --filename <i>filename.xml</i> [<i>controllername</i>]</code>

## raidconfig Command Syntax

View and configure RAID storage (hardware RAID controllers only). Before using raidconfig to create volumes (which will overwrite any existing data), use operating system tools to take an inventory of attached disks, their enumeration, and whether they contain data that you want to preserve.

Task	CLI Command
List information on controllers, RAID volumes and disks.  Available targets: all, controller, disk, raid.  To find a controller, disk, or raid volume name, use the list all command.	raidconfig list target [--controller=controller -disks=disks --raid=raid_volume] [--verbose]
Enable or disable JBOD mode on one or more disks connected to a RAID controller. Enabling JBOD mode on a controller sets JBOD mode on all its disks by default. Disks can then have JBOD mode enabled/disabled individually.  <b>Note:</b> Only supported on Oracle Storage 12 Gb SAS RAID PCIe HBA, Internal (7110116, 7110117). Do not enable or disable JBOD mode on disks that contain the OS.	raidconfig modify controller -c controller --jbod enabled disabled raidconfig modify disk -d disk --jbod enabled disabled
Create a RAID volume.	raidconfig create raid [--level raid_level] [--stripe-size stripe_size] [--subarrays size] [--name volumename] [--subdisk-size sizes]-d disks
Delete a RAID volume.	raidconfig delete raid [--raid=raid_volume] [--all]
Add a specified disk.	raidconfig add disk --disks=disks --raid=raid_volume
Remove a specified disk.	raidconfig remove disk --disks=disks --raid=raid_volume
Add a specified spare.	raidconfig add spare --disks=disks [--raid=raid_volume]
Remove a specified spare.	raidconfig remove spare --disks=disks [--raid=raid_volume]
Modify a RAID volume.	raidconfig modify raid --raid=raid_volume [--name volumename] [--bios-boot-target=true] [--read-cache enabled disabled] [--write-cache enabled disabled] [enabled_protect]
Modify a RAID controller.	raidconfig modify controller --controller=controller [--disable-auto-rebuild=true false]

Task	CLI Command
Start a maintenance task.	raidconfig start task --task=taskname [--disks=disks --raid=raid_volume] [--src-disk disk] [--dst-disk disk]
Stop a maintenance task.	raidconfig stop task --task=taskname [--disks=disks --raid=raid_volume] [--src-disk disk] [--dst-disk disk]
Restore the RAID configuration.	raidconfig restore config --controller=controller_id
Clear the RAID configuration.	raidconfig clear config --controller=controller_id
Export RAID inventory data to an XML file.	raidconfig export inventory filename.xml
Export a RAID configuration to an XML file.	raidconfig export config filename.xml
Configure RAID volumes from a configuration file.	raidconfig import config filename.xml
Create RAID volumes with partial disks.	raidconfig create raid --disks=disks --subdisk-size=sizes

## ubiosconfig Command Syntax

View and configure BIOS information on servers that support UEFI.

Task	CLI Command
Display status of import or export changes to UEFI BIOS settings at the next server boot.	ubiosconfig list status
Export a server's UEFI BIOS settings to an XML file.	ubiosconfig export all --xml_file filename.xml [--force]
Import UEFI BIOS settings stored in an XML file to the server at next boot.	ubiosconfig import all --xml_file filename.xml [--force]
Cancel any pending changes to UEFI BIOS settings.	ubiosconfig cancel config
Reset the UEFI BIOS settings to factory default at the next server boot.	ubiosconfig reset config
Cancel the pending reset action.	ubiosconfig reset cancel

Task	CLI Command
<p>Configure UEFI BIOS information over a network.</p> <p><b>Note:</b> SSL certificate checking is used for network access by default. For this feature to work, you must have installed a client-side certificate for the target SP and you must use the Common Name for the --remote_hostname option.</p>	<code>ubiosconfig subcommand type options --remote_hostname=remote_sp_ip -- remote_username=remote_username [-- cert-dir=pathname] [--no-cert-check] [--intfname=interface] [--remote- intfname-fallback=interface]</code>

## zoningcli Command Syntax

`zoningcli` can configure the disks in a Oracle SPARC T3-1 server with a 16-disk backplane into two separate 8-disk zones.

Task	CLI Command
List current zoning information.	<code>zoningcli list expander</code>
Enable zoning.	<code>zoningcli enable zoning</code>
Disable zoning.	<code>zoningcli disable zoning</code>
Set the expander to the default zoning configuration.	<code>zoningcli config zoning</code>

---

Oracle Hardware Management Pack 2.4 Command Quick Reference  
E72073-05

Copyright © 2017, 2023, Oracle and/or its affiliates.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software, software documentation, data (as defined in the Federal Acquisition Regulation), or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, then the following notice is applicable:

U.S. GOVERNMENT END USERS: Oracle programs (including any operating system, integrated software, any programs embedded, installed, or activated on delivered hardware, and modifications of such programs) and Oracle computer documentation or other Oracle data delivered to or accessed by U.S. Government end users are "commercial computer software," "commercial computer software documentation," or "limited rights data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, reproduction, duplication, release, display, disclosure, modification, preparation of derivative works, and/or adaptation of i) Oracle programs (including any operating system, integrated software, any programs embedded, installed, or activated on delivered hardware, and modifications of such programs), ii) Oracle computer documentation and/or iii) other Oracle data, is subject to the rights and limitations specified in the license contained in the applicable contract. The terms governing the U.S. Government's use of Oracle cloud services are defined by the applicable contract for such services. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle®, Java, and MySQL are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Inside are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Epyc, and the AMD logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information about content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services unless otherwise set forth in an applicable

agreement between you and Oracle. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services, except as set forth in an applicable agreement between you and Oracle.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf stipulation expresse de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, accorder de licence, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, la documentation du logiciel, les données (telles que définies dans la réglementation "Federal Acquisition Regulation") ou la documentation qui l'accompagne sont livrés sous licence au Gouvernement des Etats-Unis, ou à quiconque qui aurait souscrit la licence de ce logiciel pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

**UTILISATEURS DE FIN DU GOUVERNEMENT É.-U. :** programmes Oracle (y compris tout système d'exploitation, logiciel intégré, tout programme intégré, installé ou activé sur le matériel livré et les modifications de tels programmes) et documentation sur l'ordinateur d'Oracle ou autres logiciels Oracle. Les données fournies aux utilisateurs finaux du gouvernement des États-Unis ou auxquelles ils ont accès sont des "logiciels informatiques commerciaux", des "documents sur les logiciels informatiques commerciaux" ou des "données relatives aux droits limités" conformément au règlement fédéral sur l'acquisition applicable et aux règlements supplémentaires propres à l'organisme. A ce titre, l'utilisation, la reproduction, la duplication, la publication, l'affichage, la divulgation, la modification, la préparation des œuvres dérivées et/ou l'adaptation des i) programmes Oracle (y compris tout système d'exploitation, logiciel intégré, tout programme intégré, installé, ou activé sur le matériel livré et les modifications de ces programmes), ii) la documentation informatique d'Oracle et/ou iii) d'autres données d'Oracle, sont assujetties aux droits et aux limitations spécifiés dans la licence contenue dans le contrat applicable. Les conditions régissant l'utilisation par le gouvernement des États-Unis des services en nuage d'Oracle sont définies par le contrat applicable à ces services. Aucun autre droit n'est accordé au gouvernement américain.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer un risque de dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour des applications dangereuses.

Oracle®, Java, et MySQL sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut être une marque appartenant à un autre propriétaire qu'Oracle.

Intel et Intel Inside sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. AMD, Epyc, et le logo AMD sont des marques ou des marques déposées d'Advanced Micro Devices. UNIX est une marque déposée de The Open Group.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité et excluent toute garantie expresse ou implicite quant aux contenus, produits ou services émanant de tiers, sauf mention contraire stipulée dans un contrat entre vous et Oracle. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation, sauf mention contraire stipulée dans un contrat entre vous et Oracle.