



---

# Solaris™ 7 5/99 Release Notes Supplement for Sun™ Hardware

## **Solaris 7 5/99**

Includes Additional Release Notes and End-of-Support Statements for Solaris 7 5/99 Running on Sun Hardware Products

---

Sun Microsystems, Inc.  
901 San Antonio Road  
Palo Alto, CA 94303-4900  
U.S.A

Part No.: 806-0278-10  
May 1999, Revision A

Send comments about this document to:  
[docfeedback@sun.com](mailto:docfeedback@sun.com)

Copyright 1999 Sun Microsystems, Inc., 901 San Antonio Road, Palo Alto, California 94303-4900 U.S.A.

This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, SunSoft, SunDocs, SunExpress, and Solaris are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 1999 Sun Microsystems, Inc., 901 San Antonio Road, Palo Alto, California 94303 Etats-Unis. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, SunSoft, SunDocs, SunExpress, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" ET AUCUNE GARANTIE, EXPRESSE OU IMPLICITE, N'EST ACCORDEE, Y COMPRIS DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DE LA PUBLICATION A REPENDRE A UNE UTILISATION PARTICULIERE, OU LE FAIT QU'ELLE NE SOIT PAS CONTREFAISANTE DE PRODUIT DE TIERS. CE DENI DE GARANTIE NE S'APPLIQUERAIT PAS, DANS LA MESURE OU IL SERAIT TENU JURIDIQUEMENT NUL ET NON AVENU.



Please  
Recycle



Adobe PostScript

# Contents

---

## **1. Late Breaking News 1**

Service Contract Upgrades to  
Solaris 7 5/99 1

Unbundled Product Support 2

PC File Viewer Update 2

Documents on the Software Supplement for the Solaris 7 5/99 Operating  
Environment for Sun Computer Systems CD 3

Product Name and Title Changes 4

Sun Microsystems Name Changes 4

Solaris Name Change 4

Solaris Server Intranet Extension Name Change 4

Flash PROM Update for 64-bit Operations 5

Flash PROM Update Multimedia AnswerBook CD 5

Sun Enterprise SyMON Software Available 6

Sun StorEdge A5000 6

Localized Packages on the Software Supplement for the Solaris 7 5/99 Operating  
Environment for Sun Computer Systems CD 7

Japanese Localized Packages 7

German Localized Packages 9

Italian Localized Packages 9

French Localized Packages	9
Spanish Localized Packages	10
Swedish Localized Packages	10
Traditional Chinese Localized Packages	10
Simplified Chinese Localized Packages	12
Korean Localized Packages	13
<b>2. End-of-Support Products</b>	<b>15</b>
End-of-Support Products	15
Network Devices — BEC Device and be Driver	15
Graphics Devices—Discontinued Frame Buffers	15
PEX Graphics Library	16
Future End-of-Support Products	16
Sun4c-based Systems	16
SPARCstation Voyager	16
SPARC Xterminal 1	16
<b>3. Open Issues</b>	<b>17</b>
Prestoserve 2.4.2 — Patch Required	17
Booting From Partitions Greater Than 2-Gbytes (1234177)	18
SunFDDI Adapters Cannot Boot Sun4d Diskless Clients (4144414)	19
Quad Ethernet Controller—Dynamic Reconfiguration Not Supported	19
Serial Parallel Controller Driver	19
Serial Parallel Controller Driver Does Not Support Dynamic Reconfiguration (4177805)	19
ISDN — Power Management Not Supported	20
/usr/ucblib/sparcv9 is Not Available (4114650)	20
SunScreen SKIP 1.1.1 Not Supported in Solaris 7 5/99 Operating Environment	20

Solstice SyMON Not Supported in Solaris 7 5/99 Operating Environment	21
SunVTS 3.2 Issues	21
New Features in This Release	21
SunVTS OPEN LOOK User Interface Support	22
Running SunVTS Online Diagnostics through Sun Enterprise SyMON	22
Disk Test ( <code>disktest</code> ) Mounting Issues	22
The SunVTS User Interface Disappears (4122829)	22
Some Devices Not Displayed Under Physical Mapping (4228489)	23
ShowMe TV 1.3 Known Problems	23
Software	23
PCMCIA Issues	24
If the PC ATA, <code>pcata</code> , module is modunloaded the system will appear to hang (4096137)	24
The PCMCIA, <code>pcic_nexus</code> , driver, does not support 3.3Volts PC Card (4098998)	24
The PC ATA, <code>pcata</code> , disk driver crashes and hangs the system and causes a memory leaks (4106401)	24
When booting Solaris 7 5/99 operating environment initially with 64-bit kernel the device <code>/dev/term/pc0</code> , PC card serial driver, may not get created (4162969)	25
The PC ATA, <code>pcata</code> , driver panics the 64-bit kernel (4174177)	25
PC File Viewer Issues	25
Install in the <code>/opt</code> Directory	25
Known Bugs	25
Sun Remote System Control (RSC) Release Notes	26
What's New in This Version	26
Hardware and Software Configurations Supported for RSC	27
Testing RSC Paging	28
Known Issues	29

SunVTS Test for PGX32 Available	31
Copyright Notices	31
SunForum 2.0 Notices:	31
ShowMe TV 1.2.1 Notices:	31
Netscape Communicator Notices:	33
Sun Enterprise 10000 SSP 105684-04, 106281-01, and 106282-01 Notices:	33
Documentation Errata	34
PC launcher Manpage	34
<i>Platform Notes: The hme SunFastEthernet Device Driver Guide</i>	35
Locale-Specific Bugs	35
SunForum BugID 4234195	35
ShowMe TV BugID 4234201	35
<b>4. Sun Enterprise 10000 Server Open Issues</b>	<b>37</b>
Sun Enterprise 10000	37
General Issues	37
Solaris 7 and Boot-Disk Partition Sizes	37
Operating Mode	38
Solaris 7 and the SSP	38
Documentation Errata	39
Known Bugs	40
Fixed Bugs	41
AP on the Sun Enterprise 10000	41
Installation Issues	41
General Issues	43
Known Bugs	45
Fixed Bugs	45
Dynamic Reconfiguration on the Sun Enterprise 10000	46

General Issues	46
Known Bugs	49
DR and Inter-Domain Networks	51
Bugs Fixed	51
<b>5. Sun Enterprise 6x00, 5x00, 4x00, and 3x00 Systems Open Issues</b>	<b>53</b>
AP on Sun Enterprise Servers	53
Installation Issues	54
General Issues	55
Known Bugs	56
Fixed Bugs	57
Dynamic Reconfiguration of Sun Enterprise 6x00, 5x00, 4x00, and 3x00 Systems	58
Supported Hardware	58
Firmware Notes	58
Software Notes	60
Known Bugs	63





## Late Breaking News

---

This manual provides the following information:

- Late breaking news (this chapter)
- End-of-support statements (chapter 2)
- Open Issues (chapter 3)

This manual supplements the *Solaris 7 5/99 Sun Hardware Platform Guide* and the *Solaris 7 5/99 Release Notes*.

---

## Service Contract Upgrades to the Solaris 7 5/99 Operating Environment

You may have received a Solaris Server Media Kit to upgrade systems to the Solaris 7 5/99 operating environment. Please note that your service contract entitles you to use only those products that apply to your original Solaris operating environment license. The following products, which may be in the media kit you received, are licensed solely to customers with the Solaris Easy Access Server 2.0 product or the Solaris™ Server Intranet Extension™ product, which was included as part of Sun Microsystems Computer Corporation's Solaris 2.6, Solaris 2.6 Hardware: 3/98, or Solaris 2.6 Hardware: 5/98 SPARC™ Server Media Kits:

- Solstice™ AdminSuite™
- Solstice AutoClient™
- Solstice DiskSuite™
- Solstice Data Backup Utility
- Solstice PPP
- TotalNET Advanced Server™

- Java™ IDL
  - Solaris Management Console™
  - Sun™ WebServer™
  - Solstice Internet Mail Server™
  - Sun Directory Services
  - Solstice NFS Client™
- 

## Unbundled Product Support

If you are upgrading from an existing version of the Solaris operating environment and have installed unbundled products, either from Sun or from a different company, you must ensure that all those products are supported on the Solaris 7 5/99 operating environment prior to upgrading. Depending on the status of each unbundled product, you have three options for each unbundled product:

- Verify that the existing version of the unbundled product is supported on the Solaris 7 5/99 operating environment.
- Acquire and install a new version of the unbundled product which is supported on the Solaris 7 5/99 operating environment. Note that in this case you may need to remove the previous version of the unbundled product prior to upgrading to the Solaris 7 5/99 operating environment. See the unbundled product documentation for more details.
- Remove the unbundled product prior to upgrading to the Solaris 7 5/99 operating environment.

For additional information contact the supplier of the unbundled product or your service provider or go to:

<http://sunsolve.sun.com/sunsolve/pubpatches/patches.html>

---

## PC File Viewer Update

For updated information about PC file viewer, direct your browser to:

<http://shop.sun.com/>

From "Free Downloads" at this site, choose "PC file viewer".

---

# Documents on the Software Supplement for the Solaris 7 5/99 Operating Environment for Sun Computer Systems CD

Table 1-1 lists the documents available on the Supplement CD:

**TABLE 1-1** Documents on the Supplement CD

Path	Comment
Docs/HWPG/EOS.html	List of future end-of-support peripheral products
Docs/HWPG/Hardware.ps	Supported hardware matrices
Docs/HWPG/HWPG_en.ps	<i>Solaris 7 5/99 Sun Hardware Platform Guide</i>
Docs/ODBC/ README.ODBC_en.html	Readme file for ODBC
Docs/ShowMeTV1.2.1/UG_en.ps	<i>ShowMe™ TV™ 1.2.1 User's Guide</i>
Docs/README_en.html/	Readme file for Solaris 7 5/99 Sun Computer Systems Supplement CD

---

**Note** – The `_en` indicates an English language document. Other languages may be indicated, depending on locale.

---

The Supplement CD also contains other documentation in AnswerBook™ packages and in man page packages. The documentation in AnswerBook packages can only be read through the AnswerBook2™ server software provided on the Solaris Documentation CD. Documents in the man page packages can only be read through the `man` command. Refer to the *Solaris 7 5/99 Sun Hardware Platform Guide* for details on installing these packages from the Supplement CD.

---

# Product Name and Title Changes

## Sun Microsystems Name Changes

Earlier publications, documents, and software have included the names SunSoft™ and Sun Microsystems Computer Company or SMCC. Due to a Sun Microsystems reorganization, those names are no longer applicable.

For example, in some documents you may find references to a manual that was called *SMCC Hardware Platform Guide*. In this release, that document is now called *Solaris 7 5/99 Sun Hardware Platform Guide*. Another example is the supplement CD, which used to be called the SMCC Supplement CD, is now called the Solaris 7 5/99 Sun Computer Systems Supplement CD.

## Solaris Name Change

This release of Solaris is called Solaris 7 instead of Solaris 2.7. As the Solaris product line continues to grow, this name change will make it easier for you to determine which products in the Solaris line you might want to use.

In Solaris 7, the transition to the new name change is in process. That means that you will still see references to Solaris 2.7, and even to Solaris 2.x.

The name of the core operating system has not changed. In this release, it is SunOS™ 5.7.

## Solaris Server Intranet Extension Name Change

The new version of the Solaris™ Server Intranet Extension™ 1.0 product is named the Solaris™ Easy Access Server 2.0 product.

---

# Flash PROM Update for 64-bit Operations

Some sun4u systems need to be updated to a higher level of OpenBoot™ firmware in the flash PROM before they can run the 64-bit mode of the Solaris 7 5/99 operating environment. Systems that can only run the 32-bit mode (such as those in the sun4c, sun4d, and sun4m platform groups) do not require updated firmware to run Solaris 7 5/99 software.

The only systems that may require this flash PROM update are the following:

- Ultra™ 1
- Ultra 2
- Ultra 450 and Sun™ Enterprise™ 450
- Sun Enterprise 3000, 4000, 5000, and 6000 systems

See the *Solaris 7 5/99 Sun Hardware Platform Guide* for instructions for determining whether your system needs a flash PROM update and for instructions on performing that update.

For the Ultra and Ultra 2 systems, an antistatic wrist strap may be required for the update. If you need a wriststrap, send e-mail to [strap@eng.sun.com](mailto:strap@eng.sun.com)

## Flash PROM Update Multimedia AnswerBook CD

This CD provides video clips that illustrate how to perform steps involving hardware that are part of the procedures for updating the Flash PROM on some sun4u systems.

The video clips on this CD can be accessed several ways. Some software products are present on this CD to facilitate viewing of the videos directly from the CD. Do not use the AnswerBook2 server software or the ShowMe TV software on this CD to install these products permanently on a system. Instead, use the Solaris 7 5/99 Documentation CD to install AnswerBook2 server software and use the Supplement CD to install ShowMe TV software.

---

**Note** – The video clips on the Flash PROM Update Multimedia AnswerBook CD have English language audio tracks. The volume level for the audio tracks is set to minimum. If you want to hear the English language audio track, you must adjust the audio level.

---

---

## Sun Enterprise SyMON Software Available

Sun Enterprise SyMON™ software is an open, extensible system monitoring and management solution that uses Java™ software protocol and Simple Network Management Protocol (SNMP) to provide an integrated and comprehensive enterprise-wide management of Sun products and their subsystems, components, and peripheral devices.

Sun Enterprise SyMON technology provides a solution to extend and enhance the management capability of Sun's hardware and software solutions.

You can download Sun Enterprise SyMON software from:

<http://www.sun.com/symon>

---

## Sun StorEdge A5000

For the latest firmware and patch information for the Sun StorEdge™ A5000, go to:

<http://sunsolve1.Sun.COM>

Click on SSA/A5000 Matrix under Free Services: Public Information.

---

# Localized Packages on the Software Supplement for the Solaris 7 5/99 Operating Environment for Sun Computer Systems CD

## Japanese Localized Packages

CODE EXAMPLE 1-1 Japanese Localized Packages

Software Product	Package Name	Description
SunForum	SUNWjadat	Japanese (ja-EUC) SunForum
	SUNWjpdad	Japanese (ja-PCK) SunForum
Alternate Pathing	SUNWjaap	Japanese localization for Alternate Pathing
Remote System Control	SUNWjarsc	Japanese (EUC) Remote System Control
	SUNWjrscj	Japanese (EUC) Remote System Control GUI
ShowMe TV	SUNWjasmt	ShowMe TV Japanese (ja-EUC) Localization Files
	SUNWjpsmt	ShowMe TV Japanese (ja-PCK) Localization Files
	SUNWjusmt	ShowMe TV Japanese (ja-UTF8) Localization Files
PC launcher	SUNWjdpcv	Japanese (Common) PC launcher help
	SUNWjepcp	Japanese (EUC) PC launcher message
	SUNWjppcp	Japanese (PCK) PC launcher message
	SUNWjupcp	Japanese (UTF-8) PC launcher message
Sun Gigabit Ethernet Adapter Driver	SUNWjegem	Japanese (EUC) Sun Gigabit Ethernet Adapter Driver Man Pages
	SUNWjpgem	Japanese (PCK) Sun Gigabit Ethernet Adapter Driver Man Pages

**CODE EXAMPLE 1-1** Japanese Localized Packages *(Continued)*

<b>Software Product</b>	<b>Package Name</b>	<b>Description</b>
	SUNWjugem	Japanese (UTF-8) Sun Gigabit Ethernet Adapter Driver Man Pages
SunFDDI	SUNWjenfm	Japanese (EUC) SunFDDI SBus Man Pages
	SUNWjepfm	Japanese (EUC) SunFDDI PCI Man Pages
	SUNWjpnfm	Japanese (PCK) SunFDDI SBus Man Pages
	SUNWjppfm	Japanese (PCK) SunFDDI PCI Man Pages
	SUNWjunfm	Japanese (UTF-8) SunFDDI SBus Man Pages
	SUNWjupfm	Japanese (UTF-8) SunFDDI PCI Man Pages
PC file viewer	SUNWjepcv	Japanese (EUC) PC File Format Viewer
	SUNWjepcz	Japanese (EUC) PC File Formats support in CDE
	SUNWjppcv	Japanese (PCK) PC File Format Viewer
	SUNWjppcz	Japanese (PCK) PC File Formats support in CDE
	SUNWjupcv	Japanese (UTF-8) PC File Format Viewer
	SUNWjupcz	Japanese (UTF-8) PC File Formats support in CDE
SunVTS	SUNWjpvtm	Japanese (PCK) SunVTS Man Pages
	SUNWjuvtm	Japanese (UTF-8) SunVTS Man Pages
	SUNWjvtsm	Japanese (EUC) SunVTS Man Pages
AnswerBook	SUNWahwja	Solaris 7 5/99 on Sun Hardware Collection - Japanese



# German Localized Packages

CODE EXAMPLE 1-2 German Localized Packages

Software Product	Package Name	Description
SunForum	SUNWdedat	German SunForum
PC launcher	SUNWdepcp	PC launcher German messages
PC file viewer	SUNWdepcv	PC File Viewer German messages
	SUNWdepcz	PC File Viewer German help and icons
ShowMe TV	SUNWdesmt	ShowMe TV German Localization Files

# Italian Localized Packages

CODE EXAMPLE 1-3 Italian Localized Packages

Software Product	Package Name	Description
SunForum	SUNWitdat	Italian SunForum
PC launcher	SUNWitpcp	PC launcher Italian messages
PC file viewer	SUNWitpcv	PC File Viewer Italian messages
	SUNWitpcz	PC File Viewer Italian help and icons
ShowMe TV	SUNWitsmt	ShowMe TV Italian Localization Files

# French Localized Packages

CODE EXAMPLE 1-4 French Localized Packages

Software Product	Package Name	Description
SunForum	SUNWfrdat	French SunForum
PC launcher	SUNWfrpcp	PC launcher French messages
PC file viewer	SUNWfrpcv	PC File Viewer French messages
	SUNWfrpcz	PC File Viewer French help and icons
ShowMe TV	SUNWfrsmt	ShowMe TV French Localization Files

# Spanish Localized Packages

CODE EXAMPLE 1-5 Spanish Localized Packages

Software Product	Package Name	Description
SunForum	SUNWesdat	Spanish SunForum
PC launcher	SUNWespcp	PC launcher Spanish messages
PC file viewer	SUNWespcv	PC File Viewer Spanish messages
	SUNWespcz	PC File Viewer Spanish help and icons
ShowMe TV	SUNWessmt	ShowMe TV Spanish Localization Files

# Swedish Localized Packages

CODE EXAMPLE 1-6 Swedish Localized Packages

Software Product	Package Name	Description
SunForum	SUNWsvdat	Swedish SunForum
PC launcher	SUNWsvpcp	PC launcher Swedish messages
PC file viewer	SUNWsvpcv	PC File Viewer Swedish messages
	SUNWsvpcz	PC File Viewer Swedish help and icons
ShowMe TV	SUNWsvsmt	ShowMe TV Swedish Localization Files

# Traditional Chinese Localized Packages

CODE EXAMPLE 1-7 Traditional Chinese Localized Packages

Software Product	Package Name	Description
SunForum	SUNW5dat	Traditional Chinese (zh_TW-BIG5) SunForum
	SUNWhdat	Traditional Chinese (zh_TW-EUC) SunForum
PC launcher	SUNW5pcp	PC launcher Traditional Chinese (zh_TW-BIG5) messages
	SUNWhcpcp	PC launcher Traditional Chinese (common) messages

**CODE EXAMPLE 1-7** Traditional Chinese Localized Packages *(Continued)*

<b>Software Product</b>	<b>Package Name</b>	<b>Description</b>
	SUNWhdpcp	PC launcher Traditional Chinese (zh_TW-EUC) messages
PC file viewer	SUNW5pcv	PC File Viewer Traditional Chinese (zh_TW-BIG5) messages
	SUNWhcpcv	PC File Viewer Traditional Chinese (common) messages
	SUNWhdpcv	PC File Viewer Traditional Chinese (zh_TW-EUC) messages
	SUNW5pcz	PC File Viewer Traditional Chinese (zh_TW-BIG5) help andicons
	SUNWhdpcz	PC File Viewer Traditional Chinese (zh_TW-EUC) help andicons
Remote System Control	SUNWhrsc	Traditional Chinese (EUC) Remote System Control
	SUNWhrscj	Traditional Chinese (EUC) Remote System Control GUI
ShowMe TV	SUNW5smt	ShowMe TV Traditional Chinese (zh_TW-Big5) Localization Files

# Simplified Chinese Localized Packages

**CODE EXAMPLE 1-8** Simplified Chinese Localized Packages

<b>Software Products</b>	<b>Package Name</b>	<b>Description</b>
SunForum	SUNWcdat	Simplified Chinese (zh-EUC) SunForum
PC launcher	SUNWccpcp	PC launcher SimplifiedChinese (common) messages
	SUNWcdpcp	PC launcher SimplifiedChinese (zh-EUC) messages
	SUNWgpcp	PC launcher SimplifiedChinese (zh-GBK) messages
PC file viewer	SUNWccpcv	PC file viewer Simplified Chinese (common) messages
	SUNWcdpcv	PC file viewer Simplified Chinese (zh-EUC) messages
	SUNWgpcv	PC file viewer Simplified Chinese (zh-GBK) messages
	SUNWcdpcz	PC file viewer Simplified Chinese (zh-EUC) help and icons
	SUNWgpcz	PC file viewer Simplified Chinese (zh-GBK) help and icons
Remote System Control	SUNWcrsc	Simplified Chinese (EUC) Remote System Control
	SUNWcrscj	Simplified Chinese (EUC) Remote System Control GUI
ShowMe TV	SUNWcsmt	ShowMe TV Simplified Chinese (zh-EUC) Localization Files
	SUNWgsmt	ShowMe TV Simplified Chinese (zh-GBK) Localization Files

# Korean Localized Packages

CODE EXAMPLE 1-9 Korean Localized Packages

Software Product	Package Name	Description
SunForum	SUNWkodat	Korean SunForum
PC launcher	SUNWkpcp	PC launcher Korean (common) messages
	SUNWkdpcp	PC launcher Korean (ko) messages
	SUNWkucp	PC launcher Korean (ko.UTF-8) messages
PC file viewer	SUNWkpcv	PC file viewer Korean (common) messages
	SUNWkdpcv	PC file viewer Korean (ko) messages
	SUNWkupcv	PC file viewer Korean (ko.UTF-8) messages
	SUNWkdpcz	PC file viewer Korean (ko) help and icons
	SUNWkupcz	PC file viewer Korean (ko.UTF-8) help and icons
Remote System Control	SUNWkrsc	Korean (EUC) Remote System Control
	SUNWkrscj	Korean (EUC) Remote System Control GUI
ShowMe TV	SUNWkosmt	ShowMe TV Korean (ko-EUC) localization files
	SUNWkusmt	ShowMe TV Korean (ko-UTF-8) localization files



## End-of-Support Products

---

This chapter contains a list of the end-of-support products for the Solaris 7 release, including the Solaris 7 5/99 release.

---

### End-of-Support Products

The following hardware and software products are no longer supported in this Solaris 7 5/99 release. For more information, contact your authorized Sun support provider.

#### Network Devices — BEC Device and be Driver

The BEC device and be driver are not supported in the Solaris 7 5/99 release.

#### Graphics Devices—Discontinued Frame Buffers

The following frame buffers are not supported in the Solaris 7 5/99 release.

- MG1 (bwtwo)
- MG2 (bwtwo)
- CG2 (cgtwo)
- CG4 (cgfour)
- TC (cgeight)
- ZX (leo)
- TZX (leo)

# PEX Graphics Library

The Solaris™ PEX™ graphics library and server extension are no longer supported in this Solaris 7 5/99 release.

---

## Future End-of-Support Products

Support for the following products may be discontinued in future releases. For more information, contact your support provider.

### Sun4c-based Systems

The following sun4c architecture systems and servers based on these systems may no longer be supported in future releases:

SPARCstation™ SLC, SPARCstation ELC, SPARCstation IPC, SPARCstation IPX, SPARCstation 1, SPARCstation 1+, and SPARCstation 2

---

**Note** – All hardware options (such as SCSI devices) and supported configurations that are dependent upon the sun4c architecture may no longer be supported in future releases. A list of these options is included in the Supplement CD /docs directory in the file named EOS.html.

---

### SPARCstation Voyager

SPARCstation™ Voyager™ systems may no longer be supported in future releases.

### SPARC Xterminal 1

SPARC Xterminal™ 1 systems may no longer be supported in future releases.



## Open Issues

---

---

### Prestoserve 2.4.2 — Patch Required

The Prestoserve™ 2.4.2 release will not function properly with the Solaris 7 5/99 software environment if the workaround below is not implemented. Below is a partial list of some of the platforms and hardware options that may be affected:

- Ultra™ 1 Creator Model 170E
- Ultra 1 Creator3D Model 170E
- Sun™ Enterprise™ 1 Model 170E
- SunSwift™ SBus Adapter Card

If you installed Prestoserve 2.4.2 and are using a platform or hardware option listed above, you must do the following steps to provide compatibility:

1. **Edit the `/etc/system` file and add the following information:**

```
set fas:fas_enable_sbus64 = 0
```

2. **Reboot your system.**



---

**Caution** – Failure to reboot your system can corrupt data.

---

A Prestoserve patch (#103043-08) that automatically adds the above information to the `/etc/system` file is available. If you prefer to make this change using the Prestoserve patch, contact your authorized Sun support provider. If you edit the `/etc/system` file as described above, you do not need the Prestoserve patch.

If you installed Prestoserve 2.4.2 and are using an Ultra 2 platform (200MHz or 300MHz), you must do the following steps to provide compatibility:

1. **Edit the `/etc/system` file and add the following information:**

```
set fas:fas_enable_sbus64 = 0
```

2. **Reboot your system.**
3. **Use `pkgadd` to add the `SUNWprsto` package.**
4. **Add the Prestoserve patch (103043-08).**

---

**Note** – If the above steps are not followed, your Ultra 2 system may panic.

---

---

## Booting From Partitions Greater Than 2-Gbytes (1234177)

Due to PROM limitations, all sun4c, sun4d, and sun4m architectures will not boot from partitions greater than 2-Gbytes. These systems will fail with the following message:

```
bootblk: can't find the boot program
```

---

**Note** – All sun4u architectures support booting from larger partitions.

---

One related bug (4023466) reports a problem with `re-preinstall` where the boot image for large disks creates root partitions greater than 2-Gbytes. System Administrators are cautioned not to use `re-preinstall` on sun4c, sun4d, and sun4m systems with large root disks (4-Gbytes and greater).

---

## SunFDDI Adapters Cannot Boot Sun4d Diskless Clients (4144414)

Sun4d diskless clients cannot be booted using SunFDDI™ adapters (FDDI/S 6.0 or FDDI/P 2.0) installed in servers running the Solaris 7 5/99 operating environment. If you intend using a Sun4d as a diskless client, deploy it in an ethernet section of your network.

---

## Quad Ethernet Controller—Dynamic Reconfiguration Not Supported

The Quad Ethernet (QE) and Quad Ethernet Controller (QEC) must be configured with other non-Dynamic Reconfiguration (DR) boards. DR does not support QE and QEC on Sun Enterprise X000 platforms running the Solaris 7 5/99 operating environment or compatible versions.

---

## Serial Parallel Controller Driver

### Serial Parallel Controller Driver Does Not Support Dynamic Reconfiguration (4177805)

Contact your service provider for availability of patch 106827-01. The patch is not available at the time of this release.

---

## ISDN — Power Management Not Supported

ISDN does not support the Power Management™ suspend and resume features.

---

## /usr/ucblib/sparcv9 is Not Available (4114650)

Any application requiring `ucblib` will not link or run with the 64-bit Solaris operating environment.

Workaround: No workaround is available at this time. Contact your authorized Sun support provider for more information.

---

## SunScreen SKIP 1.1.1 Not Supported in Solaris 7 5/99 Operating Environment

If you have SunScreen™ SKIP 1.1.1 currently installed on your system, you should remove the SKIP packages before installing or upgrading to the Solaris 7 operating environment. The packages you should remove are:

- SICGbdcdr
- SICGc3des
- SICGcdes
- SICGcrc2
- SICGcrc4
- SICGcsafe
- SICGes
- SICGkdsup
- SICGkeymg
- SICGkisup

---

# Solstice SyMON Not Supported in Solaris 7 5/99 Operating Environment

If you have Solstice SyMON currently installed on your system, you should remove the SyMON packages before installing or upgrading to the Solaris 7 5/99 operating environment. The packages you should remove are:

- SUNWsysc
- SUNWsyce
- SUNWsym
- SUNWsyrt
- SUNWsys
- SUNWsyu
- SUNWsyua
- SUNWsyub
- SUNWsyuc
- SUNWsyud
- SUNWsyue
- SUNWsyuf

For information on the availability of Sun Enterprise SyMON 2.0, go to:

<http://www.sun.com/servers/symon.html>

---

## SunVTS 3.2 Issues

The following issues apply to the SunVTS™ 3.2 product.

### New Features in This Release

A new test called `sunpcitest` was added to support testing of the SunPCi plug-in PCI card.

## SunVTS OPEN LOOK User Interface Support

The SunVTS OPEN LOOK user interface may not support the latest SunVTS features. For full feature support, use the SunVTS CDE or TTY interface. The SunVTS OPEN LOOK user interface will be sustained, but not enhanced, as long as OPEN LOOK is supported in the Solaris environment.

## Running SunVTS Online Diagnostics through Sun Enterprise SyMON

The SunVTS 3.2 online diagnostics feature (`SUNWodu`) is not accessible through the SyMON interface.

Instead, you can start SunVTS so it will run safely in an online environment by using the `vt sui.online` command.

Example:

```
# /opt/SUNWvts/bin/vtsui.online -h hostname
```

For more information about running SunVTS in an online or offline environment, refer to the *SunVTS 3.2 User's Guide*.

## Disk Test (`disktest`) Mounting Issues

As of SunVTS 3.0, SunVTS `disktest` by default does not mount any mountable partitions. To have SunVTS mount all partitions which contain a file system, set the environment variable `BYPASS_FS_PROBE` to 0 (zero), then start SunVTS. For more details, refer to the `disktest` chapter in the *SunVTS 3.2 Test Reference Manual*.

## The SunVTS User Interface Disappears (4122829)

In some cases, the SunVTS user interface disappears during a SunVTS test session. The SunVTS kernel is still active and the test session may continue to run.

Workaround: Restart the SunVTS user interface.

Example (starting the SunVTS *CDE* user interface):

```
# /opt/SUNWvts/bin/vysui
```

## Some Devices Not Displayed Under Physical Mapping (4228489)

In some cases, some devices that are displayed under logical mapping are not displayed under physical mapping.

Workaround: Choose logical mapping in the SunVTS main window to select devices that do not come up under physical mapping.

---

## ShowMe TV 1.3 Known Problems

### Software

ShowMe TV 1.3 contains support for MPEG2 movie playback. Support was dropped for the SunMedia Center in ShowMe TV 1.3. Also, ShowMe TV 1.3 contains a number of bug fixes over 1.2.1. Here is a list of some known problems:

- There are various minor problems with playing MPEG1/2 files: zoom does not work on some frame-buffers, the position indicator is not accurate enough, the frame by frame step back function does not work.
- You can not switch between CIF and QCIF H.261 streams (i.e. regular resolution, or 352x288 size frames, and low resolution, or 176x244 size frames) on non\_Ultra systems.
- Mixing Asian and ASCII characters in one line of text can confuse the input/output functions in ShowMe TV. In particular, if a user sets up a transmission in which the transmission name and/or the hostname contain Asian characters, then saving/recovering these parameters to/from the `.showmetv-programs-<hostname>` configuration file might not work correctly.
- The Receiver's buttons and menus contain incorrect text in locales other than English (bug id# 4210702).

---

## PCMCIA Issues

The following bugs have been filed against PCMCIA:

### If the PC ATA, `pcata`, module is modunloaded the system will appear to hang (4096137)

Description: If there is a PCMCIA I/O card in a slot that has been accessed and the card driver is unloaded (as occurs during `modunload -i 0` at the end of multi-user boot) the system will appear to hang. Sometimes removing the card will bring the system back.

Workaround: none

### The PCMCIA, `pcic nexus`, driver, does not support 3.3Volts PC Card (4098998)

Description: The PCMCIA, `pcic nexus`, driver does not support 3.3V on devices. Cards that are 3.3V and 3.3V/5V will not work properly (seems to hang the system).

Workaround: none

### The PC ATA, `pcata`, disk driver crashes and hangs the system and causes a memory leaks (4106401)

Description: Most attempts to insert/remove and use PCMCIA cards will crash or hang the machine. If it does not crash the machine it can cause memory leaks or create situations where other modules will not load.

Workaround: none



## When booting Solaris 7 5/99 operating environment initially with 64-bit kernel the device `/dev/term/pc0`, PC card serial driver, may not get created (4162969)

Description: When booting Solaris 7 5/99 operating environment initially with 64-bit kernel, `/dev/term/pc0` hardware device node for PC card serial device may not be created.

Workaround: Boot the system up with 32-bit kernel first, then reboot with 64-bit kernel.

## The PC ATA, `pcata`, driver panics the 64-bit kernel (4174177)

Description: Inserting the PC card after system init panics the 64-bit Solaris. Booting the 32-bit Solaris and accessing the card will not panic the system. The PC ATA driver is not a 64-bit driver.

Workaround: none

---

## PC File Viewer Issues

### Install in the `/opt` Directory

The *Solaris 7 5/99 Sun Hardware Platform Guide* provides installation instructions that may indicate that PC file viewer can be installed in a directory other than the default directory. PC file viewer *must* be installed in the default (`/opt`) directory.

### Known Bugs

- Backdrop image is not displayed in PowerPoint97 document (4159447)
- Cannot display non-standard fonts in PowerPoint97 (4159448)
- Excel graph/table in PowerPoint97 document is not displayed (4159449)

- Can not display scaled font, colored text, italic-underlined text in PowerPoint97 (4159450, 4159451, 4159452)
- Copy and Paste of certain files into a text editor results in \* (asterisks) instead of actual text (4165089)
- Searching does not work for multi-byte (tch, ko) in PC file viewer (4151774)
- Wrong string is reversed in PC file viewer search on Japanese locales (4171815)
- Cannot display TCH Word95 saved in Word97 or PowerPoint97 formats in zh.TW.BIG5 locale (4150413)

---

# Sun Remote System Control (RSC) Release Notes

## What's New in This Version

This version of Sun Remote System Control (RSC) includes bug fixes and a new environment variable, `tpe_link_test`. In addition, the RSC device Internet address has been added to email and pager alert messages.

If you have already installed a previous version of Remote System Control, back up your RSC configuration before installing this version, following the directions in Chapter 2 of the RSC User's Guide, and then restore them after installation when you run the RSC configuration script.

The `tpe_link_test` variable enables 10BASE-T Ethernet link integrity tests when set to true, the default. If you are using RSC in a hub that does not support Ethernet link integrity tests or that has them disabled, set this variable to false. Changes to this variable take effect after the next RSC reset. The `tpe_link_test` variable behaves similarly to the OBP environment variable named "tpe-link-test?", which is available on some SPARC platforms.

RSC and the local hub should have Ethernet link integrity tests enabled or disabled consistently. If this setting is not consistent, communication may not be possible.

The following bugs have been fixed since the November 16, 1998 release:

- 4172574: The CLI reported a DC Power Failure when the host was powered off.
- 4152840: RSC shell commands did not query for confirmation before resetting the host system.
- 4170986: The GUI "Set Date/Time" dialog box displayed 0:00:00 when time changed to noon and midnight. This is an invalid time format.
- 4173022: The escape sequence for exiting from the RSC console did not work if the `escape_char` variable was set to "^?".

- 4175561: When connected to the server's console through RSC, a paste operation of over 336 characters into the window connected to RSC could hang the console connection. A reset of RSC was required to recover.

## Hardware and Software Configurations Supported for RSC

### Supported Server:

Sun Enterprise(tm) 250 server only, running the Solaris™ 7 or Solaris 2.6 5/98 operating environment.

The Sun Enterprise 250 flash PROM must be updated to version 3.7.7 or later before installing the RSC software. Failing to do so may cause server and RSC malfunctions. For update instructions and a downloadable image, see the Sun Enterprise 250 Supplement Web page at <http://sunsolve2.Sun.COM/sunsolve/E250/flash.html>. If you install RSC from the Sun Enterprise 250 Supplement CD, you can update the flash PROM as part of the installation process.

### Supported GUI Clients:

- Sun systems running the Solaris 7 operating environment
- Sun systems running the Solaris 2.6 5/98 operating environment
- Systems running the Microsoft Windows 95 operating environment
- Systems running the Microsoft Windows 98 operating environment
- Systems running the Windows NT Workstation operating environment

Sun JDK version 1.1.6 or a subsequent compatible version is required for GUI support on systems running the Solaris operating environment, and is included in the base Solaris 7 operating environment and the Sun Enterprise 250 Supplement CD. The required version for the Solaris 2.6 operating environment is available at <http://www.sun.com/solaris/java>. Sun JDK is included in the install package for Windows clients.

### Supported CLI Clients:

- ASCII character terminals
- Systems running ASCII terminal emulation software
- Systems with telnet client software

## Ethernet Support:

RSC is designed to function in a 10BASE-T network, and the RSC Ethernet port should be connected to a hub operating at 10-Mbps. If RSC does not respond to an Ethernet request, the first thing to check is that connection is to a 10BASE-T hub.

## Uninterruptible Power Supply (UPS):

An American Power Conversion SmartUPS 1000 with PowerChute plus 4.2.2 software was used for testing.

## SunVTS:

To run the SunVTS test for RSC on systems running the Solaris 2.6 5/98 operating environment, you must install the unbundled rsctest package. This package is available for download from the RSC Web page at [http://sunsolve2.sun.com/sunsolve/E250\\_RSC/](http://sunsolve2.sun.com/sunsolve/E250_RSC/), and is also provided on the Sun Enterprise 250 Supplement CD. The rsctest package is already included in SunVTS version 3.0 and later.

## Paging Support:

RSC paging requires that the customer's paging service adhere to the TAP protocol. Paging services in the Americas and Europe generally are TAP-compliant, but this is not necessarily so in other locales.

## Testing RSC Paging

Due to the many variables associated with paging, Sun strongly recommends that you test the RSC paging mechanism to insure that your configuration options are set correctly.

The easiest way to test that all the components associated with RSC paging are functioning properly is to use the "rscadm send\_event -c" command. This command can be invoked from a UNIX shell and will initiate an RSC alert. If the RSC page\_enabled flag is set to true, this alert will send a page to the recipients specified by the page\_info1 and page\_info2 environment variables.

If RSC fails to send a page, a message similar to the following will be added to the event log:

```
THU AUG 27 22:31:09 1998 sst4828: 00060006: "Failed to send
page alert for recent event"
```

If RSC successfully transmits a page, no error message is added to the event log.

RSC can fail to send a page notification for the following reasons:

- 1. It failed to communicate with the modem.
- 2. It failed to contact the paging service specified by the `page_info1` or `page_info2` variable.
- 3. A failure occurred while RSC was communicating with the paging service TAP server.

When a page fails, check the following:

1. That your modem dip switch and software configuration variables are set correctly.
2. That all the RSC `page_variables` (`page_info1` and 2, `page_init1` and 2, and `page_baud1` and 2) are set correctly and match the settings for your paging service.
3. Insure that your paging service supports the TAP protocol. Check with the paging service to insure that you have the proper phone number and modem configuration parameters.
4. Attempt to connect with the paging service manually. Refer to the "Troubleshooting Modem Problems" section in Appendix B of the RSC User's Guide for instructions on manually connecting to a TAP paging service.

## Troubleshooting

In some cases, it might be desirable to extend the pause period to allow the modem to recognize the dial tone of the phone line. This can be accomplished on most modems by increasing the value in the S8 register. See documentation that came with your modem for more details.

## Known Issues

1. 4151918: The RSC subtests do not provide adequate failure information.
2. 4171924: The RSC GUI occasionally reports invalid exceptions when you Logout or Exit.
3. 4168266: Heavy use of UNIX `tcsh` shell commands in an RSC console session may stop RSC from responding to requests. Killing the `tcsh` shell restores RSC to normal behavior.
4. 4167862: A log history error is reported when the "index -n" value you specify is greater than the number of lines in the buffer

5. 4171929: RSC sometimes reports a fan failure erroneously after a thermal shutdown.
6. 4145761: An RSC reset is required for changes to the serial\_hw\_handshake variable (or "Enable Hardware Handshaking" setting in the GUI) to take effect, but should not be required.
7. 4167651: RSC default configuration settings for pagers do not match modem configuration settings suggested in documentation.
8. 4171431: The GUI event log output differs from the CLI loghistory output.
9. 4170988: The RSC GUI Back button for the first instance of Help does not return you to the previous view.
10. 4172337: The error message displayed for an attempted third telnet or fifth user session needs improvement.
11. 4162419: In the Windows operating environment, the RSC GUI goes to the background when you cancel an operation after an error message.
12. 4158400: The message "[Loaded DTD html32 in 142ms]" appears when the RSC Help file is displayed.
13. 4151674: Clicking on "Set RSC Date and Time" sometimes displays a duplicate image of the "Set RSC Date and Time" option just above the option list, and below the "RSC for <hostname>" title.
14. 4159618: A GUI reset request and the resulting reset event are recorded in the incorrect order in the RSC event log.
15. 4159562: The telnet connection resets intermittently when you try to connect to the RSC console from the GUI.
16. 4159564: The Java Runtime Environment (JRE) may crash in the Windows 95 operating environment when you modify an RSC user account.
17. 4172331: In the RSC GUI Serial Port settings, there is a typo in the error message for Invalid IP Address.
18. 4159135: The RSC GUI has no option which shows the information returned by the CLI shownetwork command.
19. 4157854: Sometimes when a thermistor displays a warning in the Environmental Status window and you refresh the screen, the warning is mistakenly displayed for a different thermistor. Another refresh corrects this problem.
20. 4216814: Pressing Return in the GUI login screen fails to advance input focus to the next entry field.

---

## SunVTS Test for PGX32 Available

The PGX32 VTS package is currently not bundled with SUNWvts. For version 3.2 refer to Patch #107732. This patch has been incorporated in the S7 5/99 Supplemental CD in the Patch directory.

---

## Copyright Notices

The following copyright information was not included in the Software Supplement for the Solaris 7 5/99 Operating Environment for Sun Computer Systems CD.

### SunForum 2.0 Notices:

1. Copyright Data Connection Limited 1999. Data Connection® is a registered trademark of Data Connection Limited in the US and other countries
2. Copyright Teles Ag 1999

### ShowMe TV 1.2.1 Notices:

Copyright® 1993-1994 The Regents of the University of California. All rights reserved. Tous droits re'serve's.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

3. All advertising materials mentioning features or use of this software must display the following acknowledgement: This product includes software developed by the University of California, Berkeley and the Network Research Group at Lawrence Berkeley Laboratory.
4. Neither the name of the University nor of the Laboratory may be used to endorse or promote products derived from this software without specific prior written permission.

## Copyright 1990-1993 GROUPE BULL

Permission to use, copy, modify, and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appear in all copies and that both that copyright notice and this permission notice appear in supporting documentation, and that the name of GROUPE BULL not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission. GROUPE BULL makes no representations about the suitability of this software for any purpose. It is provided "as is" without express or implied warranty.

GROUPE BULL disclaims all warranties with regard to this software, including all implied warranties of merchantability and fitness, in no event shall GROUPE BULL be liable for any special, indirect or consequential damages or any damages whatsoever resulting from loss of use, data or profits, whether in an action, arising out of or in connection with the use or performance of this software.

## Copyright 1992 by Stichting Mathematisch Centrum, Amsterdam, The Netherlands.

All Rights Reserved. Tous droits re'serve's.

Permission to use, copy, modify and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appear in all copies and that both that copyright notice and this permission notice appear in supporting documentation, and that the names of Stichting Mathematisch Centrum or CWI not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission.

STICHTING MATHEMATISCH CENTRUM DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OR MERCHANTABILITY AND FITNESS, IN NO EVENT SHALL STICHTING MATHEMATISCH CENTRUM BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING



FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OF PERFORMANCE OF THIS SOFTWARE.

OpenGL is a trademark of Silicon Graphics

## Netscape Communicator Notices:

Copyright 1999, Netscape Communications Corporation. All Rights Reserved. Tous droits réservés.

## Sun Enterprise 10000 SSP 105684-04, 106281-01, and 106282-01 Notices:

This software is copyrighted by the Regents of the University of California, Sun Microsystems, Inc., and other parties. The following terms apply to all files associated with the software unless explicitly disclaimed in individual files.

The authors hereby grant permission to use, copy, modify, distribute, and license this software and its documentation for any purpose, provided that existing copyright notices are retained in all copies and that this notice is included verbatim in any distributions. No written agreement, license, or royalty fee is required for any of the authorized uses.

Modifications to this software may be copyrighted by their authors and need not follow the licensing terms described here, provided that the new terms are clearly indicated on the first page of each file where they apply.

IN NO EVENT SHALL THE AUTHORS OR DISTRIBUTORS BE LIABLE TO ANY PARTY FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS SOFTWARE, ITS DOCUMENTATION, OR ANY DERIVATIVES THEREOF, EVEN IF THE AUTHORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

THE AUTHORS AND DISTRIBUTORS SPECIFICALLY DISCLAIM ANY WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT. THIS SOFTWARE IS PROVIDED ON AN "AS IS" BASIS, AND THE AUTHORS AND DISTRIBUTORS HAVE NO OBLIGATION TO PROVIDE MAINTENANCE, SUPPORT, UPDATES, ENHANCEMENTS, OR MODIFICATIONS.

RESTRICTED RIGHTS: Use, duplication or disclosure by the government is subject to the restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software Clause as DFARS252.227-7013 and FAR 52.227-19.

---

## Documentation Errata

The following errors in various documents have been reported.

### PC launcher Manpage

The `sdtpcaction.conf` manpage was left out of the manpage packages. Here is the content of the manpage (bug ID 4230365):

```
NAME

sdtpcaction.conf - sdtpcaction configuration file

FILE FORMAT

The format of this file is as follows.

VERSION      : 1.0
SOLARIS_HOST: Host name of Solaris
DEFAULT      : default PC_TYPE
PC_HOST      : Host name for PC
PC_TYPE      : SunPC | SoftWindows | RemotePC

Optional:

PC_HOME      : Directory shared by PC and Solaris. Can be
               used if for security reason the user does not
               want to map unix home directory to PC.
INITIALIZATION_COMMAND: command to initialize PC emulator
CLIENT_NAME  : ICCCM client name of PC emulator window

These records are stored for each Solaris hostname.

FILES
  $HOME/.dt/.sdtpcaction.conf  PC Proxy configuration file
```

## *Platform Notes: The hme SunFastEthernet Device Driver Guide*

The *Platform Notes: The hme SunFastEthernet Device Driver Guide* lists the wrong default value for the `adv_10fdx_cap` parameter. The correct default value for this parameter is 1 for 10Mbit/sec full-duplex capable.

See bug Id 4217150 for more information.

---

## Locale-Specific Bugs

### SunForum BugID 4234195

In Helpful Information for WebStart installation, a link to the SunForum html file is broken. This problem can be seen in German, French, Italian, Spanish, and Swedish languages for the Desktop Configuration.

If it's linked correctly, the following information is displayed:

SunForum 2.0:

SunForum is a suite of collaborative tools based on the International Telecommunications Union (ITU) T.120 standards. SunForum consists of a Share Application program, a Shared Whiteboard application, File Transfer utility and a Chat Utility.

Requirements for SunForum 2.0:

You need to allocate about 11 MB of disk space to this product.

### ShowMe TV BugID 4234201

In "Co-Packaged Software Topics: Contents" for WebStart installation lists wrong version for ShowMe TV. ShowMe TV 1.2.1 is included in this release, not ShowMe TV 1.3. This problem can be seen in German, French, Italian, Spanish, and Swedish languages for the Desktop Configuration.



# Sun Enterprise 10000 Server Open Issues

---

---

## Sun Enterprise 10000 Server

This chapter contains general issues, known bugs, patches, and notes about the Solaris 7 5/99 release on the Sun Enterprise 10000 server.

### General Issues

Alternate Pathing (AP) 2.2 and Dynamic Reconfiguration (DR) are supported in the Solaris 7 release. Inter-Domain Networks (IDNs) are not supported. Upgrades from the Solaris 2.3 or Solaris 2.4 operating environments to the Solaris 7 operating environment are not supported.

---

**Note** – Before beginning the fresh install or upgrade procedures, you must install the SSP patches described in “Solaris 7 and the SSP” on page 38.

---

### The Solaris 7 Operating Environment and Boot-Disk Partition Sizes

If you are upgrading the operating environment from the Solaris 2.6 operating environment to the Solaris 7 operating environment and you used the partition layout suggested in the *SMCC Hardware Platform Guide Solaris 2.6*, the partitions may

not be large enough for the upgrade to succeed. For instance, the `/usr` partition must be at least 653 megabytes. If `/usr` is smaller than the size needed to perform the upgrade, `suninstall` uses the Dynamic Space Reallocation (DSR) mode to reallocate the space of the disk partitions.

DSR may calculate a partition layout which is not acceptable for some systems. For instance, DSR may select partitions that appear to DSR as being unused (non-UFS partitions which may contain raw data or other types of file systems). If DSR selects a used partition, data loss may occur. Therefore, you must know the current status of the partitions DSR wants to use before you allow DSR to continue with the reallocation of the disk partitions.

After DSR presents an acceptable layout and you choose to proceed with the reallocation, DSR will adjust the affected file systems, and the upgrade will continue. However, if you cannot constrain the layout so that it is acceptable for your needs, then you may need to manually repartition the boot device, or you may have to perform a fresh install.

## Operating Mode

On the Sun Enterprise 10000, you can check whether a domain is running in 32-bit or in 64-bit mode by using the following command:

```
domain_name# isainfo -k
sparcv9
```

The returned value, `sparcv9`, indicates that the domain is running the 64-bit operating mode; otherwise, the domain is running in 32-bit mode.

You can also use another command, `isalist`, to check the operating mode; however, the return value, `sparcv9+vis`, differs from the return value of the `isainfo -k` command. The values are synonymous. They both indicate that the domain is running in 64-bit mode.

## Solaris 7 and the SSP

SSP 3.1 is the first SSP release to support Solaris 7. If you are installing Solaris 7 on a domain or upgrading a domain's current Solaris operating environment, you must have SSP 3.1 installed on the SSP. SSP 3.0 does not support Solaris 7 on a domain. In addition, before you perform the fresh install or upgrade of the Solaris 7 software on an Sun Enterprise 10000 domain, the SSP must have Patch-ID 105684-04. This patch is on your Sun Computer Systems Supplements CD.

---

**Note** – If the CD contains the latest version the patch, indicated by a higher-numbered suffix, use that patch instead of the patch number indicated in this section.

---

## Patch-ID 105684-04

Description: OBP/download\_helper needs to support 2.7

BugIDs fixed with this patch: 4078459 4083870 4084325 4097230 4102171 4118746  
4137422 4146592

## Patch-ID 106281-01

Description: SSP 3.1 sys\_id -m doesn't work in year 2000 or after (Y2K bug)

BugIDs fixed with this patch: 4105569

## Patch-ID 106282-01

Description: SSP 3.1 Hostview suppresses trap messages after 1999

BugIDs fixed with this patch: 4108443

# Documentation Errata

This section contains errors in the documentation that pertains to the Solaris operating environment on the Sun Enterprise 10000 server.

## Fresh Install Procedure

In the “Solaris 7 5/99 on the Sun Enterprise 10000 Server” chapter of the *Sun Hardware Platform Guide Solaris 7 5/99*, the Fresh Install procedure points the reader to the “Setting up the SSP as a Boot Server” section if the domain in question already exists. The procedure should, however, point the reader to the “Updating the OpenBoot PROM” section.

The Fresh Install procedure is not intended to be used for installations in which the domain already has an eeprom.image file associated with it on the SSP. Note that if you have removed the domain by using the `domain_remove(1M)` command, you

will need to perform all of the procedures in the Fresh Install section to recreate the `eeprom.image`. If the `eeprom.image` already exists, refer to the “Performing an Upgrade” section.

## OBP Variables

Before you perform the `boot net` command from the OBP prompt (`ok`), you must verify that the `local-mac-address?` variable is set to `false`, which is the factory default. If it is set to `true`, you must ensure that this value is an appropriate local configuration.



---

**Caution** – If `local-mac-address?` is set to `true`, it may prevent the domain from successfully booting over the network.

---

In a `netcon(1M)` window, you can use the following command at the OBP prompt to display the values of the OBP variables:

```
ok printenv
```

### ▼ To Set the `local-mac-address?` Variable

- If the variable is set to `true`, use the `setenv` command to set it to `false`.

```
ok setenv local-mac-address? false
```

## Solaris Version Names

The version name for the Solaris operating environment changed in Sun publications with the release of Solaris 7 5/99; however, the version name in the code did not change. Thus, you should use `2.7` wherever the procedures call out for the version number of the operating system. For instance, in the “Creating a New Domain” procedure in the Fresh Install section, you should use `2.7` for the version name, as in the following example:

```
ssp# domain_create -d domain_name -b board_numbers -o 2.7 -p platform_name
```



## Known Bugs

There are no Sun Enterprise 10000-specific bugs known to exist in the Solaris 7 5/99 release.

## Fixed Bugs

This section lists important bugs that have been fixed. Minor bugs are not included. Each entry includes a 7-digit BugID assigned by Sun to aid in bug-tracking and a one-line description of the bug.

4110199 - /etc/init.d/cvc Implementation, Packaging Inconsistent

---

## AP on the Sun Enterprise 10000

Alternate Pathing (AP) 2.2 is the first release of AP that is supported on Sun Enterprise 10000 domains running the Solaris 7 5/99 operating environment.

---

**Note** – AP 2.2 is the first AP release to support Solaris 7 5/99.

---

AP enables you to define and control alternate physical paths to peripheral devices, adding increased availability and a level of fault recovery to your server. If a physical path to a device becomes unavailable, an alternate path can be used. For more information, see the *Sun Enterprise Server Alternate Pathing 2.2 User's Guide* in the Solaris 7 5/99 on Sun Hardware Collection AnswerBook.

---

**Note** – At the time of this printing, AP 2.2 Beta is not compatible with any version of Sun Enterprise Volume Manager™ (SEVM).

---

## Installation Issues

If you are upgrading from the Solaris 2.5.1 or 2.6 to Solaris 7 5/99 operating environments and have AP 2.0 or 2.1 and Solstice™ DiskSuite™ 4.0 or 4.1 (SDS) on your system, you must upgrade to AP 2.2 and SDS 4.2. This section contains an overview of the entire process, which requires you to use several sections from different publications. You should ensure that you have the following publications before you start the upgrade:

- Solaris 7 5/99 *Beta Release Notes Supplement for Sun Hardware* (available in printed form in your Solaris 7 5/99 Media Kit)
- *Solaris 7 5/99 Sun Hardware Platform Guide*, (available in printed form in your Solaris 7 5/99 Media Kit or in AnswerBook2 format on the Sun Hardware Supplements CD)
- *Sun Enterprise Server Alternate Pathing User's Guide* (available in AnswerBook2 format on the Sun Hardware Supplements CD in your Solaris 7 5/99 Media Kit)
- *Solstice DiskSuite 4.2 User's Guide* (available in AnswerBook2 format from <http://docs.sun.com> or from your SDS Media Kit)
- *Solstice DiskSuite 4.2 Installation and Product Notes* (available in AnswerBook2 format from <http://docs.sun.com> or from your SDS Media Kit)



---

**Caution** – You must follow the sequence given here to successfully complete the upgrade.

---

In general, you will perform the following tasks:

- Unconfigure SDS 4.0 or 4.1.
- Remove AP 2.0 or 2.1.
- Upgrade to the Solaris 7 5/99 operating environment.
- Install AP 2.2.
- Install and reconfigure SDS 4.2.

Specifically, you must perform the following tasks:

1. Read “Performing an Upgrade of AP” in “Alternate Pathing 2.2 on the Sun Enterprise 10000” in the *Solaris 7 5/99 Sun Hardware Platform Guide*.
2. Commit any uncommitted AP metadevices (see Step 1 in “To Upgrade AP” in “Alternate Pathing 2.2 on the Sun Enterprise 10000” in the *Solaris 7 5/99 Sun Hardware Platform Guide*).
3. Deconfigure SDS (see steps 1 through 8 in “How to Convert to DiskSuite 4.2 on SPARC Systems Running DiskSuite 4.0 or 4.1” in the *Solstice DiskSuite 4.2 Installation and Product Notes*).



---

**Caution** – Do not install Solaris 7 5/99 at this time.

---

4. Perform steps 3 through 5 in “To Upgrade AP” in “Alternate Pathing 2.2 on the Sun Enterprise 10000” in the *Solaris 7 5/99 Sun Hardware Platform Guide*).

---

**Note** – For this beta release, you must remove the SUNWapap package as part of Step 3a in “To Upgrade AP” in the *Solaris 7 5/99 Sun Hardware Platform Guide*.

---

5. Upgrade to Solaris 7 5/99 (see Step 6 in “To Upgrade AP” in “Alternate Pathing 2.2 on the Sun Enterprise 10000” in the Solaris 7 5/99 Sun Hardware Platform Guide).
6. Follow steps 6 through 9 in “To Upgrade AP” in “Alternate Pathing 2.2 on the Sun Enterprise 10000” in the Solaris 7 5/99 Sun Hardware Platform Guide).
7. Install SDS 4.2, then restore it (see Step 10 in “To Upgrade AP” in “Alternate Pathing 2.2 on the Sun Enterprise 10000” in the Solaris 7 5/99 Sun Hardware Platform Guide and steps 10 through 16 in “How to Convert to DiskSuite 4.2 on SPARC Systems Running DiskSuite 4.0 or 4.1” in Chapter 1 of the *Solstice DiskSuite 4.2 Installation and Product Notes*).

## General Issues

This section contains general issues that involve AP on the Sun Enterprise 10000 server. You should read this section before you attempt to install or configure AP.

## Supported Devices

The following devices are supported by the AP software on Sun Enterprise servers:

- SPARCstorage™ Arrays recognized by AP using the `pln`, `soc`, and `ssd` ports
- Sun™ StorEdge™ A5000 recognized by AP using `sf`, `soc`, and `ssd` ports
- SunFastEthernet™ 2.0 (`hme`)
- SunFDDI™ 5.0 (`nf`) SAS (Single-Attach Station) and DAS (Dual-Attach Station)
- SCSI-2/Buffered Ethernet FSBE/S and DSBE/S (`le`)
- Quad Ethernet (`qe`)
- Sun™ Quad FastEthernet™ (`qfe`)
- Sun GigabitEthernet 2.0 (`ge`)

The following table lists which network devices are supported in which releases:

**TABLE 4-1** Supported Network Devices

	AP 2.0	AP 2.1	AP 2.2
Solaris 2.5.1	<code>hme</code> , <code>le</code> , <code>nf</code> , <code>bf</code> , <code>hi</code> , <code>qe</code> , <code>qfe</code>	N/A	N/A
Solaris 2.6 (5/98)	N/A	<code>ge</code> , <code>hme</code> , <code>le</code> , <code>nf</code> , <code>qe</code> , <code>qfe</code> , <code>vge</code>	N/A
Solaris 7 5/99	N/A	N/A	<code>ge</code> , <code>hme</code> , <code>le</code> , <code>nf</code> , <code>qe</code> , <code>qfe</code>

## SunFDDI Devices

AP 2.2 validation tests were performed on SunFDDI (revision 6.0). If you install this device, you must use the revision level that was tested, unless a higher revision level exists. In addition, you must install all of the available patches for this device. Refer to <http://www.sunsolve.sun.com> for more information about the patches.

## Sun StorEdge A3000

The Sun StorEdge A3000 supports failover capabilities that are similar to those provided by AP. Because of this, AP does not support the Sun StorEdge A3000. See that product's documentation for more information about its failover support.

## Sun StorEdge A5000

AP supports the Sun StorEdge A5000 for this release.

## Sun StorEdge A7000

AP 2.2 does not support the Sun StorEdge A7000 for this release.

## Software Compatibility

The following figures show the possible combinations of SSP, AP, and Solaris software you can install on a Sun Enterprise server. Note that the Sun Enterprise 10000 can have any combination of domains with the operating environment and software listed on the right of the figures. The version of the Solaris operating environment on the SSP and the version on the domain do not need to match.

---

**Note** – In the following figures, “base only” means no AP and no DR, unless otherwise noted. Mainly, “base only” refers to a domain that has only the Solaris operating environment installed. In addition, some of the scenarios below are possible only if you install a patch, or a set of patches, on the SSP or on the domain. For more information about what patch, or patches, refer to the patch descriptions at <http://sunsolve.sun.com>.

---

**SSP**  
SSP 3.0  
AP 2.0  
Solaris 2.5.1



**Up to five domains running:**  
• Solaris 2.5.1 with or without AP 2.0 and DR

**FIGURE 4-1** SSP 3.0, AP 2.0, and Solaris 2.5.1 on the Sun Enterprise 10000

**SSP**  
SSP 3.1\*  
AP 2.1  
Solaris 2.5.1



\* Requires  
patch 105684  
for Solaris 7

**Up to eight domains running:**  
• Solaris 2.5.1\* with or without AP 2.0 and DR  
• Solaris 2.6 3/98 (base only)  
• Solaris 2.6 5/98 with or without AP 2.1 and DR  
• Solaris 7 (base only)

\* Requires patch 105029-11

**FIGURE 4-2** SSP 3.1, AP 2.1, Solaris 2.5.1, Solaris 2.6 3/98, Solaris 2.6 5/98, and Solaris 7 on the Sun Enterprise 10000

**SSP**  
SSP 3.1\*  
AP 2.2  
Solaris 2.5.1



\* Requires  
patch 105684  
for Solaris 7

**Up to eight domains running:**  
• Solaris 2.5.1\* with or without AP 2.0 and DR  
• Solaris 2.6 3/98 (base only)  
• Solaris 2.6 5/98 with or without AP 2.1 and DR  
• Solaris 7 (base only)  
• Solaris 7 3/99 (base only)  
• Solaris 7 5/99 with or without AP 2.2 and DR

\* Requires patch 105029-11

**FIGURE 4-3** SSP 3.1, AP 2.2, AP 2.1, Solaris 2.5.1, Solaris 2.6 3/98, Solaris 2.6 5/98, Solaris 7, Solaris 7 3/99, and Solaris 7 5/99 on the Sun Enterprise 10000

## Known Bugs

There are no known bugs in this release of AP.

## Fixed Bugs

This section contains the synopses and Sun BugID number of the more important bugs that have been fixed since the AP 2.1 release (Solaris 2.6 5/98). This list does not include all of the fixed bugs.

4126743 – AP disk autofailover hangs on simultaneous multi-pathgroup failures (this bug was fixed by BugID 4136249).

4126897 – Domain panics when there are no AP database and metadvice entry in `/etc/vfstab`.

4136249 – I/O's to SEVM RAID volumes hang after AP autofailover.

4141438 – `mhme` interface hangs under heavy use of network.

4143514 – FDDI with AP hangs with heavy use of network.

4147674 – AP causes `ifconfig` to hang on a mutex.

4153152 – `apconfig` works as an ordinary user.

4161396 – AP 2.x needs capability to work with GEM.

4163270 – `netstat` of network `ap` network meta interface shows no tallies.

4166620 – `snoop` of AP meta network interface stops snooping after switch.

4170818 – If you run the `$(callouts nadb` macro, or `fm2's "callout ts" command`, you see thousands of `qenable` timeouts in the timeshare callout table.

4180055 – Accessing an AP'd metadisk with a failed active alternate panics.

4180702 – Messages from `swap.c` are not internationalized.

4183581 – `apboot disk` causes `coredump` when `disk` is the same as the current boot disk.

4185154 – GigabitEthernet stress test hangs.

4188418 – It is possible for a hard disk error to go undetected by Veritas [SEVM].

4195441 – AP2.0 `ap_daemon` doesn't communicate with AP2.2.

4226867 – `ap_reboot_host` fails for photon in mixed AP versions.

4228731 – Non-existent network interfaces not marked as detached after reboot.

---

# Dynamic Reconfiguration on the Sun Enterprise 10000

Release notes and other technical information in this section apply only to the Solaris 7 5/99 version of Sun Enterprise 10000 Dynamic Reconfiguration (DR).

## General Issues

This section contains general issues that involve DR on the Sun Enterprise 10000 server. You should read this section before you attempt to install or configure DR.

### `dr-max-mem` Utility

The way `dr-max-mem` is used has changed since the Solaris 2.5.1 release. Please see the appropriate section of the Solaris 7 5/99 version of the *Sun Enterprise 10000 Dynamic Reconfiguration User's Guide* for a detailed description of this important OBP variable.

## DR and Bound User Processes

For the Solaris 7 5/99 operating environment, DR no longer automatically unbinds user processes from CPUs that are being detached. Users are now required to perform this operation themselves before initiating a DR Detach sequence. The DR Drain operation will fail if CPUs are found with bound processes.

## Nonpageable Memory Location

For the Solaris 7 5/99 operating environment, the location of nonpageable memory (that is, OBP and kernel memory), the kernel cage, resides in the highest physical address space, which generally is on the highest-numbered system board in the domain. The direction of growth of this area is from highest to lowest physical addresses. Exceptions to this rule do exist. Always use `drshow(1M)` to verify a board's memory state.

## Kernel Cage Location

For the Solaris 7 5/99 operating environment, the location of the kernel cage changed from the lowest numbered system board(s) to the highest numbered board(s). However, some customers require the kernel cage to be located on the lowest numbered system board. If you have this requirement, you can apply Patch 105873-08, as a minimum level, on the SSP to change the location of the cage. Refer to the Patch README file for instructions on how to install the patch. You can obtain the patch from

<http://sunsolve.corp.sun.com> or from your local service provider.

## DR and Tape Drives

For the Solaris 7 5/99 operating environment, the `st` driver, which has been considered DR unsafe in the past, is now DR safe. The driver now waits for existing I/O requests to complete before the drive is suspended.

## DR and SunFDDI

If your Sun Enterprise 10000 server contains any SunFDDI™ SBus Adapter 5.0 interfaces and you plan to use DR, you must install Sun Patch 104572-05, or the highest revision level available. You can obtain this patch at the following Web site:

- <http://sunsolve.corp.sun.com>

## DR and the Sun StorEdge A3000

Dynamic Reconfiguration of Sun™ StorEdge™ A3000 arrays on the Sun Enterprise 10000 running the Solaris 2.6 operating environment requires RAID Manager 6.01.00, or later, for correct operation.

## DR and the Sun StorEdge A5000

DR will be supported on systems configured with Sun StorEdge A5000 devices and the latest StorEdge A5000 patch. Contact your service provider for more information on how to obtain the patch.

For I/O boards connected to the A5000, you must ensure that the FC-AL disk firmware version is ST19171FC 0413 or newer version. For more information, refer to the following Web site:

- <http://sunsolve2.Sun.COM/sunsolve/Enterprise-dr/>



## DR and pln and soc Drivers

If you are using `pln` and/or `soc` drivers on your server, you must ensure that the parameters are properly set in the `/etc/system` file. The file should include the following two entries, exactly as they appear in the example.

```
set pln:pln_enable_detach_suspend=1
set soc:soc_enable_detach_suspend=1
```

## Quiesce Test

On a large system, the `quiesce-test` command `cfgadm -x quiesce-test sysctrl0:slotnumber` may run as long as a minute or so. During this time no messages are displayed if `cfgadm` does not find incompatible drivers. This is normal behavior.

## Known Bugs

This section contains the known bugs in the Sun Enterprise 10000 DR feature of the Solaris 7 5/99 release.

### DR Abort Detach May Not Resume All Detached Disks (4010910)

If a DR detach operation fails to detach an `sd` device and the controller has `sd` devices that have already been detached, the `abort-detach` operation does not resume (that is, re-attach) those devices that share the same controller instance and that have already been detached. This situation rarely occurs. The most likely time for it to happen is if the disk drive firmware is locked up.

Workaround: None

### dr\_daemon Does Not Find Veritas Device Usage (4011123)

Veritas software usage of disks is not displayed by DR applications in their device-usage displays.

Workaround: None

## `disks(1M)` Command Preens Controller Entries and Corrupts the Sun StorEdge A3000 Device Tree (4096048)

The Solaris `disks(1M)` command preens or deletes symbolic link entries when disk devices are no longer present in an Enterprise 10000 domain. If you have dynamically reconfigured the devices so that they are no longer present, the Symbios-managed device tree and the Solaris-managed device tree can become inconsistent.

Workaround: You must obtain the proper patch from SunSolve or from your service representative. This patch contains fixes that ensure persistent node names under the Solaris operating environment when StorEdge A3000 devices are dynamically reconfigured out of a given Enterprise 10000 domain. The patch ensures that when the same array is brought back into the domain, it inherits the same node name it originally had, thereby maintaining data availability without having to modify system mount points or user application configurations. You must ensure that you do not perform reconfiguration reboot operations (`boot -r`) in a domain when A3000 devices are present on the system boards.

## Cannot Drain and/or Detach Sun Enterprise Server System Boards that Host QFE Cards (4231845)

The configuration of a boot server for Solaris 2.5.1-based x86 clients results in the execution of `rpld` daemons. These daemons maintain an active (open) reference to all network devices, whether or not such devices are in use. These active references prevent DR operations from detaching these devices.

Workaround: Remove or rename the `/rplboot` directory, then shut down and restart NFS with these commands:

```
# sh /etc/init.d/nfs.server stop
# sh /etc/init.d/nfs.server start
```

## Sonoma Daemon Cannot Be Suspended (4100212)

The presence of Sonoma daemons (`rdaemon`) prevent a DR Detach operation from completing if the operating environment must be quiesced (that is, suspended and resumed) to detach non-pageable memory.

Workaround: Temporarily disable the daemon before the DR operation, then restart the daemon after the DR operation by using the following command:

```
# sh /etc/rc2.d/S90amon stop
# sh /etc/rc2.d/S90amon start
```

## Unable to Drain Sysboards in Solaris 7 and dr\_daemon Segmentation Faults (4229238)

After numerous iterations through a failure handling condition within the DR daemon, the daemon can encounter a segmentation violation (that is, a core dump). Note that this condition occurs during an error handling flow (that is, a DR operation failure).

Workaround: Restart the DR applications on the SSP.

## DR and Inter-Domain Networks

The Inter-Domain Network (IDN) software is not supported in this release. However, IDN messages may appear during DR detach operations. If you see any IDN-related messages you can safely ignore them.

## Bugs Fixed

The following important bugs have been fixed since the last release of DR. This list does not include minor bugs, nor does it include those bugs that were fixed in patches.

4083412 – `socal` and `sf` need to support DETACH/SUSPEND/RESUME

4090750 – DR panics during detach when `dr-max-mem` set is high.

4067860 – `SUNWcsr` on upgrading from Solaris 2.5.1 8/97 to Solaris 2.6 5/98 creates duplicate majors in `name_to_major`.

4131197 – `dr_daemon` core dumps with Solaris 2.6 5/98 release.

4133607 – DR operations with `mem_board_interleave_ok` cause problems.

4134357 – `availrmem` is not being reduced during Sun Enterprise 10000 memory detach.

4135366 – Sun StorEdge A3000 patch has been changed.

4136544 – Getting “flusher thread” hang during DR drain with official -20 KU patch.

## Sun Enterprise 6x00, 5x00, 4x00, and 3x00 Systems Open Issues

---

---

### AP on Sun Enterprise Servers

This section contains the release notes for Alternate Pathing (AP) 2.2 on all Sun Enterprise servers, except the Sun Enterprise 10000. See “AP on the Sun Enterprise 10000” for information about the Enterprise 10000 server.

---

**Note** – AP 2.2 is the first release of AP that supports Solaris 7 5/99.

---

AP enables you to define and control alternate physical paths to peripheral devices, adding increased availability and a level of fault recovery to your server. If a physical path to a device becomes unavailable, an alternate path can be used. For more information, see the *Sun Enterprise Server AP User's Guide* in the Solaris 7 5/99 on Sun Hardware Collection AnswerBook2™.

---

**Note** – At the time of this printing, AP 2.2 Beta is not compatible with any version of Sun Enterprise Volume Manager™ (SEVM).

---

### Installation Issues

If you are upgrading from the Solaris 2.6 operating environment to the Solaris 7 5/99 operating environment and have AP 2.1 and Solstice™ DiskSuite™ 4.0 or 4.1 (SDS) on your system, you must upgrade to AP 2.2 and SDS 4.2. This section

contains an overview of the entire process, which requires you to use several sections from different publications. You should ensure that you have the following publications before you start the upgrade:

- *Solaris 7 5/99 Beta Release Notes Supplement for Sun Hardware* (available in printed form in your Solaris 7 5/99 Media Kit)
- *Solaris 7 5/99 Sun Hardware Platform Guide*, (available in printed form in your Solaris 7 5/99 Media Kit or in AnswerBook2 format on the Sun Hardware Supplements CD)
- *Sun Enterprise Server Alternate Pathing User's Guide* (available in AnswerBook2 format on the Sun Hardware Supplements CD in your Solaris 7 5/99 Media Kit)
- *Solstice DiskSuite 4.2 User's Guide* (available in AnswerBook2 format from <http://docs.sun.com> or from your SDS Media Kit)
- *Solstice DiskSuite 4.2 Installation and Product Notes* (available in AnswerBook2 format from <http://docs.sun.com> or from your SDS Media Kit)



---

**Caution** – You must follow the sequence given here to successfully complete the upgrade.

---

In general, you will perform the following tasks:

- Unconfigure SDS 4.0 or 4.1.
- Remove AP 2.1.
- Upgrade to the Solaris 7 5/99 operating environment.
- Install AP 2.2.
- Install and reconfigure SDS 4.2.

Specifically, you must perform the following tasks:

1. Read “Performing an Upgrade of AP” in the *Solaris 7 5/99 Sun Hardware Platform Guide*.
2. Commit any uncommitted AP metadevices (see Step 1 in “To Upgrade AP” in the *Solaris 7 5/99 Sun Hardware Platform Guide*).
3. Deconfigure SDS (see steps 1 through 8 in “How to Convert to DiskSuite 4.2 on SPARC Systems Running DiskSuite 4.0 or 4.1” in the *Solstice DiskSuite 4.2 Installation and Product Notes*).



---

**Caution** – Do not install Solaris 7 5/99 at this time.

---

4. Remove the current AP configuration (see Step 3 in “To Upgrade AP” in the *Solaris 7 5/99 Sun Hardware Platform Guide*).
5. Upgrade to Solaris 7 5/99 (see Step 4 in “To Upgrade AP” in the *Solaris 7 5/99 Sun Hardware Platform Guide*).

6. Upgrade to AP 2.2 (see Step 5 in “To Upgrade AP” in the Solaris 7 5/99 Sun Hardware Platform Guide).
7. Install SDS 4.2, then restore it (see Step 6 in “To Upgrade AP” in the Solaris 7 5/99 Sun Hardware Platform Guide and steps 10 through 16 in “How to Convert to DiskSuite 4.2 on SPARC Systems Running DiskSuite 4.0 or 4.1” in Chapter 1 of the *Solstice DiskSuite 4.2 Installation and Product Notes*).

## General Issues

This section contains general issues that involve AP on Sun Enterprise servers. Read this section before you attempt to install or configure AP.

## Supported Devices

The following devices are supported by the AP software on Sun Enterprise servers:

- SPARCstorage™ Arrays recognized by AP using the `pln`, `soc`, and `ssd` ports
- Sun™ StorEdge™ A5000 recognized by AP using `sf`, `socal`, and `ssd` ports
- SunFastEthernet™ 2.0 (`hme`)
- SunFDDI™ 5.0 (`nf`) SAS (Single-Attach Station) and DAS (Dual-Attach Station)
- SCSI-2/Buffered Ethernet FSBE/S and DSBE/S (`le`)
- Quad Ethernet (`qe`)
- Sun™ Quad FastEthernet™ (`qfe`)
- Sun GigabitEthernet 2.0 (`ge`)

The following table lists which devices are supported in which releases:

**TABLE 5-1** Supported Network Devices

	AP 2.0	AP 2.1	AP 2.2
Solaris 2.5.1	<code>hme</code> , <code>le</code> , <code>nf</code> , <code>bf</code> , <code>hi</code> , <code>qe</code> , <code>qfe</code>	N/A	N/A
Solaris 2.6 (5/98)	N/A	<code>ge</code> , <code>hme</code> , <code>le</code> , <code>nf</code> , <code>qe</code> , <code>qfe</code> , <code>vge</code>	N/A
Solaris 7 5/99	N/A	N/A	<code>ge</code> , <code>hme</code> , <code>le</code> , <code>nf</code> , <code>qe</code> , <code>qfe</code>

## SunFDDI and GigabitEthernet Devices

AP 2.2 validation tests were performed on SunFDDI (revision 6.0) and GigabitEthernet (revision 2.0). If you install either of these devices, you must use the revision level that was tested, unless a higher revision level exists. In addition, you must install all of the available patches for these devices. Refer to <http://www.sunsolve.sun.com> for more information about the patches.

## Sun StorEdge A3000

The Sun StorEdge A3000 supports failover capabilities that are similar to those provided by AP. Because of this, AP does not support the Sun StorEdge A3000. See that product's documentation for more information about its failover support.

## Sun StorEdge A5000

AP supports the Sun StorEdge A5000 for this release.

## Sun StorEdge A7000

AP 2.2 does not support the Sun StorEdge A7000 for this release.

## Software Compatibility

The following lists includes the possible combinations of AP and Solaris software you can install on a Sun Enterprise server.

- Solaris 2.6 5/98 with AP 2.1 and DR
- Solaris 7 with AP 2.2 and DR
- Solaris 7 5/99 with AP 2.2 and DR

## Known Bugs

The following bugs are known to exist in the Beta version of AP 2.2:



## Fixed Bugs

This section contains the synopses and Sun BugID number of the more important bugs that have been fixed since the AP 2.1 release (Solaris 2.6 5/98). This list does not include all of the fixed bugs.

4126743 – AP disk autofailover hangs on simultaneous multi-pathgroup failures (this bug was fixed by BugID 4136249).

4126897 – Domain panics when there are no AP database and metadvice entry in `/etc/vfstab`.

4136249 – I/O's to SEVM RAID volumes hang after AP autofailover.

4141438 – `mhme` interface hangs under heavy use of network.

4143514 – FDDI with AP hangs with heavy use of network.

4147674 – AP causes `ifconfig` to hang on a mutex.

4153152 – `apconfig` works as an ordinary user.

4161396 – AP 2.x needs capability to work with GEM.

4163270 – `netstat` of network ap network meta interface shows no tallies.

4166620 – `snoop` of AP meta network interface stops snooping after switch.

4170818 – If you run the `$<callouts nadb` macro, or `fm2`'s “callout ts” command, you see thousands of `qenable` timeouts in the timeshare callout table.

4180055 – Accessing an AP'd metadisk with a failed active alternate panics.

4180702 – Messages from `swap.c` are not internationalized.

4183581 – `apboot disk` causes `coredump` when `disk` is the same as the current boot disk.

4185154 – AP GigabitEthernet stress test hands.

4188418 – It is possible for a hard disk error to go undetected by Veritas [SEVM].

4195441 – AP2.0 `ap_daemon` doesn't communicate with AP2.2.

4228731 – Non-existent network interfaces not marked as detached after reboot.

---

# Dynamic Reconfiguration of Sun Enterprise 6x00, 5x00, 4x00, and 3x00 Systems

These release notes provide the latest information on Dynamic Reconfiguration (DR) functionality for Sun Enterprise 6x00, 5x00, 4x00, and 3x00 systems running update version 5/99 of the Solaris 7 product line from Sun Microsystems. For more information on Sun Enterprise Server Dynamic Reconfiguration, refer to the *Dynamic Reconfiguration User's Guide for Sun Enterprise 3x00/4x00/5x00/6x00 Systems*.

The 5/99 update includes support for CPU/Memory boards on Sun Enterprise 6x00, 5x00, 4x00, and 3x00 systems.

## Supported Hardware

Before proceeding, ensure the system supports dynamic reconfiguration. If you see the following message on your console or in your console logs, the hardware is of an older design and not suitable for dynamic reconfiguration.

```
Hot Plug not supported in this system
```

Supported I/O boards are listed in the “Solaris 7 5/99” section on the web site

<http://sunsolve5.sun.com/sunsolve/Enterprise-dr/>

I/O board type 2 (graphics), type 3 (PCI), and type 5 (graphics and SOC+) are not currently supported.

## Firmware Notes

### FC-AL Disk Arrays or Internal Drives

For Sun StorEdge A5000 disk arrays or for internal FC-AL disks in the Sun Enterprise 3500 system, the firmware version must be ST19171FC 0413 or later. For more information, refer to the “Solaris 7 5/99” section at the web site:

<http://sunsolve5.sun.com/sunsolve/Enterprise-dr/>

## PROM Updates for CPU and I/O Boards

Users of Solaris 7 5/99 software who wish to use dynamic reconfiguration must be running CPU PROM version 3.2.22 (firmware patch ID 103346-22) or later. This firmware is available from the web site. See “How To Obtain Firmware” on page 59.

Older versions of the CPU PROM may display the following message during boot:

```
Firmware does not support Dynamic Reconfiguration
```



**Caution** – CPU PROM 3.2.16 and earlier versions do not display this message, although they do not support dynamic reconfiguration of CPU/memory boards.

- **To see your current PROM revision, enter `.version` and banner at the `ok` prompt. Your display will be similar to the following:**

```
ok .version
Slot 0 - I/O Type 1 FCODE 1.8.22 1999/xx/xx 19:26 iPOST 3.4.22 1999/xx/xx 19:31
Slot 1 - I/O Type 1 FCODE 1.8.22 1999/xx/xx 19:26 iPOST 3.4.22 1999/xx/xx 19:31
Slot 2 - CPU/Memory OBP 3.2.22 1999/xx/xx 19:27 POST 3.9.22 1999/xx/xx 19:31
Slot 3 - I/O Type 4 FCODE 1.8.22 1999/xx/xx 19:27 iPOST 3.4.22 1999/xx/xx 19:31
Slot 4 - CPU/Memory OBP 3.2.22 1999/xx/xx 19:27 POST 3.9.22 1999/xx/xx 19:31
Slot 5 - CPU/Memory OBP 3.2.22 1999/xx/xx 19:27 POST 3.9.22 1999/xx/xx 19:31
Slot 6 - CPU/Memory OBP 3.2.22 1999/xx/xx 19:27 POST 3.9.22 1999/xx/xx 19:31
Slot 7 - CPU/Memory OBP 3.2.22 1999/xx/xx 19:27 POST 3.9.22 1999/xx/xx 19:31
Slot 9 - CPU/Memory OBP 3.2.22 1999/xx/xx 19:27 POST 3.9.22 1999/xx/xx 19:31
Slot 11 - CPU/Memory OBP 3.2.22 1999/xx/xx 19:27 POST 3.9.22 1999/xx/xx 19:31
Slot 12 - CPU/Memory OBP 3.2.22 1999/xx/xx 19:27 POST 3.9.22 1999/xx/xx 19:31
Slot 14 - CPU/Memory OBP 3.2.22 1999/xx/xx 19:27 POST 3.9.22 1999/xx/xx 19:31
ok banner
16-slot Sun Enterprise E6500
OpenBoot 3.2.22, 4672 MB memory installed, Serial #xxxxxxxx.
Ethernet address 8:0:xx:xx:xx:xx, Host ID: xxxxxxxx.
```

## How To Obtain Firmware

For information about updating your firmware, refer to the “Solaris 7 5/99” section at the web site.

<http://sunsolve5.sun.com/sunsolve/Enterprise-dr/>

At this site, you will find information on how to:

- Download the DR-capable PROM firmware
- Upgrade the PROM

If you cannot use the web site, contact your Sun support service provider for assistance.

## Software Notes

### Enabling Dynamic Reconfiguration

In the `/etc/system` file, two variables must be set to enable dynamic reconfiguration and an additional variable must be set to enable the removal of CPU/memory boards.

1. **Log in as root.**
2. **To enable dynamic reconfiguration, edit the `/etc/system` file and add the following lines to the `/etc/system` file:**

```
set pln:pln_enable_detach_suspend=1
set soc:soc_enable_detach_suspend=1
```

3. **To enable the removal of a CPU/memory board, add this line to the `/etc/system` file:**

```
set kernel_cage_enable=1
```

Setting this variable enables the memory unconfiguration operation.

4. **Reboot the system to put the changes into effect.**

### Quiesce Test

On a large system, the `quiesce-test` command (`cfgadm -x quiesce-test sysctrl0:slot $number$` ) may run as long as a minute or so. During this time no messages are displayed if `cfgadm` does not find incompatible drivers. This is normal behavior.

## Disabled Board List

If a board is on the disabled board list, an attempt to connect the board may produce an error message:

```
# cfgadm -c connect sysctrl0:slotnumber
cfgadm: Hardware specific failure: connect failed: board is
disabled: must override with [-f][-o enable-at-boot]
```

- **To override the disabled condition, use the force flag (-f) or the enable option (-o enable-at-boot) with the cfgadm command:**

```
# cfgadm -f -c connect sysctrl0:slotnumber
```

```
# cfgadm -o enable-at-boot -c connect sysctrl0:slotnumber
```

- **To remove all boards from the disabled board list, set the disabled-board-list variable to a null set with the system command:**

```
# eeprom disabled-board-list=
```

- **If you are at the OpenBoot prompt, use this OBP command instead to remove all boards from the disabled board list:**

```
OK set-default disabled-board-list
```

For further information about the `disabled-board-list` setting, refer to the section “Specific NVRAM Variables” in the *Platform Notes: Sun Enterprise 3x00, 4x00, 5x00, and 6x00 Systems*, part number 805-4454.

## Disabled Memory List

For information about the OBP `disabled-memory-list` setting, refer to the section “Specific NVRAM Variables” in the *Platform Notes: Sun Enterprise 3x00, 4x00, 5x00, and 6x00 Systems*, part number 805-4454.

## Unloading Detach-Unsafe Drivers

If it is necessary to unload detach-unsafe drivers, use the `modinfo(1M)` line command to find the module IDs of the drivers. You can then use the module IDs in the `modunload(1M)` command to unload detach-unsafe drivers.

## Interleaved Memory

A memory board or CPU/memory board that contains interleaved memory cannot be dynamically unconfigured.

To determine if memory is interleaved, use the `prtdiag` command or the `cfgadm` command.

To permit DR operations on CPU/memory boards, set the NVRAM `memory-interleave` property to `min`.

For related information about interleaved memory, see “Memory Interleaving Set Incorrectly After a Fatal Reset, Bug-ID 4156075” on page 63 and “DR: Cannot Unconfigure a CPU/Memory Board That Has Interleaved Memory, Bug ID 4210234” on page 65.

## Self-test Failure During a Connect Sequence

If the error “`cfgadm: Hardware specific failure: connect failed: firmware operation error`” is displayed during a DR connect sequence, remove the board from the system as soon as possible. The board has failed self-test, and removing the board avoids possible reconfiguration errors that can occur during the next reboot.

If you want to immediately retry the failed operation, you must first remove and reinsert the board, because the board status does not allow further operations.

## Dynamic Reconfiguration Feature in Sun Enterprise SyMON Software

As noted in the *Dynamic Reconfiguration User's Guide for Sun Enterprise 3x00/4x00/5x00/6x00 Systems*, Sun Enterprise SyMON system monitoring and management software supports dynamic reconfiguration. However, the user's guide listed the wrong reference. The correct reference is *Sun Enterprise SyMON 2.0.1 Supplement for Sun Enterprise Midrange Servers*, part number 806-0649.

# Known Bugs

## `cfgadm -v` Not Working Properly, bug-ID 4149371

Category: RFE

The memory test should give occasional indications that it is still running. During a long test, the user cannot easily determine that the system is not hanging.

Workaround: Monitor system progress in another shell or window, using `vmstat(1M)`, `ps(1)`, or similar shell commands.

## Memory Interleaving Set Incorrectly After a Fatal Reset, Bug-ID 4156075

Category: Bug

Memory interleaving is left in an incorrect state after a Sun Enterprise X500 server encounters a Fatal Reset. Subsequent DR operations fail. The problem only occurs on systems with memory interleaving set to `min`.

Workarounds: Two choices are listed below.

- To clear the problem after it occurs, manually reset the system at the `OK` prompt.
- To avoid the problem before it occurs, set the NVRAM `memory-interleave` property to `max`. This causes memory to be interleaved whenever the system is booted. However, you may find this option to be unacceptable, as a memory board containing interleaved memory cannot be dynamically unconfigured. See “DR: Cannot Unconfigure a CPU/Memory Board That Has Interleaved Memory, Bug ID 4210234” on page 65.

## `vmstat` Output Is Incorrect After Configuring Processors, Bug-ID 4159024

Category: Bug

vmstat shows an unusually high number of interrupts after configuring CPUs. With vmstat in the background, the interrupt field becomes abnormally large (but this does not indicate a problem exists). In the last row in the example below, the interrupts (in) column has a value of 4294967216:

#	procs			memory		page				disk				faults				cpu				
	r	b	w	swap	free	re	mf	pi	po	fr	de	sr	s6	s9	s1	--	in	sy	cs	us	sy	id
0	0	0	0	437208	146424	0	1	4	0	0	0	0	0	1	0	0	50	65	79	0	1	99
0	0	0	0	413864	111056	0	0	0	0	0	0	0	0	0	0	0	198	137	214	0	3	97
0	0	0	0	413864	111056	0	0	0	0	0	0	0	0	0	0	0	286	101	200	0	3	97
0	0	0	0	413864	111072	0	11	0	0	0	0	0	1	0	0	0	4294967216	43	68	0	0	100

Workaround: Restart vmstat.

## POST System Board Status Displays Only 1 of the 2 Failing CPUs, Bug-ID 4200513

Category: Bug

If two CPUs on a single board fail before reporting to the master CPU, the POST system status display lists one CPU as failing, but the second CPU may not be listed at all.

Workaround: None.



## DR: Cannot Unconfigure a CPU/Memory Board That Has Interleaved Memory, Bug ID 4210234

Category: RFE

Cannot unconfigure a CPU/Memory board that has interleaved memory.

To unconfigure and subsequently disconnect a CPU board with memory or a memory-only board, it is necessary to first unconfigure the memory. However, if the memory on the board is interleaved with memory on other boards, the memory cannot currently be unconfigured dynamically.

Memory interleaving can be displayed using the `prtdiag` or the `cfgadm` commands.

Workaround: Shut down the system before servicing the board, then reboot afterward. To permit future DR operations on the CPU/memory board, set the NVRAM `memory-interleave` property to `min`. See also “Memory Interleaving Set Incorrectly After a Fatal Reset, Bug-ID 4156075” on page 63 for a related discussion on interleaved memory.

## DR: Cannot Unconfigure a CPU/Memory Board That Has Permanent Memory, Bug ID 4210280

Category: RFE

To unconfigure and subsequently disconnect a CPU board with memory or a memory-only board, it is necessary to first unconfigure the memory. However, some memory is not currently relocatable. This memory is considered permanent.

Permanent memory on a board is marked “permanent” in the `cfgadm` status display:

```
# cfgadm -s cols=ap_id:type:info
Ap_Id Type Information
ac0:bank0 memory slot3 64Mb base 0x0 permanent
ac0:bank1 memory slot3 empty
ac1:bank0 memory slot5 empty
ac1:bank1 memory slot5 64Mb base 0x40000000
```

In this example, the board in slot3 has permanent memory and so cannot be removed.

Workaround: Shut down the system before servicing the board, then reboot afterward.

## cfgadm Disconnect Fails When Running Concurrent cfgadm Commands, Bug-ID 4220105

Category: Bug

If a `cfgadm` process is running on one board, an attempt to simultaneously disconnect a second board fails.

A `cfgadm` disconnect operation fails if another `cfgadm` process is already running on a different board. The message is:

```
cfgadm: Hardware specific failure: disconnect failed: nexus error
during detach: address
```

**Workaround:** Do only one `cfgadm` operation at a time. If a `cfgadm` operation is running on one board, wait for it to finish before you start a `cfgadm` disconnect operation on a second board.

## Fatal Reset on `init 5` After DR Operations, Bug-ID 4220852

Category: Bug

After DR operations have been run, an attempt to power down a system with the `init 5` command may cause a fatal reset.

**Workaround:** Reset the system, then power it off by entering the command `power-off` at the `ok` prompt.

## Cannot Drain And/or Detach Sun Enterprise Server Boards That Host QFE Cards, Bug-ID 4231845

When a server is configured as a boot server for Solaris 2.5.1-based x86 clients, it has several `rpld` jobs running, whether or not such devices are in use. These active references prevent DR operations from detaching these devices.

**Workaround:** To perform a DR detach operation:

1. **Remove or rename the `/rplboot` directory.**
2. **Shut down NFS services with this command:**

```
# sh /etc/init.d/nfs.server stop
```

**3. Perform the DR detach operation.**

**4. Restart NFS services with this command:**

```
# sh /etc/init.d/nfs.server start
```

