



# Sun Fire™ E2900/V1280 and Netra™ 1280 Slide Rail Installation Kit Guide

---

Sun Fire E2900/V1280/Netra 1280 systems utilize a slide rail mounting kit containing the following:

- Inner/outer slides (2 each)
- Locking spacers (2 each)
- Locking nuts (2 each)
- 8 MM wrench

The kit contents are used to mount and secure one or more systems in a cabinet.

The rails are used for mounting one or more systems in a cabinet and the locking spacers and nuts are to secure systems mounted in a cabinet when the cabinet is to be moved. For Netra 1280 systems mounted in cabinets the locking spacers and nuts are required for NEBS certification.

---

**Note** – Only systems mounted in Sun Fire and StorEdge cabinets utilize the adjustable bracket included with the rails, for all other installations the adjustable bracket is removed and discarded.

---

For all types of installation, first refer to the install manual for your system and perform as indicated in Section 1.1.2, “Installing the Inner Slides on the System” on page 1-4. Once the inner slides are mounted on a system, refer to TABLE 1 and perform the sectional procedure applicable to your installation type.

**TABLE 1** Installation Type Versus Install Manual Reference Section

<b>Installation Type</b>	<b>Reference Section</b>
Two-post	Section 1.1.3, "Preparing the Rails for Two-Post Installations" on page 1-6
Sun Fire/ StorEdge cabinet	Section 1.1.4, "Installing the Rail Assemblies in a Sun Fire/StorEdge Cabinet" on page 1-7
Sun Rack 900 cabinet	Section 1.1.5, "Installing the Rail Assemblies in a Sun Rack 900 Cabinet" on page 1-9
19 inch 4-post	Section 1.1.6, "Installing the Rail Assemblies in a 19-Inch Four-Post Cabinet" on page 1-11
19-inch 4-post	Section 1.1.7, "Installing the Rail Assemblies in a 19-inch Two-Post Rack" on page 1-12

## Locking Nut and Spacer Installation

The locking spacers and nuts provided in the kit are not required for post installations. For all cabinet installations refer to the install manual for your system and the following table which references locking spacer and nut procedures which are contained in an applicable section of the system install manual.

**TABLE 2** Platform Install Manual Versus Locking Nut/Spacer Install Reference Section

<b>Platform</b>	<b>Reference Section</b>
E2900	Section 1.3, "Installing Slide Rail Locking Nuts" on page 1-19
V1280/Netra 1280	Section 1.3, "Installing Slide Rail Locking Nuts" on page 1-19

## Accessing Sun Documentation

You can view, print, or purchase a broad selection of Sun documentation, including localized versions, at:

<http://www.sun.com/documentation>

## Third-Party Web Sites

Sun is not responsible for the availability of third-party web sites mentioned in this document. Sun does not endorse and is not responsible or liable for any content, advertising, products, or other materials that are available on or through such sites or resources. Sun will not be responsible or liable for any actual or alleged damage or loss caused by or in connection with the use of or reliance on any such content, goods, or services that are available on or through such sites or resources.

## Contacting Sun Technical Support

If you have technical questions about this product that are not answered in this document, go to:

<http://www.sun.com/service/contacting>

## Sun Welcomes Your Comments

Sun is interested in improving its documentation and welcomes your comments and suggestions. You can submit your comments by going to:

<http://www.sun.com/hwdocs/feedback>

Please include the title and part number of your document with your feedback:

*Sun Fire E2900/V1280 and Netra 1280 Slide Rail Installation Kit Guide*, part number 819-4152-10

Copyright 2005 Sun Microsystems, Inc. All rights reserved. Use is subject to license terms. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers. Portions may be derived from Berkeley BSD systems, licensed from U. of CA. Sun, Sun Microsystems, the Sun logo, Java, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and in other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and in other countries. U.S. Government Rights—Commercial use. Government users are subject to the Sun Microsystems, Inc. standard license agreement and applicable provisions of the FAR and its supplements.

Copyright 2005 Sun Microsystems, Inc. Tous droits réservés. Distribué par des licences qui en restreignent l'utilisation. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun. Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. Sun, Sun Microsystems, le logo Sun, Java, et Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays.



Sun Microsystems, Inc.  
[www.sun.com](http://www.sun.com)