

Policy Management

Release 8.0

Roadmap to Hardware Documentation

910-6441-001 Revision A

June 2012



Copyright 2012 Tekelec. All Rights Reserved. Printed in USA.

Legal Information can be accessed from the Main Menu of the optical disc or on the Tekelec Customer Support web site in the *Legal Information* folder of the *Product Support* tab.

Table of Contents

- Chapter 1: Introduction.....5**
 - About this Manual.....6
 - Scope and Audience.....6
 - Organization.....6
 - Documentation Admonishments.....6
 - Customer Care Center.....7
 - Emergency Response.....9
 - Related Publications.....10
 - Locate Product Documentation on the Customer Support Site.....10

- Chapter 2: Roadmap.....11**
 - Introduction.....12
 - General Descriptions and Hardware Features.....12
 - User Operations - LEDs.....13
 - Policy Management Platform Configuration.....13

List of Figures

Figure 1: Example of Policy Management c-Class Cabinet Configuration (DC).....14
Figure 2: Example of Policy Management c-Class Cabinet Configuration (AC).....15

List of Tables

Table 1: Admonishments.....	7
-----------------------------	---

Chapter 1

Introduction

Topics:

- *About this Manual.....6*
- *Scope and Audience.....6*
- *Organization.....6*
- *Documentation Admonishments.....6*
- *Customer Care Center.....7*
- *Emergency Response.....9*
- *Related Publications.....10*
- *Locate Product Documentation on the Customer Support Site.....10*

About this Manual

This document is an aid to navigate the respective manufacturer online documentation related to the Tekelec Policy Management (Policy). This document provides links to typical hardware-related user information. The referenced documentation includes hardware descriptions and operation information.

The hardware included with Policy utilizes the HP ProLiant G6/G7 line of servers mounted in an HP 10000 G2 Series cabinet. Dependent upon customer order and system configuration delivered, the cabinet may be powered by either an AC or DC input from the customer site. There are separate cabinet assemblies for AC or DC installations.

The individual customer ordered system configuration dictates the components installed in the cabinet. The components shipped in the cabinet may include:

- DC cabinet assembly - Telect 100A 4-Position Demarcation DC Power Distribution Panel ([Telect 100A 4-Position Demarcation Circuit Breaker panel, ±24V/-48V](#))
- DC cabinet assembly - Telect 100A Dual-feed DC Power Distribution Panel ([Telect 100A Dual-feed 4/4 TPA/GMT, -48V](#))
- AC cabinet assembly - AC Power Distribution Unit ([HP 252663 Modular Power Distribution Unit](#))
- HP BladeSystem c7000 Enclosure ([Technologies in the HP BladeSystem c7000 Enclosure](#))
- PM&C Management Server ([HP ProLiant DL360 G6 Server](#))
- Aggregation Switch ([Cisco Catalyst 4948E Series Switch](#))
- Ethernet Switch ([Cisco Catalyst 4948E-F Series Switch Installation](#))

Scope and Audience

Note: All personnel must be aware of and conform to the safety information provided throughout the documentation included with this product.

Testing, system software, or applications software are not discussed in this manual.

Organization

This manual is organized into the following chapters:

- [Introduction](#) provides information about the manual and installation support.
- [Roadmap](#) points to the respective manufacturer documentation for typical user information.

Documentation Admonishments

Admonishments are icons and text throughout this manual that alert the reader to assure personal safety, to minimize possible service interruptions, and to warn of the potential for equipment damage.

Table 1: Admonishments

	DANGER: (This icon and text indicate the possibility of <i>personal injury</i> .)
	WARNING: (This icon and text indicate the possibility of <i>equipment damage</i> .)
	CAUTION: (This icon and text indicate the possibility of <i>service interruption</i> .)

Customer Care Center

The Tekelec Customer Care Center is your initial point of contact for all product support needs. A representative takes your call or email, creates a Customer Service Request (CSR) and directs your requests to the Tekelec Technical Assistance Center (TAC). Each CSR includes an individual tracking number. Together with TAC Engineers, the representative will help you resolve your request.

The Customer Care Center is available 24 hours a day, 7 days a week, 365 days a year, and is linked to TAC Engineers around the globe.

Tekelec TAC Engineers are available to provide solutions to your technical questions and issues 7 days a week, 24 hours a day. After a CSR is issued, the TAC Engineer determines the classification of the trouble. If a critical problem exists, emergency procedures are initiated. If the problem is not critical, normal support procedures apply. A primary Technical Engineer is assigned to work on the CSR and provide a solution to the problem. The CSR is closed when the problem is resolved.

Tekelec Technical Assistance Centers are located around the globe in the following locations:

Tekelec - Global

Email (All Regions): support@tekelec.com

- **USA and Canada**

Phone:

1-888-FOR-TKLC or 1-888-367-8552 (toll-free, within continental USA and Canada)

1-919-460-2150 (outside continental USA and Canada)

TAC Regional Support Office Hours:

8:00 a.m. through 5:00 p.m. (GMT minus 5 hours), Monday through Friday, excluding holidays

- **Caribbean and Latin America (CALA)**

Phone:

USA access code +1-800-658-5454, then 1-888-FOR-TKLC or 1-888-367-8552 (toll-free)

TAC Regional Support Office Hours (except Brazil):

10:00 a.m. through 7:00 p.m. (GMT minus 6 hours), Monday through Friday, excluding holidays

- **Argentina**

Phone:

0-800-555-5246 (toll-free)

- **Brazil**

Phone:

0-800-891-4341 (toll-free)

TAC Regional Support Office Hours:

8:00 a.m. through 5:48 p.m. (GMT minus 3 hours), Monday through Friday, excluding holidays

- **Chile**

Phone:

1230-020-555-5468

- **Colombia**

Phone:

01-800-912-0537

- **Dominican Republic**

Phone:

1-888-367-8552

- **Mexico**

Phone:

001-888-367-8552

- **Peru**

Phone:

0800-53-087

- **Puerto Rico**

Phone:

1-888-367-8552 (1-888-FOR-TKLC)

- **Venezuela**

Phone:

0800-176-6497

- **Europe, Middle East, and Africa**

Regional Office Hours:

8:30 a.m. through 5:00 p.m. (GMT), Monday through Friday, excluding holidays

- **Signaling**

Phone:

+44 1784 467 804 (within UK)

- **Software Solutions**

Phone:

+33 3 89 33 54 00

- **Asia**

- **India**

Phone:

+91 124 436 8552 or +91 124 436 8553

TAC Regional Support Office Hours:

10:00 a.m. through 7:00 p.m. (GMT plus 5 1/2 hours), Monday through Saturday, excluding holidays

- **Singapore**

Phone:

+65 6796 2288

TAC Regional Support Office Hours:

9:00 a.m. through 6:00 p.m. (GMT plus 8 hours), Monday through Friday, excluding holidays

Emergency Response

In the event of a critical service situation, emergency response is offered by the Tekelec Customer Care Center 24 hours a day, 7 days a week. The emergency response provides immediate coverage, automatic escalation, and other features to ensure that the critical situation is resolved as rapidly as possible.

A critical situation is defined as a problem with the installed equipment that severely affects service, traffic, or maintenance capabilities, and requires immediate corrective action. Critical situations affect service and/or system operation resulting in one or several of these situations:

- A total system failure that results in loss of all transaction processing capability
- Significant reduction in system capacity or traffic handling capability
- Loss of the system's ability to perform automatic system reconfiguration
- Inability to restart a processor or the system
- Corruption of system databases that requires service affecting corrective actions
- Loss of access for maintenance or recovery operations
- Loss of the system ability to provide any required critical or major trouble notification

Any other problem severely affecting service, capacity/traffic, billing, and maintenance capabilities may be defined as critical by prior discussion and agreement with the Tekelec Customer Care Center.

Related Publications

For information about additional publications that are related to this document, refer to the *Related Publications* document. The *Related Publications* document is published as a part of the *Release Documentation* and is also published as a separate document on the Tekelec Customer Support Site.

Locate Product Documentation on the Customer Support Site

Access to Tekelec's Customer Support site is restricted to current Tekelec customers only. This section describes how to log into the Tekelec Customer Support site and locate a document. Viewing the document requires Adobe Acrobat Reader, which can be downloaded at www.adobe.com.

1. Log into the [Tekelec Customer Support](#) site.

Note: If you have not registered for this new site, click the **Register Here** link. Have your customer number available. The response time for registration requests is 24 to 48 hours.

2. Click the **Product Support** tab.
3. Use the Search field to locate a document by its part number, release number, document name, or document type. The Search field accepts both full and partial entries.
4. Click a subject folder to browse through a list of related files.
5. To download a file to your location, right-click the file name and select **Save Target As**.

Chapter 2

Roadmap

Topics:

- *Introduction.....12*
- *General Descriptions and Hardware Features.....12*
- *User Operations - LEDs.....13*
- *Policy Management Platform Configuration.....13*

Introduction

This chapter contains links as an aid to navigate the respective manufacturer online documentation related to the Tekelec Policy Management (Policy).

Note: Viewing the user online documentation requires Internet access. For the most current user documentation, always reference the latest manufacturer online documentation.

Not all components, features, or documents referenced in this aid may be installed or used. For any questions related to available components or hardware features, contact your Sales representative. For assistance with the content of the referenced user documentation or help with procedures, contact the Tekelec [Customer Care Center](#).

General Descriptions and Hardware Features

This category directs you to the manufacturer online documentation that provides general descriptions of equipment including hardware features available.

Note: Not all features presented in the manufacturer documentation may be supported by this configuration. Contact the Tekelec [Customer Care Center](#) for additional information.

- [HP BladeSystem c-Class architecture technology brief](#) provides a general explanation of c-Class architecture and describes how the components within BladeSystem c-Class work together.
- [Important Safety Information - For Server, Storage, Power, Networking, and Rack Products](#) contains important safety information concerning Server, Storage, Power, Networking, and Rack Products.
- The [HP 10000 G2 Series Racks User Guide](#) provides additional installation information for the HP 10000 G2 Series Racks.
- [Best practices for HP 10000 Series and HP 10000 G2 Series Racks](#) outlines recommended practices for configuring, installing, transporting, and establishing a work environment for the HP 10000 and HP 10000 Generation 2 (G2) Series Racks.
- [HP ProLiant Intel-based 300-series G6 and G7 servers](#) describes the key technologies implemented in Intel-based HP ProLiant 300-series G6 and G7 servers.
- [HP ProLiant DL360 G6 Server User Guide](#) describes the HP ProLiant DL360 G6 Server system features and components.
- [Cisco Catalyst 4948E-F Series Switch Installation](#) describes the Cisco Catalyst 4948E-F switches, as well as system features and components.
- [Telect 100A 4-Position Demarcation Circuit Breaker panel, ±24V/-48V](#) describes the Telect 100A 4-Position Demarcation DC Power Distribution Panel.
- [Telect 100A Dual-feed 4/4 TPA/GMT, -48V](#) describes the Telect 100A Dual-feed DC Power Distribution Panel.
- [HP 252663 Modular Power Distribution Unit with Extension Bars](#) describes the AC Power Distribution Unit.

User Operations - LEDs

This category directs you to specific sections of the manufacturer online documentation on LED indicators for the specified equipment.



WARNING: Customers do not perform installation procedures; these procedures are performed by Tekelec authorized personnel. Contact the Tekelec [Customer Care Center](#) for assistance with any procedure.




WARNING: Performing any procedure not authorized or approved by Tekelec may void any or all Tekelec warranties. Contact the Tekelec [Customer Care Center](#) for assistance with any procedure.

- The section [Front Panel LEDs in the Catalyst 4948E-F Switch Installation Guide](#) describes LED functions of the Cisco Catalyst 4948E-F switch.
- The section [Front panel LEDs and buttons in the HP ProLiant DL360 G6 Server User Guide](#) provides information describing LED functions of the DL 360 server.
- See [Telect 100A 4-Position Demarcation Circuit Breaker panel](#) for information describing the Telect 100A 4-Position Demarcation DC Power Distribution Panel LEDs.
- See [Telect 100A Dual-feed 4/4 TPA/GMT, -48V](#) for information describing the Telect 100A Dual-feed DC Power Distribution Panel LEDs.

Policy Management Platform Configuration

Cabinet configurations are specific to customer requirements. [Figure 1: Example of Policy Management c-Class Cabinet Configuration \(DC\)](#) and [Figure 2: Example of Policy Management c-Class Cabinet Configuration \(AC\)](#) present an example of a possible cabinet configuration. All hardware components may not be shown in the example configurations presented. You must refer to your customer order for exact configuration and rack line-up.



Add enclosure 1 (U3-U12) and enclosure 2 (U14-U23)

NOTE: All Bays 1-16 are BASE SERVERS.
 Populate each enclosure from Bay 1 to Bay 16,
 in that order. Once one enclosure is
 completely populated, then another enclosure
 can be added and populated in the same

Figure 1: Example of Policy Management c-Class Cabinet Configuration (DC)




Figure 2: Example of Policy Management c-Class Cabinet Configuration (AC)